
MITSUBISHI ELECTRIC

700 series

INVERTER FR-A700 INSTRUCTION MANUAL

FR-A720-00030 to 03460-NA
FR-A740-00015 to 09620-NA
FR-A720-00030 to 00330-N4
FR-A740-00015 to 00170-N4



OUTLINE 1

WIRING 2

PRECAUTIONS FOR USE OF THE INVERTER 3

PARAMETERS 4

PROTECTIVE FUNCTIONS 5

PRECAUTIONS FOR MAINTENANCE AND INSPECTION 6

SPECIFICATIONS 7

WWW.BSNEW.IR

Thank you for choosing this Mitsubishi Inverter.
This Instruction Manual provides instructions for advanced use of the FR-A700 series inverters.
Incorrect handling might cause an unexpected fault. Before using the inverter, always read this instruction manual and the Installation Guideline [IB-0600254ENG] packed with the product carefully to use the equipment to its optimum.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect the inverter until you have read through instruction manual and appended documents carefully and can use the equipment correctly. Do not use the inverter until you have a full knowledge of the equipment, safety information and instructions. In this instruction manual, the safety instruction levels are classified into "WARNING" and "CAUTION".

⚠WARNING Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

⚠CAUTION Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the **⚠CAUTION** level may lead to a serious consequence according to conditions. Please follow strictly the instructions of both levels because they are important to personnel safety.

1. Electric Shock Prevention

⚠WARNING

- While power is on or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.
- Do not run the inverter with the front cover or wiring cover removed. Otherwise, you may access the exposed high-voltage terminals or the charging part of the circuitry and get an electric shock.
- Even if power is off, do not remove the front cover except for wiring or periodic inspection.You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, check to make sure that the operation panel indicator is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- This inverter must be earthed (grounded). Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)
- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the inverter before wiring. Otherwise, you may get an electric shock or be injured.
- Perform setting dial and key operations with dry hands to prevent an electric shock. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.
- Do not replace the cooling fan while power is on. It is dangerous to replace the cooling fan while power is on.
- Do not touch the printed circuit board with wet hands. You may get an electric shock.
- When measuring the main circuit capacitor capacity, the DC voltage is applied to the motor for 1s at powering off. Never touch the motor terminal, etc. right after powering off to prevent an electric shock.

2. Fire Prevention ⚠CAUTION

- Install the inverter on an incombustible wall without holes, etc. Mounting it to or near combustible material can cause a fire.
- If the inverter has become faulty, switch off the inverter power. A continuous flow of large current could cause a fire.
- When using a brake resistor, make up a sequence that will turn off power when an alarm signal is output. Otherwise, the brake resistor may excessively overheat due to damage of the brake transistor and such, causing a fire.
- Do not connect the resistor directly to the DC terminals P/+ and N/-. This could cause a fire.

3. Injury Prevention ⚠CAUTION

- Apply only the voltage specified in the instruction manual to each terminal. Otherwise, burst, damage, etc. may occur.
- Ensure that the cables are connected to the correct terminals. Otherwise, burst, damage, etc. may occur.
- Always make sure that polarity is correct to prevent damage, etc. Otherwise, burst, damage, etc. may occur.
- While power is on or for some time after power-off, do not touch the inverter as it is hot and you may get burnt.

4. Additional Instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.

(1) Transportation and installation

⚠CAUTION

- When carrying products, use correct lifting gear to prevent injury.
- Do not stack the inverter boxes higher than the number recommended.
- Ensure that installation position and material can withstand the weight of the inverter. Install according to the information in the instruction manual.
- Do not install or operate the inverter if it is damaged or has parts missing. This can result in breakdowns.
- When carrying the inverter, do not hold it by the front cover or setting dial; it may fall off or fail.
- Do not stand or rest heavy objects on the product.
- Check the inverter mounting orientation is correct.
- Prevent other conductive bodies such as screws and metal fragments or other flammable substance such as oil from entering the inverter.
- As the inverter is a precision instrument, do not drop or subject it to impact.
- Use the inverter under the following environmental conditions. Otherwise, the inverter may be damaged.

Environment	Ambient temperature	LD, ND (initial setting), HD	-10°C to +50°C (14°F to 122°F)(non-freezing)
		SLD	-10°C to +40°C (14°F to 104°F)(non-freezing)
	Ambient humidity		90% RH or less (non-condensing)
	Storage temperature		-20°C to +65°C *1 (-4°F to 149°F)
	Atmosphere		Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)
	Altitude, vibration		Maximum 1000m (3280.80feet) above sea level for standard operation. After that derate by 3% for every extra 500m (1640.40feet) up to 2500m (8202feet) (92%) 5.9m/s^2 or less *2

*1 Temperature applicable for a short time, e.g. in transit.
*2 2.9m/s^2 or less for the FR-A740-03250 or more.

(2) Wiring ⚠CAUTION

- Do not install a power factor correction capacitor or surge suppressor/radio noise filter (capacitor type filter) on the inverter output side.
- The connection orientation of the output cables U, V, W to the motor will affect the direction of rotation of the motor.

(3) Test operation and adjustment

⚠CAUTION

- Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.

(4) Operation ⚠WARNING

- When you have chosen the retry function, stay away from the equipment as it will restart suddenly after an alarm stop.
- Since the STOP RESET key is valid only when functions are set *(refer to page 302)*, provide a circuit and switch separately to make an emergency stop (power off, mechanical brake operation for emergency stop, etc).
- Make sure that the start signal is off before resetting the inverter alarm. A failure to do so may restart the motor suddenly.
- The load used should be a three-phase induction motor only. Connection of any other electrical equipment to the inverter output may damage the inverter as well as equipment.
- Performing pre-excitation (LX signal and X13 signal) under torque control (real sensorless vector control) may start the motor running at a low speed even when the start command (STF or STR) is not input. The motor may run also at a low speed when the speed limit value = 0 with a start command input. Perform pre-excitation after making sure that there will be no problem in safety if the motor runs.
- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the inverter.

⚠CAUTION

- The electronic thermal relay function does not guarantee protection of the motor from overheating.
- Do not use a magnetic contactor on the inverter input for frequent starting/ stopping of the inverter.
- Use a noise filter to reduce the effect of electromagnetic interference. Otherwise nearby electronic equipment may be affected.
- Take measures to suppress harmonics. Otherwise power supply harmonics from the inverter may heat/damage the power factor correction capacitor and generator.
- When a 400V class motor is inverter-driven, please use an insulation-enhanced motor or measures taken to suppress surge voltages. Surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.
- When parameter clear or all clear is performed, reset the required parameters before starting operations. Each parameter returns to the initial value.
- The inverter can be easily set for high-speed operation. Before changing its setting, fully examine the performances of the motor and machine.
- In addition to the inverter's holding function, install a holding device to ensure safety.
- Before running an inverter which had been stored for a long period, always perform inspection and test operation.
- For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

(5) Emergency stop ⚠CAUTION

- Provide a safety backup such as an emergency brake which will prevent the machine and equipment from hazardous conditions if the inverter fails.
- When the breaker on the inverter input side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.
- When the protective function is activated, take the corresponding corrective action, then reset the inverter, and resume operation.

(6) Maintenance, inspection and parts replacement

⚠CAUTION

- Do not carry out a megger (insulation resistance) test on the control circuit of the inverter.

(7) Disposing of the inverter

⚠CAUTION

- Treat as industrial waste.

General instructions

Many of the diagrams and drawings in this instruction manual show the inverter without a cover, or partially open. Never run the inverter in this status. Always replace the cover and follow this instruction manual when operating the inverter.

WWW.BSNEW.IR

CONTENTS

1 OUTLINE 1

1.1 Product checking and parts identification 2
1.2 Inverter and peripheral devices 3
1.2.1 Peripheral devices 4
1.3 Method of removal and reinstallation of the front cover 6
1.4 Installation of the inverter and enclosure design 8
1.4.1 Inverter installation environment 8
1.4.2 Cooling system types for inverter enclosure 10
1.4.3 Inverter placement 10

2 WIRING 13

2.1 Wiring 14
2.1.1 Terminal connection diagram 14
2.1.2 EMC filter 15
2.2 Main circuit terminal specifications 16
2.2.1 Specification of main circuit terminal 16
2.2.2 Terminal arrangement of the main circuit terminal, power supply and the motor wiring. 17
2.2.3 Cables and wiring length 22
2.2.4 When connecting the control circuit and the main circuit separately to the power supply (separate power) 26
2.3 Control circuit specifications 28
2.3.1 Control circuit terminals 28
2.3.2 Changing the control logic 31
2.3.3 Control circuit terminal layout 33
2.3.4 Wiring instructions 34
2.3.5 When connecting the operation panel using a connection cable 35
2.3.6 RS-485 terminal block 35
2.3.7 Communication operation 35
2.4 Connection of motor with encoder (vector control) 36
2.5 Connection of stand-alone option units 43
2.5.1 Connection of the dedicated external brake resistor (FR-ABR) (FR-A720-00900 (FR-A740-00440) or less) 43
2.5.2 Connection of the brake unit (FR-BU2) 46
2.5.3 Connection of the brake unit (FR-BU/MT-BU5) 48
2.5.4 Connection of the brake unit (BU type) 50
2.5.5 Connection of the high power factor converter (FR-HC/MT-HC) 50
2.5.6 Connection of the power regeneration common converter (FR-CV) (FR-A720-02150 (FR-A740-01100) or less) 52

WWW.BSNEW.IR

2.5.7 Connection of power regeneration converter (MT-RC) (FR-A720-02880 (FR-A740-01440) or more) 53
2.5.8 Connection of the power factor improving DC reactor (FR-HEL) 53

3 PRECAUTIONS FOR USE OF THE INVERTER 55

3.1 Noise and leakage currents 56
3.1.1 Leakage currents and countermeasures 56
3.1.2 Inverter-generated noises and their reduction techniques 58
3.1.3 Power supply harmonics 60
3.2 Installation of a reactor 61
3.3 Power-off and magnetic contactor (MC) 62
3.4 Inverter-driven 400V class motor 63
3.5 Precautions for use of the inverter 64

4 PARAMETERS 67

4.1 Operation panel (FR-DU07) 68
4.1.1 Parts of the operation panel (FR-DU07) 68
4.1.2 Basic operation (factory setting) 69
4.1.3 Change the parameter setting value 70
4.1.4 Setting dial push 70
4.2 Parameter List 71
4.2.1 Parameter list 71
4.3 Control mode 88
4.3.1 What is vector control? 89
4.3.2 Change the control method (Pr. 80, Pr. 81, Pr. 451, Pr. 800) 92
4.4 Speed control by real sensorless vector control, vector control 96
4.4.1 Setting procedure of real sensorless vector control (speed control) 97
4.4.2 Setting procedure of vector control (speed control) 98
4.4.3 Torque limit level setting for speed control (Pr. 22, Pr. 803, Pr. 810 to Pr. 817, Pr. 858, Pr. 868, Pr. 874) 99
4.4.4 To perform high accuracy/fast response operation (gain adjustment of real sensorless vector control and vector control) (Pr. 818 to Pr. 821, Pr. 830, Pr. 831, Pr. 880) 104
4.4.5 Speed feed forward control, model adaptive speed control (Pr. 828, Pr. 877 to Pr. 881) ... 111
4.4.6 Torque biases (Pr. 840 to Pr. 848) 113
4.4.7 Prevent the motor from overrunning (Pr. 285, Pr. 853, Pr. 873) 116
4.4.8 Notch filter (Pr. 862, Pr. 863) 117

WWW.BSNEW.IR

4.5 Torque control by real sensorless vector control, vector control 118
4.5.1 Torque control 118
4.5.2 Setting procedure of real sensorless vector control (torque control) 120
4.5.3 Setting procedure of vector control (torque control) 121
4.5.4 Torque command (Pr. 803 to Pr. 806) 122
4.5.5 Speed limit (Pr. 807 to Pr. 809) 124
4.5.6 Gain adjustment of torque control (Pr. 824, Pr. 825, Pr. 834, Pr. 835) 127
4.6 Position control by vector control 129
4.6.1 Position control 129
4.6.2 Conditional position feed function by contact input (Pr. 419, Pr. 464 to Pr. 494) 131
4.6.3 Position control (Pr. 419, Pr. 428 to Pr. 430) by inverter pulse train input 134
4.6.4 Setting of the electronic gear (Pr. 420, Pr. 421, Pr. 424) 136
4.6.5 Setting of positioning adjustment parameter (Pr. 426, Pr. 427) 137
4.6.6 Gain adjustment of position control (Pr. 422, Pr. 423, Pr. 425) 138
4.6.7 Trouble shooting for when position control is not exercised normally 140
4.7 Adjustment of real sensorless vector control, vector control 141
4.7.1 Speed detection filter and torque detection filter (Pr. 823, Pr. 827, Pr. 833, Pr. 837) 141
4.7.2 Excitation ratio (Pr. 854) 142
4.8 Adjust the output torque of the motor (current) 143
4.8.1 Manual torque boost (Pr. 0, Pr. 46, Pr. 112) 143
4.8.2 Advanced magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 89, Pr. 450, Pr. 451, Pr. 453, Pr. 454, Pr. 569, Pr. 800) 145
4.8.3 Slip compensation (Pr. 245 to Pr. 247) 149
4.8.4 Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 49, Pr. 66, Pr. 114, Pr. 115, Pr. 148, Pr. 149, Pr. 154, Pr. 156, Pr. 157, Pr. 858, Pr. 868) 150
4.8.5 Multiple rating (Pr. 570) 155
4.9 Limit the output frequency 157
4.9.1 Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18) 157
4.9.2 Avoid mechanical resonance points (Frequency jump) (Pr. 31 to Pr. 36) 158
4.10 Set V/F pattern 159
4.10.1 Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47, Pr. 113) 159
4.10.2 Load pattern selection (Pr. 14) 161
4.10.3 Elevator mode (automatic acceleration/deceleration) (Pr. 61, Pr. 64, Pr. 292) 163
4.10.4 Adjustable 5 points V/F (Pr. 71, Pr. 100 to Pr. 109) 165
4.11 Frequency setting by external terminals 166
4.11.1 Multi-speed setting operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239) 166
4.11.2 Jog operation (Pr. 15, Pr. 16) 168

WWW.BSNEW.IR

4.11.3 Input compensation of multi-speed and remote setting (Pr. 28) 170
4.11.4 Remote setting function (Pr. 59) 170

4.12 Setting of acceleration/deceleration time and acceleration/deceleration pattern 173

4.12.1 Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 110, Pr. 111) 173
4.12.2 Starting frequency and start-time hold function (Pr. 13, Pr. 571) 175
4.12.3 Acceleration/deceleration pattern (Pr. 29, Pr. 140 to Pr. 143, Pr. 380 to Pr. 383, Pr. 516 to Pr. 519) 176
4.12.4 Shortest acceleraiton/deceleration and optimum acceleration/deceleration (automatic acceleration/deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293) 179

4.13 Selection and protection of a motor 181

4.13.1 Motor protection from overheat (Electronic thermal relay function) (Pr. 9, Pr. 51) 181
4.13.2 Applied motor (Pr. 71, Pr. 450) 185
4.13.3 Offline auto tuning (Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 450, Pr. 453 to Pr. 463, Pr. 684, Pr. 859, Pr. 860) 187
4.13.4 Online auto tuning (Pr. 95, Pr. 574) 197

4.14 Motor brake and stop operation 200

4.14.1 DC injection brake and zero speed control, servo lock (LX signal, X13 signal, Pr. 10 to Pr. 12, Pr. 802, Pr. 850) 200
4.14.2 Selection of regenerative brake and DC feeding (Pr. 30, Pr. 70) 204
4.14.3 Stop selection (Pr. 250) 210
4.14.4 Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270, Pr. 275, Pr. 276) 211
4.14.5 Brake sequence function (Pr. 278 to Pr. 285, Pr. 292) 214
4.14.6 Orientation control (Pr. 350 to Pr. 366, Pr. 369, Pr. 393, Pr. 396 to Pr. 399) 217

4.15 Function assignment of external terminal and control 228

4.15.1 Input terminal function selection (Pr. 178 to Pr. 189) 228
4.15.2 Inverter output shutoff signal (MRS signal, Pr. 17) 231
4.15.3 Condition selection of function validity by the second function selection signal (RT) and third function selection signal (X9) (RT signal, X9 signal, Pr. 155) 232
4.15.4 Start signal operation selection (STF, STR, STOP signal, Pr. 250) 233
4.15.5 Magnetic flux decay output shutoff signal (X74 signal) 235
4.15.6 Output terminal function selection (Pr. 190 to Pr. 196) 236
4.15.7 Detection of output frequency (SU, FU, FU2 , FU3, FB, FB2, FB3, LS signal, Pr. 41 to Pr. 43, Pr. 50, Pr. 116, Pr. 865) 243
4.15.8 Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153, Pr. 166, Pr. 167) 245
4.15.9 Detection of output torque (TU signal, Pr. 864) 246
4.15.10 Remote output function (REM signal, Pr. 495 to Pr. 497) 247

4.16 Monitor display and monitor output signal 248

WWW.BSNEW.IR

4.16.1 Speed display and speed setting (Pr. 37, Pr. 144, Pr. 505, Pr. 811) 248
4.16.2 DU/PU, FM, AM terminal monitor display selection (Pr. 52, Pr. 54, Pr. 158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891) 250
4.16.3 Reference of the terminal FM (pulse train output) and AM (analog voltage output) (Pr. 55, Pr. 56, Pr. 291, Pr. 866, Pr. 867) 255
4.16.4 Terminal FM, AM calibration (Calibration parameter C0 (Pr. 900), C1 (Pr. 901)) 258

4.17 Operation selection at power failure and instantaneous power failure 261

4.17.1 Automatic restart after instantaneous power failure/flying start (Pr. 57, Pr. 58, Pr. 162 to Pr. 165, Pr. 299, Pr. 611) 261
4.17.2 Power failure-time deceleration-to-stop function (Pr. 261 to Pr. 266, Pr. 294) 265

4.18 Operation setting at alarm occurrence 268

4.18.1 Retry function (Pr. 65, Pr. 67 to Pr. 69) 268
4.18.2 Alarm code output selection (Pr. 76) 270
4.18.3 Input/output phase failure protection selection (Pr. 251, Pr. 872) 271
4.18.4 Overspeed detection (Pr. 374) 271
4.18.5 Encoder signal loss detection (Pr. 376) 271
4.18.6 Fault definition (Pr. 875) 272

4.19 Energy saving operation and energy saving monitor 273

4.19.1 Energy saving control (Pr. 60) 273
4.19.2 Energy saving monitor (Pr. 891 to Pr. 899) 274

4.20 Motor noise, noise reduction 279

4.20.1 PWM carrier frequency and Soft-PWM control (Pr. 72, Pr. 240, Pr. 260) 279

4.21 Frequency/torque setting by analog input (terminal 1, 2, 4) 281

4.21.1 Function assignment of analog input terminal (Pr. 858, Pr. 868) 281
4.21.2 Analog input selection (Pr. 73, Pr. 267) 282
4.21.3 Analog input compensation (Pr. 73, Pr. 242, Pr. 243, Pr. 252, Pr. 253) 285
4.21.4 Response level of analog input and noise elimination (Pr. 74, Pr. 822, Pr. 826, Pr. 832, Pr. 836, Pr. 849) 287
4.21.5 Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2(Pr. 902) to C7(Pr. 905), C12(Pr. 917) to C15(Pr. 918)) 289
4.21.6 Bias and gain of torque (magnetic flux) setting voltage (current) (Pr. 241, C16(Pr. 919) to C19(Pr. 920), C38 (Pr. 932) to C41 (Pr. 933)) 295
4.21.7 4mA input check of current input (Pr. 573) 300

4.22 Misoperation prevention and parameter setting restriction 302

4.22.1 Reset selection/disconnected PU detection/PU stop selection (Pr. 75) 302
4.22.2 Parameter write selection (Pr. 77) 305
4.22.3 Reverse rotation prevention selection (Pr. 78) 306
4.22.4 Display of applied parameters and user group function (Pr. 160, Pr. 172 to Pr. 174) 306

WWW.BSNEW.IR

4.23 Selection of operation mode and operation location 308
4.23.1 Operation mode selection (Pr. 79) 308
4.23.2 Operation mode at power on (Pr. 79, Pr. 340) 316
4.23.3 Operation command source and speed command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551) 317
4.24 Communication operation and setting 322
4.24.1 Wiring and configuration of PU connector 322
4.24.2 Wiring and arrangement of RS-485 terminals 324
4.24.3 Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 124, Pr. 331 to Pr. 337, Pr. 341, Pr. 549) 327
4.24.4 Communication EEPROM write selection (Pr. 342) 328
4.24.5 Mitsubishi inverter protocol (computer link communication) 329
4.24.6 Modbus-RTU communication specifications (Pr. 331, Pr. 332, Pr. 334, Pr. 343, Pr. 539, Pr. 549) 340
4.24.7 Operation by PLC function (Pr. 414 to Pr. 417, Pr. 498, Pr. 506 to Pr. 515) 353
4.24.8 USB communication (Pr. 547, Pr. 548) 354
4.25 Special operation and frequency control 355
4.25.1 PID control (Pr. 127 to Pr. 134, Pr. 575 to Pr. 577) 355
4.25.2 Bypass-inverter switchover function (Pr. 57, Pr. 58, Pr. 135 to Pr. 139, Pr. 159) 363
4.25.3 Load torque high speed frequency control (Pr. 4, Pr. 5, Pr. 270 to Pr. 274) 368
4.25.4 Droop control (Pr. 286 to Pr. 288) 370
4.25.5 Frequency setting by pulse train input (Pr. 291, Pr. 384 to Pr. 386) 372
4.25.6 Encoder feedback control (Pr. 144, Pr. 285, Pr. 359, Pr. 367 to Pr. 369) 375
4.25.7 Regeneration avoidance function (Pr. 665, Pr. 882 to Pr. 886) 377
4.26 Useful functions 379
4.26.1 Cooling fan operation selection (Pr. 244) 379
4.26.2 Display of the life of the inverter parts (Pr. 255 to Pr. 259) 380
4.26.3 Maintenance timer alarm (Pr. 503, Pr. 504) 383
4.26.4 Current average value monitor signal (Pr. 555 to Pr. 557) 384
4.26.5 Free parameter (Pr. 888, Pr. 889) 386
4.27 Setting of the parameter unit and operation panel 387
4.27.1 PU display language selection (Pr. 145) 387
4.27.2 Operation panel frequency setting/key lock operation selection (Pr. 161) 387
4.27.3 Buzzer control (Pr. 990) 389
4.27.4 PU contrast adjustment (Pr. 991) 389
4.28 Parameter clear 390
4.29 All parameter clear 391

WWW.BSNEW.IR

4.30 Parameter copy and parameter verification 392
4.30.1 Parameter copy 392
4.30.2 Parameter verification 393
4.31 Check and clear of the alarm history 394

5 PROTECTIVE FUNCTIONS 397

5.1 Reset method of protective function 398
5.2 List of alarm display 399
5.3 Causes and corrective actions 400
5.4 Correspondences between digital and actual characters 413
5.5 Check first when you have troubles 414
5.5.1 Motor will not start 414
5.5.2 Motor generates abnormal noise 414
5.5.3 Motor generates heat abnormally 415
5.5.4 Motor rotates in opposite direction 415
5.5.5 Speed greatly differs from the setting 415
5.5.6 Acceleration/deceleration is not smooth 415
5.5.7 Motor current is large 415
5.5.8 Speed does not increase 415
5.5.9 Speed varies during operation 416
5.5.10 Operation mode is not changed properly 416
5.5.11 Operation panel (FR-DU07) display is not operating 416
5.5.12 POWER lamp is not lit 416
5.5.13 Parameter write cannot be performed 416

6 PRECAUTIONS FOR MAINTENANCE AND INSPECTION 417

6.1 Inspection item 418
6.1.1 Daily inspection 418
6.1.2 Periodic inspection 418
6.1.3 Daily and periodic inspection 419
6.1.4 Display of the life of the inverter parts 420
6.1.5 Checking the inverter and converter modules 420
6.1.6 Cleaning 421
6.1.7 Replacement of parts 421
6.1.8 Inverter replacement 425
6.2 Measurement of main circuit voltages, currents and powers 426
6.2.1 Measurement of powers 428

WWW.BSNEW.IR

6.2.2 Measurement of voltages and use of PT 428
6.2.3 Measurement of currents 429
6.2.4 Use of CT and transducer 429
6.2.5 Measurement of inverter input power factor 429
6.2.6 Measurement of converter output voltage (across terminals P/+ - N/-) 430
6.2.7 Measurement of inverter output frequency 430
6.2.8 Insulation resistance test using megger 430
6.2.9 Pressure test 430

7 SPECIFICATIONS 431

7.1 Rating 432
7.1.1 Inverter rating 432
7.2 Common specifications 435
7.3 Outline dimension drawings 436
7.3.1 Inverter outline dimension drawings 436
7.4 Installation of the heatsink portion outside the enclosure for use 447
7.4.1 When using a heatsink protrusion attachment (FR-A7CN) 447
7.4.2 Protrusion of heatsink of the FR-A740-03250 or more 447

APPENDICES 451

Appendix 1 For customers who have replaced the older model with this inverter 452
Appendix 1-1 Replacement of the FR-A500 series 452
Appendix 1-2 Replacement of the FR-A200 <EXCELENT> series 453
Appendix 2 Control mode-based parameter (function) correspondence table and instruction code list 454
Appendix 3 SERIAL number check 471

WWW.BSNEW.IR

1 OUTLINE

This chapter describes the basic "OUTLINE" for use of this product.
Always read the instructions before using the equipment

1.1 Product checking and parts identification 2
1.2 Inverter and peripheral devices 3
1.3 Method of removal and reinstallation of the front cover 6
1.4 Installation of the inverter and enclosure design 8

<Abbreviations>
DU .....Operation panel (FR-DU07)
PU .....Operation panel (FR-DU07) and parameter unit (FR-PU04/FR-PU07)
Inverter .....Mitsubishi inverter FR-A700 series
FR-A700 .....Mitsubishi inverter FR-A700 series
Pr. .....Parameter Number
PU operation.....Operation using the PU (FR-DU07/FR-PU04/FR-PU07).
External operation .....Operation using the control circuit signals
Combined operation .....Combined operation using the PU (FR-DU07/FR-PU04/FR-PU07) and external operation.
Mitsubishi standard motor .....SF-JR
Mitsubishi constant-torque motor.SF-HRCA
Vector dedicated motor.....SF-V5RU

<Trademarks>

- LONWORKS® is a registered trademark of Echelon Corporation in the U.S.A and other countries.
- DeviceNet® is a registered trademark of ODVA (Open DeviceNet Vender Association, Inc.).
- Other company and product names herein are the trademarks and registered trademarks of their respective owners.

WWW.BSNEW.IR

1.1 Product checking and parts identification

Unpack the inverter and check the capacity plate on the front cover and the rating plate on the inverter side face to ensure that the product agrees with your order and the inverter is intact.


- **Inverter Type**

FR - A720 - 00175 - NA

Symbol	Voltage Class
A720	Three-phase 200V class
A740	Three-phase 400V class

Symbol		Type number
200V class	400V class	
00030 to 03460	00015 to 09620	Displays the rated current

Symbol	Specifications
NA	U.S. specifications
N4	U.S. specifications (UL type 1)



	Overload Current Rating	Ambient Temperature
SLD	110% 60s, 120% 3s	40℃ (104℉)
LD	120% 60s, 150% 3s	50℃ (122℉)
ND	150% 60s, 200% 3s	50℃ (122℉)
HD	200% 60s, 250% 3s	50℃ (122℉)

- **Accessory**
  - **Fan cover fixing screws (FR-A720-00900 (FR-A740-00440) or less) (*Refer to Installation Guideline*)**
    These screws are necessary for compliance with the European Directive

	Capacity	Screw Size (mm)	Number
200V	00080 to 00175	M3 × 35	1
	00240 to 00460	M4 × 40	2
	00610 to 00900	M4 × 50	1
400V	00060 to 00090	M3 × 35	1
	00120 to 00310	M4 × 40	2
	00380, 00440	M4 × 50	1

  - **DC reactor supplied (FR-A720-02880 (FR-A740-01440) or more)**
  - **Eyebolt for hanging the inverter (FR-A720-01250 to 03460, FR-A740-00570 to 05470)**
    M8 × two pieces



REMARKS

For removal and reinstallation of covers, refer to *page 6*.

WWW.BSNEW.IR

1.2 Inverter and peripheral devices



Three-phase AC power supply
Use within the permissible power supply specifications of the inverter.
(Refer to page 432)



Moulded case circuit breaker (MCCB) or earth leakage current breaker (ELB), fuse
The breaker must be selected carefully since an in-rush current flows in the inverter at power on.
(Refer to page 4)



Magnetic contactor (MC)
Install the magnetic contactor to ensure safety. Do not use this magnetic contactor to start and stop the inverter. Doing so will cause the inverter life to be shorten.
(Refer to page 4)

Reactor (FR-HAL, FR-HEL option)
Reactors (option) must be used when power harmonics measures are taken, the power factor is to be improved or the inverter is installed near a large power supply system (1000kVA or more). The inverter may be damaged if you do not use reactors. Select the reactor according to the model. Remove the jumpers across terminals P/+ - P1 to connect the DC reactor to the FR-A720-02150 (FR-A740-01100) or less.
(Refer to page 4.)



AC reactor (FR-HAL)



DC reactor (FR-HEL)
For the FR-A720-02880 (FR-A740-01440) or more, a DC reactor is supplied. Always install the reactor. When using the FR-A720-02150 (FR-A740-01100) with LD or SLD set, always use a DC reactor (option).




Noise filter (FR-BLF)
The FR-A720-02150 (FR-A740-01100) or less has a built-in common mode core.

USB connector
A personal computer and an inverter can be connected with a USB (Ver1. 1) cable.





Inverter (FR-A700)
The life of the inverter is influenced by ambient temperature. The ambient temperature should be as low as possible within the permissible range. This must be noted especially when the inverter is installed in an enclosure. *(Refer to page 8)*
Wrong wiring might lead to damage of the inverter. The control signal lines must be kept fully away from the main circuit to protect them from noise. *(Refer to page 14)*
Refer to *page 15* for the built-in EMC filter.



High-duty brake resistor (FR-ABR*3)
Braking capability of the inverter built-in brake can be improved. Remove the jumper across terminal PR-PX when connecting the high-duty brake resistor. (FR-A720-00330 (FR-A740-00170 or less)
Always install a thermal relay when using a brake resistor whose capacity is 11K or more.
(Refer to page 43)
*3 Compatible with the FR-A720-00900 (FR-A740-00440) or less.


P/+ PR

P/+ P1 R/L1 S/L2 T/L3 P/+ N/- U V W

Earth (Ground)




Noise filter (FR-BSF01, FR-BLF)
Install a noise filter to reduce the electromagnetic noise generated from the inverter. Effective in the range from about 1MHz to 10MHz. A wire should be wound four turns at a maximum.




Motor

Earth (Ground)




High power factor converter (FR-HC*1, MT-HC*2)
Power supply harmonics can be greatly suppressed.
Install this as required.



Power regeneration common converter (FR-CV*1)
Power regeneration converter (MT-RC*2)
Great braking capability is obtained.
Install this as required.

Brake unit (FR-BU2, FR-BU*1, MT-BU5*2)



Resistor unit (FR-BR*1, MT-BR5*2)
The regenerative braking capability of the inverter can be exhibited fully.
Install this as required.

*1 Compatible with the FR-A720-02150 (FR-A740-01100) or less.
*2 Compatible with the FR-A720-02880 (FR-A740-01440) or more.

Devices connected to the output
Do not install a power factor correction capacitor, surge suppressor or radio noise filter on the output side of the inverter. When installing a moulded case circuit breaker on the output side of the inverter, contact each manufacturer for selection of the moulded case circuit breaker.

Earth (Ground)
To prevent an electric shock, always earth (ground) the motor and inverter.

CAUTION

- Do not install a power factor correction capacitor, surge suppressor or radio noise filter on the inverter output side. This will cause the inverter to trip or the capacitor, and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them.
- Electromagnetic wave interference
  The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, set the EMC filter valid to minimize interference.
  (Refer to page 15.)
- Refer to the instruction manual of each option and peripheral devices for details of peripheral devices.

WWW.BSNEW.IR

1.2.1 Peripheral devices


Check the motor capacity of the inverter you purchased. Appropriate peripheral devices must be selected according to the capacity. Refer to the following list and prepare appropriate peripheral devices:

200V class

Motor Output (kW(HP))*1	Applicable Inverter Type	Breaker Selection*2,4		Input Side Magnetic Contactor*3	
		Reactor connection		Reactor connection	
		without	with	without	with
0.4 (1/2)	FR-A720-00030-NA/N4	30AF 5A	30AF 5A	S-N10	S-N10
0.75 (1)	FR-A720-00050-NA/N4	30AF 10A	30AF 10A	S-N10	S-N10
1.5 (2)	FR-A720-00080-NA/N4	30AF 15A	30AF 15A	S-N10	S-N10
2.2 (3)	FR-A720-00110-NA/N4	30AF 20A	30AF 15A	S-N10	S-N10
3.7 (5)	FR-A720-00175-NA/N4	30AF 30A	30AF 30A	S-N20, N21	S-N10
5.5 (7.5)	FR-A720-00240-NA/N4	50AF 50A	50AF 40A	S-N25	S-N20, N21
7.5 (10)	FR-A720-00330-NA/N4	100AF 60A	50AF 50A	S-N25	S-N25
11 (15)	FR-A720-00460-NA	100AF 75A	100AF 75A	S-N35	S-N35
15 (20)	FR-A720-00610-NA	225AF 125A	100AF 100A	S-N50	S-N50
18.5 (25)	FR-A720-00760-NA	225AF 150A	225AF 125A	S-N65	S-N50
22 (30)	FR-A720-00900-NA	225AF 175A	225AF 150A	S-N80	S-N65
30 (40)	FR-A720-01150-NA	225AF 225A	225AF 175A	S-N95	S-N80
37 (50)	FR-A720-01450-NA	400AF 250A	225AF 225A	S-N150	S-N125
45 (60)	FR-A720-01750-NA	400AF 300A	400AF 300A	S-N180	S-N150
55 (75)	FR-A720-02150-NA	400AF 400A	400AF 350A	S-N220	S-N180
75 (100)	FR-A720-02880-NA	—	400AF 400A	—	S-N300
90 (125)	FR-A720-03460-NA	—	400AF 400A	—	S-N300

*1 Selections for use of the Mitsubishi 4-pole standard motor with power supply voltage of 200VAC 50Hz.

*2 Select the MCCB according to the inverter power supply capacity.
Install one MCCB per inverter.
For installations in the United States or Canada, use the fuse certified by the UL and cUL.
(Refer to Installation Guideline.)



*3 Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stop during motor driving, the electrical durability is 25 times.
When using the MC for emergency stop during motor driving or using on the motor side during commercial-power supply operation, select the MC with class AC-3 rated current for the motor rated current.

*4 When the breaker on the inverter primary side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.


WWW.BSNEW.IR

400V class

Motor Output (kW(HP))*1	Applicable Inverter Type	Breaker Selection*2,4		Input Side Magnetic Contactor*3	
		Reactor connection		Reactor connection	
		without	with	without	with
0.4 (1/2)	FR-A740-00015-NA/N4	30AF 5A	30AF 5A	S-N10	S-N10
0.75 (1)	FR-A740-00025-NA/N4	30AF 5A	30AF 5A	S-N10	S-N10
1.5 (2)	FR-A740-00040-NA/N4	30AF 10A	30AF 10A	S-N10	S-N10
2.2 (3)	FR-A740-00060-NA/N4	30AF 10A	30AF 10A	S-N10	S-N10
3.7 (5)	FR-A740-00090-NA/N4	30AF 20A	30AF 15A	S-N10	S-N10
5.5 (7.5)	FR-A740-00120-NA/N4	30AF 30A	30AF 20A	S-N20	S-N11, N12
7.5 (10)	FR-A740-00170-NA/N4	30AF 30A	30AF 30A	S-N20	S-N20
11 (15)	FR-A740-00230-NA	50AF 50A	50AF 40A	S-N20	S-N20
15 (20)	FR-A740-00310-NA	100AF 60A	50AF 50A	S-N25	S-N20
18.5 (25)	FR-A740-00380-NA	100AF 75A	100AF 60A	S-N25	S-N25
22 (30)	FR-A740-00440-NA	100AF 100A	100AF 75A	S-N35	S-N25
30 (40)	FR-A740-00570-NA	225AF 125A	100AF 100A	S-N50	S-N50
37 (50)	FR-A740-00710-NA	225AF 150A	225AF 125A	S-N65	S-N50
45 (60)	FR-A740-00860-NA	225AF 175A	225AF 150A	S-N80	S-N65
55 (75)	FR-A740-01100-NA	225AF 200A	225AF 175A	S-N80	S-N80
75 (100)	FR-A740-01440-NA	—	225AF 225A	—	S-N95
90 (125)	FR-A740-01800-NA	—	225AF 225A	—	S-N150
110 (150)	FR-A740-02160-NA	—	225AF 225A	—	S-N180
132 (200)	FR-A740-02600-NA	—	400AF 400A	—	S-N220
160 (250)	FR-A740-03250-NA	—	400AF 400A	—	S-N300
185 (300)	FR-A740-03610-NA	—	400AF 400A	—	S-N300
220 (350)	FR-A740-04320-NA	—	600AF 500A	—	S-N400
250 (400)	FR-A740-04810-NA	—	600AF 600A	—	S-N600
280 (450)	FR-A740-05470-NA	—	600AF 600A	—	S-N600
315 (500)	FR-A740-06100-NA	—	800AF 700A	—	S-N600
355 (550)	FR-A740-06830-NA	—	800AF 800A	—	S-N600
400 (600)	FR-A740-07700-NA	—	1000AF 900A	—	S-N800
450 (700)	FR-A740-08660-NA	—	1000AF 1000A	—	1000A Rated product
500 (750)	FR-A740-09620-NA	—	1200AF 1200A	—	1000A Rated product

*1 Selections for use of the Mitsubishi 4-pole standard motor with power supply voltage of 400VAC 50Hz.

*2 Select the MCCB according to the inverter power supply capacity.
Install one MCCB per inverter.
For installations in the United States or Canada, use the fuse certified by the UL and cUL.
(Refer to Installation Guideline.)



*3 Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stop during motor driving, the electrical durability is 25 times.
When using the MC for emergency stop during motor driving or using on the motor side during commercial-power supply operation, select the MC with class AC-3 rated current for the motor rated current.


*4 When the breaker on the inverter primary side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.

WWW.BSNEW.IR


1.3 Method of removal and reinstallation of the front cover

•Removal of the operation panel

1) Loosen the two screws on the operation panel. (These screws cannot be removed.)



2) Push the left and right hooks of the operation panel and pull the operation panel toward you to remove.




When reinstalling the operation panel, insert it straight to reinstall securely and tighten the fixed screws of the operation panel.

FR-A720-00900 or less, FR-A740-00440 or less

•Removal

1) Loosen the installation screws of the front cover.

2) Pull the front cover toward you to remove by pushing an installation hook using left fixed hooks as supports.




•Reinstallation

1) Insert the two fixed hooks on the left side of the front cover into the sockets of the inverter.

2) Using the fixed hooks as supports, securely press the front cover against the inverter. (Although installation can be done with the operation panel mounted, make sure that a connector is securely fixed.)

3) Tighten the installation screws and fix the front cover.




WWW.BSNEW.IR


FR-A720-01150 or more, FR-A740-00570 or more

•Removal


1) Remove installation screws on the front cover 1 to remove the front cover 1.



2) Loosen the installation screws of the front cover 2.




3) Pull the front cover 2 toward you to remove by pushing an installation hook on the right side using left fixed hooks as supports.



•Reinstallation


1) Insert the two fixed hooks on the left side of the front cover 2 into the sockets of the inverter.

2) Using the fixed hooks as supports, securely press the front cover 2 against the inverter.
(Although installation can be done with the operation panel mounted, make sure that a connector is securely fixed.)



3) Fix the front cover 2 with the installation screws.

4) Fix the front cover 1 with the installation screws.



REMARKS

· For the FR-A720-02150-NA and the FR-A740-03250-NA or more, the front cover 1 is separated into two parts.

CAUTION

1. Fully make sure that the front cover has been reinstalled securely. Always tighten the installation screws of the front cover.
2. The same serial number is printed on the capacity plate of the front cover and the rating plate of the inverter. Before reinstalling the front cover, check the serial numbers to ensure that the cover removed is reinstalled to the inverter from where it was removed.

WWW.BSNEW.IR

1.4 Installation of the inverter and enclosure design

When an inverter enclosure is to be designed and manufactured, heat generated by contained equipment, etc., the environment of an operating place, and others must be fully considered to determine the enclosure structure, size and equipment layout. The inverter unit uses many semiconductor devices. To ensure higher reliability and long period of operation, operate the inverter in the ambient environment that completely satisfies the equipment specifications.

1.4.1 Inverter installation environment

As the inverter installation enviromnet should satisfiy the standard specifications indicated in the following table, operation in any place that does not meet these conditions not only deteriorates the performance and life of the inverter, but also causes a failure. Refer to the following points and take adequate measures.

Environmental standard specifications of inverter

Item	Description	
Ambient temperature	LD, ND(Initial setting), HD	-10 to +50°C (14°F to 122°F) (non-freezing)
	SLD	-10 to +40°C (14°F to 104°F) (non-freezing)
Ambient humidity	90% RH maximum (non-condensing)	
Atmosphere	Free from corrosive and explosive gases, dust and dirt	
Maximum Altitude	1,000m (3280.80 feet) or less	
Vibration	5.9m/s^2 or less *1	

*1 2.9m/s^2 or less for the FR-A740-03250 or more.

(1) Temperature

The permissible ambient temperature of the inverter is -10°C (14°F) to +50°C (122°F) or -10°C (14°F) to +40°C (104°F) (when SLD is set). Always operate the inverter within this temperature range. Operation outside this range will considerably shorten the service lives of the semiconductors, parts, capacitors and others. Take the following measures so that the ambient temperature of the inverter falls within the specified range.

1) Measures against high temperature
- Use a forced ventilation system or similar cooling system. *(Refer to page 10.)*
- Install the enclosure in an air-conditioned electrical chamber.
- Block direct sunlight.
- Provide a shield or similar plate to avoid direct exposure to the radiated heat and wind of a heat source.
- Ventilate the area around the enclosure well.

2) Measures against low temperature
- Provide a space heater in the enclosure.
- Do not power off the inverter. (Keep the start signal of the inverter off.)

3) Sudden temperature changes
- Select an installation place where temperature does not change suddenly.
- Avoid installing the inverter near the air outlet of an air conditioner.
- If temperature changes are caused by opening/closing of a door, install the inverter away from the door.

(2) Humidity

Normally operate the inverter within the 45 to 90% range of the ambient humidity. Too high humidity will pose problems of reduced insulation and metal corrosion. On the other hand, too low humidity may produce a spatial electrical breakdown. The insulation distance specified in JEM1103 "Control Equipment Insulator" is defined as humidity 45 to 85%.

1) Measures against high humidity
- Make the enclosure enclosed, and provide it with a hygroscopic agent.
- Take dry air into the enclosure from outside.
- Provide a space heater in the enclosure.

2) Measures against low humidity
What is important in fitting or inspection of the unit in this status is to discharge your body (static electricity) beforehand and keep your body from contact with the parts and patterns, besides blowing air of proper humidity into the enclosure from outside.

3) Measures against condensation
Condensation may occur if frequent operation stops change the in-enclosure temperature suddenly or if the outside-air temperature changes suddenly.
Condensation causes such faults as reduced insulation and corrosion.
- Take the measures against high humidity in 1).
- Do not power off the inverter. (Keep the start signal of the inverter off.)

WWW.BSNEW.IR

(3) Dust, dirt, oil mist

Dust and dirt will cause such faults as poor contact of contact points, reduced insulation or reduced cooling effect due to moisture absorption of accumulated dust and dirt, and in-enclosure temperature rise due to clogged filter.
In the atmosphere where conductive powder floats, dust and dirt will cause such faults as malfunction, deteriorated insulation and short circuit in a short time.
Since oil mist will cause similar conditions, it is necessary to take adequate measures.

Countermeasures
- Place in a totally enclosed enclosure.
  Take measures if the in-enclosure temperature rises. *(Refer to page 10.)*
- Purge air.
  Pump clean air from outside to make the in-enclosure pressure higher than the outside-air pressure.

(4) Corrosive gas, salt damage

If the inverter is exposed to corrosive gas or to salt near a beach, the printed board patterns and parts will corrode or the relays and switches will result in poor contact.
In such places, take the measures given in Section (3).

(5) Explosive, flammable gases

As the inverter is non-explosion proof, it must be contained in an explosion proof enclosure.
In places where explosion may be caused by explosive gas, dust or dirt, an enclosure cannot be used unless it structurally complies with the guidelines and has passed the specified tests. This makes the enclosure itself expensive (including the test charges).
The best way is to avoid installation in such places and install the inverter in a non-hazardous place.

(6) Highland

Use the inverter at the altitude of within 1000m (3280.80 feet).
If it is used at a higher place, it is likely that thin air will reduce the cooling effect and low air pressure will deteriorate dielectric strength.

(7) Vibration, impact

The vibration resistance of the inverter is up to 5.9m/s^2 (2.9m/s^2 for the FR-A740-03250 or more) at 10 to 55Hz frequency and 1mm (0.04 inch) amplitude.
Vibration or impact, if less than the specified value, applied for a long time may make the mechanism loose or cause poor contact to the connectors.
Especially when impact is imposed repeatedly, caution must be taken as the part pins are likely to break.






Countermeasures
- Provide the enclosure with rubber vibration isolators.
- Strengthen the structure to prevent the enclosure from resonance.
- Install the enclosure away from sources of vibration.

WWW.BSNEW.IR

1.4.2 Cooling system types for inverter enclosure

From the enclosure that contains the inverter, the heat of the inverter and other equipment (transformers, lamps, resistors, etc.) and the incoming heat such as direct sunlight must be dissipated to keep the in-enclosure temperature lower than the permissible temperatures of the in-enclosure equipment including the inverter.
The cooling systems are classified as follows in terms of the cooling calculation method.

1) Cooling by natural heat dissipation from the enclosure surface (Totally enclosed type)
2) Cooling by heat sink (Aluminum fin, etc.)
3) Cooling by ventilation (Forced ventilation type, pipe ventilation type)
4) Cooling by heat exchanger or cooler (Heat pipe, cooler, etc.)


Cooling System		Enclosure Structure	Comment
Natural cooling	Natural ventilation (Enclosed, open type)		Low in cost and generally used, but the enclosure size increases as the inverter capacity increases. For relatively small capacities.
	Natural ventilation (Totally enclosed type)		Being a totally enclosed type, the most appropriate for hostile environment having dust, dirt, oil mist, etc. The enclosure size increases depending on the inverter capacity.
Forced cooling	Heatsink cooling		Having restrictions on the heatsink mounting position and area, and designed for relative small capacities.
	Forced ventilation		For general indoor installation. Appropriate for enclosure downsizing and cost reduction, and often used.
	Heat pipe		Totally enclosed type for enclosure downsizing.

1.4.3 Inverter placement


(1) Installation of the Inverter

Installation on the enclosure

FR-A720-00030(FR-A740-00015) to FR-A720-00900(FR-A740-00440)




FR-A720-01150(FR-A740-00570) or more



Fix six positions for the FR-A740-03250 to 06830 and fix eight positions for the FR-A740-07700 to 09620.

CAUTION

When encasing multiple inverters, install them in parallel as a cooling measure. Install the inverter vertically.




* Refer to the clearances on the next page.

WWW.BSNEW.IR

(2) Clearances around the inverter

To ensure ease of heat dissipation and maintenance, leave at least the shown clearances around the inverter. At least the following clearances are required under the inverter as a wiring space, and above the inverter as a heat dissipation space.



REMARKS

For replacing the cooling fan of the FR-A740-03250 or more, 30cm (11.8inches) of space is necessary in front of the inverter. Refer to *page 422* for fan replacement.

(3) Inverter mounting orientation

Mount the inverter on a wall as specified. Do not mount it horizontally or any other way.


(4) Above the inverter

Heat is blown up from inside the inverter by the small fan built in the unit. Any equipment placed above the inverter should be heat resistant.

(5) Arrangement of multiple inverters

When multiple inverters are placed in the same enclosure, generally arrange them horizontally as shown in the right figure (a). When it is inevitable to arrange them vertically to minimize space, take such measures as to provide guides since heat from the bottom inverters can increase the temperatures in the top inverters, causing inverter failures.


When mounting multiple inverters, fully take caution not to make the ambient temperature of the inverter higher than the permissible value by providing ventilation and increasing the enclosure size.



Arrangement of multiple inverters

(6) Placement of ventilation fan and inverter

Heat generated in the inverter is blown up from the bottom of the unit as warm air by the cooling fan. When intalling a ventilation fan for that heat, determine the place of ventilation fan installation after fully considering an air flow. (Air passes through areas of low resistance. Make an airway and airflow plates to expose the inverter to cool air.)



Placement of ventilation fan and inverter

WWW.BSNEW.IR

MEMO

WWW.BSNEW.IR

2 WIRING


This chapter describes the basic "WIRING" for use of this product.
Always read the instructions before using the equipment

2.1 Wiring 14
2.2 Main circuit terminal specifications 16
2.3 Control circuit specifications 28
2.4 Connection of motor with encoder (vector control) .36
2.5 Connection of stand-alone option units 43

WWW.BSNEW.IR

2.1 Wiring

2.1.1 Terminal connection diagram




CAUTION


- To prevent a malfunction due to noise, keep the signal cables more than 10cm (3.94inches) away from the power cables.
- After wiring, wire offcuts must not be left in the inverter.
  Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean.
  When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- Set the voltage/current input switch correctly. Different setting may cause a fault, failure or malfunction.

WWW.BSNEW.IR

2.1.2 EMC filter

This inverter is equipped with a built-in EMC filter (capacitive filter) and zero-phase reactor.
Effective for reduction of air-propagated noise on the input side of the inverter.
The EMC filter is factory-set to disable (OFF).
To enable it, fit the EMC filter ON/OFF connector to the ON position.
The input side zero-phase reactor, built-in the FR-A720-02150(FR-A740-01100) or less inverter, is always valid regardless of on/off of the EMC filter on/off connector.






The FR-A720-00030 and 00050 are not provided with the EMC filter ON/OFF connector. (The EMC filter is always valid.)

<How to disconnect the connector>

(1) Before removing a front cover, check to make sure that the indication of the inverter operation panel is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. (*Refer to page 6.*)

(2) When disconnecting the connector, push the fixing tab and pull the connector straight without pulling the cable or forcibly pulling the connector with the tab fixed. When installing the connector, also engage the fixing tab securely. (If it is difficult to disconnect the connector, use a pair of long-nose pliers, etc.)



CAUTION

- Fit the connector to either ON or OFF.
- Enabling (turning on) the EMC filter increases leakage current. *(Refer to page 57)*

⚠ WARNING

⚠ While power is on or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.

WWW.BSNEW.IR

2.2 Main circuit terminal specifications

2.2.1 Specification of main circuit terminal

Terminal Symbol	Terminal Name	Description
R/L1, S/L2, T/L3	**AC power input**	Connect to the commercial power supply. Keep these terminals open when using the high power factor converter (FR-HC and MT-HC) or power regeneration common converter (FR-CV).
U, V, W	**Inverter output**	Connect a three-phase squirrel-cage motor.
R1/L11, S1/L21	**Power supply for control circuit**	Connected to the AC power supply terminals R/L1 and S/L2. To retain the alarm display and alarm output or when using the high power factor converter (FR-HC and MT-HC) or power regeneration common converter (FR-CV), remove the jumpers from terminals R/L1-R1/L11 and S/L2-S1/L21 and apply external power to these terminals. Do not turn off the power supply for control circuit (R1/L11, S1/L21) with the main circuit power (R/L1, S/L2, T/L3) on. Doing so may damage the inverter. The circuit should be configured so that the main circuit power (R/L1, S/L2, T/L3) is also turned off when the power supply for control circuit (R1/L11, S1/L21) is off. FR-A720-00610 (FR-A740-00310) or less : 60VA, FR-A720-00760 (FR-A740-00380) or more : 80VA
P/+, PR	**Brake resistor connection (FR-A720-00900 (FR-A740-00440) or less)**	Remove the jumper from terminals PR-PX (FR-A720-00330 (FR-A740-00170) or less) and connect an optional brake resistor (FR-ABR) across terminals P/+-PR. For the FR-A720-00900 (FR-A740-00440) or less, connecting the resistor further provides regenerative braking power.
P/+, N/-	**Brake unit connection**	Connect the brake unit (FR-BU2, FR-BU, BU and MT-BU5), power regeneration common converter (FR-CV), high power factor converter (FR-HC and MT-HC) or power regeneration converter (MT-RC).
P/+, P1	**DC reactor connection**	For the FR-A720-02150 (FR-A740-01100) or less, remove the jumper across terminals P/+ - P1 and connect the DC reactor. (As a DC reactor is supplied with the FR-A720-02880 (FR-A740-01440) or more as standard, be sure to connect the DC reactor. When using the FR-A720-02150 (FR-A740-01100) with LD or SLD set, always use a DC reactor (option).)
PR, PX	**Built-in brake circuit connection**	When the jumper is connected across terminals PX-PR (initial status), the built-in brake circuit is valid. (Provided for the FR-A720-00330 (FR-A740-00170) or less.)
⏚	**Earth (Ground)**	For earthing (grounding) the inverter chassis. Must be earthed (grounded).

CAUTION


· When connecting a dedicated brake resistor (FR-ABR) and brake unit (FR-BU2, FR-BU, BU) remove jumpers across terminals PR-PX (FR-A720-00330 (FR-A740-00170) or less). For details, refer to *page 43 to 48*.

WWW.BSNEW.IR


2.2.2 Terminal arrangement of the main circuit terminal, power supply and the motor wiring.

200V class


FR-A720-00030, 00050-NA/N4



FR-A720-00080, 00110, 00175-NA/N4




FR-A720-00240, 00330-NA/N4




* Screw size of terminal R1/L11, S1/L21, PR, and PX is M4.


FR-A720-00460-NA



FR-A720-00610, 00760, 00900-NA




FR-A720-01150, 01450, 01750-NA




WWW.BSNEW.IR

FR-A720-02150-NA



* When using the inverter with LD or SLD set, remove a jumper between P/+ and P1 and connect a DC reactor (option FR-HEL-75K).


FR-A720-02880, 03460-NA




WWW.BSNEW.IR

400V class


FR-A740-00015 to 00090-NA/N4




FR-A740-00120, 00170-NA/N4




FR-A740-00230, 00310-NA/N4




FR-A740-00380, 00440-NA



FR-A740-00570, 00710, 00860-NA




FR-A740-01100-NA




* When using the inverter with LD or SLD set, remove a jumper between P/+ and P1 and connect a DC reactor (option FR-HEL-H90K).

WWW.BSNEW.IR


FR-A740-01440, 01800-NA




FR-A740-02160, 02600-NA



FR-A740-03250, 03610-NA




FR-A740-04320 to 09620-NA



CAUTION

- The power supply cables must be connected to R/L1, S/L2, T/L3. Never connect the power cable to the U, V, W of the inverter. Doing so will damage the inverter. (Phase sequence needs not to be matched.)
- Connect the motor to U, V, W. At this time, turning on the forward rotation switch (signal) rotates the motor in the counterclockwise direction when viewed from the motor shaft.
- When wiring the inverter main circuit conductor of the FR-A740-04320 or more, tighten a nut from the right side of the conductor. When wiring two wires, place wires on both sides of the conductor. (Refer to the drawing on the right.) For wiring, use bolts (nuts) provided with the inverter.




WWW.BSNEW.IR

Wiring cover and Handling (FR-A720-00760 (FR-A740-00440) or less)

1) Remove the wiring cover of the inverter. Punch out a knockout by firmly tapping it with such as a hammer. Remove any sharp edges and burrs from knockout holes of the wiring cover.

2) Install conduits and fix with conduits clamps. Pass the cable always through the conduit.



CAUTION

When handling the wiring cover, care must be taken not to cut fingers or hands with sharp edges and burrs.
To avoide wire offcuts and other foreign matter to enter the inverter, conduits must be installed to the all knockout holes.

⚠ WARNING

⚠ Do not wire without using conduits. Otherwise, the cable sheathes may be scratched by the wiring cover edges, resulting in a short circuit or ground fault.

REMARKS

· When using conduits for the FR-A720-00030 and 00050, fix the conduits to the wiring cover after connecting the earth cable to the inverter earth terminal.

WWW.BSNEW.IR

2.2.3 Cables and wiring length

(1) Applied cable size

Select the recommended cable size to ensure that a voltage drop will be 2% max.
If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.
The following table indicates a selection example for the wiring length of 20m (65.62feet).

200V class (when input power supply is 220V)

Applicable Inverter Type	Terminal Screw Size *4	Tightening Torque N·m	Crimping Terminal		Cable Sizes								
					HIV, etc. (mm^2) *1				AWG/MCM *2		PVC, etc. (mm^2) *3		
			R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	P/+, P1	Earth (Ground) cable	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	Earth (Ground) cable
FR-A720-00030 to 00110-NA/N4	M4	1.5	2-4	2-4	2	2	2	2	14	14	2.5	2.5	2.5
FR-A720-00175-NA/ N4	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	3.5	12	12	4	4	4
FR-A720-00240-NA/ N4	M4-M5	2.5	5.5-5	5.5-5	5.5	5.5	5.5	5.5	10	10	6	6	6
FR-A720-00330-NA/ N4	M4-M5	2.5	14-5	8-5	14	8	14	14	6	8	16	10	16
FR-A720-00460-NA	M5	2.5	14-5	14-5	14	14	14	14	6	6	16	16	16
FR-A720-00610-NA	M6	4.4	22-6	22-6	22	22	22	14	4	4	25	25	16
FR-A720-00760-NA	M8-M6	7.8	38-8	38-8	38	38	38	22	2	2	35	35	25
FR-A720-00900-NA	M8-M6	7.8	38-8	38-8	38	38	38	22	2	2	35	35	25
FR-A720-01150-NA	M8-M6	7.8	60-8	60-8	60	60	60	38	1/0	1/0	50	50	25
FR-A720-01450-NA	M10-M8	14.7	80-10	80-10	80	80	80	38	3/0	3/0	70	70	35
FR-A720-01750-NA	M10-M8	14.7	100-10	100-10	100	100	100	60	4/0	4/0	95	95	50
FR-A720-02150-NA	M12-M8	24.5	100-12	100-12	100	100	100	60	4/0	4/0	95	95	50
FR-A720-02880-NA	M12-M10	24.5	150-12	150-12	125	125	125	38	250	250	—	—	—
FR-A720-03460-NA	M12-M10	24.5	150-12	150-12	150	150	150	60	300	300	—	—	—

*1 For the 02150 or less, the cable size is that of the cable (HIV cable (600V class 2 vinyl-insulated cable) etc.) with continuous maximum permissible temperature of 75°C (167°F). Assumes that the ambient temperature is 50°C (122°F) or less and the wiring distance is 20m (65.62feet) or less.
For the 02880 or more, the recommended cable size is that of the cable (LMFC (heat resistant flexible cross-linked polyethylene insulated cable) etc.) with continuous maximum permissible temperature of 90°C (194°F). Assumes that the ambient temperature is 50°C (122°F) or less and wiring is performed in an enclosure.

*2 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 75°C (167°F). Assumes that the ambient temperature is 40°C (104°F) or less and the wiring distance is 20m (65.62feet) or less.
(Selection example for use mainly in the United States.)

*3 For the 00610 or less, the recommended cable size is that of the cable (PVC cable) with continuous maximum permissible temperature of 70°C (158°F). Assumes that the ambient temperature is 40°C (104°F) or less and the wiring distance is 20m (65.62feet) or less.
For the 00760 or more, the recommended cable size is that of the cable (XLPE cable) with continuous maximum permissible temperature of 90°C (194°F). Assumes that the ambient temperature is 40°C (104°F) or less and wiring is performed in an enclosure.
(Selection example for use mainly in Europe.)

*4 The terminal screw size indicates the terminal size for R/L1, S/L2, T/L3, U, V, W, and a screw for earthing (grounding). For the 00240 and 00330, screw sizes are different (<R1/L11, S1/L21, PR, PX> - <R/L1, S/L2, T/L3, U, V, W, a screw for earthing (grounding)>). For the 00760 or more, screw sizes are different. (<R/L1, S/L2, T/L3, U, V, W> - < a screw for earthing (grounding)>)

WWW.BSNEW.IR

400V class (when input power supply is 440V)

Applicable Inverter Type	Terminal Screw Size *4	Tightening Torque N·m	Crimping Terminal		Cable Sizes								
					HIV, etc. (mm^2) *1				AWG/MCM *2		PVC, etc. (mm^2) *3		
			R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	P/+, P1	Earth (Ground) Cable	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	Earth (Ground) Cable
FR-A740-00015 to 00090-NA/N4	M4	1.5	2-4	2-4	2	2	2	2	14	14	2.5	2.5	2.5
FR-A740-00120-NA/ N4	M4	1.5	2-4	2-4	2	2	3.5	3.5	12	14	2.5	2.5	4
FR-A740-00170-NA/ N4	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	3.5	12	12	4	4	4
FR-A740-00230-NA	M5	2.5	5.5-5	5.5-5	5.5	5.5	5.5	8	10	10	6	6	10
FR-A740-00310-NA	M5	2.5	8-5	8-5	8	8	8	8	8	8	10	10	10
FR-A740-00380-NA	M6	4.4	14-6	8-6	14	8	14	14	6	8	16	10	16
FR-A740-00440-NA	M6	4.4	14-6	14-6	14	14	22	14	6	6	16	16	16
FR-A740-00570-NA	M6	4.4	22-6	22-6	22	22	22	14	4	4	25	25	16
FR-A740-00710-NA	M8	7.8	22-8	22-8	22	22	22	14	4	4	25	25	16
FR-A740-00860-NA	M8	7.8	38-8	38-8	38	38	38	22	1	2	50	50	25
FR-A740-01100-NA	M8	7.8	60-8	60-8	60	60	60	22	1/0	1/0	50	50	25
FR-A740-01440-NA	M10	14.7	60-10	60-10	60	60	60	38	1/0	1/0	50	50	25
FR-A740-01800-NA	M10	14.7	60-10	60-10	60	60	80	38	3/0	3/0	50	50	25
FR-A740-02160-NA	M10-M12	14.7	80-10	80-10	80	80	80	38	3/0	3/0	70	70	35
FR-A740-02600-NA	M10-M12	14.7	100-10	100-10	100	100	100	38	4/0	4/0	95	95	50
FR-A740-03250-NA	M12-M10	24.5	150-12	150-12	125	150	150	38	250	250	120	120	70
FR-A740-03610-NA	M12-M10	24.5	150-12	150-12	150	150	150	38	300	300	150	150	95
FR-A740-04320-NA	M12-M10	24.5	100-12	100-12	2×100	2×100	2×100	60	2×4/0	2×4/0	2×95	2×95	95
FR-A740-04810-NA	M12-M10	24.5	100-12	100-12	2×100	2×100	2×125	60	2×4/0	2×4/0	2×95	2×95	95
FR-A740-05470-NA	M12-M10	24.5	150-12	150-12	2×125	2×125	2×125	60	2×250	2×250	2×120	2×120	120
FR-A740-06100-NA	M12-M10	24.5	150-12	150-12	2×150	2×150	2×150	100	2×300	2×300	2×150	2×150	150
FR-A740-06830-NA	M12-M10	24.5	C2-200	C2-200	2×200	2×200	2×200	100	2×350	2×350	2×185	2×185	2×95
FR-A740-07700-NA	M12-M10	24.5	C2-200	C2-200	2×200	2×200	2×200	100	2×400	2×400	2×185	2×185	2×95
FR-A740-08660-NA	M12-M10	24.5	C2-250	C2-250	2×250	2×250	2×250	100	2×500	2×500	2×240	2×240	2×120
FR-A740-09620-NA	M12-M10	24.5	C2-200	C2-250	3×200	2×250	3×200	2×100	2×500	2×500	2×240	2×240	2×120

*1 For the 01100 or less, the cable size is that of the cable (HIV cable (600V class 2 vinyl-insulated cable) etc.) with continuous maximum permissible temperature of 75°C (167°F). Assumes that the ambient temperature is 50°C (122°F) or less and the wiring distance is 20m (65.62feet) or less.
For the 01440 or more, the recommended cable size is that of the cable (LMFC (heat resistant flexible cross-linked polyethylene insulated cable) etc.) with continuous maximum permissible temperature of 90°C (194°F). Assumes that the ambient temperature is 50°C (122°F) or less and wiring is performed in an enclosure.

*2 For the 00860 or less, the recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 75°C (167°F). Assumes that the ambient temperature is 40°C (104°F) or less and the wiring distance is 20m (65.62feet) or less.
For the 01100 or more, the recommended cable size is that of the cable (THHN cable) with continuous maximum permissible temperature of 90°C (194°F). Assumes that the ambient temperature is 40°C (104°F) or less and wiring is performed in an enclosure.
(Selection example for use mainly in the United States.)

*3 For the 00860 or less, the recommended cable size is that of the cable (PVC cable) with continuous maximum permissible temperature of 70°C (158°F). Assumes that the ambient temperature is 40°C (104°F) or less and the wiring distance is 20m (65.62feet) or less.
For the 01100 or more, the recommended cable size is that of the cable (XLPE cable) with continuous maximum permissible temperature of 90°C (194°F). Assumes that the ambient temperature is 40°C (104°F) or less and wiring is performed in an enclosure.
(Selection example for use mainly in Europe.)

*4 The terminal screw size indicates the terminal size for R/L1, S/L2, T/L3, U, V, W, and a screw for earthing (grounding).
For the 02160 and 02600, screw sizes are different (<R/L1, S/L2, T/L3, U, V, W, a screw for earthing (grounding)> - <P/+ for option connection>)
For the 03250 or more, screw sizes are different. (<R/L1, S/L2, T/L3, U, V, W> - <a screw for earthing (grounding)>)

The line voltage drop can be calculated by the following formula:

$$\text{line voltage drop [V]} = \frac{\sqrt{3} \times \text{wire resistance[m}\Omega\text{/m]} \times \text{wiring distance[m]} \times \text{current[A]}}{1000}$$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.

CAUTION

- Tighten the terminal screw to the specified torque.
  A screw that has been tighten too loosely can cause a short circuit or malfunction.
  A screw that has been tighten too tightly can cause a short circuit or malfunction due to the unit breakage.
- Use crimping terminals with insulation sleeve to wire the power supply and motor.

WWW.BSNEW.IR

(2) Notes on earthing (grounding)

- Always earth (ground) the motor and inverter.

1)Purpose of earthing (grounding)

Generally, an electrical apparatus has an earth (ground) terminal, which must be connected to the ground before use.

An electrical circuit is usually insulated by an insulating material and encased. However, it is impossible to manufacture an insulating material that can shut off a leakage current completely, and actually, a slight current flow into the case. The purpose of earthing (grounding) the case of an electrical apparatus is to prevent operator from getting an electric shock from this leakage current when touching it.

To avoid the influence of external noises, this earthing (grounding) is important to audio equipment, sensors, computers and other apparatuses that handle low-level signals or operate very fast.

2)Earthing (grounding) methods and earthing (grounding) work

As described previously, earthing (grounding) is roughly classified into an electrical shock prevention type and a noise-affected malfunction prevention type. Therefore, these two types should be discriminated clearly, and the following work must be done to prevent the leakage current having the inverter's high frequency components from entering the malfunction prevention type earthing (grounding):

(a) Where possible, use independent earthing (grounding) for the inverter. If independent earthing (grounding) (I) is impossible, use joint earthing (grounding) (II) where the inverter is connected with the other equipment at an earthing (grounding) point. Joint earthing (grounding) as in (III) must be avoided as the inverter is connected with the other equipment by a common earth (ground) cable.

Also a leakage current including many high frequency components flows in the earth (ground) cables of the inverter and inverter-driven motor. Therefore, they must use the independent earthing (grounding) method and be separated from the earthing (grounding) of equipment sensitive to the aforementioned noises.


In a tall building, it will be a good policy to use the noise malfunction prevention type earthing (grounding) with steel frames and carry out electric shock prevention type earthing (grounding) in the independent earthing (grounding) method.

(b) This inverter must be earthed (grounded). Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards).

(c) Use the thickest possible earth (ground) cable. The earth (ground) cable should be of not less than the size indicated in the table on the previous page.

(d) The grounding point should be as near as possible to the inverter, and the ground wire length should be as short as possible.

(e) Run the earth (ground) cable as far away as possible from the I/O wiring of equipment sensitive to noises and run them in parallel in the minimum distance.



(I) Independent earthing (grounding) .....Good (II) Common earthing (grounding).....Good (III) Common earthing (grounding).....Not allowed

To be compliant with the European Directive (Low Voltage Directive), refer to *the Installation guideline*.


WWW.BSNEW.IR

(3) Total wiring length

The overall wiring length for connection of a single motor or multiple motors should be within the value in the table below. (The wiring length should be 100m (328.08feet) maximum for vector control.)

Pr. 72 PWM frequency selection setting (carrier frequency)	FR-A720-00030 FR-A740-00015	FR-A720-00050 FR-A740-00025	FR-A720-00080 or more FR-A740-00040 or more
2 (2kHz) or less	300m (984.25 feet)	500m (1640.42 feet)	500m (1640.42 feet)
3 to 15 (3kHz to 14.5kHz)	200m (656.19 feet)	300m (984.25 feet)	500m (1640.42 feet)

Total wiring length (FR-A720-00080 (FR-A740-00040) or more)



300m (984.25feet) + 300m (984.25feet) = 600m (1968.50feet)

When driving a 400V class motor by the inverter, surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.
Refer to *page 63* for measures against deteriorated insulation.

CAUTION

- Especially for long-distance wiring, the inverter may be affected by a charging current caused by the stray capacitances of the wiring, leading to a malfunction of the overcurrent protective function or fast response current limit function or a malfunction or fault of the equipment connected on the inverter output side. If fast response current limit function malfunctions, disable this function. (For *Pr. 156 Stall prevention operation selection, refer to page 150* .)
- For details of *Pr. 72 PWM frequency selection , refer to page 279*.


(4) Cable size of the control circuit power supply (terminal R1/L11, S1/L21)

- Terminal screw size: M4
- Cable size: 0.75mm^2 to 2mm^2
- Tightening torque: 1.5N·m

WWW.BSNEW.IR

2.2.4 When connecting the control circuit and the main circuit separately to the power supply (separate power)


<Connection diagram>



When the protected circuit is activated, opening of the electromagnetic contactor (MC) on the inverter power supply side results in power loss in the control circuit, disabling the alarm output signal retention. Terminals R1/L11 and S1/L21 are provided to hold an alarm signal. In this case, connect the power supply terminals R1/L11 and S1/L21 of the control circuit to the primary side of the MC.


• FR-A720-00030 to 00175, FR-A740-00015 to 00090

1) Loosen the upper screws.
2) Remove the lower screws.
3) Remove the jumper
4) Connect the separate power supply cable for the control circuit to the lower terminals (R1/L11, S1/L21).



• FR-A720-00240, 00330, FR-A740-00120, 00170


1) Remove the upper screws.
2) Remove the lower screws.
3) Remove the jumper.
4) Connect the separate power supply cable for the control circuit to the upper terminals (R1/L11, S1/L21).



WWW.BSNEW.IR

• FR-A720-00460 or more, FR-A740-00230 or more

1) Remove the upper screws.
2) Remove the lower screws.
3) Pull the jumper toward you to remove.
4) Connect the separate power supply cable for the control circuit to the upper terminals (R1/L11, S1/L21). Never connect the power cable to the terminals in the lower stand. Doing so will damage the inverter.



CAUTION

- Do not turn off the control power (terminals R1/L11 and S1/L21) with the main circuit power (R/L1, S/L2, T/L3) on. Doing so may damage the inverter.
- Be sure to use the inverter with the jumpers across terminals R/L1-R1/L11 and S/L2-S1/L21 removed when supplying power from other sources. The inverter may be damaged if you do not remove the jumper.
- The voltage should be the same as that of the main control circuit when the control circuit power is supplied from other than the primary side of the MC.
- The power capacity necessary when separate power is supplied from R1/L11 and S1/L21 differs according to the inverter capacity.

200V class	FR-A720-00460 or less 60VA	FR-A720-00610 or less 80VA	FR-A720-00760 or more 80VA
400V class	FR-A740-00230 or less 60VA	FR-A740-00310 or less 60VA	FR-A740-00380 or more 80VA

- When the power supply used with the control circuit is different from the one used with the main circuit, make up a circuit which will switch off the main circuit power supply terminals R/L1, S/L2, T/L3 when the control circuit power supply terminals R1/L11, S1/L21 are switched off.
- If the main circuit power is switched off (for 0.1s or more) then on again, the inverter resets and an alarm output will not be held.

WWW.BSNEW.IR

2.3 Control circuit specifications


2.3.1 Control circuit terminals

indicates that terminal functions can be selected using *Pr. 178 to Pr. 196 (I/O terminal function selection) (Refer to page 228.)*

(1) Input signals

Type	Terminal Symbol	Terminal Name	Description		Rated Specifications	Refer to page
Contact input	STF	Forward rotation start	Turn on the STF signal to start forward rotation and turn it off to stop.	When the STF and STR signals are turned on simultaneously, the stop command is given.	Input resistance 4.7kΩ Voltage at opening: 21 to 27VDC Contacts at short-circuited: 4 to 6mADC	228
	STR	Reverse rotation start	Turn on the STR signal to start reverse rotation and turn it off to stop.			228
	STOP	Start self-holding selection	Turn on the STOP signal to self-hold the start signal.			228
	RH, RM, RL	Multi-speed selection	Multi-speed can be selected according to the combination of RH, RM and RL signals.			228
	JOG	Jog mode selection	Turn on the JOG signal to select Jog operation (initial setting) and turn on the start signal (STF or STR) to start Jog operation.			228
		Pulse train input	JOG terminal can be used as pulse train input terminal. To use as pulse train input terminal, the *Pr. 291* setting needs to be changed. (maximum input pulse: 100kpulses/s)		Input resistance 2kΩ Contacts at short-circuited: 8 to 13mADC	228
	RT	Second function selection	Turn on the RT signal to select second function. When the second function such as "second torque boost" and "second V/F (base frequency)" are set, turning on the RT signal selects these functions.		Input resistance 4.7kΩ Voltage at opening: 21 to 27VDC Contacts at short-circuited: 4 to 6mADC	228
	MRS	Output stop	Turn on the MRS signal (20ms or more) to stop the inverter output. Use to shut off the inverter output when stopping the motor by electromagnetic brake.			228
	RES	Reset	Used to reset alarm output provided when protective circuit is activated. Turn on the RES signal for more than 0.1s, then turn it off. Initial setting is for reset always. By setting *Pr. 75*, reset can be set to enabled only at an inverter alarm occurrence. Recover about 1s after reset is cancelled.			228
	AU	Terminal 4 input selection	Terminal 4 is made valid only when the AU signal is turned on. (The frequency setting signal can be set between 4 and 20mADC.) Turning the AU signal on makes terminal 2 (voltage input) invalid.			282
		PTC input	AU terminal is used as PTC input terminal (thermal protection of the motor). When using it as PTC input terminal, set the AU/PTC switch to PTC.			184
	CS	Selection of automatic restart after instantaneous power failure	When the CS signal is left on, the inverter restarts automatically at power restoration. Note that restart setting is necessary for this operation. In the initial setting, a restart is disabled. *(Refer to Pr. 57 Restart coasting time in page 261)*			228
	SD	Contact input common (sink)	Common terminal for contact input terminal (sink logic) and terminal FM. Common output terminal for 24VDC 0.1A power supply (PC terminal). Isolated from terminals 5 and SE.		———	—
	PC	External transistor common, 24VDC power supply, contact input common (source)	When connecting the transistor output (open collector output), such as a programmable controller (PLC), when sink logic is selected, connect the external power supply common for transistor output to this terminal to prevent a malfunction caused by undesirable currents. Can be used as 24VDC 0.1A power supply. When source logic has been selected, this terminal serves as a contact input common.		Power supply voltage range 19.2 to 28.8VDC Current consumption 100mA	32

WWW.BSNEW.IR

Type	Terminal Symbol	Terminal Name	Description	Rated Specifications	Refer to page
Frequency setting	10E	Frequency setting power supply	When connecting the frequency setting potentiometer at an initial status, connect it to terminal 10. Change the input specifications of terminal 2 when connecting it to terminal 10E. *(Refer to Pr. 73 Analog input selection page 285.)*	10VDC±0.4V Permissible load current 10mA	282
	10			5.2VDC±0.2V Permissible load current 10mA	282
	2	Frequency setting (voltage)	Inputting 0 to 5VDC (or 0 to 10V, 0 to 20mA) provides the maximum output frequency at 5V (10V, 20mA) and makes input and output proportional. Use *Pr. 73* to switch from among input 0 to 5VDC (initial setting), 0 to 10VDC, and 0 to 20mA. Set the voltage/current input switch in the ON position to select current input (0 to 20mA). *1	Voltage input: Input resistance 10kΩ ± 1kΩ Maximum permissible voltage 20VDC Current input: Input resistance 245Ω ± 5Ω Maximum permissible current 30mA	282
	4	Frequency setting (current)	Inputting 4 to 20mADC (or 0 to 5V, 0 to 10V) provides the maximum output frequency at 20mA makes input and output proportional. This input signal is valid only when the AU signal is on (terminal 2 input is invalid). Use *Pr. 267* to switch from among input 4 to 20mA (initial setting), 0 to 5VDC, and 0 to 10VDC. Set the voltage/current input switch in the OFF position to select voltage input (0 to 5V/0 to 10V). *1 Use *Pr. 858* to switch terminal functions.		282
	1	Frequency setting auxiliary	Inputting 0 to ±5 VDC or 0 to ±10VDC adds this signal to terminal 2 or 4 frequency setting signal. Use *Pr. 73* to switch between the input 0 to ±5VDC and 0 to ±10VDC (initial setting).	Input resistance 10kΩ ± 1kΩ Maximum permissible voltage ± 20VDC	282
	5	Frequency setting common	Common terminal for frequency setting signal (terminal 2, 1 or 4) and analog output terminal AM. Do not earth (ground).	———	282

*1 Set *Pr. 73*, *Pr. 267*, and a voltage/current input switch correctly, then input an analog signal in accordance with the setting.
Applying a voltage signal with voltage/current input switch on (current input is selected) or a current signal with switch off (voltage input is selected) could cause component damage of the inverter or analog circuit of signal output devices. (For details, *refer to page 282*.)

(2) Output signals

Type	Terminal Symbol	Terminal Name	Description	Rated Specifications	Refer to page
Relay	A1, B1, C1	Relay output 1 (alarm output)	1 changeover contact output indicates that the inverter protective function has activated and the output stopped. Abnormal: No conduction across B-C (Across A-C Continuity), Normal: Across B-C Continuity (No conduction across A-C)	Contact capacity: 230VAC 0.3A (Power factor=0.4) 30VDC 0.3A	236
	A2, B2, C2	Relay output 2	1 changeover contact output		236

WWW.BSNEW.IR

Type	Terminal Symbol	Terminal Name	Description		Rated Specifications	Refer to page
Open collector	RUN	Inverter running	Switched low when the inverter output frequency is equal to or higher than the starting frequency (initial value 0.5Hz). Switched high during stop or DC injection brake operation.*1		Permissible load 24VDC (27VDC maximum) 0.1A (A voltage drop is 2.8V maximum when the signal is on.)	236
	SU	Up to frequency	Switched low when the output frequency reaches within the range of ±10% (initial value) of the set frequency. Switched high during acceleration/ deceleration and at a stop. *1	Alarm code (4bit) output (Refer to *page 270*)		236
	OL	Overload warning	Switched low when stall prevention is activated by the stall prevention function. Switched high when stall prevention is cancelled. *1			236
	IPF	Instantaneous power failure	Switched low when an instantaneous power failure and under voltage protections are activated. *1			236
	FU	Frequency detection	Switched low when the inverter output frequency is equal to or higher than the preset detected frequency and high when less than the preset detected frequency. *1			236
	SE	Open collector output common	Common terminal for terminals RUN, SU, OL, IPF, FU		———	—
Pulse	FM	For meter	Select one e.g. output frequency from monitor items. *2 The output signal is proportional to the magnitude of the corresponding monitoring item.	Output item: Output frequency (initial setting)	Permissible load current 2mA 1440pulses/s at 60Hz	250
		NPN open collector output		Signals can be output from the open collector terminals by setting *Pr. 291*.	Maximum output pulse: 50kpulses/s Permissible load current : 80mA	372
Analog	AM	Analog signal output		Output item: Output frequency (initial setting)	Output signal 0 to 10VDC Permissible load current 1mA (load impedance 10kΩ or more) Resolution 8 bit	250

*1 Low indicates that the open collector output transistor is on (conducts).
High indicates that the transistor is off (does not conduct).
*2 Not output during inverter reset.

(3) Communication


Type	Terminal Symbol		Terminal Name	Description	Refer to page
RS-485	———		PU connector	With the PU connector, communication can be made through RS-485. (for connection on a 1:1 basis only) . Conforming standard : EIA-485 (RS-485) . Transmission format : Multidrop . Communication speed : 4800 to 38400bps . Overall length : 500m (1640.42feet)	322
	RS-485 terminals	TXD+	Inverter transmission terminal	With the RS-485 terminals, communication can be made through RS-485. Conforming standard : EIA-485 (RS-485) Transmission format : Multidrop link Communication speed : 300 to 38400bps Overall length : 500m (1640.42feet)	324
		TXD-			
		RXD+	Inverter reception terminal		
		RXD-			
		SG	Earth (Ground)		
USB	———		USB connector	The FR-Configurator can be performed by connecting the inverter to the personnel computer through USB. Interfase:Conforms to USB1.1 Transmission speed:12Mbps Connector:USB B connector (B receptacle)	354

WWW.BSNEW.IR


2.3.2 Changing the control logic

The input signals are set to sink logic (SINK) when shipped from the factory.
To change the control logic, the jumper connector on the back of the control circuit terminal block must be moved to the other position.
(The output signals may be used in either the sink or source logic independently of the jumper connector position.)


1) Loosen the two installation screws in both ends of the control circuit terminal block. (These screws cannot be removed.)
   Pull down the terminal block from behind the control circuit terminals.



2) Change the jumper connector set to the sink logic (SINK) on the rear panel of the control circuit terminal block to source logic (SOURCE).



3) Using care not to bend the pins of the inverter's control circuit connector, reinstall the control circuit terminal block and fix it with the mounting screws.



CAUTION


1. Make sure that the control circuit connector is fitted correctly.
2. While power is on, never disconnect the control circuit terminal block.

WWW.BSNEW.IR


4) Sink logic and source logic

- In sink logic, a signal switches on when a current flows from the corresponding signal input terminal. Terminal SD is common to the contact input signals. Terminal SE is common to the open collector output signals.
- In source logic, a signal switches on when a current flows into the corresponding signal input terminal. Terminal PC is common to the contact input signals. Terminal SE is common to the open collector output signals.



●Current flow concerning the input/output signal when sink logic is selected



●Current flow concerning the input/output signal when source logic is selected




- When using an external power supply for transistor output

· Sink logic type Use terminal PC as a common terminal to prevent a malfunction caused by undesirable current. (Do not connect terminal SD of the inverter with terminal 0V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install a power supply in parallel in the outside of the inverter. Doing so may cause a malfunction due to undesirable current.)	· Source logic type When using an external power supply for transistor output, use terminal SD as a common to prevent misoperation caused by undesirable current.
	

WWW.BSNEW.IR

2.3.3 Control circuit terminal layout

Terminal screw size: M3.5
Tightening torque: 1.2N·m




(1) Common terminals of the control circuit (SD, 5, SE)

Terminals SD, 5, and SE are all common terminals (0V) for I/O signals and are isolated from each other. Do not earth (ground) these terminals.
Avoid connecting the terminal SD and 5 and the terminal SE and 5.
Terminal SD is a common terminal for the contact input terminals (STF, STR, STOP, RH, RM, RL, JOG, RT, MRS, RES, AU, CS) and frequency output signal (FM).
The open collector circuit is isolated from the internal control circuit by photocoupler.
Terminal 5 is a common terminal for frequency setting signal (terminal 2, 1 or 4) and analog output terminal AM.
It should be protected from external noise using a shielded or twisted cable.
Terminal SE is a common terminal for the open collector output terminal (RUN, SU, OL, IPF, FU).
The contact input circuit is isolated from the internal control circuit by photocoupler.

(2) Signal inputs by contactless switches

The contacted input terminals of the inverter (STF, STR, STOP, RH, RM, RL, JOG, RT, MRS, RES, AU, CS) can be controlled using a transistor instead of a contacted switch as shown on the right.




External signal input using transistor


WWW.BSNEW.IR

2.3.4 Wiring instructions

1) Terminals 5, SD and SE are common to the I/O signals and isolated from each other. Do not earth (ground). Avoid connecting the terminal SD and 5 and the terminal SE and 5.
2) Use shielded or twisted cables for connection to the control circuit terminals and run them away from the main and power circuits (including the 200V relay sequence circuit).
3) Use two or more parallel micro-signal contacts or twin contacts to prevent a contact faults when using contact inputs since the control circuit input signals are micro-currents.



Micro signal contacts




Twin contacts


4) Do not apply a voltage to the contact input terminals (e.g. STF) of the control circuit.
5) Always apply a voltage to the alarm output terminals (A, B, C) via a relay coil, lamp, etc.
6) It is recommended to use the cables of 0.75mm^2 gauge for connection to the control circuit terminals.
   If the cable gauge used is 1.25mm^2 or more, the front cover may be lifted when there are many cables running or the cables are run improperly, resulting in an operation panel contact fault.
7) The wiring length should be 30m (98.43feet) (200m (656.17feet) for terminal FM) maximum.

● Wiring of the control circuit of the FR-A720-02800 (FR-A740-01440) or more

For wiring of the control circuit of the FR-A720-02800 (FR-A740-01440) or more, separate away from wiring of the main circuit.
Make cuts in rubber bush of the inverter side and lead wires.




<Wiring>



WWW.BSNEW.IR

2.3.5 When connecting the operation panel using a connection cable

When connecting the operation panel (FR-DU07) to the inverter using a cable, the operation panel can be mounted on the enclosure surface and operationality improves.




REMARKS

- Overall wiring length when the operation panel is connected: 20m(65.6 feet)
- Refer to the following when fabricating the cable on the user side.
  Commercially available product examples (as of Sep., 2006)

	Product	Type	Maker
1)	10BASE-T cable	SGLPEV-T 0.5mm × 4P	Mitsubishi Cable Industries, Ltd.
2)	RJ-45 connector	5-554720-3	Tyco Electronics Corporation

2.3.6 RS-485 terminal block

- Conforming standard: EIA-485(RS-485)
- Transmission format: Multidrop link
- Communication speed: MAX 38400bps
- Overall length: 500m (1640 feet)
- Connection cable:Twisted pair cable
  (4 paires)



2.3.7 Communication operation


Using the PU connector or RS-485 terminal, you can perform communication operation from a personal computer etc. When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.
For the Mitsubishi inverter protocol (computer link operation), communication can be performed with the PU connector and RS-485 terminal.
For the Modbus RTU protocol, communication can be performed with the RS-485 terminal.
For further details, *refer to 322*.

WWW.BSNEW.IR

2.4 Connection of motor with encoder (vector control)

Orientation control and encoder feedback control, and speed control, torque control and position control by full-scale vector control operation can be performed using a motor with encoder and a plug-in option FR-A7AP.

(1) Structure of the FR-A7AP




(2) Terminals of the FR-A7AP

Terminal	Terminal Name	Description
PA1	Encoder A-phase signal input terminal	A-, B- and Z-phase signals are input from the encoder.
PA2	Encoder A-phase inverse signal input terminal	
PB1	Encoder B-phase signal input terminal	
PB2	Encoder B-phase inverse signal input terminal	
PZ1	Encoder Z-phase signal input terminal	
PZ2	Encoder Z-phase inversion signal input terminal	
PG	Encoder power supply (positive side) input terminal	Input terminal for the encoder power supply. Connect the external power supply (5V, 12V, 15V, 24V) and the encoder power cable.
SD	Encoder power supply ground terminal	
PIN	Not used.	
PO		


WWW.BSNEW.IR

(3) Switches of the FR-A7AP

- Encoder specification selection switch (SW1)
  Select either differential line driver or complementary
  It is initially set to the differential line driver. Switch its position according to output circuit.



- Terminating resistor selection switch (SW2)
  Select ON/OFF of the internal terminating resistor. Set the switch to ON (initial status) when an encoder output type is differential line driver and set to OFF when complimentary.
  ON : with internal terminating resistor (initial status)
  OFF : without internal terminating resistor



REMARKS

- Set all swithces to the same setting (ON/OFF).
- If the encoder output type is differential line driver, set the terminating resistor switch to the "OFF" position when sharing the same encoder with other unit (NC (numerical controller), etc) or a terminating resistor is connected to other unit.

- Motor used and switch setting

Motor		Encoder Specification Selection Switch (SW1)	Terminating Resistor Selection Switch (SW2)	Power Specifications *2
Mitsubishi standard motor with encoder Mitsubishi high efficiency motor with encoder	SF-JR	Differential	ON	5V
	SF-HR	Differential	ON	5V
	Others	*1	*1	*1
Mitsubishi constant-torque motor with encoder	SF-JRCA	Differential	ON	5V
	SF-HRCA	Differential	ON	5V
	Others	*1	*1	*1
Vector control dedicated motor	SF-V5RU	Complimentary	OFF	12V
Other manufacturer motor with encoder	–	*1	*1	*1

*1 Set according to the motor (encoder) used.
*2 Choose a power supply (5V/12V/15V/24V) for encoder according to the encoder used.

CAUTION

SW3 switch is for manufacturer setting. Do not change the setting.

- Encoder specification

Item	Encoder for SF-JR	Encoder for SF-V5RU
Resolution	1024 Pulse/Rev	2048 Pulse/Rev
Power supply voltage	5VDC±10%	12VDC±10%
Current consumption	150mA	150mA
Output signal form	A, B phases (90° phase shift) Z phase: 1 pulse/rev	A, B phases (90° phase shift) Z phase: 1 pulse/rev
Output circuit	Differential line driver 74LS113 equivalent	Complimentary
Output voltage	H level: 2.4V or more L level: 0.5V or less	H level: "Power supply for encoder-3V" or more L level: 3V or less


CAUTION

Encoder with resolution of 1000 to 4096 pulse/rev is recommended.


WWW.BSNEW.IR

(4) Encoder Cable


SF-JR Motor with Encoder



Type	Length L (m(feet))
FR-JCBL5	5 (16.4)
FR-JCBL15	15 (49.2)
FR-JCBL30	30 (98.4)




SF-V5RU, SF-THY




· A P clip for earthing (grounding) a shielded cable is provided.

Type	Length L (m(feet))
FR-V7CBL5	5 (16.4)
FR-V7CBL15	15 (49.2)
FR-V7CBL30	30 (98.4)



* As the terminal block of the FR-A7AP is an insertion type, earth cables need to be modified. (See below)

- When using the dedicated encoder cable (FR-JCBL, FR-V5CBL, etc.) for the conventional motor, cut the crimpling terminal of the encoder cable and strip its sheath to make its cables loose.
  Also, protect the shielded cable of the twisted pair shielded cable to ensure that it will not make contact with the conductive area.



Wire the stripped cable after twisting it to prevent it from becoming loose. In addition, do not solder it.
Use a bar terminal as necessary.

REMARKS

Information on bar terminals
Introduced products (as of September, 2006): Phoenix Contact Co.,Ltd.

Terminal Screw Size	Bar Terminal Model (with insulation sleeve)	Bar Terminal Model (without insulation sleeve)	Wire Size (mm²)
M2	Al 0.5-6WH	A 0.5-6	0.3 to 0.5

· Bar terminal crimping tool: CRIMPFOX ZA3 (Phoenix Contact Co., Ltd.)

When using the bar terminal (without insulation sleeve), use care so that the twisted wires do not come out.





Connection terminal compatibility table

Motor		SF-V5RU, SF-THY	SF-JR/HR/JRCA/HRCA (with Encoder)
Encoder cable		FR-V7CBL	FR-JCBL
FR-A7AP terminal	PA1	PA	PA
	PA2	Keep this open.	PAR
	PB1	PB	PB
	PB2	Keep this open.	PBR
	PZ1	PZ	PZ
	PZ2	Keep this open.	PZR
	PG	PG	5E
	SD	SD	AG2



WWW.BSNEW.IR

(5) Wiring

• Speed control

Standard motor with encoder (SF-JR), 5V differential line driver	Vector control dedicated motor (SF-V5RU, SF-THY), 12V complimentary
	

• Torque control

Standard motor with encoder (SF-JR), 5V differential line driver	Vector control dedicated motor (SF-V5RU, SF-THY), 12V complimentary
	

*1 The pin number differs according to the encoder used.
Speed control and torque control are properly performed even without connecting Z phase.

*2 Connect the encoder so that there is no looseness between the motor and motor shaft. Speed ratio should be 1:1.

*3 Earth (Ground) the shielded cable of the encoder cable to the enclosure with a P clip, etc. *(Refer to page 41.)*


*4 For the complementary, set the terminating resistor selection switch to off position. *(Refer to page 37.)*

*5 A separate power supply of 5V/12V/15V/24V is necessary according to the encoder power specification.

*6 For terminal compatibility of the FR-JCBL, FR-V7CBL and FR-A7AP, refer to *page 38*.

*7 For the fan of the 7.5kW or less dedicated motor, the power supply is single phase. (200V/50Hz, 200 to 230V/60Hz)


*8 Assign OH (external thermal input) signal to the terminal CS. (Set "7" in *Pr. 186*)
Connect a 2W1kΩ resistor between the terminal PC and CS (OH). Install the resistor pushing against the bottom part of the terminal block so as to avoid a contact with other cables.
Refer to page 228 for details of Pr. 186 CS terminal function selection.



WWW.BSNEW.IR

- Position control

Vector control dedicated motor (SF-V5RU, SF-THY), 12V complimentary



*1 The pin number differs according to the encoder used.
Position control by pulse train input is properly performed even without connecting Z phase.

*2 Connect the encoder so that there is no looseness between the motor and motor shaft. Speed ratio should be 1:1.

*3 Earth (Ground) the shielded cable of the encoder cable to the enclosure with a P clip, etc. *(Refer to page 41.)*

*4 For the complementary, set the terminating resistor selection switch to off position. *(Refer to page 37.)*

*5 A separate power supply of 5V/12V/15V/24V is necessary according to the encoder power specification.

*6 For terminal compatibility of the FR-JCBL, FR-V7CBL and FR-A7AP, refer to *page 38*.


*7 Assign the function using *Pr. 178 to Pr. 184, Pr. 187 to Pr. 189 (input terminal function selection)*.

*8 When position control is selected, terminal JOG function is made invalid and conditional position pulse train input terminal becomes valid.

*9 Assign the function using *Pr. 190 to Pr. 194 (output terminal function selection)*.

*10 For the fan of the 7.5kW or less dedicated motor, the power supply is single phase. (200V/50Hz, 200 to 230V/60Hz)

*11 Assign OH (external thermal input) signal to the terminal CS. (Set "7" in *Pr. 186*)
Connect a 2W1kΩ resistor between the terminal PC and CS (OH). Install the resistor pushing against the bottom part of the terminal block so as to avoid a contact with other cables.
Refer to page 228 for details of Pr. 186 CS terminal function selection.



WWW.BSNEW.IR

(6) Instructions for encoder cable wiring


• Use twisted pair shield cables (0.2mm^2 or larger) to connect the FR-A7AP and position detector. Cables to terminals PG and SD should be connected in paralell or be larger in size according to the cable length.
To protect the cables from noise, run them away from any source of noise (e.g. the main circuit and power supply voltage).

Wiring Length	Paralell Connection		Larger-Size Cable
Within 10m (32.8feet)	At least 2 cables	Cable gauge 0.2mm^2	0.4mm^2 or larger
Within 20m (65.6feet)	At least 4 cables		0.75mm^2 or larger
Within 100m (328.1feet) *	At least 6 cables		1.25mm^2 or larger

* When differential line driver is set and a wiring length is 30m (98.4feet) or more
The wiring length can be extended to 100m by slightly increasing the power by 5V (approx. 5.5V) using six or more cables with gauge size of 0.2mm^2 in parallel or a cable with gauge size of 1.25mm^2 or more. Note that the voltage applied should be within power supply specifications of encoder.

• To reduce noise of the encoder cable, earth (ground) the encoder shielded cable to the enclosure (as near as the inverter) with a P clip or U clip made of metal.



Earthing (grounding) example using a P clip



REMARKS

- For details of the optional encoder dedicated cable (FR-JCBL/FR-V7CBL), refer to *page 38*.
- The FR-V7CBL is provided with a P clip for earthing (grounding) shielded cable.

(7) Parameter for encoder *(Pr. 359, Pr. 369)*

Parameter Number	Name	Initial Value	Setting Range	Description
359	**Encoder rotation direction**	1	0	 Forward rotation is clockwise rotation when viewed from A.
			1	 Forward rotation is counterclockwise rotation when viewed from A.
369	**Number of encoder pulses**	1024	0 to 4096	Set the number of encoder pulses output. Set the number of pulses before it is multiplied by 4.

The above parameters can be set when the FR-A7AP (option) is mounted.

(8) Motor for vector control and parameter setting

Motor Name		*Pr. 9* Electronic thermal O/L relay	*Pr. 71* Applied motor	*Pr. 80* Motor capacity	*Pr. 81* Number of motor poles	*Pr. 359* Encoder rotation direction	*Pr. 369* Number of encoder pulses
Mitsubishi standard motor	SF-JR	Motor rated current	0	Motor capacity	Number of motor poles	1	1024
	SF-JR 4P 1.5kW or less	Motor rated current	20	Motor capacity	Number of motor poles	1	1024
	SF-HR	Motor rated current	40	Motor capacity	Number of motor poles	1	1024
	Others	Motor rated current	3 *1	Motor capacity	Number of motor poles	*2	*2
Mitsubishi constant-torque motor	SF-JRCA 4P	Motor rated current	1	Motor capacity	4	1	1024
	SF-HRCA 4P	Motor rated current	50	Motor capacity	4	1	1024
	Others	Motor rated current	13 *1	Motor capacity	Number of motor poles	*2	*2
Mitsubishi vector control dedicated motor	SF-V5RU (1500r/min series)	0 *3	30	Motor capacity	4	1	2048
	SF-THY	0 *3	33 *1	Motor capacity	4	1	2048
Other manufacturer's standard motor	—	Motor rated current	3 *1	Motor capacity	Number of motor poles	*2	*2
Other manufacturer's constant torque motor	—	Motor rated current	13 *1	Motor capacity	Number of motor poles	*2	*2

Values in the bolded frame are initial values.

*1 Offline auto tuning is necessary. *(Refer to page 187)*
*2 Set this parameter according to the motor (encoder) used.
*3 Use thermal protector input provided with the motor.

♦Parameters referred to♦

Vector control (speed control) ☞ *Refer to page 97.*
Vector control (torque control) ☞ *Refer to page 121.*
Vector control (position control) ☞ *Refer to page 129.*
Orientation control ☞ *Refer to page 217.*
Encoder feedback control ☞ *Refer to page 375.*

WWW.BSNEW.IR

(9) Combination with a vector control dedicated motor

Refer to the table below when using with a vector control dedicated motor.

• Combination with the SF-V5RU and SF-THY

Voltage	200V class			400V class		
Rated speed	1500r/min					
Base frequency	50Hz					
Maximum speed	3000r/min					
Motor capacity	Motor frame number	Motor type	Inverter type	Motor frame number	Motor type	Inverter type
1.5kW	90L	SF-V5RU1K	FR-A720-00110	90L	SF-V5RUH1K	FR-A740-00060
2.2kW	100L	SF-V5RU2K	FR-A720-00175	100L	SF-V5RUH2K	FR-A740-00060
3.7kW	112M	SF-V5RU3K	FR-A720-00240	112M	SF-V5RUH3K	FR-A740-00090
5.5kW	132S	SF-V5RU5K	FR-A720-00330	132S	SF-V5RUH5K	FR-A740-00170
7.5kW	132M	SF-V5RU7K	FR-A720-00460	132M	SF-V5RUH7K	FR-A740-00230
11kW	160M	SF-V5RU11K	FR-A720-00610	160M	SF-V5RUH11K	FR-A740-00310
15kW	160L	SF-V5RU15K	FR-A720-00760	160L	SF-V5RUH15K	FR-A740-00380
18.5kW	180M	SF-V5RU18K	FR-A720-00900	180M	SF-V5RUH18K	FR-A740-00440
22kW	180M	SF-V5RU22K	FR-A720-01150	180M	SF-V5RUH22K	FR-A740-00570
30kW	200L *2	SF-V5RU30K	FR-A720-01450	200L *2	SF-V5RUH30K	FR-A740-00710
37kW	200L *2	SF-V5RU37K	FR-A720-01750	200L *2	SF-V5RUH37K	FR-A740-00860
45kW	200L *2	SF-V5RU45K	FR-A720-02150	200L *2	SF-V5RUH45K	FR-A740-01100
55kW	225S *1	SF-V5RU55K	FR-A720-02880	225S *1	SF-V5RUH55K	FR-A740-01440
75kW	250MD	SF-THY	FR-A720-03460	250MD	SF-THY	FR-A740-01800
90kW	—	—	—	250MD	SF-THY	FR-A740-02160
110kW	—	—	—	280MD	SF-THY	FR-A740-02600
132kW	—	—	—	280MD	SF-THY	FR-A740-03250
160kW	—	—	—	280MD	SF-THY	FR-A740-03610
200kW	—	—	—	280L	SF-THY	FR-A740-04320
250kW	—	—	—	315H	SF-THY	FR-A740-05470

*1 The maximum speed is 2400r/min.

*2 80% output in the high-speed range. (The output is reduced when the speed is 2400r/min or more.)

*3 90% output in the high-speed range. (The output is reduced when the speed is 1000r/min or more.)

WWW.BSNEW.IR

2.5 Connection of stand-alone option units

The inverter accepts a variety of stand-alone option units as required.
Incorrect connection will cause inverter damage or accident. Connect and operate the option unit carefully in accordance with the corresponding option unit manual.

2.5.1 Connection of the dedicated external brake resistor (FR-ABR) (FR-A720-00900 (FR-A740-00440) or less)



The built-in brake resistor is connected across terminals P/+ and PR. Fit the external dedicated brake resistor (FR-ABR) when the built-in brake resistor does not have enough thermal capability for high-duty operation. At this time, remove the jumper from across terminals PR-PX (FR-A720-00330 (FR-A740-00170) or less) and connect the dedicated brake resistor (FR-ABR) across terminals P/+-PR.
(For the locations of terminal P/+ and PR, refer to the terminal block layout *(page 17)*.)
Removing jumpers across terminal PR-PX disables the built-in brake resistor (power is not supplied).
Note that the built-in brake resistor is not need to be removed from the inverter.
The lead wire of the built-in brake resistor is not need to be removed from the terminal.
Set parameters below.
· *Pr. 30 Regenerative function selection* = "1"
· *Pr. 70 Special regenerative brake duty* = "FR-A720-00330 (FR-A740-00170) or less: 10%, FR-A720-00460 (FR-A740-00230) or more: 6%" (Refer to *page 204*)

CAUTION

1. The brake resistor connected should only be the dedicated brake resistor.
2. The jumper across terminals PR-PX (FR-A720-00330 (FR-A740-00170) or less) must be disconnected before connecting the dedicated brake resistor. Doing so may damage the inverter.



●FR-A720-00030, 00050

1) Remove the screws in terminals PR and PX and remove the jumper.
2) Connect the brake resistor across terminals P/+ and PR. (The jumper should remain disconnected.)

1) Removal of Jumper	2) Connection of Brake Resistor
	

●FR-A720-00080 to 00175, FR-A740-00015 to 00090



1) Remove the screws in terminals PR and PX and remove the jumper.
2) Connect the brake resistor across terminals P/+ and PR. (The jumper should remain disconnected.)

1) Removal of Jumper	2) Connection of Brake Resistor
	

WWW.BSNEW.IR



●FR-A720-00240, 00330, FR-A740-00120, 00170

1) Remove the screws in terminals PR and PX and remove the jumper.
2) Connect the brake resistor across terminals P/+ and PR. (The jumper should remain disconnected.)

1) Removal of Jumper	2) Connection of Brake Resistor
	

●FR-A720-00460 to 00900, FR-A740-00230 to 00440


Connect the brake resistor across terminals P/+ and PR.

FR-A720-00460 **FR-A740-00230, 00310**	**FR-A720-00610 to 00900** **FR-A740-00380, 00440**
	

· Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

WWW.BSNEW.IR


● When the regenerative brake transistor is damaged, the following sequence is recommended to prevent overheat and burnout of the brake resistor.



*1 Since the FR-A720-00460 (FR-A740-00230) or more inverter is not provided with the PX terminal, a jumper is not need to be removed.

*2 Refer to the table below for the type number of each capacity of thermal relay and the diagram below for the connection. (Always install a thermal relay when using the FR-A720-00460 (FR-A740-00230) or more)

Power Supply Voltage	High-Duty Brake Resistor	Thermal Relay Type (Mitsubishi product)	Contact Rating
200V	FR-ABR-0.4K	TH-N20CXHZ-0.7A	110V 5AAC, 220V 2AAC(AC-11 class) 110V 0.5ADC, 220V 0.25ADC(DC-11 class)
	FR-ABR-0.75K	TH-N20CXHZ-1.3A	
	FR-ABR-2.2K	TH-N20CXHZ-2.1A	
	FR-ABR-3.7K	TH-N20CXHZ-3.6A	
	FR-ABR-5.5K	TH-N20CXHZ-5A	
	FR-ABR-7.5K	TH-N20CXHZ-6.6A	
	FR-ABR-11K	TH-N20CXHZ-11A	
	FR-ABR-15K	TH-N20CXHZ-11A	
	FR-ABR-22K	TH-N60-22A	
400V	FR-ABR-H0.4K	TH-N20CXHZ-0.24A	
	FR-ABR-H0.75K	TH-N20CXHZ-0.35A	
	FR-ABR-H1.5K	TH-N20CXHZ-0.9A	
	FR-ABR-H2.2K	TH-N20CXHZ-1.3A	
	FR-ABR-H3.7K	TH-N20CXHZ-2.1A	
	FR-ABR-H5.5K	TH-N20CXHZ-2.5A	
	FR-ABR-H7.5K	TH-N20CXHZ-3.6A	
	FR-ABR-H11K	TH-N20CXHZ-6.6A	
	FR-ABR-H15K	TH-N20CXHZ-6.6A	
	FR-ABR-H22K	TH-N20-9A	




WWW.BSNEW.IR

2.5.2 Connection of the brake unit (FR-BU2)

Connect the brake unit (FR-BU2) as shown below to improve the braking capability at deceleration.

(1) Connection example with the GRZG type brake resitor



*1 Connect the inverter terminals (P/+, N/-) and brake unit (FR-BU2) terminals so that their terminal names match with each other. (Incorrect connection will damage the inverter and brake unit.)

*2 When the power supply is 400V class, install a step-down transformer.

*3 Be sure to remove a jumper across terminal PR-PX when using the FR-BU2 with the inverter of FR-A720-00330 (FR-A740-00170) or less.

*4 Keep a wiring distance of within 5m between the inverter, brake unit (FR-BU2) and brake resistor. Even when the wiring is twisted, the cable length must not exceed 10m (32.8feet).

*5 It is recommended to install an external thermal relay to prevent overheat of brake resistors.

<Recommended external thermal relay>


Brake Unit	Brake Resistor	Recommended External Thermal Relay
FR-BU2-1.5K	GZG 300W-50Ω	TH-N20CXHZ 1.3A
FR-BU2-3.7K	GRZG 200-10Ω	TH-N20CXHZ 3.6A
FR-BU2-7.5K	GRZG 300-5Ω	TH-N20CXHZ 6.6A
FR-BU2-15K	GRZG 400-2Ω	TH-N20CXHZ 11A
FR-BU2-H7.5K	GRZG 200-10Ω	TH-N20CXHZ 3.6A
FR-BU2-H15K	GRZG 300-5Ω	TH-N20CXHZ 6.6A
FR-BU2-H30K	GRZG 400-2Ω	TH-N20CXHZ 11A

CAUTION

- To replace the existing BU type brake unit, set "1" in *Pr. 0 Brake mode selection* of the FR-BU2.
- Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

WWW.BSNEW.IR

(2) FR-BR-(H) connection example with resistor unit




*1 Connect the inverter terminals (P/+, N/-) and brake unit (FR-BU2) terminals so that their terminal names match with each other. (Incorrect connection will damage the inverter and brake unit.)
*2 When the power supply is 400V class, install a step-down transformer.
*3 Be sure to remove a jumper across terminal PR-PX when using the FR-BU with the inverter of FR-A720-00330 (FR-A740-00170) or less.
*4 The wiring distance between the inverter, brake unit (FR-BU) and resistor unit (FR-BR) should be within 5m (16.4feet). Even when the wiring is twisted, the cable length must not exceed 10m (32.8feet).
*5 Normal: across TH1-TH2...close, Alarm: across TH1-TH2...open

CAUTION

· Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

(3) Connection example with MT-BR5 type resistor unit



*1 Connect the inverter terminals (P/+, N/-) and brake unit (FR-BU2) terminals so that their terminal names match with each other. (Incorrect connection will damage the inverter and brake unit.)
*2 When the power supply is 400V class, install a step-down transformer.
*3 The wiring distance between the inverter, brake unit (FR-BU2) and resistor unit (MT-BR5) should be within 5m (16.4feet). If twisted wires are used, the distance should be within 10m (32.8feet).
*4 Normal: across TH1-TH2...open, Alarm: across TH1-TH2...close
*5 CN8 connector used with the MT-BU5 type brake unit is not used.

CAUTION


· When replacing the existing MT-BU5 type brake unit, set "2" in *Pr. 0 Brake mode selection* of the FR-BU2, "1" in *Pr. 30 Regenerative function selection* and "10%" in *Pr. 70 Special regenerative brake duty* (refer to *page 204*) of the inverter.

WWW.BSNEW.IR

2.5.3 Connection of the brake unit (FR-BU/MT-BU5)

When connecting the brake unit (FR-BU(H)/MT-BU5) to improve the brake capability at deceleration, make connection as shown below.

(1) Connection with the FR-BU (FR-A720-02150 (FR-A740-01100) or less)



*1 Connect the inverter terminals (P/+, N/-) and brake unit (FR-BU (H)) terminals so that their terminal signals match with each other. (Incorrect connection will damage the inverter.)

*2 When the power supply is 400V class, install a step-down transformer.

*3 Be sure to remove a jumper across terminal PR-PX when using the FR-BU with the inverter of FR-A720-00330 (FR-A740-00170) or less.


*4 The wiring distance between the inverter, brake unit (FR-BU) and resistor unit (FR-BR) should be within 5m(16.4 feet). If twisted wires are used, the distance should be within 10m(32.8feet).

CAUTION

- If the transistors in the brake unit should become faulty, the resistor can be unusually hot, causing a fire. Therefore, install a magnetic contactor on the inverter's input side to configure a circuit so that a current is shut off in case of fault.
- Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

WWW.BSNEW.IR

(2) Connection with the MT-BU5 (FR-A720-02800 (FR-A740-01440) or more)
After making sure that the MT-BU5 is properly connected, set the following parameters.
Pr. 30 Regenerative function selection = "1"
Pr. 70 Special regenerative brake duty = "10%" (*Refer to page 204*)



*1 When the power supply is 400V class, install a step-down transformer.
*2 The wiring length between the resistor unit and brake resistor should be 10m(32.8feet) maximum when wires are twisted and 5m(16.4feet) maximum when wires are not twisted.


CAUTION

- Install the brake unit in a place where a cooling air reaches the brake unit heatsink and within a distance of the cable supplied with the brake unit reaches the inverter.
- For wiring of the brake unit and inverter, use an accessory cable supplied with the brake unit. Connect the main circuit cable to the inverter terminals P/+ and N/- and connect the control circuit cable to the CN8 connector inside by making cuts in the rubber bush at the top of the inverter for leading the cable.
- The brake unit which uses multiple resistor units has terminals equal to the number of resistor units. Connect one resistor unit to one pair of terminal (P, PR).


<Inserting the CN8 connector>

Make cuts in rubber bush of the upper portion of the inverter and lead a cable.

1) Make cuts in the rubber bush for leading the CN8 connector cable with a nipper or cutter knife.



2) Insert a connector on the MT-BU5 side through a rubber bush to connect to a connector on the inverter side.




CAUTION

Clamp the CN8 connector cable on the inverter side with a wire clamp securely.
Do not connect the MT-BU5 to a CN8 connector of the FR-A740-01100.

WWW.BSNEW.IR

2.5.4 Connection of the brake unit (BU type)

Connect the brake unit (BU type) correctly as shown below. Incorrect connection will damage the inverter. Remove the jumper across terminals HB-PC and terminals TB-HC of the brake unit and fit it to across terminals PC-TB.




*1 When the power supply is 400V class, install a step-down transformer.
*2 For capacity FR-A720-00330 (FR-A740-00170) or less, remove the jumper across terminals PR-PX.

CAUTION

- The wiring distance between the inverter, brake unit and resistor unit should be within 2m(6.56feet). If twisted wires are used, the distance should be within 5m(16.4feet).
- If the transistors in the brake unit should become faulty, the resistor can be unusually hot, causing a fire. Therefore, install a magnetic contactor on the inverter's power supply side to configure a circuit so that a current is shut off in case of fault.
- Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

2.5.5 Connection of the high power factor converter (FR-HC/MT-HC)

When connecting the high power factor converter (FR-HC/MT-HC) to suppress power harmonics, perform wiring securely as shown below.
Incorrect connection will damage the high power factor converter and inverter.
After making sure that the wiring is correct, set "2" in *Pr. 30 Regenerative function selection*. (*Refer to page 204.*)
(1) Connection with the FR-HC (FR-A720-02150 (FR-A740-01100) or less)




*1 Remove the jumpers across the inverter terminals R/L1-R1/L11, S/L2-S1/L21, and connect the control circuit power supply to the R1/L11 and S1/L21 terminals. Always keep the power input terminals R/L1, S/L2, T/L3 open. Incorrect connection will damage the inverter. (E.OPT (option alarm) will occur. (*Refer to page 408.*))
*2 Do not insert the MCCB between terminals P/+ – N/- (P/+ – P/+, N/- – N/-). Opposite polarity of terminals N/-, P/+ will damage the inverter.
*3 Use *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the terminals used for the X10 (X11) signal. (*Refer to page 228.)*
For communication where the start command is sent only once, e.g. RS-485 communication operation, use the X11 signal when making setting to hold the mode at occurrence of an instantaneous power failure. (*Refer to page 205.)*

CAUTION

- The voltage phases of terminals R/L1, S/L2, T/L3 and terminals R4, S4, T4 must be matched.
- Use sink logic (factory setting) when the FR-HC is connected. The FR-HC cannot be connected when source logic is selected.
- Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

WWW.BSNEW.IR

(2) Connection with the MT-HC (FR-A720-02880 (FR-A740-01440) or more)



*1 Remove the jumper across terminals R/L1 - R1/L11, S/L2 - S1/L21 of the inverter, and connect the control circuit power supply to the R1/L11 and S1/L21 terminals. The power input terminals R/L1, S/L2, T/L3 must be open. Incorrect connection will damage the inverter. (E.OPT (option alarm) will occur. (*Refer to page 408.*)

*2 Do not insert the MCCB between terminals P/+ – N/- (P – P/+, N – N/-). Opposite polarity of terminals N, P will damage the inverter.

*3 Use *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the terminals used for the X10 (X11) signal. (*Refer to page 228.)* For communication where the start command is sent only once, e.g. RS-485 communication operation, use the X11 signal when making setting to hold the mode at occurrence of an instantaneous power failure. *(Refer to page 205.)*

*4 Connect the power supply to terminals R1 and S1 of the MT-HC via an insulated transformer.


CAUTION

- The voltage phases of terminals R/L1, S/L2, T/L3 and terminals R4, S4, T4 must be matched.
- Use sink logic (factory setting) when the MT-HC is connected. The MT-HC cannot be connected when source logic is selected.
- When connecting the inverter to the MT-HC, do not connect the DC reactor provided to the inverter.

WWW.BSNEW.IR

2.5.6 Connection of the power regeneration common converter (FR-CV) (FR-A720-02150 (FR-A740-01100) or less)

When connecting the power regeneration common converter (FR-CV), make connection so that the inverter terminals (P/+, N/-) and the terminal symbols of the power regeneration common converter (FR-CV) are the same.
After making sure that the wiring is correct, set "2" in *Pr. 30 Regenerative function selection*. (*Refer to page 204.)*



*1 Remove the jumpers across terminals R/L1-R1/L11 and S/L2-S1/L21 of the inverter, and connect the control circuit power supply across terminals R1/L11-S1/L21. Always keep the power input terminals R/L1, S/L2, T/L3 open. Incorrect connection will damage the inverter. (E.OPT (option alarm) will occur. *(Refer to page 408)*)

*2 Do not insert an MCCB between the terminals P/+ – N/- (between P/L+ – P/+, between N/L- – N/-). Opposite polarity of terminals N/-, P/+ will damage the inverter.

*3 Assign the terminal for X10 signal using any of *Pr. 178 to Pr. 189 (input terminal function selection)*. *(Refer to page 228)*

*4 Be sure to connect the power supply and terminals R/L11, S/L21, T/MC1.
Operating the inverter without connecting them will damage the power regeneration common converter.


CAUTION

- The voltage phases of terminals R/L11, S/L21, T/MC1 and terminals R2/L1, S2/L2, T2/L3 must be matched.
- Use sink logic (factory setting) when the FR-CV is connected. The FR-CV cannot be connected when source logic is selected.
- Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

WWW.BSNEW.IR

2.5.7 Connection of power regeneration converter (MT-RC) (FR-A720-02880 (FR-A740-01440) or more)

When connecting a power regeneration converter (MT-RC), perform wiring securely as shown below. Incorrect connection will damage the regeneration converter and inverter. After connecting securely, set "1" in *Pr. 30 Regenerative function selection* and "0" in *Pr. 70 Special regenerative brake duty*.




CAUTION

- Refer to the MT-RC manual for precautions for connecting the power coordination reactor and others.

2.5.8 Connection of the power factor improving DC reactor (FR-HEL)

When using the DC reactor (FR-HEL), connect it between terminals P1-P/+.
For the FR-A720-02150 (FR-A740-01100) or less, the jumper connected across terminals P1-P/+ must be removed. Otherwise, the reactor will not exhibit its performance.
For the FR-A720-02880 (FR-A740-01440) or more, a DC reactor is supplied. Always install the reactor.
When using the FR-A720-02150 with LD or SLD set, always use a DC reactor (option FR-HEL-75K).
When using the FR-A740-01100 with LD or SLD set, always use a DC reactor (option FR-HEL-H90K).



CAUTION

- The wiring distance should be within 5m (16.4feet).
- The size of the cables used should be equal to or larger than that of the power supply cables (R/L1, S/L2, T/L3). *(Refer to page 22)*

WWW.BSNEW.IR

MEMO

WWW.BSNEW.IR

3 PRECAUTIONS FOR USE OF THE INVERTER

This chapter explains the "PRECAUTIONS FOR USE OF THE INVERTER" for use of this product.
Always read the instructions before using the equipment

3.1 Noise and leakage currents 56
3.2 Installation of a reactor 61
3.3 Power-off and magnetic contactor (MC) 62
3.4 Inverter-driven 400V class motor 63
3.5 Precautions for use of the inverter 64

WWW.BSNEW.IR

3.1 Noise and leakage currents

3.1.1 Leakage currents and countermeasures

Capacitances exist between the inverter I/O cables, other cables and earth and in the motor, through which a leakage current flows. Since its value depends on the capacitances, carrier frequency, etc., low acoustic noise operation at the increased carrier frequency of the inverter will increase the leakage current. Therefore, take the following measures. Select the earth leakage breaker according to its rated sensitivity current, independently of the carrier frequency setting.

(1) To-earth (ground) leakage currents

Leakage currents may flow not only into the inverter's own line but also into the other lines through the earth (ground) cable, etc. These leakage currents may operate earth (ground) leakage circuit breakers and earth leakage relays unnecessarily.

- Countermeasures
  - If the carrier frequency setting is high, decrease the *Pr. 72 PWM frequency selection* setting. Note that motor noise increases.Selecting *Pr. 240 Soft-PWM operation selection* makes the sound inoffensive.
  - By using earth leakage circuit breakers designed for harmonic and surge suppression in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).
- To-earth (ground) leakage currents
  - Take caution as long wiring will increase the leakage current. Decreasing the carrier frequency of the inverter reduces the leakage current.
  - Increasing the motor capacity increases the leakage current. The leakage current of the 400V class is larger than that of the 200V class.

(2) Line-to-line leakage currents


Harmonics of leakage currents flowing in static capacities between the inverter output cables may operate the external thermal relay unnecessarily. When the wiring length is long (50m (164.04feet) or more) for the 400V class small-capacity model (FR-A740-00170 or less), the external thermal relay is likely to operate unnecessarily because the ratio of the leakage current to the rated motor current increases.

- Line-to-line leakage current data example (200V class)

Motor Capacity (kW(HP))	Rated Motor Current(A)	Leakage Currents(mA)	
		Wiring length 50m(164.04feet)	Wiring length 100m(328.08feet)
0.4(1/2)	1.8	310	500
0.75(1)	3.2	340	530
1.5(2)	5.8	370	560
2.2(3)	8.1	400	590
3.7(5)	12.8	440	630
5.5(7.5)	19.4	490	680
7.5(10)	25.6	535	725

·Dedicated motor SF-JR 4P
·Carrier frequency: 14.5kHz
·Used wire: 2mm^2, 4cores Cabtyre cable

*The leakage currents of the 400V class are about twice as large.



Line-to-line leakage currents path

- Countermeasures
  - Use *Pr. 9 Electronic thermal O/L relay*.
  - If the carrier frequency setting is high, decrease the *Pr. 72 PWM frequency selection* setting. Note that motor noise increases. Selecting *Pr. 240 Soft-PWM operation selection* makes the sound inoffensive. To ensure that the motor is protected against line-to-line leakage currents, it is recommended to use a temperature sensor to directly detect motor temperature.
- Installation and selection of moulded case circuit breaker

  Install a moulded case circuit breaker (MCCB) on the power receiving side to protect the wiring of the inverter input side. Select the MCCB according to the inverter input side power factor (which depends on the power supply voltage, output frequency and load). Especially for a completely electromagnetic MCCB, one of a slightly large capacity must be selected since its operation characteristic varies with harmonic currents. (Check it in the data of the corresponding breaker.) As an earth (ground) leakage breaker, use the Mitsubishi earth (ground) leakage breaker designed for harmonics and surge suppression.

WWW.BSNEW.IR


(3) Selection of rated sensitivity current of earth (ground) leakage breaker

When using the earth (ground) leakage circuit breaker with the inverter circuit, select its rated sensitivity current as follows, independently of the PWM carrier frequency:


- Breaker designed for harmonic and surge suppression
  Rated sensitivity current:
  $I\Delta n \geq 10 \times (Ig1 + Ign + Igi + Ig2 + Igm)$
- Standard breaker
  Rated sensitivity current:
  $I\Delta n \geq 10 \times \{Ig1 + Ign + Igi + 3 \times (Ig2 + Igm)\}$

Ig1, Ig2: Leakage currents in wire path during commercial power supply operation
Ign: Leakage current of inverter input side noise filter
Igm: Leakage current of motor during commercial power supply operation
Igi: Leakage current of inverter unit


Example of leakage current of cable path per 1km during the commercial power supply operation when the CV cable is routed in metal conduit (200V 60Hz)




Leakage current example of three-phase induction motor during the commercial power supply operation (200V 60Hz)



Example of leakage current per 1km during the commercial power supply operation when the CV cable is routed in metal conduit (Three-phase three-wire delta connection 400V60Hz)




Leakage current example of three-phase induction motorduring the commercial power supply operation (Totally-enclosed fan-cooled type motor 400V60Hz)



For "人" connection, the amount of leakage current is appox.1/3 of the above value.

<Example>




	Breaker Designed for Harmonic and Surge Suppression	Standard Breaker
Leakage current Ig1 (mA)	$\frac{1}{3} \times 66 \times \frac{5m(16.40feet)}{1000m(3280.80feet)} = 0.11$	
Leakage current Ign (mA)	0 (without noise filter)	
Leakage current Igi (mA)	1 (without EMC filter) Refer to the following table for the leakage current of the inverter*	
Leakage current Ig2 (mA)	$\frac{1}{3} \times 66 \times \frac{60m(196.86feet)}{1000m(3280.80feet)} = 1.32$	
Motor leakage current Igm (mA)	0.36	
Total leakage current (mA)	2.79	6.66
Rated sensitivity current (mA) (≥ Ig × 10)	30	100

* *Refer to page 15* for the EMC filter.

●Inverter leakage current (with and without EMC filter)

Input power conditions
(200V class: 220V/60Hz, 400V class: 440V/60Hz, power supply unbalance within 3%)

	Voltage (V)	EMC Filter	
		ON (mA)	OFF (mA)
Phase grounding 	**200**	22(1)*	1
	400	30	1
Earthed-neutral system 	**400**	1	1

*For the FR-A720-00030 and 00050, the EMC filter is always valid. The leakage current is 1mA.

CAUTION

- Install the earth leakage breaker (ELB) on the input side of the inverter.
- In the 人 connection earthed-neutral system, the sensitivity current is blunt against an earth (ground) fault in the inverter output side. Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)
- When the breaker is installed on the output side of the inverter, it may be unnecessarily operated by harmonics even if the effective value is less than the rating. In this case, do not install the breaker since the eddy current and hysteresis loss will increase, leading to temperature rise.
- The following models are standard breakers
  BV-C1, BC-V, NVB, NV-L, NV-G2N, NV-G3NA and NV-2F earth leakage relay (except NV-ZHA), NV with AA neutral wire open-phase protection
  The other models are designed for harmonic and surge suppression

WWW.BSNEW.IR


3.1.2 Inverter-generated noises and their reduction techniques


Some noises enter the inverter to malfunction it and others are radiated by the inverter to malfunction peripheral devices. Though the inverter is designed to be insusceptible to noises, it handles low-level signals, so it requires the following basic techniques. Also, since the inverter chops outputs at high carrier frequency, that could generate noises. If these noises cause peripheral devices to malfunction, measures should be taken to suppress noises. These techniques differ slightly depending on noise propagation paths.

1) Basic techniques
- Do not run the power cables (I/O cables) and signal cables of the inverter in parallel with each other and do not bundle them.
- Use twisted pair shielded cables for the detector connection and control signal cables, and connect the sheathes of the shield cables to terminal SD.
- Earth (Ground) the inverter, motor, etc. at one point.

2) Techniques to reduce noises that enter and malfunction the inverter
When devices that generate many noises (which use magnetic contactors, magnetic brakes, many relays, for example) are installed near the inverter and the inverter may be malfunctioned by noises, the following measures must be taken:
- Provide surge suppressors for devices that generate many noises to suppress noises.
- Fit data line filters (*page 59*) to signal cables.
- Earth (Ground) the shields of the detector connection and control signal cables with cable clamp metal.

3) Techniques to reduce noises that are radiated by the inverter to malfunction peripheral devices
Inverter-generated noises are largely classified into those radiated by the cables connected to the inverter and inverter main circuits (I/O), those electromagnetically and electrostatically induced to the signal cables of the peripheral devices close to the main circuit power supply, and those transmitted through the power supply cables.






WWW.BSNEW.IR

Noise Propagation Path	Measures
1) 2) 3)	When devices that handle low-level signals and are liable to malfunction due to noises, e.g. instruments, receivers and sensors, are contained in the enclosure that contains the inverter or when their signal cables are run near the inverter, the devices may be malfunctioned by air-propagated noises. The following measures must be taken: (1) Install easily affected devices as far away as possible from the inverter. (2) Run easily affected signal cables as far away as possible from the inverter and its I/O cables. (3) Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them. (4) Set the EMC filter ON/OFF connector of the inverter to the ON position. *(Refer to page 15)* (5) Inserting a line noise filter into the output suppresses the radiation noise from the cables. (6) Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
4) 5) 6)	When the signal cables are run in parallel with or bundled with the power cables, magnetic and static induction noises may be propagated to the signal cables to malfunction the devices and the following measures must be taken: (1) Install easily affected devices as far away as possible from the inverter. (2) Run easily affected signal cables as far away as possible from the I/O cables of the inverter. (3) Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them. (4) Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
7)	When the power supplies of the peripheral devices are connected to the power supply of the inverter in the same line, inverter-generated noises may flow back through the power supply cables to malfunction the devices and the following measures must be taken: (1) Set the EMC filter ON/OFF connector of the inverter to the ON position. *(Refer to page 15)* (2) Install the line noise filter (FR-BLF, FR-BSF01) to the power cables (I/O cables) of the inverter.
8)	When a closed loop circuit is formed by connecting the peripheral device wiring to the inverter, leakage currents may flow through the earth (ground) cable of the inverter to malfunction the device. In such a case, disconnection of the earth (ground) cable of the device may cause the device to operate properly.

● Data line filter

Noise entry can be prevented by providing a data line filter for the detector cable etc.

●Noise reduction examples



WWW.BSNEW.IR

3.1.3 Power supply harmonics

The inverter may generate power supply harmonics from its converter circuit to affect the power generator, power capacitor etc. Power supply harmonics are different from noise and leakage currents in source, frequency band and transmission path. Take the following countermeasure suppression techniques.


●The differences between harmonics and noises are indicated below:

Item	Harmonics	Noise
Frequency	Normally number 40 to 50 max. (3kHz or less)	High frequency (several 10kHz to 1GHz order)
Environment	To-electric channel, power impedance	To-space, distance, wiring path
Quantitative understanding	Theoretical calculation possible	Random occurrence, quantitative grasping difficult
Generated amount	Nearly proportional to load capacity	Depending on the current fluctuation ratio (larger as switching is faster)
Affected equipment immunity	Specified in standard per equipment	Different depending on maker's equipment specifications
Suppression example	Provide reactor.	Increase distance.

●Measures

The harmonic current generated from the inverter to the input side differs according to various conditions such as the wiring impedance, whether a reactor is used or not, and output frequency and output current on the load side.

For the output frequency and output current, we understand that they should be calculated in the conditions under the rated load at the maximum operating frequency.




CAUTION


The power factor improving capacitor and surge suppressor on the inverter output side may be overheated or damaged by the high frequency components of the inverter output. Also, since an excessive current flows in the inverter to activate overcurrent protection, do not provide a capacitor and surge suppressor on the inverter output side when the motor is driven by the inverter. For power factor improvement, install a reactor on the inverter input side or in the DC circuit.

WWW.BSNEW.IR

3.2 Installation of a reactor

When the inverter is connected near a large-capacity power transformer (1000kVA or more) or when a power capacitor is to be switched over, an excessive peak current may flow in the power input circuit, damaging the converter circuit. To prevent this, always install the optional AC reactor (FR-HAL)





* When connecting the FR-HEL to the FR-A720-02150 (FR-A740-01100) or less, remove the jumper across terminals P/+ - P1. For the FR-A720-02880 (FR-A740-01440) or more, a DC reactor is supplied. Always install the reactor.
When using the FR-A720-02150 with LD or SLD set, always use a DC reactor (option FR-HEL-75K).
When using the FR-A740-01100 with LD or SLD set, always use a DC reactor (option FR-HEL-H90K)

REMARKS

The wiring length between the FR-HEL and inverter should be 5m (16.4feet) maximum and minimized. Use the same wire size as that of the power supply wire (R/L1, S/L2, T/L3). *(Refer to page 22)*

WWW.BSNEW.IR

3.3 Power-off and magnetic contactor (MC)

(1) Inverter input side magnetic contactor (MC)


On the inverter input side, it is recommended to provide an MC for the following purposes.

(Refer to *page 4* for selection.)

1) To release the inverter from the power supply when the inverter's protective function is activated or when the drive is not functioning (e.g. emergency stop operation). When cycle operation or heavy-duty operation is performed with an optional brake resistor connected, overheat and burnout of the electrical-discharge resistor can be prevented if a regenerative brake transistor is damaged due to insufficient heat capacity of the electrical-discharge resistor and excess regenerative brake duty.
2) To prevent any accident due to an automatic restart at restoration of power after an inverter stop made by a power failure
3) To reset the inverter for an extended period of time
   The control power supply for inverter is always running and consumes a little power. When stopping the inverter for an extended period of time, powering off the inverter will save power slightly.
4) To separate the inverter from the power supply to ensure safe maintenance and inspection work
   The inverter's input side MC is used for the above purpose, select class JEM1038-AC3MC for the inverter input side current when making an emergency stop during normal operation.

REMARKS

Since repeated inrush currents at power on will shorten the life of the converter circuit (switching life is about 1,000,000 times. (For the 200V class FR-A720-01450 or more, switching life is about 500,000)), frequent starts and stops of the MC must be avoided. Turn on/off the inverter start controlling terminals (STF, STR) to run/stop the inverter.



• Inverter start/stop circuit example

As shown on the left, always use the start signal (ON or OFF across terminals STF or STR-SD) to make a start or stop. *(Refer to page 233)*

*1 When the power supply is 400V class, install a step-down transformer.

*2 Connect the power supply terminals R1/L11, S1/L21 of the control circuit to the primary side of the MC to hold an alarm signal when the inverter's protective circuit is activated. At this time, remove jumpers across terminals R/L1-R1/L11 and S/L2-S1/L21. (Refer to *page 26* for removal of the jumper.)

(2) Handling of the inverter output side magnetic contactor

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned on while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided to switch to a commercial power supply, for example, it is recommended to use bypass-inverter switchover operation *Pr. 135 to Pr. 139 (Refer to page363)*.

WWW.BSNEW.IR

3.4 Inverter-driven 400V class motor

In the PWM type inverter, a surge voltage attributable to wiring constants is generated at the motor terminals. Especially for a 400V class motor, the surge voltage may deteriorate the insulation. When the 400V class motor is driven by the inverter, consider the following measures:

●Measures

It is recommended to take either of the following measures:

(1) Rectifying the motor insulation and limiting the PWM carrier frequency according to the wiring length
For the 400V class motor, use an insulation-enhanced motor.
Specifically,
1)Specify the "400V class inverter-driven insulation-enhanced motor".
2)For the dedicated motor such as the constant-torque motor and low-vibration motor, use the "inverter-driven, dedicated motor".
3)Set *Pr. 72 PWM frequency selection* as indicated below according to the wiring length

	Wiring Length		
	50m (164.04feet) or less	**50m to 100m (164.04feet to 328.09feet)**	**exceeding 100m (328.09feet)**
Pr. 72 PWM frequency selection	15 (14.5kHz) or less	9 (9kHz) or less	4 (4kHz) or less

(2) Suppressing the surge voltage on the inverter side
Connect the surge voltage suppression filter (FR-ASF-H) to the FR-A720-02150 (FR-A740-01100) or less and the sine wave filter (MT-BSL/BSC) to the FR-A720-02880 (FR-A740-01440) or more on the inverter output side.

CAUTION

- For details of *Pr. 72 PWM frequency selection* , *refer to page279*. (When using an option sine wave filter (MT-BSL/BSC) for the FR-A720-02150 (FR-A740-01100) or more, set "25" (2.5kHz) in *Pr. 72*.)
- For explanation of surge voltage suppression filter (FR-ASF-H) and sine wave filter (MT-BSL/BSC), refer to the manual of each option.
- Do not perform vector control with a surge voltage suppression filter (FR-ASF-H) or sine wave filer (MT-BSL/BSC) connected.

WWW.BSNEW.IR

3.5 Precautions for use of the inverter

The FR-A700 series is a highly reliable product, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the product.
Before starting operation, always recheck the following items.

(1) Use crimping terminals with insulation sleeve to wire the power supply and motor.

(2) Application of power to the output terminals (U, V, W) of the inverter will damage the inverter. Never perform such wiring.

(3) After wiring, wire offcuts must not be left in the inverter.
Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean. When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.

(4) Use cables of the size to make a voltage drop 2% maximum.
If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.
Refer to *page 22* for the recommended cable sizes.

(5) The overall wiring length should be 500m (1640.4 feet) maximum.
(The wiring length should be 100m (328.09 feet) maximum for vector control.)
Especially for long distance wiring, the fast response current limit function may be reduced or the equipment connected to the inverter output side may malfunction or become faulty under the influence of a charging current due to the stray capacity of the wiring. Therefore, note the overall wiring length. *(Refer to page 25.)*

(6) Electromagnetic wave interference
The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, set the EMC filter valid to minimize interference. *(Refer to page 15)*

(7) Do not install a power factor correction capacitor, surge suppressor or radio noise filter on the inverter output side.
This will cause the inverter to trip or the capacitor, and surge suppressor to be damaged. If any of the above devices is installed, immediately remove it.

(8) Before starting wiring or other work after the inverter is operated, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.


(9) A short circuit or earth (ground) fault on the inverter output side may damage the inverter modules.
- Fully check the insulation resistance of the circuit prior to inverter operation since repeated short circuits caused by peripheral circuit inadequacy or an earth (ground) fault caused by wiring inadequacy or reduced motor insulation resistance may damage the inverter modules.
- Fully check the to-earth (ground) insulation and inter-phase insulation of the inverter output side before power-on. Especially for an old motor or use in hostile atmosphere, securely check the motor insulation resistance etc.

(10) Do not use the inverter input side magnetic contactor to start/stop the inverter.
Always use the start signal (ON/OFF of STF and STR signals) to start/stop the inverter. *(Refer to page 62)*

(11) Across P/+ and PR terminals, connect only an external regenerative brake discharge resistor.
Do not connect a mechanical brake.

(12) Do not apply a voltage higher than the permissible voltage to the inverter I/O signal circuits.
Application of permissible voltage to the inverter I/O signal circuit and incorrect polarity may damage the I/O terminal. Especially check the wiring to prevent the speed setting potentiometer from being connected incorrectly to short terminals 10E-5.

(13) Provide electrical and mechanical interlocks for MC1 and MC2 which are used for electronic bypass.
When the wiring is incorrect or if there is an electronic bypass circuit as shown on the right, the inverter will be damaged by leakage current from the power supply due to arcs generated at the time of switch-over or chattering caused by a sequence error.
(Commercial operation can not be performed with the vector dedicated motor (SF-V5RU, SF-THY).)



WWW.BSNEW.IR

(14) If the machine must not be restarted when power is restored after a power failure, provide a magnetic contactor in the inverter's input side and also make up a sequence which will not switch on the start signal.
If the start signal (start switch) remains on after a power failure, the inverter will automatically restart as soon as the power is restored.

(15) Instructions for overload operation
When performing an operation of frequent start/stop with the inverter, rise/fall in the temperature of the transistor element of the inverter will repeat due to a continuous flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing current at locked condition, starting current, etc. Decreasing current may increase the life. However, decreasing current will result in insufficient torque and the inverter may not start. Therefore, choose the inverter which has enough allowance for current (up to 2 rank larger in capacity).

(16) Make sure that the specifications and rating match the system requirements.

(17) A motor with encoder is necessary for vector control. In addition, connect the encoder directly to the backlash-free motor shaft. (An encoder is not necessary for real sensorless vector control.)

WWW.BSNEW.IR

MEMO

WWW.BSNEW.IR

4 PARAMETERS

This chapter explains the "PARAMETERS" for use of this product.
Always read this instructions before use.

The abbreviations in the explanations below are as follows:

V/f ...V/F control,

...Advanced magnetic flux vector control,


...Real sensorless vector control

Vector ...Vector control

WWW.BSNEW.IR


4.1 Operation panel (FR-DU07)

4.1.1 Parts of the operation panel (FR-DU07)



WWW.BSNEW.IR

4.1.2 Basic operation (factory setting)



WWW.BSNEW.IR

4.1.3 Change the parameter setting value

Changing example | Change the *Pr. 1 Maximum frequency* .

Operation	Display
1. Screen at powering on The monitor display appears.	
2. Press (PU/EXT) to choose the PU operation mode.	(PU/EXT) ⇨  PU indication is lit.
3. Press (MODE) to choose the parameter setting mode.	(MODE) ⇨  The parameter number read previously appears.
4. Turn dial until P. 1 (*Pr. 1*) appears.	⇨ 
5. Press (SET) to read the currently set value. " 120.0"(initial value) appears.	(SET) ⇨ 
6. Turn dial to change it to the set value "60.00".	⇨ 
7. Press (SET) to set.	(SET) ⇨  **Flicker ··· Parameter setting complete!!**

· By turning dial, you can read another parameter.
· Press (SET) to show the setting again.
· Press (SET) twice to show the next parameter.
· Press (MODE) twice to return the monitor to frequency monitor.

? Er 1 to Er 4 are displayed ... Why?

☞ Er 1 appears. ..... Write disable error
Er2 appears. ..... Write error during operation
Er 3 appears. ..... Calibration error
Er 4 appears. ..... Mode designation error

For details refer to *page 400*.

REMARKS

The number of digits displayed on the operation panel (FR-DU07) is four.
If the values to be displayed have five digits or more including decimal places, the fifth or later numerals can not be displayed nor set.
(Example) When *Pr. 1*
When 60Hz is set, 60.00 is displayed.
When 120Hz is set, 120.0 is displayed and second decimal place is not displayed nor set.

4.1.4 Setting dial push

Push the setting dial () to display the set frequency currently set.

WWW.BSNEW.IR

4.2 Parameter List

4.2.1 Parameter list

For simple variable-speed operation of the inverter, the initial setting of the parameters may be used as they are. Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check can be made from the operation panel (FR-DU07).

REMARKS

- ◎ indicates simple mode parameters. (initially set to extended mode)
- The shaded parameters in the table allow its setting to be changed during operation even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.
- Refer to the appendix 4 (*page 454*) for instruction codes for communication and availability of parameter clear, all clear, and parameter copy of each parameter.

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Basic functions	◎ 0	Torque boost	0 to 30%	0.1%	6/4/3/2/1% *1	143	
	◎ 1	Maximum frequency	0 to 120Hz	0.01Hz	120/60Hz *2	157	
	◎ 2	Minimum frequency	0 to 120Hz	0.01Hz	0Hz	157	
	◎ 3	Base frequency	0 to 400Hz	0.01Hz	60Hz	159	
	◎ 4	Multi-speed setting (high speed)	0 to 400Hz	0.01Hz	60Hz	166	
	◎ 5	Multi-speed setting (middle speed)	0 to 400Hz	0.01Hz	30Hz	166	
	◎ 6	Multi-speed setting (low speed)	0 to 400Hz	0.01Hz	10Hz	166	
	◎ 7	Acceleration time	0 to 3600/360s	0.1/0.01s	5/15s *3	173	
	◎ 8	Deceleration time	0 to 3600/360s	0.1/0.01s	5/15s *3	173	
	◎ 9	Electronic thermal O/L relay	0 to 500/0 to 3600A *2	0.01/0.1A *2	Rated inverter current	181	
DC injection brake	10	DC injection brake operation frequency	0 to 120Hz, 9999	0.01Hz	3Hz	200	
	11	DC injection brake operation time	0 to 10s, 8888	0.1s	0.5s	200	
	12	DC injection brake operation voltage	0 to 30%	0.1%	4/2/1%*4	200	
—	13	Starting frequency	0 to 60Hz	0.01Hz	0.5Hz	175	
—	14	Load pattern selection	0 to 5	1	0	161	
Jog operation	15	Jog frequency	0 to 400Hz	0.01Hz	5Hz	168	
	16	Jog acceleration/deceleration time	0 to 3600/360s	0.1/0.01s	0.5s	168	
—	17	MRS input selection	0, 2, 4	1	0	231	
—	18	High speed maximum frequency	120 to 400Hz	0.01Hz	120/60Hz *2	157	
—	19	Base frequency voltage	0 to 1000V, 8888, 9999	0.1V	9999	159	
Acceleration/deceleration times	20	Acceleration/deceleration reference frequency	1 to 400Hz	0.01Hz	60Hz	173	
	21	Acceleration/deceleration time increments	0, 1	1	0	173	
Stall prevention	22	Stall prevention operation level (torque limit level)	0 to 400%	0.1%	150%	150	
	23	Stall prevention operation level compensation factor at double speed	0 to 200%, 9999	0.1%	9999	150	
Multi-speed setting	24 to 27	Multi-speed setting(4 speed to 7 speed)	0 to 400Hz, 9999	0.01Hz	9999	166	
—	28	Multi-speed input compensation selection	0, 1	1	0	170	
—	29	Acceleration/deceleration pattern selection	0 to 5	1	0	176	
—	30	Regenerative function selection	0, 1, 2, 10, 11, 20, 21	1	0	204	
Frequency jump	31	Frequency jump 1A	0 to 400Hz, 9999	0.01Hz	9999	158	
	32	Frequency jump 1B	0 to 400Hz, 9999	0.01Hz	9999	158	
	33	Frequency jump 2A	0 to 400Hz, 9999	0.01Hz	9999	158	
	34	Frequency jump 2B	0 to 400Hz, 9999	0.01Hz	9999	158	
	35	Frequency jump 3A	0 to 400Hz, 9999	0.01Hz	9999	158	
	36	Frequency jump 3B	0 to 400Hz, 9999	0.01Hz	9999	158	
—	37	Speed display	0, 1 to 9998	1	0	248	

WWW.BSNEW.IR

Func-tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Frequency detection	41	Up-to-frequency sensitivity	0 to 100%	0.1%	10%	243	
	42	Output frequency detection	0 to 400Hz	0.01Hz	6Hz	243	
	43	Output frequency detection for reverse rotation	0 to 400Hz, 9999	0.01Hz	9999	243	
Second functions	44	Second acceleration/deceleration time	0 to 3600/360s	0.1/0.01s	5s	173	
	45	Second deceleration time	0 to 3600/360s, 9999	0.1/0.01s	9999	173	
	46	Second torque boost	0 to 30%, 9999	0.1%	9999	143	
	47	Second V/F (base frequency)	0 to 400Hz, 9999	0.01Hz	9999	159	
	48	Second stall prevention operation current	0 to 220%	0.1%	150%	150	
	49	Second stall prevention operation frequency	0 to 400Hz, 9999	0.01Hz	0Hz	150	
	50	Second output frequency detection	0 to 400Hz	0.01Hz	30Hz	243	
	51	Second electronic thermal O/L relay	0 to 500A, 9999/ 0 to 3600A, 9999 *2	0.01/0.1A *2	9999	181	
Monitor functions	52	DU/PU main display data selection	0, 5 to 14, 17 to 20, 22 to 25, 32 to 35, 50 to 57, 100	1	0	250	
	54	FM terminal function selection	1 to 3, 5 to 14, 17, 18, 21, 24, 32 to 34, 50, 52, 53, 70	1	1	250	
	55	Frequency monitoring reference	0 to 400Hz	0.01Hz	60Hz	255	
	56	Current monitoring reference	0 to 500/0 to 3600A *2	0.01/0.1A *2	Rated inverter current	255	
Automatic restart	57	Restart coasting time	0, 0.1 to 5s, 9999/ 0, 0.1 to 30s, 9999 *2	0.1s	9999	261	
	58	Restart cushion time	0 to 60s	0.1s	1s	261	
—	59	Remote function selection	0, 1, 2, 3	1	0	170	
—	60	Energy saving control selection	0, 4	1	0	273	
Automatic acceleration/ deceleration	61	Reference current	0 to 500A, 9999/ 0 to 3600A, 9999 *2	0.01A/0.1A *2	9999	163, 179	
	62	Reference value at acceleration	0 to 220%, 9999	0.1%	9999	179	
	63	Reference value at dcceleration	0 to 220%, 9999	0.1%	9999	179	
	64	Starting frequency for elevator mode	0 to 10Hz, 9999	0.01Hz	9999	163	
—	65	Retry selection	0 to 5	1	0	268	
—	66	Stall prevention operation reduction starting frequency	0 to 400Hz	0.01Hz	60Hz	150	
Retry	67	Number of retries at alarm occurrence	0 to 10, 101 to 110	1	0	268	
	68	Retry waiting time	0 to 10s	0.1s	1s	268	
	69	Retry count display erase	0	1	0	268	
—	70	Special regenerative brake duty	0 to 30%/0 to 10% *2	0.1%	0%	204	
—	71	Applied motor	0 to 8, 13 to 18, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54	1	0	145, 185	
—	72	PWM frequency selection	0 to 15/0 to 6, 25 *2	1	2	279	
—	73	Analog input selection	0 to 7, 10 to 17	1	1	285	
—	74	Input filter time constant	0 to 8	1	1	287	
—	75	Reset selection/disconnected PU detection/PU stop selection	0 to 3, 14 to 17, 100 to 103, 114 to 117	1	14	302	
—	76	Alarm code output selection	0, 1, 2	1	0	270	
—	77	Parameter write selection	0, 1, 2	1	0	305	
—	78	Reverse rotation prevention selection	0, 1, 2	1	0	306	
—	◎ 79	Operation mode selection	0, 1, 2, 3, 4, 6, 7	1	0	308	

WWW.BSNEW.IR

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Motor constants	80	Motor capacity	0.4 to 55kW, 9999/ 0 to 3600kW, 9999 *2	0.01/0.1kW *2	9999	145, 187	
	81	Number of motor poles	2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 9999	1	9999	145, 187	
	82	Motor excitation current	0 to 500A, 9999/ 0 to 3600A, 9999 *2	0.01/0.1A *2	9999	187	
	83	Motor rated voltage	0 to 1000V	0.1V	200/400V *5	187	
	84	Rated motor frequency	10 to 120Hz	0.01Hz	60Hz	187	
	89	Speed control gain (magnetic flux vector)	0 to 200%, 9999	0.1%	9999	145	
	90	Motor constant (R1)	0 to 50Ω, 9999/ 0 to 400mΩ, 9999 *2	0.001Ω/ 0.01mΩ *2	9999	187	
	91	Motor constant (R2)	0 to 50Ω, 9999/ 0 to 400mΩ, 9999 *2	0.001Ω/ 0.01mΩ *2	9999	187	
	92	Motor constant (L1)	0 to 50Ω (0 to 1000mH), 9999/ 0 to 3600mΩ (0 to 400mH), 9999 *2	0.001Ω (0.1mH)/ 0.01mΩ(0.01mH) *2	9999	187	
	93	Motor constant (L2)	0 to 50Ω (0 to 1000mH), 9999/ 0 to 3600mΩ (0 to 400mH), 9999 *2	0.001Ω (0.1mH)/ 0.01mΩ(0.01mH) *2	9999	187	
	94	Motor constant (X)	0 to 500Ω (0 to 100%), 9999/ 0 to 100Ω (0 to 100%), 9999 *2	0.01Ω (0.1%)/ 0.01Ω (0.01%) *2	9999	187	
	95	Online auto tuning selection	0 to 2	1	0	197	
	96	Auto tuning setting/status	0, 1, 101	1	0	187	
Adjustable 5 points V/F	100	V/F1(first frequency)	0 to 400Hz, 9999	0.01Hz	9999	165	
	101	V/F1(first frequency voltage)	0 to 1,000V	0.1V	0V	165	
	102	V/F2(second frequency)	0 to 400Hz, 9999	0.01Hz	9999	165	
	103	V/F2(second frequency voltage)	0 to 1,000V	0.1V	0V	165	
	104	V/F3(third frequency)	0 to 400Hz, 9999	0.01Hz	9999	165	
	105	V/F3(third frequency voltage)	0 to 1,000V	0.1V	0V	165	
	106	V/F4(fourth frequency)	0 to 400Hz, 9999	0.01Hz	9999	165	
	107	V/F4(fourth frequency voltage)	0 to 1,000V	0.1V	0V	165	
	108	V/F5(fifth frequency)	0 to 400Hz, 9999	0.01Hz	9999	165	
	109	V/F5(fifth frequency voltage)	0 to 1,000V	0.1V	0V	165	
Third functions	110	Third acceleration/deceleration time	0 to 3600/360s, 9999	0.1/0.01s	9999	173	
	111	Third deceleration time	0 to 3600/360s, 9999	0.1/0.01s	9999	173	
	112	Third torque boost	0 to 30%, 9999	0.1%	9999	143	
	113	Third V/F (base frequency)	0 to 400Hz, 9999	0.01Hz	9999	159	
	114	Third stall prevention operation current	0 to 220%	0.1%	150%	150	
	115	Thrid stall prevention operation frequency	0 to 400Hz	0.01Hz	0	150	
	116	Third output frequency detection	0 to 400Hz	0.01Hz	60Hz	243	
PU connector communication	117	PU communication station number	0 to 31	1	0	327	
	118	PU communication speed	48, 96, 192, 384	1	192	327	
	119	PU communication stop bit length	0, 1, 10, 11	1	1	327	
	120	PU communication parity check	0, 1, 2	1	2	327	
	121	Number of PU communication retries	0 to10, 9999	1	1	327	
	122	PU communication check time interval	0, 0.1 to 999.8s, 9999	0.1s	9999	327	
	123	PU communication waiting time setting	0 to 150ms, 9999	1	9999	327	
	124	PU communication CR/LF selection	0, 1, 2	1	1	327	
—	◎ 125	Terminal 2 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	289	
—	◎ 126	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	289	

WWW.BSNEW.IR

Func-tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
PID operation	127	PID control automatic switchover frequency	0 to 400Hz, 9999	0.01Hz	9999	355	
	128	PID action selection	10, 11, 20, 21, 50, 51, 60, 61, 70, 71, 80, 81, 90, 91, 100, 101	1	10	355	
	129	PID proportional band	0.1 to 1000%, 9999	0.1%	100%	355	
	130	PID integral time	0.1 to 3600s, 9999	0.1s	1s	355	
	131	PID upper limit	0 to 100%, 9999	0.1%	9999	355	
	132	PID lower limit	0 to 100%, 9999	0.1%	9999	355	
	133	PID action set point	0 to 100%, 9999	0.01%	9999	355	
	134	PID differential time	0.01 to 10.00s, 9999	0.01s	9999	355	
Electronic bypass	135	Electronic bypass sequence selection	0, 1	1	0	363	
	136	MC switchover interlock time	0 to 100s	0.1s	1s	363	
	137	Start waiting time	0 to 100s	0.1s	0.5s	363	
	138	Bypass selection at an alarm	0, 1	1	0	363	
	139	Automatic switchover frequency from inverter to bypass operation	0 to 60Hz, 9999	0.01Hz	9999	363	
Backlash measures	140	Backlash acceleration stopping frequency	0 to 400Hz	0.01Hz	1Hz	176	
	141	Backlash acceleration stopping time	0 to 360s	0.1s	0.5s	176	
	142	Backlash deceleration stopping frequency	0 to 400Hz	0.01Hz	1Hz	176	
	143	Backlash deceleration stopping time	0 to 360s	0.1s	0.5s	176	
—	144	Speed setting switchover	0, 2, 4, 6, 8, 10, 102, 104, 106, 108, 110	1	4	248	
PU	145	PU display language selection	0 to 7	1	1	387	
Current detection	148	Stall prevention level at 0V input	0 to 220%	0.1%	150%	150	
	149	Stall prevention level at 10V input	0 to 220%	0.1%	200%	150	
	150	Output current detection level	0 to 220%	0.1%	150%	245	
	151	Output current detection signal delay time	0 to 10s	0.1s	0s	245	
	152	Zero current detection level	0 to 220%	0.1%	5%	245	
	153	Zero current detection time	0 to 1s	0.01s	0.5s	245	
—	154	Voltage reduction selection during stall prevention operation	0, 1	1	1	150	
—	155	RT signal function validity condition selection	0, 10	1	0	232	
—	156	Stall prevention operation selection	0 to 31, 100, 101	1	0	150	
—	157	OL signal output timer	0 to 25s, 9999	0.1s	0s	150	
—	158	AM terminal function selection	1 to 3, 5 to 14, 17, 18, 21, 24, 32 to 34, 50, 52, 53, 70	1	1	250	
—	159	Automatic switchover frequency range from bypass to inverter operation	0 to 10Hz, 9999	0.01Hz	9999	363	
—	◎ 160	User group read selection	0, 1, 9999	1	0	306	
—	161	Frequency setting/key lock operation selection	0, 1, 10, 11	1	0	387	
Automatic restart functions	162	Automatic restart after instantaneous power failure selection	0, 1, 2, 10, 11, 12	1	0	261	
	163	First cushion time for restart	0 to 20s	0.1s	0s	261	
	164	First cushion voltage for restart	0 to 100%	0.1%	0%	261	
	165	Stall prevention operation level for restart	0 to 220%	0.1%	150%	261	
Current detection	166	Output current detection signal retention time	0 to 10s, 9999	0.1s	0.1s	245	
	167	Output current detection operation selection	0, 1	1	0	245	

WWW.BSNEW.IR

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
—	168	Parameter for manufacturer setting. Do not set.					
—	169						
Cumulative monitor clear	170	Watt-hour meter clear	0, 10, 9999	1	9999	250	
	171	Operation hour meter clear	0, 9999	1	9999	250	
User group	172	User group registered display/batch clear	9999, (0 to 16)	1	0	306	
	173	User group registration	0 to 999, 9999	1	9999	306	
	174	User group clear	0 to 999, 9999	1	9999	306	
input terminal function assignment	178	STF terminal function selection	0 to 20, 22 to 28, 42 to 44, 50, 60, 62, 64 to 71, 74, 9999	1	60	228	
	179	STR terminal function selection	0 to 20, 22 to 28, 42 to 44, 50, 61, 62, 64 to 71, 74, 9999	1	61	228	
	180	RL terminal function selection	0 to 20, 22 to 28, 42 to 44, 50, 62, 64 to 71, 74, 9999	1	0	228	
	181	RM terminal function selection		1	1	228	
	182	RH terminal function selection		1	2	228	
	183	RT terminal function selection		1	3	228	
	184	AU terminal function selection	0 to 20, 22 to 28, 42 to 44, 50, 62 to 71, 74, 9999	1	4	228	
	185	JOG terminal function selection	0 to 20, 22 to 28, 42 to 44, 50, 62, 64 to 71, 74, 9999	1	5	228	
	186	CS terminal function selection		1	6	228	
	187	MRS terminal function selection		1	24	228	
	188	STOP terminal function selection		1	25	228	
	189	RES terminal function selection		1	62	228	
Output terminal function assignment	190	RUN terminal function selection	0 to 8, 10 to 20, 25 to 28, 30 to 36, 39, 41 to 47, 64, 70, 84, 85, 90 to 99, 100 to 108, 110 to 116, 120, 125 to 128, 130 to 136, 139, 141 to 147, 164, 170, 184, 185, 190 to 199, 9999	1	0	236	
	191	SU terminal function selection		1	1	236	
	192	IPF terminal function selection		1	2	236	
	193	OL terminal function selection		1	3	236	
	194	FU terminal function selection		1	4	236	
	195	ABC1 terminal function selection	0 to 8, 10 to 20, 25 to 28, 30 to 36, 39, 41 to 47, 64, 70, 84, 85, 90, 91, 94 to 99, 100 to 108, 110 to 116, 120, 125 to 128, 130 to 136, 139, 141 to 147, 164, 170, 184, 185, 190, 191, 194 to 199, 9999	1	99	236	
	196	ABC2 terminal function selection		1	9999	236	
Multi-speed setting	232 to 239	Multi-speed setting(8 speed to 15 speed)	0 to 400Hz, 9999	0.01Hz	9999	166	
—	240	Soft-PWM operation selection	0, 1	1	1	285	
—	241	Analog input display unit switchover	0, 1	1	0	289	
—	242	Terminal 1 added compensation amount (terminal 2)	0 to 100%	0.1%	100%	285	
—	243	Terminal 1 added compensation amount (terminal 4)	0 to 100%	0.1%	75%	285	
—	244	Cooling fan operation selection	0, 1	1	1	379	

WWW.BSNEW.IR

Func-tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Slip compensation	245	Rated slip	0 to 50%, 9999	0.01%	9999	149	
	246	Slip compensation time constant	0.01 to 10s	0.01s	0.5s	149	
	247	Constant-power range slip compensation selection	0, 9999	1	9999	149	
—	250	Stop selection	0 to 100s,1000 to 1100s 8888, 9999	0.1s	9999	210	
—	251	Output phase failure protection selection	0, 1	1	1	271	
Frequency compensation function	252	Override bias	0 to 200%	0.1%	50%	285	
	253	Override gain	0 to 200%	0.1%	150%	285	
Life check	255	Life alarm status display	(0 to 15)	1	0	380	
	256	Inrush current limit circuit life display	(0 to 100%)	1%	100%	380	
	257	Control circuit capacitor life display	(0 to 100%)	1%	100%	380	
	258	Main circuit capacitor life display	(0 to 100%)	1%	100%	380	
	259	Main circuit capacitor life measuring	0, 1	1	0	380	
—	260	PWM frequency automatic switchover	0, 1	1	1	279	
Power failure stop	261	Power failure stop selection	0, 1, 2, 11, 12	1	0	265	
	262	Subtracted frequency at deceleration start	0 to 20Hz	0.01Hz	3Hz	265	
	263	Subtraction starting frequency	0 to 120Hz, 9999	0.01Hz	60Hz	265	
	264	Power-failure deceleration time 1	0 to 3600/360s	0.1/0.01s	5s	265	
	265	Power-failure deceleration time 2	0 to 3600s/360s, 9999	0.1/0.01s	9999	265	
	266	Power failure deceleration time switchover frequency	0 to 400Hz	0.01Hz	60Hz	265	
—	267	Terminal 4 input selection	0, 1, 2	1	0	282	
—	268	Monitor decimal digits selection	0,1, 9999	1	9999	250	
—	269	Parameter for manufacturer setting. Do not set.					
—	270	Stop-on contact/load torque high-speed frequency control selection	0, 1, 2, 3	1	0	211, 368	
Load torque high speed frequency control	271	High-speed setting maximum current	0 to 220%	0.1%	50%	368	
	272	Middle-speed setting minimum current	0 to 220%	0.1%	100%	368	
	273	Current averaging range	0 to 400Hz, 9999	0.01Hz	9999	368	
	274	Current averaging filter time constant	1 to 4000	1	16	368	
Stop-on contact control	275	Stop-on contact excitation current low-speed multiplying factor	0 to 1000%, 9999	0.1%	9999	211	
	276	PWM carrier frequency at stop-on contact	0 to 9, 9999/ 0 to 4, 9999 *2	1	9999	211	

WWW.BSNEW.IR

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Brake sequence function	278	Brake opening frequency	0 to 30Hz	0.01Hz	3Hz	214	
	279	Brake opening current	0 to 220%	0.1%	130%	214	
	280	Brake opening current detection time	0 to 2s	0.1s	0.3s	214	
	281	Brake operation time at start	0 to 5s	0.1s	0.3s	214	
	282	Brake operation frequency	0 to 30Hz	0.01Hz	6Hz	214	
	283	Brake operation time at stop	0 to 5s	0.1s	0.3s	214	
	284	Deceleration detection function selection	0, 1	1	0	214	
	285	Overspeed detection frequency (Excessive speed deviation detection frequency)	0 to 30Hz, 9999	0.01Hz	9999	116, 214	
Droop control	286	Droop gain	0 to 100%	0.1%	0%	370	
	287	Droop filter time constant	0 to 1s	0.01s	0.3s	370	
	288	Droop function activation selection	0, 1, 2, 10, 11	1	0	370	
—	291	Pulse train I/O selection	0, 1, 10, 11, 20, 21, 100	1	0	255, 372	
—	292	Automatic acceleration/deceleration	0, 1, 3, 5 to 8, 11	1	0	163, 179, 214	
—	293	Acceleration/deceleration separate selection	0 to 2	1	0	179	
—	294	UV avoidance voltage gain	0 to 200%	0.1%	100%	265	
—	299	Rotation direction detection selection at restarting	0, 1, 9999	1	0	261	
RS-485 communication	331	RS-485 communication station number	0 to 31(0 to 247)	1	0	327	
	332	RS-485 communication speed	3, 6, 12, 24, 48, 96, 192, 384	1	96	327	
	333	RS-485 communication stop bit length	0, 1, 10, 11	1	1	327	
	334	RS-485 communication parity check selection	0, 1, 2	1	2	327	
	335	RS-485 communication retry count	0 to 10, 9999	1	1	327	
	336	RS-485 communication check time interval	0 to 999.8s, 9999	0.1s	0s	327	
	337	RS-485 communication waiting time setting	0 to 150ms, 9999	1	9999	327	
	338	Communication operation command source	0, 1	1	0	317	
	339	Communication speed command source	0, 1, 2	1	0	317	
	340	Communication startup mode selection	0, 1, 2, 10, 12	1	0	316	
	341	RS-485 communication CR/LF selection	0, 1, 2	1	1	327	
	342	Communication EEPROM write selection	0, 1	1	0	328	
	343	Communication error count	—	1	0	340	

WWW.BSNEW.IR

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Orientation control	350 *6	Stop position command selection	0, 1, 9999	1	9999	217	
	351 *6	Orientation speed	0 to 30Hz	0.01Hz	2Hz	217	
	352 *6	Creep speed	0 to 10Hz	0.01Hz	0.5Hz	217	
	353 *6	Creep switchover position	0 to 16383	1	511	217	
	354 *6	Position loop switchover position	0 to 8191	1	96	217	
	355 *6	DC injection brake start position	0 to 255	1	5	217	
	356 *6	Internal stop position command	0 to 16383	1	0	217	
	357 *6	Orientation in-position zone	0 to 255	1	5	217	
	358 *6	Servo torque selection	0 to 13	1	1	217	
	359 *6	Encoder rotation direction	0, 1	1	1	217	
	360 *6	16 bit data selection	0 to 127	1	0	217	
	361 *6	Position shift	0 to 16383	1	0	217	
	362 *6	Orientation position loop gain	0.1 to 100	0.1	1	217	
	363 *6	Completion signal output delay time	0 to 5s	0.1s	0.5s	217	
	364 *6	Encoder stop check time	0 to 5s	0.1s	0.5s	217	
	365 *6	Orientation limit	0 to 60s, 9999	1s	9999	217	
	366 *6	Recheck time	0 to 5s, 9999	0.1s	9999	217	
Encoder feedback	367 *6	Speed feedback range	0 to 400Hz, 9999	0.01Hz	9999	375	
	368 *6	Feedback gain	0 to 100	0.1	1	375	
	369 *6	Number of encoder pulses	0 to 4096	1	1024	217, 375	
	374	Overspeed detection level	0 to 400Hz	0.01Hz	140Hz	271	
	376 *6	Encoder signal loss detection enable/ disable selection	0, 1	1	0	271	
S-pattern acceleration/ deceleration C	380	Acceleration S-pattern 1	0 to 50%	1%	0	176	
	381	Deceleration S-pattern 1	0 to 50%	1%	0	176	
	382	Acceleration S-pattern 2	0 to 50%	1%	0	176	
	383	Deceleration S-pattern 2	0 to 50%	1%	0	176	
Pulse train input	384	Input pulse division scaling factor	0 to 250	1	0	372	
	385	Frequency for 0 input pulse	0 to 400Hz	0.01Hz	0	372	
	386	Frequency for maximum input pulse	0 to 400Hz	0.01Hz	60Hz	372	
Orientation control	393 *6	Orientation selection	0, 1, 2	1	0	217	
	396 *6	Orientation speed gain (P term)	0 to 1000	1	60	217	
	397 *6	Orientation speed integral time	0 to 20s	0.001s	0.333s	217	
	398 *6	Orientation speed gain (D term)	0 to 100	0.1	1	217	
	399 *6	Orientation deceleration ratio	0 to 1000	1	20	217	
PLC function	414	PLC function operation selection	0, 1	1	0	353	
	415	Inverter operation lock mode setting	0, 1	1	0	353	
	416	Pre-scale function selection	0 to 5	1	0	353	
	417	Pre-scale setting value	0 to 32767	1	1	353	

WWW.BSNEW.IR

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Position control	**419** *6	**Position command source selection**	0, 2	1	0	131, 134	
	420 *6	**Command pulse scaling factor numerator**	0 to 32767	1	1	136	
	421 *6	**Command pulse scaling factor denominator**	0 to 32767	1	1	136	
	422 *6	**Position loop gain**	0 to 150s^{-1}	1s^{-1}	25s^{-1}	138	
	423 *6	**Position feed forward gain**	0 to 100%	1%	0	138	
	424 *6	**Position command acceleration/ deceleration time constant**	0 to 50s	0.001s	0s	136	
	425 *6	**Position feed forward command filter**	0 to 5s	0.001s	0s	138	
	426 *6	**In-position width**	0 to 32767pulse	1	100	137	
	427 *6	**Excessive level error**	0 to 400K, 9999	1K	40K	137	
	428 *6	**Command pulse selection**	0 to 5	1	0	134	
	429 *6	**Clear signal selection**	0, 1	1	1	134	
	430 *6	**Pulse monitor selection**	0 to 5, 9999	1	9999	134	
Second motor constants	**450**	**Second applied motor**	0 to 8, 13 to 18, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54, 9999	1	9999	145, 185	
	451	**Second motor control method selection**	10, 11, 12, 20, 9999	1	9999	145	
	453	**Second motor capacity**	0.4 to 55kW, 9999/ 0 to 3600kW, 9999 *2	0.01kW/0.1kW *2	9999	145	
	454	**Number of second motor poles**	2, 4, 6, 8, 10, 9999	1	9999	145	
	455	**Second motor excitation current**	0 to 500A,9999/ 0 to 3600A, 9999 *2	0.01/0.1A *2	9999	187	
	456	**Rated second motor voltage**	0 to 1000V	0.1V	200/400V *5	187	
	457	**Rated second motor frequency**	10 to 120Hz	0.01Hz	60Hz	187	
	458	**Second motor constant (R1)**	0 to 50Ω, 9999/ 0 to 400mΩ, 9999 *2	0.001Ω/ 0.01mΩ *2	9999	187	
	459	**Second motor constant (R2)**	0 to 50Ω, 9999/ 0 to 400mΩ, 9999 *2	0.001Ω/ 0.01mΩ *2	9999	187	
	460	**Second motor constant (L1)**	0 to 50Ω (0 to 1000mH), 9999/ 0 to 3600mΩ (0 to 400mH), 9999 *2	0.001Ω (0.1mH)/ 0.01mΩ(0.01mH) *2	9999	187	
	461	**Second motor constant (L2)**	0 to 50Ω (0 to 1000mH), 9999/ 0 to 3600mΩ (0 to 400mH), 9999 *2	0.001Ω (0.1mH)/ 0.01mΩ(0.01mH) *2	9999	187	
	462	**Second motor constant (X)**	0 to 500Ω (0 to 100%), 9999/ 0 to 100Ω (0 to 100%), 9999 *2	0.01Ω (0.1%)/ 0.01Ω (0.01%) *2	9999	187	
	463	**Second motor auto tuning setting/ status**	0, 1, 101	1	0	187	

WWW.BSNEW.IR

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Conditional position feed function	464 *6	Digital position control sudden stop deceleration time	0 to 360.0s	0.1s	0	131	
	465 *6	First position feed amount lower 4 digits	0 to 9999	1	0	131	
	466 *6	First position feed amount upper 4 digits	0 to 9999	1	0	131	
	467 *6	Second position feed amount lower 4 digits	0 to 9999	1	0	131	
	468 *6	Second position feed amount upper 4 digits	0 to 9999	1	0	131	
	469 *6	Third position feed amount lower 4 digits	0 to 9999	1	0	131	
	470 *6	Third position feed amount upper 4 digits	0 to 9999	1	0	131	
	471 *6	Fourth position feed amount lower 4 digits	0 to 9999	1	0	131	
	472 *6	Fourth position feed amount upper 4 digits	0 to 9999	1	0	131	
	473 *6	Fifth position feed amount lower 4 digits	0 to 9999	1	0	131	
	474 *6	Fifth position feed amount upper 4 digits	0 to 9999	1	0	131	
	475 *6	Sixth position feed amount lower 4 digits	0 to 9999	1	0	131	
	476 *6	Sixth position feed amount upper 4 digits	0 to 9999	1	0	131	
	477 *6	Seventh position feed amount lower 4 digits	0 to 9999	1	0	131	
	478 *6	Seventh position feed amount upper 4 digits	0 to 9999	1	0	131	
	479 *6	Eighth position feed amount lower 4 digits	0 to 9999	1	0	131	
	480 *6	Eighth position feed amount upper 4 digits	0 to 9999	1	0	131	
	481 *6	Ninth position feed amount lower 4 digits	0 to 9999	1	0	131	
	482 *6	Ninth position feed amount upper 4 digits	0 to 9999	1	0	131	
	483 *6	Tenth position feed amount lower 4 digits	0 to 9999	1	0	131	
	484 *6	Tenth position feed amount upper 4 digits	0 to 9999	1	0	131	
	485 *6	Eleventh position feed amount lower 4 digits	0 to 9999	1	0	131	
	486 *6	Eleventh position feed amount upper 4 digits	0 to 9999	1	0	131	
	487 *6	Twelfth position feed amount lower 4 digits	0 to 9999	1	0	131	
	488 *6	Twelfth position feed amount upper 4 digits	0 to 9999	1	0	131	
	489 *6	Thirteenth position feed amount lower 4 digits	0 to 9999	1	0	131	
	490 *6	Thirteenth position feed amount upper 4 digits	0 to 9999	1	0	131	
	491 *6	Fourteenth position feed amount lower 4 digits	0 to 9999	1	0	131	
	492 *6	Fourteenth position feed amount upper 4 digits	0 to 9999	1	0	131	
	493 *6	Fifteenth position feed amount lower 4 digits	0 to 9999	1	0	131	
	494 *6	Fifteenth position feed amount upper 4 digits	0 to 9999	1	0	131	
Remote output	495	Remote output selection	0, 1, 10, 11	1	0	247	
	496	Remote output data 1	0 to 4095	1	0	247	
	497	Remote output data 2	0 to 4095	1	0	247	
—	498	PLC function flash memory clear	0 to 9999	1	0	353	
Maintenance	503	Maintenance timer	0 (1 to 9998)	1	0	383	
	504	Maintenance timer alarm output set time	0 to 9998, 9999	1	9999	383	
—	505	Speed setting reference	1 to 120Hz	0.01Hz	60Hz	248	
PLC function	506	Parameter 1 for user	0 to 65535	1	0	353	
	507	Parameter 2 for user	0 to 65535	1	0	353	
	508	Parameter 3 for user	0 to 65535	1	0	353	
	509	Parameter 4 for user	0 to 65535	1	0	353	
	510	Parameter 5 for user	0 to 65535	1	0	353	
	511	Parameter 6 for user	0 to 65535	1	0	353	
	512	Parameter 7 for user	0 to 65535	1	0	353	
	513	Parameter 8 for user	0 to 65535	1	0	353	
	514	Parameter 9 for user	0 to 65535	1	0	353	
	515	Parameter 10 for user	0 to 65535	1	0	353	

WWW.BSNEW.IR

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
S-pattern acceleration/ deceleration D	516	S-pattern time at a start of acceleration	0.1 to 2.5s	0.1s	0.1s	176	
	517	S-pattern time at a completion of acceleration	0.1 to 2.5s	0.1s	0.1s	176	
	518	S-pattern time at a start of deceleraiton	0.1 to 2.5s	0.1s	0.1s	176	
	519	S-pattern time at a completion of deceleraiton	0.1 to 2.5s	0.1s	0.1s	176	
—	539	Modbus-RTU communication check time interval	0 to 999.8s, 9999	0.1s	9999	340	
USB	547	USB communication station number	0 to 31	1	0	354	
	548	USB communication check time interval	0 to 999.8s, 9999	0.1s	9999	354	
Communication	549	Protocol selection	0, 1	1	1	340	
	550	NET mode operation command source selection	0, 1, 9999	1	9999	317	
	551	PU mode operation command source selection	1, 2, 3	1	2	317	
Current average value monitor	555	Current average time	0.1 to 1.0s	0.1s	1s	384	
	556	Data output mask time	0.0 to 20.0s	0.1s	0s	384	
	557	Current average value monitor signal output reference current	0 to 500/0 to 3600A *2	0.01/0.1A *2	Rated inverter current	384	
—	563	Energization time carrying-over times	(0 to 65535)	1	0	250	
—	564	Operating time carrying-over times	(0 to 65535)	1	0	250	
Second motor constants	569	Second motor speed control gain	0 to 200%, 9999	0.1%	9999	145	
Multiple rating	570	Multiple rating setting	0 to 3	1	2	155	
—	571	Holding time at a start	0.0 to 10.0s, 9999	0.1s	9999	175	
—	573	4mA input check selection	1, 9999	1	9999	300	
—	574	Second motor online auto tuning	0, 1	1	0	197	
PID control	575	Output interruption detection time	0 to 3600s, 9999	0.1s	1s	355	
	576	Output interruption detection level	0 to 400Hz	0.01Hz	0Hz	355	
	577	Output interruption cancel level	900 to 1100%	0.1%	1000%	355	
—	611	Acceleration time at a restart	0 to 3600s, 9999	0.1s	5/15s *2	261	
—	665	Regeneration avoidance frequency gain	0 to 200%	0.1%	100%	377	
—	684	Tuning data unit switchover	0, 1	1	0	187	
—	800	Control method selection	0 to 5, 9 to 12, 20	1	20	92, 145	
—	802 *6	Pre-excitation selection	0, 1	1	0	200	
Torque command	803	Constant power range torque characteristic selection	0, 1	1	0	99, 122	
	804	Torque command source selection	0, 1, 3 to 6	1	0	122	
	805	Torque command value (RAM)	600 to 1400%	1%	1000%	122	
	806	Torque command value (RAM,EEPROM)	600 to 1400%	1%	1000%	122	

WWW.BSNEW.IR

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Speed limit	807	Speed limit selection	0, 1, 2	1	0	124	
	808	Forward rotation speed limit	0 to 120Hz	0.01Hz	60Hz	124	
	809	Reverse rotation speed limit	0 to 120Hz, 9999	0.01Hz	9999	124	
Torque limit	810	Torque limit input method selection	0, 1	1	0	99	
	811	Set resolution switchover	0, 1, 10, 11	1	0	99, 248	
	812	Torque limit level (regeneration)	0 to 400%, 9999	0.1%	9999	99	
	813	Torque limit level (3rd quadrant)	0 to 400%, 9999	0.1%	9999	99	
	814	Torque limit level (4th quadrant)	0 to 400%, 9999	0.1%	9999	99	
	815	Torque limit level 2	0 to 400%, 9999	0.1%	9999	99	
	816	Torque limit level during acceleration	0 to 400%, 9999	0.1%	9999	99	
	817	Torque limit level during deceleration	0 to 400%, 9999	0.1%	9999	99	
Easy gain tuning	818	Easy gain tuning response level setting	1 to 15	1	2	104	
	819	Easy gain tuning selection	0 to 2	1	0	104	
Adjustment function	820	Speed control P gain 1	0 to 1000%	1%	60%	104	
	821	Speed control integral time 1	0 to 20s	0.001s	0.333s	104	
	822	Speed setting filter 1	0 to 5s, 9999	0.001s	9999	287	
	823 *6	Speed detection filter 1	0 to 0.1s	0.001s	0.001s	141	
	824	Torque control P gain 1	0 to 200%	1%	100%	127	
	825	Torque control integral time 1	0 to 500ms	0.1ms	5ms	127	
	826	Torque setting filter 1	0 to 5s, 9999	0.001s	9999	287	
	827	Torque detection filter 1	0 to 0.1s	0.001s	0s	141	
	828	Model speed control gain	0 to 1000%	1%	60%	111	
	830	Speed control P gain 2	0 to 1000%, 9999	1%	9999	104	
	831	Speed control integral time 2	0 to 20s, 9999	0.001s	9999	104	
	832	Speed setting filter2	0 to 5s, 9999	0.001s	9999	287	
	833 *6	Speed detection filter 2	0 to 0.1s, 9999	0.001s	9999	141	
	834	Torque control P gain 2	0 to 200%, 9999	1%	9999	127	
	835	Torque control integral time 2	0 to 500ms, 9999	0.1ms	9999	127	
	836	Torque setting filter2	0 to 5s, 9999	0.001s	9999	287	
	837	Torque detection filter 2	0 to 0.1s, 9999	0.001s	9999	141	
Torque bias	840 *6	Torque bias selection	0 to 3, 9999	1	9999	113	
	841 *6	Torque bias 1	600 to 1400%, 9999	1%	9999	113	
	842 *6	Torque bias 2	600 to 1400%, 9999	1%	9999	113	
	843 *6	Torque bias 3	600 to 1400%, 9999	1%	9999	113	
	844 *6	Torque bias filter	0 to 5s, 9999	0.001s	9999	113	
	845 *6	Torque bias operation time	0 to 5s, 9999	0.01s	9999	113	
	846 *6	Torque bias balance compensation	0 to 10V, 9999	0.1V	9999	113	
	847 *6	Fall-time torque bias terminal 1 bias	0 to 400%, 9999	1%	9999	113	
	848 *6	Fall-time torque bias terminal 1 gain	0 to 400%, 9999	1%	9999	113	
Additional function	849	Analog input off set adjustment	0 to 200%	0.1%	100%	287	
	850	Control operation selection	0, 1	1	0	200	
	853 *6	Speed deviation time	0 to 100s	0.1s	1s	116	
	854	Excitation ratio	0 to 100%	1%	100%	142	
	858	Terminal 4 function assignment	0, 1, 4, 9999	1	0	281	
	859	Torque current	0 to 500A, 9999/ 0 to 3600A, 9999 *2	0.01A/0.1A *2	9999	187	
	860	Second motor torque current	0 to 500A, 9999/ 0 to 3600A, 9999 *2	0.01A/0.1A *2	9999	187	
	862	Notch filter time constant	0 to 60	1	0	117	
	863	Notch filter depth	0, 1, 2, 3	1	0	117	
	864	Torque detection	0 to 400%	0.1%	150%	246	
	865	Low speed detection	0 to 400Hz	0.01Hz	1.5Hz	243	

WWW.BSNEW.IR

Func-tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Indication function	866	Torque monitoring reference	0 to 400%	0.1%	150%	255	
—	867	AM output filter	0 to 5s	0.01s	0.01s	255	
—	868	Terminal 1 function assignment	0 to 6, 9999	1	0	281	
Protective Functions	872	Input phase failure protection selection	0, 1	1	0	271	
	873 *6	Speed limit	0 to 120Hz	0.01Hz	20Hz	116	
	874	OLT level setting	0 to 200%	0.1%	150%	99	
	875	Fault definition	0, 1	1	0	272	
Control system functions	877	Speed feed forward control/model adaptive speed control selection	0, 1, 2	1	0	111	
	878	Speed feed forward filter	0 to 1s	0.01s	0s	111	
	879	Speed feed forward torque limit	0 to 400%	0.1%	150%	111	
	880	Load inertia ratio	0 to 200 times	0.1	7	104, 111	
	881	Speed feed forward gain	0 to 1000%	1%	0%	111	
Regeneration avoidance function	882	Regeneration avoidance operation selection	0, 1, 2	1	0	377	
	883	Regeneration avoidance operation level	300 to 800V	0.1V	380/760VDC *5	377	
	884	Regeneration avoidance at deceleration detection sensitivity	0 to 5	1	0	377	
	885	Regeneration avoidance compensation frequency limit value	0 to 10Hz, 9999	0.01Hz	6Hz	377	
	886	Regeneration avoidance voltage gain	0 to 200%	0.1%	100%	377	
Free parameters	888	Free parameter 1	0 to 9999	1	9999	386	
	889	Free parameter 2	0 to 9999	1	9999	386	
Energy saving monitor	891	Cumulative power monitor digit shifted times	0 to 4, 9999	1	9999	274	
	892	Load factor	30 to 150%	0.1%	100%	274	
	893	Energy saving monitor reference (motor capacity)	0.1 to 55/0 to 3600kW *2	0.01/ 0.1kW *2	Inverter rated capacity	274	
	894	Control selection during commercial power-supply operation	0, 1, 2, 3	1	0	274	
	895	Power saving rate reference value	0, 1, 9999	1	9999	274	
	896	Power unit cost	0 to 500, 9999	0.01	9999	274	
	897	Power saving monitor average time	0, 1 to 1000h, 9999	1	9999	274	
	898	Power saving cumulative monitor clear	0, 1, 10, 9999	1	9999	274	
	899	Operation time rate (estimated value)	0 to 100%, 9999	0.1%	9999	274	

WWW.BSNEW.IR

Func-tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Calibration parameters	C0 (900)	FM terminal calibration	—	—	—	258	
	C1 (901)	AM terminal calibration	—	—	—	258	
	C2 (902)	Terminal 2 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	289	
	C3 (902)	Terminal 2 frequency setting bias	0 to 300%	0.1%	0%	289	
	125 (903)	Terminal 2 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	289	
	C4 (903)	Terminal 2 frequency setting gain	0 to 300%	0.1%	100%	289	
	C5 (904)	Terminal 4 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	289	
	C6 (904)	Terminal 4 frequency setting bias	0 to 300%	0.1%	20%	289	
	126 (905)	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	289	
	C7 (905)	Terminal 4 frequency setting gain	0 to 300%	0.1%	100%	289	
Calibration parameters	C12 (917)	Terminal 1 bias frequency (speed)	0 to 400Hz	0.01Hz	0Hz	289	
	C13 (917)	Terminal 1 bias (speed)	0 to 300%	0.1%	0%	289	
	C14 (918)	Terminal 1 gain frequency (speed)	0 to 400Hz	0.01Hz	60Hz	289	
	C15 (918)	Terminal 1 gain (speed)	0 to 300%	0.1%	100%	289	
	C16 (919)	Terminal 1 bias command (torque/ magnetic flux)	0 to 400%	0.1%	0%	295	
	C17 (919)	Terminal 1 bias (torque/magnetic flux)	0 to 300%	0.1%	0%	295	
	C18 (920)	Terminal 1 gain command (torque/ magnetic flux)	0 to 400%	0.1%	150%	295	
	C19 (920)	Terminal 1 gain (torque/magnetic flux)	0 to 300%	0.1%	100%	295	
	C38 (932)	Terminal 4 bias command (torque/ magnetic flux)	0 to 400%	0.1%	0%	295	
	C39 (932)	Terminal 4 bias (torque/magnetic flux)	0 to 300%	0.1%	20%	295	
	C40 (933)	Terminal 4 gain command (torque/ magnetic flux)	0 to 400%	0.1%	150%	295	
	C41 (933)	Terminal 4 gain (torque/magnetic flux)	0 to 300%	0.1%	100%	295	
—	989	Parameter copy alarm release	10, 100	1	10/100 *2	392	
PU	990	PU buzzer control	0, 1	1	1	389	
	991	PU contrast adjustment	0 to 63	1	58	389	
Clear parameters	Pr. CL	Parameter clear	0, 1	1	0	390	
	ALLC	All parameter clear	0, 1	1	0	391	
	Er.CL	Alarm history clear	0, 1	1	0	394	
	PCPY	Parameter copy	0, 1, 2, 3	1	0	392	

*1 Differ according to capacities.
6%: FR-A720-00030, 00050 (FR-A740-00015, 00025)
4%: FR-A720-00080 to 00175 (FR-A740-00040 to 00090)
3%: FR-A720-00240, 00330(FR-A740-00120, 00170)
2%: FR-A720-00460 to 02150(FR-A740-00230 to 01100)
1%: FR-A720-02880(FR-A740-01440) or more
*2 Differ according to capacities. (FR-A720-02150(FR-A740-01100) or less/FR-A720-02880(FR-A740-01440) or more)
*3 Differ according to capacities. (FR-A720-00330(FR-A740-00170) or less/FR-A720-00460(FR-A740-00230) or more)
*4 Differ according to capacities. (FR-A720-00330(FR-A740-00170) or less/FR-A720-00460 to 02150(FR-A740-00230 to 01100)/FR-A720-02880(FR-A740-01440) or more)
*5 Differs according to the voltage class. (200V class/400V class)
*6 Setting can be made only when the FR-A7AP is mounted.

WWW.BSNEW.IR

4.3 Control mode 88

4.3.1 What is vector control? ... 89
4.3.2 Change the control method (Pr. 80, Pr. 81, Pr. 451, Pr. 800) ... 92

4.4 Speed control by real sensorless vector control, vector control 96

4.4.1 Setting procedure of real sensorless vector control (speed control) ... 97
4.4.2 Setting procedure of vector control (speed control) ... 98
4.4.3 Torque limit level setting for speed control (Pr. 22, Pr. 803, Pr. 810 to Pr. 817, Pr. 858, Pr. 868, Pr. 874) ... 99
4.4.4 To perform high accuracy/fast response operation (gain adjustment of real sensorless vector control and vector control) (Pr. 818 to Pr. 821, Pr. 830, Pr. 831, Pr. 880) ... 104
4.4.5 Speed feed forward control, model adaptive speed control (Pr. 828, Pr. 877 to Pr. 881) ... 111
4.4.6 Torque biases (Pr. 840 to Pr. 848) ... 113
4.4.7 Prevent the motor from overrunning (Pr. 285, Pr. 853, Pr. 873) ... 116
4.4.8 Notch filter (Pr. 862, Pr. 863) ... 117

4.5 Torque control by real sensorless vector control, vector control 118

4.5.1 Torque control ... 118
4.5.2 Setting procedure of real sensorless vector control (torque control) ... 120
4.5.3 Setting procedure of vector control (torque control) ... 121
4.5.4 Torque command (Pr. 803 to Pr. 806) ... 122
4.5.5 Speed limit (Pr. 807 to Pr. 809) ... 124
4.5.6 Gain adjustment of torque control (Pr. 824, Pr. 825, Pr. 834, Pr. 835) ... 127

4.6 Position control by vector control 129

4.6.1 Position control ... 129
4.6.2 Conditional position feed function by contact input (Pr. 419, Pr. 464 to Pr. 494) ... 131
4.6.3 Position control (Pr. 419, Pr. 428 to Pr. 430) by inverter pulse train input ... 134
4.6.4 Setting of the electronic gear (Pr. 420, Pr. 421, Pr. 424) ... 136
4.6.5 Setting of positioning adjustment parameter (Pr. 426, Pr. 427) ... 137
4.6.6 Gain adjustment of position control (Pr. 422, Pr. 423, Pr. 425) ... 138
4.6.7 Trouble shooting for when position control is not exercised normally ... 140

4.7 Adjustment of real sensorless vector control, vector control 141

4.7.1 Speed detection filter and torque detection filter (Pr. 823, Pr. 827, Pr. 833, Pr. 837) ... 141
4.7.2 Excitation ratio (Pr. 854) ... 142

4.8 Adjust the output torque of the motor (current) 143

4.8.1 Manual torque boost (Pr. 0, Pr. 46, Pr. 112) ... 143
4.8.2 Advanced magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 89, Pr. 450, Pr. 451, Pr. 453, Pr. 454, Pr. 569, Pr. 800) ... 145
4.8.3 Slip compensation (Pr. 245 to Pr. 247) ... 149
4.8.4 Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 49, Pr. 66, Pr. 114, Pr. 115, Pr. 148, Pr. 149, Pr. 154, Pr. 156, Pr. 157, Pr. 858, Pr. 868) ... 150
4.8.5 Multiple rating (Pr. 570) ... 155

4.9 Limit the output frequency 157

4.9.1 Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18) ... 157
4.9.2 Avoid mechanical resonance points (Frequency jump) (Pr. 31 to Pr. 36) ... 158

4.10 Set V/F pattern 159

4.10.1 Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47, Pr. 113) ... 159
4.10.2 Load pattern selection (Pr. 14) ... 161
4.10.3 Elevator mode (automatic acceleration/deceleration) (Pr. 61, Pr. 64, Pr. 292) ... 163
4.10.4 Adjustable 5 points V/F (Pr. 71, Pr. 100 to Pr. 109) ... 165

4.11 Frequency setting by external terminals 166

4.11.1 Multi-speed setting operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239) ... 166
4.11.2 Jog operation (Pr. 15, Pr. 16) ... 168
4.11.3 Input compensation of multi-speed and remote setting (Pr. 28) ... 170
4.11.4 Remote setting function (Pr. 59) ... 170

4.12 Setting of acceleration/deceleration time and acceleration/deceleration pattern 173

4.12.1 Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 110, Pr. 111) ... 173
4.12.2 Starting frequency and start-time hold function (Pr. 13, Pr. 571) ... 175

WWW.BSNEW.IR

4.12.3 Acceleration/deceleration pattern (Pr. 29, Pr. 140 to Pr. 143, Pr. 380 to Pr. 383, Pr. 516 to Pr. 519) ... 176
4.12.4 Shortest acceleraiton/deceleration and optimum acceleration/deceleration (automatic acceleration/deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293) ... 179

4.13 Selection and protection of a motor 181

4.13.1 Motor protection from overheat (Electronic thermal relay function) (Pr. 9, Pr. 51) ... 181
4.13.2 Applied motor (Pr. 71, Pr. 450) ... 185
4.13.3 Offline auto tuning (Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 450, Pr. 453 to Pr. 463, Pr. 684, Pr. 859, Pr. 860) ... 187
4.13.4 Online auto tuning (Pr. 95, Pr. 574) ... 197

4.14 Motor brake and stop operation 200

4.14.1 DC injection brake and zero speed control, servo lock (LX signal, X13 signal, Pr. 10 to Pr. 12, Pr. 802, Pr. 850) ... 200
4.14.2 Selection of regenerative brake and DC feeding (Pr. 30, Pr. 70) ... 204
4.14.3 Stop selection (Pr. 250) ... 210
4.14.4 Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270, Pr. 275, Pr. 276) ... 211
4.14.5 Brake sequence function (Pr. 278 to Pr. 285, Pr. 292) ... 214
4.14.6 Orientation control (Pr. 350 to Pr. 366, Pr. 369, Pr. 393, Pr. 396 to Pr. 399) ... 217

4.15 Function assignment of external terminal and control 228

4.15.1 Input terminal function selection (Pr. 178 to Pr. 189) ... 228
4.15.2 Inverter output shutoff signal (MRS signal, Pr. 17) ... 231
4.15.3 Condition selection of function validity by the second function selection signal (RT) and third function selection signal (X9) (RT signal, X9 signal, Pr. 155) ... 232
4.15.4 Start signal operation selection (STF, STR, STOP signal, Pr. 250) ... 233
4.15.5 Magnetic flux decay output shutoff signal (X74 signal) ... 235
4.15.6 Output terminal function selection (Pr. 190 to Pr. 196) ... 236
4.15.7 Detection of output frequency (SU, FU, FU2 , FU3, FB, FB2, FB3, LS signal, Pr. 41 to Pr. 43, Pr. 50, Pr. 116, Pr. 865) ... 243
4.15.8 Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153, Pr. 166, Pr. 167) ... 245
4.15.9 Detection of output torque (TU signal, Pr. 864) ... 246
4.15.10 Remote output function (REM signal, Pr. 495 to Pr. 497) ... 247

4.16 Monitor display and monitor output signal 248

4.16.1 Speed display and speed setting (Pr. 37, Pr. 144, Pr. 505, Pr. 811) ... 248
4.16.2 DU/PU, FM, AM terminal monitor display selection (Pr. 52, Pr. 54, Pr. 158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891) ... 250
4.16.3 Reference of the terminal FM (pulse train output) and AM (analog voltage output) (Pr. 55, Pr. 56, Pr. 291, Pr. 866, Pr. 867) ... 255
4.16.4 Terminal FM, AM calibration (Calibration parameter C0 (Pr. 900), C1 (Pr. 901)) ... 258

4.17 Operation selection at power failure and instantaneous power failure 261

4.17.1 Automatic restart after instantaneous power failure/flying start (Pr. 57, Pr. 58, Pr. 162 to Pr. 165, Pr. 299, Pr. 611) ... 261
4.17.2 Power failure-time deceleration-to-stop function (Pr. 261 to Pr. 266, Pr. 294) ... 265

4.18 Operation setting at alarm occurrence 268

4.18.1 Retry function (Pr. 65, Pr. 67 to Pr. 69) ... 268
4.18.2 Alarm code output selection (Pr. 76) ... 270
4.18.3 Input/output phase failure protection selection (Pr. 251, Pr. 872) ... 271
4.18.4 Overspeed detection (Pr. 374) ... 271
4.18.5 Encoder signal loss detection (Pr. 376) ... 271
4.18.6 Fault definition (Pr. 875) ... 272

4.19 Energy saving operation and energy saving monitor 273

4.19.1 Energy saving control (Pr. 60) ... 273
4.19.2 Energy saving monitor (Pr. 891 to Pr. 899) ... 274

4.20 Motor noise, noise reduction 279

4.20.1 PWM carrier frequency and Soft-PWM control (Pr. 72, Pr. 240, Pr. 260) ... 279

4.21 Frequency/torque setting by analog input (terminal 1, 2, 4) 281

4.21.1 Function assignment of analog input terminal (Pr. 858, Pr. 868) ... 281
4.21.2 Analog input selection (Pr. 73, Pr. 267) ... 282
4.21.3 Analog input compensation (Pr. 73, Pr. 242, Pr. 243, Pr. 252, Pr. 253) ... 285

WWW.BSNEW.IR

4.21.4 Response level of analog input and noise elimination (Pr. 74, Pr. 822, Pr. 826, Pr. 832, Pr. 836, Pr. 849) ... 287
4.21.5 Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2(Pr. 902) to C7(Pr. 905), C12(Pr. 917) to C15(Pr. 918)) ... 289
4.21.6 Bias and gain of torque (magnetic flux) setting voltage (current) (Pr. 241, C16(Pr. 919) to C19(Pr. 920), C38 (Pr. 932) to C41 (Pr. 933)) ... 295
4.21.7 4mA input check of current input (Pr. 573) ... 300

4.22 Misoperation prevention and parameter setting restriction 302

4.22.1 Reset selection/disconnected PU detection/PU stop selection (Pr. 75) ... 302
4.22.2 Parameter write selection (Pr. 77) ... 305
4.22.3 Reverse rotation prevention selection (Pr. 78) ... 306
4.22.4 Display of applied parameters and user group function (Pr. 160, Pr. 172 to Pr. 174) ... 306

4.23 Selection of operation mode and operation location 308

4.23.1 Operation mode selection (Pr. 79) ... 308
4.23.2 Operation mode at power on (Pr. 79, Pr. 340) ... 316
4.23.3 Operation command source and speed command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551) ... 317

4.24 Communication operation and setting 322

4.24.1 Wiring and configuration of PU connector ... 322
4.24.2 Wiring and arrangement of RS-485 terminals ... 324
4.24.3 Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 124, Pr. 331 to Pr. 337, Pr. 341, Pr. 549) ... 327
4.24.4 Communication EEPROM write selection (Pr. 342) ... 328
4.24.5 Mitsubishi inverter protocol (computer link communication) ... 329
4.24.6 Modbus-RTU communication specifications (Pr. 331, Pr. 332, Pr. 334, Pr. 343, Pr. 539, Pr. 549) ... 340
4.24.7 Operation by PLC function (Pr. 414 to Pr. 417, Pr. 498, Pr. 506 to Pr. 515) ... 353
4.24.8 USB communication (Pr. 547, Pr. 548) ... 354

4.25 Special operation and frequency control 355

4.25.1 PID control (Pr. 127 to Pr. 134, Pr. 575 to Pr. 577) ... 355
4.25.2 Bypass-inverter switchover function (Pr. 57, Pr. 58, Pr. 135 to Pr. 139, Pr. 159) ... 363
4.25.3 Load torque high speed frequency control (Pr. 4, Pr. 5, Pr. 270 to Pr. 274) ... 368
4.25.4 Droop control (Pr. 286 to Pr. 288) ... 370
4.25.5 Frequency setting by pulse train input (Pr. 291, Pr. 384 to Pr. 386) ... 372
4.25.6 Encoder feedback control (Pr. 144, Pr. 285, Pr. 359, Pr. 367 to Pr. 369) ... 375
4.25.7 Regeneration avoidance function (Pr. 665, Pr. 882 to Pr. 886) ... 377

4.26 Useful functions 379

4.26.1 Cooling fan operation selection (Pr. 244) ... 379
4.26.2 Display of the life of the inverter parts (Pr. 255 to Pr. 259) ... 380
4.26.3 Maintenance timer alarm (Pr. 503, Pr. 504) ... 383
4.26.4 Current average value monitor signal (Pr. 555 to Pr. 557) ... 384
4.26.5 Free parameter (Pr. 888, Pr. 889) ... 386

4.27 Setting of the parameter unit and operation panel 387

4.27.1 PU display language selection (Pr. 145) ... 387
4.27.2 Operation panel frequency setting/key lock operation selection (Pr. 161) ... 387
4.27.3 Buzzer control (Pr. 990) ... 389
4.27.4 PU contrast adjustment (Pr. 991) ... 389

4.28 Parameter clear 390

4.29 All parameter clear 391

4.30 Parameter copy and parameter verification 392

4.30.1 Parameter copy ... 392
4.30.2 Parameter verification ... 393

4.31 Check and clear of the alarm history 394

WWW.BSNEW.IR

4.3 Control mode

V/F control (initial setting), advanced magnetic flux vector control, real sensorless vector control and vector control are available with this inverter.

(1) V/F Control

· It controls frequency and voltage so that the ratio of frequency (F) to voltage (V) is constant when changing frequency.

(2) Advanced magnetic flux vector control

· This control devides the inverter output current into an excitation current and a torque current by vector calculation and makes voltage compensation to flow a motor current which meets the load torque.

POINT

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.
· The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity should be 0.4kW or more)
· Motor to be used is any of Mitsubishi standard motor, high efficiency motor (SF-JR, SF-HR two-pole, four-pole, six-pole 0.4kW or more) or Mitsubishi constant torque motor (SF-JRCA, SF-HRCA 200V class four-pole 0.4kW to 55kW). When using a motor other than the above (other manufacturer's motor, SF-TH, etc.), perform offline auto tuning without fail.
· Single-motor operation (one motor run by one inverter) should be performed.
· Wiring length from inverter to motor should be within 30m (98.4feet). (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m (98.4feet).)

(3) Real sensorless vector control

· By estimating the motor speed, speed control and torque control with more advanced current control function are enabled. When high accuracy and fast response is necessary, select the real sensorless vector control and perform offline auto tuning and online auto tuning.
· This control can be applied to the following applications.
  · To minimize the speed fluctuation even at at a severe load fluctuation
  · To generate low speed torque
  · To prevent machine from damage due to too large torque (torque limit)
  · To perform torque control

POINT

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.
· The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity should be 0.4kW or more)
· Perform offline auto tuning without fail. Offline auto tuning is necessary under real sensorless vector control even when the Mitsubishi motor is used.
· Single-motor operation (one motor run by one inverter) should be performed.

(4) Vector control

· When the FR-A7AP is mounted, full-scale vector control operation can be performed using a motor with encoder. Fast response/high accuracy speed control (zero speed control, servo lock), torque control, and position control can be performed.
· What is vector control?
  Excellent control characteristics when compared to V/F control and other control techniques, achieving the control characteristics equal to those of DC machines.
  It is suitable for applications below.
  · To minimize the speed fluctuation even at a severe load fluctuation
  · To generate low speed torque
  · To prevent machine from damage due to too large torque (torque limit)
  · To perform torque control or position control
  · Servo-lock torque control which generates torque at zero speed (i.e. status of motor shaft = stopped)


POINT

If the conditions below are not satisfied, malfunction such as insufficient torque and uneven rotation may occur.
· The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity should be 0.4kW or more)
· Motor to be used is any of Mitsubishi standard motor with encoder, high efficiency motor with encoder (SF-JR, SF-HR two-pole, four-pole, six-pole 0.4kW or more) or Mitsubishi constant torque motor with encoder (SF-JRCA, SF-HRCA 200V class four-pole 0.4kW to 55kW) or vector control dedicated motor (SF-V5RU). When using a motor other than the above (other manufacturer's motor), perform offline auto tuning without fail.
· Single-motor operation (one motor run by one inverter) should be performed.
· Wiring length from inverter to motor should be within 30m (98.4feet). (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m (98.4feet).)

WWW.BSNEW.IR


4.3.1 What is vector control?

Vector control is one of the control techniques for driving an induction motor. To help explain vector control, the fundamental equivalent circuit of an induction motor is shown below:



r1 : Primary resistance
r2 : Secondary resistance
ℓ_1 : Primary leakage inductance
ℓ_2 : Secondary leakage inductance
M : Mutual inductance
S : Slip
id : Excitation current
iq : Torque current
im : Motor current

In the above diagram, currents flowing in the induction motor can be classified into a current id (excitation current) for making a magnetic flux in the motor and a current iq (torque current) for causing the motor to develop a torque.



In vector control, the voltage and output frequency are calculated to control the motor so that the excitation current and torque current (as shown in the left figure) flow to the optimum as described below:

(1) The excitation current is controlled to place the internal magnetic flux of the motor in the optimum status.

(2) Derive the torque command value so that the difference between the motor speed command and the actual speed (speed estimated value for real sensorless vector control) obtained from the encoder connected to the motor shaft is zero. Torque current is controlled so that torque as set in the torque command is developed.

Motor-generated torque (TM), slip angular velocity (ωs) and the motor's secondary magnetic flux (ϕ2) can be found by the following calculation:

$$T_M \propto \phi_2 \cdot iq$$

$$\phi_2 = M \cdot id$$

$$\omega s = \frac{r2}{L2} \cdot \frac{iq}{id}$$

where, L2 = secondary inductance

$L2 = \ell_2 + M$

Vector control provides the following advantages:

(1) Excellent control characteristics when compared to V/F control and other control techniques, achieving the control characteristics equal to those of DC machines.


(2) Applicable to fast response applications with which induction motors were previously regarded as difficult to use. Applications requiring a wide variable-speed range from extremely low speed to high speed, frequent acceleration/deceleration operations, continuous four-quadrant operations etc.

(3) Allows torque control.


(4) Allows servo-lock torque control which generates a torque at zero speed (i.e. status of motor shaft = stopped). (Cannot be performed under real sensorless vector control.)

WWW.BSNEW.IR

Block diagram of real sensorless vector control



Block diagram of vector control



WWW.BSNEW.IR

(1) Speed control
Speed control operation is performed to zero the difference between the speed command (ω*) and actual rotation detection value (ωFB). At this time, the motor load is found and its result is transferred to the torque current controller as a torque current command (iq*).

(2) Torque current control
A voltage (Vq) is calculated to start a current (iq*) which is identical to the torque current command (iq) found by the speed controller.

(3) Magnetic flux control
The magnetic flux (ϕ2) of the motor is derived from the excitation current (id). The excitation current command (id*) is calculated to use that motor magnetic flux (ϕ2) as a predetermined magnetic flux.

(4) Excitation current control
A voltage (Vd) is calculated to start a current (id) which is identical to the excitation current command (id*) found by magnetic flux control.

(5) Output frequency calculation
Motor slip (ωs) is calculated on the basis of the torque current value (iq) and magnetic flux (ϕ2). The output frequency (w0) is found by adding that slip (ωs) to the feedback (ωFB) found by a feedback from the encoder.

The above results are used to make PWM modulation and run the motor.

WWW.BSNEW.IR

4.3.2 Change the control method (Pr. 80, Pr. 81, Pr. 451, Pr. 800)

Set when selecting the advanced magnetic flux vector control, real sensorless vector control or vector control. Select a control mode from speed control mode, torque control mode and position control mode under real sensorless vector control or vector control. The initial value is V/F control.

- Select a control method using *Pr. 800 (Pr. 451) Control method selection* .
- Each control method can be switched using a method switching signal (MC).

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description	
80	Motor capacity	9999	02150 (01100) or less	0.4 to 55kW	Set the applied motor capacity.	
			02880 (01440) or more	0 to 3600kW		
			9999		V/F control	
81	Number of motor poles	9999	2, 4, 6, 8, 10		Set the number of motor poles.	
			12, 14, 16, 18, 20		X18 signal-ON:V/F control	Set 10 + number of motor poles
			9999		V/F control	
800	Control method selection	20	0 to 5		Vector control	
			9		Vector control test operation	
			10, 11, 12		Real sensorless vector control	
			20		V/F control (advanced magnetic flux vector control)	
451	Second motor control method selection	9999	10, 11, 12		Real sensorless vector control	
			20, 9999		V/F control (advanced magnetic flux vector control)	

(1) Setting of the motor capacity and the number of motor poles (*Pr. 80, Pr. 81*)

- Motor specifications(the motor capacity and the number of motor poles) must be set to select advanced magnetic flux vector control, real sensorless vector control or vector control.
- Set the motor capacity (kW) in *Pr. 80 Motor capacity* and set the number of motor poles in *Pr. 81 Number of motor poles*.

REMARKS

- Setting number of motor poles in *Pr. 81* changes the *Pr. 144 Speed setting switchover* setting automatically. (Refer to *page 248*.)

(2) Selection of control method and control mode

- Select the inverter control method for V/F control, advanced magnetic flux vector control (speed control), real sensorless vector control (speed control, torque control) and vector control (speed control, torque control, and position control).

Pr. 80, Pr. 81 Setting	*Pr. 800* Setting	*Pr. 451* Setting	Control Method	Control Mode	Remarks
Other than 9999	0	—	Vector control	Speed control	—
	1	—		Torque control	—
	2	—		Speed control-torque control switchover	MC ON: Torque control MC OFF: Speed control
	3	—		Position control	—
	4	—		Speed control-position control switchover	MC ON: Position control MC OFF: Speed control
	5	—		Position control-torque control switchover	MC ON: Torque control MC OFF: Position control
	9	—	Vector control test operation		
	10		Real sensorless vector control	Speed control	—
	11			Torque control	—
	12			Speed control-torque control switchover	MC ON: Torque control MC OFF: Speed control
	20 (*Pr. 800* initial value)		Advanced magnetic flux vector control	Speed control	—
	—	9999 (*Pr. 451* initial value)	V/F control, advanced magnetic flux vector control		
9999	— *		V/F control		

* Control method is V/F control regardless of the setting value of *Pr. 800* when "9999" is set in *Pr. 80 Motor capacity* or *Pr. 81 Number of motor poles*.

WWW.BSNEW.IR

(3) Vector control test operation (*Pr. 800* = "9")

· Speed control test operation can be performed even when the motor is not connected.
The speed calculation value changes to track the speed command and the transition can be checked with the operation panel and analog signal output at FM and AM.

CAUTION

· Since current is not detected and voltage is not output, monitors related to current and voltage such as output current and output voltage, etc. and output signals do not function.
· For speed calcuration, speed is calculated in consideration of *Pr. 880 Load inertia ratio*.

(4) Control method switching by external terminals (RT signal, X18 signal)

· The switching of the control method (V/F control, advanced magnetic flux vector control, real sensorless vector control and vector control) by the external terminal may be made in either of the following two ways: switching by the second function selection signal (RT), or V/F switching signal (X18).
· Two types of control method can be switched with the RT signal by setting the type of motor to be used as second motor in *Pr. 450 Second applied motor* and control method of the motor in *Pr. 451 Second motor control method selection*. Turn on the RT signal to select the second function.
· For switching by the X18 signal, setting "12, 14, 16, 18, 20" in *Pr. 81 Number of motor poles* and turning the X18 signal on switches the currently selected control method (advanced magnetic flux vector control, real sensorless vector control and vector control) to V/F control. In this case, use this signal only for changing the control method of one motor since second function as electronic thermal relay characteristic, etc. can not be changed. (Use the RT signal to change the second function.)
For the terminal used for X18 signal input, set "18" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.

First Motor Control Method	Second Motor Control Method (RT signal is on)	*Pr. 450* Setting	*Pr. 453, Pr. 454* Setting	*Pr. 451* Setting
V/F control	V/F control	9999	—	—
		Other than 9999	9999	—
	Advanced magnetic flux vector control		Other than 9999	20, 9999
	Real sensorless vector control			10 to 12
Advanced magnetic flux vector control Real sensorless vector control	Same control as the first motor *1	9999	—	—
	V/F control	Other than 9999	9999	—
	Advanced magnetic flux vector control		Other than 9999	20, 9999
	Real sensorless vector control			10 to 12

*1 V/F control is selected when "12, 14, 16, 18, 20" is set in *Pr. 81* and the X18 signal is on. When the X18 signal is not assigned, turning the RT signal on selects V/F control as the RT signal shares this function.

REMARKS

· The RT signal is assigned to the terminal RT in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189* (*input terminal function selection*), you can assign the RT signal to the other terminal.
· The RT signal acts as the second function selection signal and makes the other second functions valid. *(Refer to page 232.)*

WWW.BSNEW.IR

(5) Switching the control method from the external terminal (MC signal)

· When "12 (2)" is set in *Pr. 800* (*Pr. 451*), speed control is selected when the control mode switching signal (MC) is off, and torque control is selected when the signal is off under real sensorless vector control and vector control. Switching between speed control and torque control is always enabled.
Under vector control, speed control/position control switchover and torque control/position control switchover can be made by setting "4, 5" in *Pr. 800*. For the terminal used for MC signal input, set "26" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.

· When an analog input terminal (terminal 1,4) is used for torque limit, torque command, etc., terminal functions also switch as below if control mode is switched.

● Terminal 1 function according to control

Pr. 868 Setting	Real Sensorless Vector Control (*Pr. 800* = 12), Vector Control (*Pr. 800* = 2)	
	Speed control (MC signal-OFF)	Torque control (MC signal-ON)
0 (initial value)	Speed setting auxiliary	Speed limit auxiliary
1	Magnetic flux command	Magnetic flux command
2	Regenerative torque limit (*Pr. 810* = 1)	—
3	—	Torque command (*Pr. 804* = 0)
4	Torque limit (*Pr. 810* = 1)	Torque command (*Pr. 804* = 0)
5	—	Forward reverse speed limit (*Pr. 807* = 2)
6	—	—
9999	—	—

Pr. 868 Setting	Vector Control (*Pr. 800* = 4)	
	Speed control (MC signal-OFF)	Position control (MC signal-ON)
0 (initial value)	Speed setting auxiliary	—
1	Magnetic flux command	Magnetic flux command
2	Regenerative torque limit (*Pr. 810* = 1)	Regenerative torque limit (*Pr. 810* = 1)
3	—	—
4	Torque limit (*Pr. 810* = 1)	Torque limit (*Pr. 810* = 1)
5	—	—
6	Torque bias	—
9999	—	—

Pr. 868 Setting	Vector Control (*Pr. 800* = 5)	
	Position control (MC signal-OFF)	Torque control (MC signal-ON)
0 (initial value)	—	Speed setting auxiliary
1	Magnetic flux command	Magnetic flux command
2	Regenerative torque limit (*Pr. 810* = 1)	—
3	—	Torque command (*Pr. 804* = 0)
4	Torque limit (*Pr. 810* = 1)	Torque command (*Pr. 804* = 0)
5	—	Forward reverse speed limit (*Pr. 807* = 2)
6	—	—
9999	—	—

WWW.BSNEW.IR

● Terminal 4 function according to control

Pr. 858 Setting	Real Sensorless Vector Control (*Pr. 800* = 12), Vector Control (*Pr. 800* = 2)	
	Speed control (MC signal-OFF)	Torque control (MC signal-ON)
0 (initial value)	Speed command (AU signal-ON)	Speed limit (AU signal-ON)
1	Magnetic flux command	Magnetic flux command
4	Torque limit (*Pr. 810* = 1)	—
9999	—	—

Pr. 858 Setting	Vector Control (*Pr. 800* = 4)	
	Speed control (MC signal-OFF)	Position control (MC signal-ON)
0 (initial value)	Speed command (AU signal-ON)	—
1	Magnetic flux command	Magnetic flux command
4	Torque limit (*Pr. 810* = 1)	Torque limit (*Pr. 810* = 1)
9999	—	—

Pr. 858 Setting	Vector Control (*Pr. 800* = 5)	
	Position control (MC signal-OFF)	Torque control (MC signal-ON)
0 (initial value)	—	Speed limit (AU signal-ON)
1	Magnetic flux command	Magnetic flux command
4	Torque limit (*Pr. 810* = 1)	—
9999	—	—

— :No function

REMARKS

- Switching between speed control and torque control is always enabled independently of whether the motor is at a stop or running or the DC injection brake operation (pre-excitation).
- Speed control/position control switchover and torque control/position control switchover is made when frequency drops to the *Pr. 865 Low speed detection*, and not switched during motor operation.

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Advanced magnetic flux vector control ☞ *Refer to page 145*
Real sensorless vector control, vector control (speed control) ☞ *Refer to page 96*
Real sensorless vector control, vector control (torque control) ☞ *Refer to page 118*
Vector control (position control) ☞ *Refer to page 129*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*
Pr. 450 Second applied motor ☞ *Refer to page 185*
Pr. 804 Torque command source selection ☞ *Refer to page 122*
Pr. 807 Speed limit selection ☞ *Refer to page 124*
Pr. 810 Torque limit input method selection ☞ *Refer to page 99*
Pr. 858 Terminal 4 function assignment, Pr. 868 Terminal 1 function assignment ☞ *Refer to page 281*

WWW.BSNEW.IR

4.4 Speed control by real sensorless vector control, vector control

Purpose	Parameter that should be Set		Refer to Page
To perform torque limit during speed control	Torque limit	Pr. 22, Pr. 803, Pr. 810, Pr. 812 to Pr. 817, Pr. 858, Pr. 868, Pr. 874	99
Gain adjustment of speed control	Easy gain tuning Gain adjustment	Pr. 818 to Pr. 821, Pr. 830, Pr. 831, Pr. 880	104
To enhance the trackability of the motor in response to a speed command change	Speed feed forward control, model adaptive speed control	Pr. 828, Pr. 877 to Pr. 881	111
Stabilize the speed detection signal	Speed detection filter	Pr. 823, Pr. 833	141
Accelerates the rise of the torque at a start	Torque bias	Pr. 840 to Pr. 848	113
Avoid mechanical resonance	Notch filter	Pr. 862, Pr. 863	117

Speed control is exercised to match the speed command and actual motor speed.

WWW.BSNEW.IR

4.4.1 Setting procedure of real sensorless vector control (speed control)

Perform secure wiring. *(Refer to page 14.)*

↓

Set the motor. *(Pr. 71) (Refer to page 185.)*

↓ Set "3" (standard motor) or "13" (constant torque motor) in *Pr. 71 Applied motor*.

Set the motor capacity and the number of motor poles. *(Pr. 80, Pr. 81) (Refer to page 92.)*

↓ Set the motor capacity (kW) in *Pr. 80 Motor capacity* and set the number of motor poles (number of poles) in *Pr. 81 Number of motor poles*. (V/F control is performed when the setting is "9999" (initial value).)

Select a control method. *(Refer to page 92)*

↓ Set "10" (speed control) or "12" (speed-torque switchover) in *Pr. 800* and make speed control valid.

Set the operation command. *(Refer to page 308)*

↓ Select the start command and speed command.

(1) Start command

1) Operation panel: Setting by pressing FWD / REV of the operation panel

2) External command: Setting by forward rotation and reverse rotation command (terminal STF or STR)

(2) Speed command

1) Operation panel: Setting by turning of the operation panel

2) External analog command (terminal 2 or 4) : Give a speed command using the analog signal input to terminal 2 (or terminal 4).

3) Multi-speed command: The external signals (RH, RM, RL) may also be used to give speed command.

Set the torque limit. *(Pr. 810) (Refer to page99.)*

↓

Perform offline auto tuning. *(Pr. 96) (Refer to page 187.)*

↓

Test run

As required

- Easy gain tuning *(Refer to page 104)*
- Select online auto tuning. *(Pr. 95) (Refer to page197)*
- Manual input speed control gain adjustment *(Refer to page 107)*

CAUTION

- Make sure to perform offline auto tuning before performing real sensorless vector control.
- Speed command setting range is 0 to 120Hz for real sensorless vector control.
- The carrier frequencies are selectable from among 2k, 6k, 10k, 14kHz for real sensorless vector control.
- Torque control can not be performed in the low speed (approx. 10Hz or less) regeneration range and with light load at low speed (approx. 20% or less of rated torque at approx. 5Hz or less). Choose vector control.
- Performing pre-excitation (LX signal and X13 signal) under torque control may start the motor running at a low speed even when the start command (STF or STR) is not input. The motor may run also at a low speed when the speed limit value = 0 with a start command input. Perform pre-excitation after making sure that there will be no problem in safety if the motor runs.
- Do not switch between the STF (forward rotation command) and STR (reverse rotation command) during operation under torque control. Overcurrent shut-off error (E.OC☐) or opposite rotation deceleration error (E.11) occurs.
- For the FR-A720-00030 to 00175 (FR-A740-00015 to 00090), the speed deviation may become large at 20Hz or less and torque may become insufficient in the low speed range under 1Hz during continuous operation under real sensorless vector control. In this case, stop the inverter once, then start (online auto tuning) again to improve.
- When the inverter is likely to start during motor coasting under real sensorless vector control, set to make frequency search of automatic restart after instantaneous power failure valid (*Pr. 57* ≠ "9999", *Pr. 162* = "10").
- Enough torque may not be generated in the ultra-low speed range less than approx. 2Hz when performing real sensorless vector control.
  The guideline of speed control range is as shown below.

Driving:	1:200	(2, 4, 6 poles)	Can be used at 0.3Hz or more at rated 60Hz
	1:30	(8, 10 poles)	Can be used at 2Hz or more at rated 60Hz
Regeneration:	1:12	(2 to 10 poles)	Can be used at 5Hz or more at rated 60Hz

WWW.BSNEW.IR

4.4.2 Setting procedure of vector control (speed control) Vector

Perform secure wiring. *(Refer to page 39.)*

↓ Mount the FR-A7AP.

Set the motor and encoder. *(Pr. 71, Pr. 359, Pr. 369)*

↓ Set *Pr. 71 Applied motor*, *Pr. 359 Encoder rotation direction* and *Pr. 369 Number of encoder pulses* according to the motor and encoder used. *(Refer to page 41.)*

Set the motor capacity and the number of motor poles *(Pr. 80, Pr. 81) (Refer to page92.)*

↓ Set the motor capacity (kW) in *Pr. 80 Motor capacity* and set the number of motor poles (number of poles) in *Pr. 81 Number of motor poles*. (V/F control is performed when the setting is "9999" (initial value).)

Select a control method. *(Refer to page 92.)*

↓ Make speed control valid by selecting "0" (speed control), "2" (speed-torque switchover), or "4" (speed-position switchover) for *Pr. 800*.

Set the run command. *(Refer to page 308.)*

↓ Select the start command and speed command.

(1) Start command

1)Operation panel: Setting by pressing FWD / REV of the operation panel

2)External command: Setting by forward rotation or reverse rotation command (terminal STF or STR)

(2)Speed command

1)Operation panel: Setting by pressing of the operation panel

2)External analog command (terminal 2 or 4) :
Give a speed command using the analog signal input to terminal 2 (or terminal 4).

3)Multi-speed command:
The external signals (RH, RM, RL) may also be used to give speed command.

Set the torque limit. *(Pr. 810)* *(Refer to page 99.)*

↓

Test run

As required

- Perform offline auto tuning. *(Pr. 96) (refer to page187)*.
- Select online auto tuning. *(Pr. 95) (refer to page197)*.
- Easy gain tuning *(refer to page 104)*
- Manual input speed control gain adjustment *(refer to page 107)*

CAUTION

- Speed command setting range is 0 to 120Hz for vector control.
- The carrier frequencies are selectable from among 2k, 6k, 10k, 14kHz for vector control. (2k and 6kHz for the FR-A720-02880 (FR-A740-01440) or more)

WWW.BSNEW.IR

4.4.3 Torque limit level setting for speed control (Pr. 22, Pr. 803, Pr. 810 to Pr. 817, Pr. 858, Pr. 868, Pr. 874)

This function limits the output torque to the predetermined value during speed control under real sensorless vector control or vector control.

- Set the torque limit level within the range 0 to 400% in *Pr. 22*.
  When the TL signal is turned on, torque limit level 2 functions.
- You can select whether the torque limit level is set using parameters or analog input teminals (terminal 1, 4).
  In addition, you can set torque limit level for forward (power driving/regeneration) and reverse (power driving/regeneration) operation individually.


Parameter Number	Name	Initial Value	Setting Range	Description
22	Stall prevention operation level (torque limit level)	150/200%*	0 to 400%	Set the torque limit level in % on the assumption that the rated torque is 100% * For the FR-A720-00175 (FR-A740-00090) or less, the value changes from 150% to 200% when V/F control or advanced magnetic flux vector control is changed to real sensorless vector control or vector control.
803	Constant power range torque characteristic selection	0	0	Constant motor output limit — Select the torque limit in the constant output region by torque limit setting.
			1	Constant torque limit
810	Torque limit input method selection	0	0	Internal torque limit (torque limit by parameter settings)
			1	External torque limit (torque limit by terminal 1, 4)
811	Set resolution switchover	0		Speed setting and running speed monitor increments from the PU, RS-485 communication or communication option. — Torque limit setting increments *Pr. 22, Pr. 812 to Pr. 817*
			0	1r/min — 0.1%
			1	0.1r/min
			10	1r/min — 0.01%
			11	0.1r/min
812	Torque limit level (regeneration)	9999	0 to 400%	Set the torque limit level for forward rotation regeneration.
			9999	Limit at the value of *Pr. 22* or analog terminal
813	Torque limit level (3rd quadrant)	9999	0 to 400%	Set the torque limit level for reverse rotation driving.
			9999	Limit at the value of *Pr. 22* or analog terminal
814	Torque limit level (4th quadrant)	9999	0 to 400%	Set the torque limit level for reverse rotation regeneration.
			9999	Limit at the value of *Pr. 22* or analog terminal
815	Torque limit level 2	9999	0 to 400%	When the torque limit selection (TL) signal is on, the *Pr. 815* value is a torque limit value regardless of *Pr. 810* .
			9999	Limit at the value of *Pr. 22* or analog terminal
816	Torque limit level during acceleration	9999	0 to 400%	Set the torque limit value during acceleration.
			9999	Same torque limit as at constant speed
817	Torque limit level during deceleration	9999	0 to 400%	Set the torque limit value during deceleration.
			9999	Same torque limit as at constant speed
858	Terminal 4 function assignment	0	0, 4, 9999	When "4" is set in, the torque limit can be changed with a signal to terminal 4.
868	Terminal 1 function assignment	0	0, 2 to 5, 9999	When "4" is set in, the torque limit can be changed with a signal to terminal 1.
874	OLT level setting	150%	0 to 200%	This function can make an alarm stop if the torque limit is activated to stall the motor. Set the output at which an alarm stop is made.

CAUTION

· Under real sensorless vector control, the lower limit of torque limit level is set 30% if the value less than 30% is input.

WWW.BSNEW.IR

(1) Torque limit block diagram




(2) Selection of torque limit input method (*Pr. 810*)

· Set *Pr. 810 Torque limit input method selection* to select the method to limit output torque during speed control. Torque limit by parameter setting is initially set.

Parameter Number	Setting Range	Torque Limit Input Method	Description
810	0 (initial value)	Internal torque limit	Parameter-set torque limit operation is performed. Changing the torque limit parameter value by communication enables torque limit to be input by communication.
	1	External torque limit	Torque limit using the analog voltage (current) from terminal 1 or terminal 4 is made valid.

(3) Torque limit level by parameter setting (*Pr. 810* = "0", *Pr. 812* to *Pr. 814*)



· In the initial setting, limit is made on all quadrants on the *Pr. 22 Stall prevention operation level (torque limit level)* .

· When you want to set the level on a quadrant basis, set the torque limit level in *Pr. 812 Torque limit level (regeneration)*, *Pr. 813 Torque limit level (3rd quadrant)*, *Pr. 814 Torque limit level (4th quadrant)*.
When "9999" is set, *Pr. 22* is the torque limit level.


(4) Torque limit level by analog input (terminal 1, 4) (*Pr. 810* = "1", *Pr. 858*, *Pr. 868*)


· With the upper limit of torque limit as set in *Pr. 22*, the analog input from terminal 1 input is used as the torque limit value within the *Pr. 22* setting range.

· When torque limit value is input from terminal 1, set "4" in *Pr. 868 Terminal 1 function assignment*. When torque limit value is input from terminal 4, set "4" in *Pr. 858 Terminal 4 function assignment*.

· When *Pr. 858* = "4" and *Pr. 868* = "2", torque is limitted by analog input from terminal 1 for regeneration and by terminal 4 for driving.

· Torque limit by analog input can be calibrated using *calibration parameter C16 (Pr. 919) to C19 (Pr. 920), C38 (Pr. 932) to C41 (Pr. 933) . (Refer to page 295)*





* Analog input (terminal 1, 4) or internal torque control (*Pr. 22* etc.) whichever is smaller


WWW.BSNEW.IR

● Terminal 1, 4 function according to control (— : without function)

Pr. 858 Setting *1	*Pr. 868* Setting *2	Real Sensorless Vector Control (Speed Control)	
		Terminal 4 function	Terminal 1 function
0 (initial value)	0 (initial value)	Speed command (AU signal-ON)	Speed setting auxiliary
	1 *4		Magnetic flux command
	2		—
	3		—
	4		Torque limit (*Pr. 810* = 1)
	5		—
	6 *4		Torque bias (*Pr. 840* = 1 to 3)
	9999		—
1 *4	0 (initial value)	Magnetic flux command	Speed setting auxiliary
	1 *4	—*3	Magnetic flux command
	2	Magnetic flux command	—
	3		—
	4		Torque limit (*Pr. 810* = 1)
	5		—
	6 *4		Torque bias (*Pr. 840* = 1 to 3)
	9999		—
4 *2	0 (initial value)	Torque limit (*Pr. 810* = 1)	Speed setting auxiliary
	1 *4		Magnetic flux command
	2	Driving torque limit (*Pr. 810* = 1)	Regenerative torque limit (*Pr. 810* = 1)
	3	Torque limit (*Pr. 810* = 1)	—
	4	—*3	Torque limit (*Pr. 810* = 1)
	5	Torque limit (*Pr. 810* = 1)	—
	6 *4		Torque bias (*Pr. 840* = 1 to 3)
	9999		—
9999	—	—	—

*1 When the *Pr. 868* setting is other than "0", other functions of terminal 1 (auxiliary input, override function, PID control) do not function.
*2 When the *Pr. 858* setting is other than "0", PID control and speed command from terminal 4 do not function even if the AU signal turns on.
*3 When "1" (magnetic flux command) or "4" (torque limit) is set in both *Pr. 858* and *Pr. 868*, function of terminal 1 has higher priority and terminal 4 has no function.
*4 Setting is valid only when exercising vector control with the FR-A7AP.

(5) Second torque limit level (TL signal, *Pr. 815*)



- For *Pr. 815 Torque limit level 2* , the *Pr. 815* value is a torque limit value regardless of *Pr. 810 Torque limit input method selection* when the torque limit selection signal (TL) is on.
- Set "27" in *Pr. 178 to Pr. 189 (input terminal function selection)* to assign a function to the TL signal.


CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

WWW.BSNEW.IR

(6) Set a torque limit value during acceleration and deceleration individually (*Pr. 816*, *Pr. 817*)

· You can set torque limit during acceleration and deceleration individually.
The following chart shows torque limit according to the settings of *Pr. 816 Torque limit level during acceleration* and *Pr. 817 Torque limit level during deceleration*.




(7) Setting increments switchover of the torque limit level (*Pr. 811*)

· By setting "10, 11" in *Pr. 811 Set resolution switchover*, the setting increments of *Pr. 22 Torque limit level* and *Pr. 812 to Pr. 817 (torque limit level)* can be switched to 0.01%.

REMARKS

· The internal resolution of the torque limit is 0.024% ($100/2^{12}$) and the fraction less than the resolution is rounded off.
· When the torque limit setting increments have been changed (0.1%⇔0.01%), reset is necessary because the settings of *Pr. 22* and *Pr. 812 to Pr. 817* are multiplied by 1/10 (ten times).
For example, when 10 (0.01%) set in *Pr. 811* is changed to 1 (0.1%) with *Pr. 22* = 150.00%, *Pr. 22* = 1500.0% and the maximum torque is 400%.
· The fraction less than the resolution equivalent to 0.1% is rounded off even if "10 or 11" is set in *Pr. 811* when real sensorless vector control is selected.
· Refer to *page 248* for switchover of speed setting increments.


(8) Change the torque characteristics in the constant power range (*Pr. 803*)



· You can select whether the torque imit in the constant power range be constant torque limit (setting is "1") or constant power limit (initial setting is "0"), using *Pr. 803 Constant power range torque characteristic selection* under torque limit operation.

WWW.BSNEW.IR

(9) Alarm stop when torque limit is activated (*Pr. 874*)



- This function can make an alarm stop if the torque limit is activated to stall the motor.
- The motor stalls if the torque limit is activated under a high load applied during speed control or position control. At this time, if the motor speed is lower than the speed set in *Pr. 865 Low speed detection* and also the output torque exceeds the level set in *Pr. 874 OLT level setting* for 3s, it is regarded as a stop effected by stall prevention and E. OLT is output, resulting in an alarm stop.

REMARKS

- If the frequency has fallen to 0.5Hz by stall prevention operation and remains for 3s under V/F control and advanced magnetic flux vector control, an alarm (E.OLT) appears to shutoff the inverter output. In this case, this function is activated regardless of *Pr. 874* .
  This alarm is not provided under torque control.

♦Parameters referred to♦

- *Pr. 22 Stall prevention operation level* ☞ *Refer to page 150*
- *Pr. 178 to Pr. 189 (input terminal function selection)* ☞ *Refer to page 228*
- *Pr. 840 Torque bias selection* ☞ *Refer to page 113*
- *Pr. 865 Low speed detection* ☞ *Refer to page 243*

WWW.BSNEW.IR


4.4.4 To perform high accuracy/fast response operation (gain adjustment of real sensorless vector control and vector control) (Pr. 818 to Pr. 821, Pr. 830, Pr. 831, Pr. 880)

Vector

The ratio of the load inertia to the motor inertia (load inertia moment) is estimated in real time from the torque command and speed during motor operation by vector control. As optimum gain of speed control and position control are automatically set from the load inertia ratio and response level, time and effort of making gain adjustment are reduced. (Easy gain tuning)
When the load inertia ratio can not be estimated due to load fluctuation or real sensorless vector control is exercised, control gain is automatically set by manually inputting the load inertia ratio.
Make a manual input adjustment when vibration, noise or any other unfavorable phenomenon occurs due to large load inertia or gear backlash, for example, or when you want to exhibit the best performance that matches the machine.

Parameter Number	Name	Initial Value	Setting Range	Description
818	Easy gain tuning response level setting	2	1 to 15	Set the response level. 1: Slow response to 15: Fast response
819	Easy gain tuning selection	0	0	Without easy gain tuning
			1	With load estimation, with gain calculation (valid only during vector control)
			2	With load *(Pr. 880)* manual input, gain calculation
820	Speed control P gain 1	60%	0 to 1000%	Set the proportional gain for speed control. (Increasing the value improves trackability in response to a speed command change and reduces speed variation with disturbance.)
821	Speed control integral time 1	0.333s	0 to 20s	Set the integral time during speed control. (Decrease the value to shorten the time taken for returning to the original speed if speed variation with disturbance occurs.)
830	Speed control P gain 2	9999	0 to 1000%	Second function of *Pr. 820* (valid when RT signal is on)
			9999	No function
831	Speed control integral time 2	9999	0 to 20s	Second function of *Pr. 821* (valid when RT signal is on)
			9999	No function
880	Load inertia ratio	7 times	0 to 200 times	Set the load intertia ratio to the motor.

(1) Block diagram of easy gain tuning function




WWW.BSNEW.IR

(2) Easy gain tuning execution procedure (*Pr. 819* = "1" load inertia ratio automatic estimation)

Easy gain tuning (load inertia ratio automatic estimation) is valid only in the speed control or position control mode under vector control.
It is invalid under torque control, V/F control, advanced magnetic flux vector control and real sensorless vector control.

Pr. 818 setting	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Response level	Slow response ⟷							Middle response			⟷				Fast response
Guideline of mechanical resonance frequency (Hz)	8	10	12	15	18	22	28	34	42	52	64	79	98	122	150



1) Set the response level using *Pr. 818 Easy gain tuning response level setting*.
   Refer to the diagram on the right and set the response level.
   Increasing the value will improve trackability to the command, but too high value will generate vibration. The relationship between the setting and response level are shown on the right.
2) Each control gain is automatically set from the load inertia ratio estimated during acceleration/deceleration operation and the *Pr. 818 Easy gain tuning response level setting* value.
   Pr. 880 Load inertia ratio is used as the initial value of the load inertia ratio for tuning. Estimated value is set in *Pr. 880* during tuning.
   The load inertia ratio may not be estimated well, e.g. it takes a long time for estimation, if the following conditions are not satisfied.
   - Time taken for acceleration/deceleration to reach 1500r/min is 5s or less.
   - Speed is 150r/min or more.
   - Acceleration/deceleration torque is 10% or more of the rated torque.
   - Abrupt disturbance is not applied during acceleration/deceleration.
   - Load inertia ratio is approx. 30 times or less.
   - No gear backlash nor belt looseness is found.
3) Press FWD or REV to estimate the load inertia ratio or calculate gain any time. (The operation command for external operation is the STF or STR signal.)

(3) Easy gain tuning execution procedure (*Pr.819* = "2" load inertia manual input)

Easy gain tuning (load inertia ratio manual input) is valid only in the speed control mode under real sensorless vector control or in the speed control or position control mode under vector control.

1) Set the load inertia ratio to the motor in *Pr. 880 Load inertia ratio*.
2) Set "2" (with easy gain tuning) in *Pr. 819 Easy gain tuning selection*. Then, *Pr. 820 Speed control P gain 1* and *Pr. 821 Speed control integral time 1* are automaticaly set by gain calculation.
   Operation is performed in a gain adjusted status from the next operation.
3) Perform a test run and set the response level in *Pr. 818 Easy gain tuning response level setting*. Increasing the value will improve trackability to the command, but too high value will generate vibration. (When "2" (parameter write enabled during operation) is set in *Pr. 77 Parameter write selection* , response level adjustment can be made during operation.)

REMARKS

- When "1 or 2" is set in *Pr. 819* and then returned the *Pr. 819* setting to "0" after tuning is executed, tuning results which are set in each parameter remain unchanged.
- When good tuning accuracy is not obtained after executing easy gain tuning due to disturbance and such, perform fine adjustment by manual input. Set "0" (without easy gain tuning) in *Pr. 819*.

WWW.BSNEW.IR

(4) Parameters automatically set by easy gain tuning

The following table indicates the relationship between easy gain tuning function and gain adjustment parameter.

	Easy Gain Tuning Selection *(Pr. 819)* Setting		
	0	**1**	**2**
Load inertia ratio *(Pr. 880)*	Manual input	a) Inertia estimation result (RAM) by easy gain tuning is dispayed. b) Set the value in the following cases: • Every hour after power-on • When a value other than "1" is set in *Pr. 819* • When vector control is changed to other control (V/F control etc.) using *Pr. 800* c) Write is enabled only during a stop (manual input)	Manual input
Speed control P gain 1 *(Pr. 820)* Speed control integral time 1 *(Pr. 821)* Model speed control gain *(Pr. 828)* Position loop gain *(Pr. 422)*	Manual input	a) Tuning result (RAM) is displayed. b) Set the value in the following cases: • Every hour after power-on • When a value other than "1" is set in *Pr. 819* • When vector control is changed to other control (V/F control etc.) using *Pr. 800* c) Write (manual input) disabled	a) Gain is calculated when "2" is set in *Pr. 819* and the result is set in the parameter. b) When the value is read, the tuning result (parameter setting value) is displayed. c) Write (manual input) disabled


CAUTION

· Performing easy gain tuning with larger inertia than the specified value during vector control may cause malfunction such as hunting. In addition, when the motor shaft is fixed with servo lock or position control, bearing may be damaged. To prevent these, make gain adjustment by manual input without performing easy gain tuning.

WWW.BSNEW.IR

(5) Manual input speed control gain adjustment


· Make adjustment when any of such phenomena as unusual machine vibration/noise, low response level and overshoot has occurred.



· *Pr. 820 Speed control P gain 1* = "60%" (initial value) is equivalent to 120rad/s (speed responce of the motor alone). Increasing the setting value improves the response level, but a too large gain will produce vibration and/or unusual noise.

· Decreasing the *Pr. 821 Speed control integral time 1* shortens the return time taken at a speed change. However, a too short time will generate an overshoot.

· When there is load inertia, the actual speed gain is as given below.



$$\text{Actual speed gain} = \text{speed gain of motor without load} \times \frac{JM}{JM+JL}$$

JM: Inertia of the motor
JL: Motor shaft-equivalent load inertia

· Adjustment procedures are as below:
1)Check the conditions and simultaneously change the *Pr. 820* value.
2)If you cannot make proper adjustment, change the *Pr. 821* value and repeat step 1).

No.	Phenomenon/ Condition	Adjustment Method	
1	Load inertia is large	Set the *Pr. 820* and *Pr. 821* values a little higher.	
		Pr. 820	When a speed rise is slow, increase the value 10% by 10% until just before vibration/noise is produced, and set about 0.8 to 0.9 of that value.
		Pr. 821	If an overshoot occurs, double the value until an overshoot does not occur, and set about 0.8 to 0.9 of that value.
2	Vibration/noise generated from mechanical system	Set the *Pr. 820* value a little lower and the *Pr. 821* value a little higher.	
		Pr. 820	Decrease the value 10% by 10% until just before vibration/noise is not produced, and set about 0.8 to 0.9 of that value.
		Pr. 821	If an overshoot occurs, double the value until an overshoot does not occur, and set about 0.8 to 0.9 of that value.
3	Slow response	Set the *Pr. 820* value a little higher.	
		Pr. 820	When a speed rise is slow, increase the value 5% by 5% until just before vibration/noise is produced, and set about 0.8 to 0.9 of that value.
4	Long return time (response time)	Set the *Pr. 821* value a little lower.	
		Decrease the *Pr. 821* value by half until just before an overshoot or the unstable phenomenon does not occur, and set about 0.8 to 0.9 of that value.	
5	Overshoot or unstable phenomenon occurs.	Set the *Pr. 821* value a little higher.	
		Increase the *Pr. 821* value double by double until just before an overshoot or the unstable phenomenon does not occur, and set about 0.8 to 0.9 of that value.	

REMARKS

· When making manual input gain adjustment, set "0" (without easy gain tuning) (initial value) in *Pr. 819 Easy gain tuning selection*.

· *Pr. 830 Speed control P gain 2* and *Pr. 831 Speed control integral time 2* are made valid when the RT terminal is switched on. Make adjustments in the same way as *Pr. 820* and *Pr. 821*.

WWW.BSNEW.IR

(6) When using a multi-pole motor (8 poles or more)

Specially when using a multi-pole motor with more than 8 poles under real sensorless vector control or vector control, adjust *Pr. 820 Speed control P gain 1* and *Pr. 824 Torque control P gain 1* according to the motor referring to the following methods.

- For *Pr. 820 Speed control P gain 1*, increasing the setting value improves the response level, but a too large gain will produce vibration and/or unusual noise.
- For *Pr. 824 Torque control P gain 1*, note that a too low value will produce current ripples, causing the motor to generate sound synchronizing the cycle of current ripples.


Adjustment method

No.	Phenomenon/Condition	Adjustment Method
1	The motor rotation is unstable in the low speed range.	Set a higher value in *Pr. 820 Speed control P gain 1* according to the motor inertia. Since the self inertia of a multi-pole motor tends to become large, make adjustment to improve the unstable phenomenon, then make fine adjustment in consideration of the response level using that setting as reference. In addition, when performing vector control with encoder, gain adjustment according to the inertia can be easily done using easy gain tuning (*Pr. 819* = 1).
2	Speed trackability is poor	Set a higher value in *Pr. 820 Speed control P gain 1*. Increase the value 10% by 10% until just before vibration or unusual noise is produced, and set about 0.8 to 0.9 of that value. If you cannot make proper adjustment, increase the value of *Pr. 821 Speed control integral time 1* double by double and make adjustment of *Pr. 820* again.
3	Speed variation at the load fluctuation is large	
4	Torque becomes insufficient or torque ripple occurs at starting or in the low speed range under real sensorless vector control.	Set the speed control gain a little higher. (same as No. 1) If the problem still persists after gain adjustment, increase *Pr. 13 Starting frequency* or set the acceleration time shorter if the inverter is starting to avoid continuous operation in the ultra low speed range.
5	Unusual motor and machine vibration, noise or overcurrent occurs.	Set a lower value in *Pr. 824 Torque control P gain 1*. Decrease the value 10% by 10% until just before the phenomenon is improved, and set about 0.8 to 0.9 of that value.
6	Overcurrent or overspeed (E.OS) occurs at a start under real sensorless vector control.	

(7) P/PI switchover (X44 signal)

- By turning the P/PI control switching signal (X44) on/off during seed control operation under real sensorless vector control or vector control, you can select whether to add the integral time (I) or not when performing gain adjustment with P gain and integral time.
  When the X44 signal is off..... PI control
  When the X44 signal is on..... P control
- For the terminal used for X44 signal input, set "44" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.

[Function block diagram]






CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

WWW.BSNEW.IR

(8) Troubleshooting (speed)

<table>
<tr><th></th><th>Phenomenon</th><th>Cause</th><th>Countermeasures</th></tr>
<tr><td rowspan="5">1</td><td rowspan="5">Motor does not rotate.
(Vector control)</td><td>(1) The motor wiring is wrong</td><td>(1) Wiring check
Select V/F control (set "9999" in Pr. 80 or Pr. 81) and check the rotation direction of the motor.
For the SF-V5RU, set "170V(340V)" for 3.7kW or less and "160V(320V)" for more in Pr. 19 Base frequency voltage, and set "50Hz" in Pr. 3 Base frequency.
 
When the forward rotation signal is input, the motor running in the counterclockwise direction as viewed from the motor shaft is normal. (If it runs in the clockwise direction, the phase sequence of the inverter secondary side wiring is incorrect.)</td></tr>
<tr><td>(2) Encoder specifications (encoder specification selection switch FR-A7AP) are wrong</td><td>(2) Check the encoder specifications.
Check the encoder specifications selection switch (FR-A7AP) of differential/complimentary</td></tr>
<tr><td>(3) The encoder wiring is wrong.</td><td>(3) Check that FWD is displayed when running the motor in the counter-clockwise direction from outside during a stop of the inverter with vector control setting.
If REV is displayed, the encoder phase sequence is wrong.
Perform the correct wiring or match the Pr. 359 Encoder rotation direction.
<table><tr><th>Pr. 359 Setting</th><th>Relationship between the Motor and Encoder</th></tr><tr><td>0</td><td> 

Clockwise direction as viewed from A is forward rotation</td></tr><tr><td>1
(Initial value)</td><td> 

Counter clockwise direction as viewed from A is forward rotation</td></tr></table></td></tr>
<tr><td>(4) The Pr. 369 Number of encoder pulses setting and the number of encoder used are different.</td><td>(4) The motor will not run if the parameter setting is smaller than the number of encoder pulses used. Set the Pr. 369 Number of encoder pulses correctly.</td></tr>
<tr><td>(5) Encoder power specifications are wrong. Or, power is not input.</td><td>(5) Check the power specifications (5V/12V/15V/24V) of encoder and input the external power supply.</td></tr>
<tr><td>2</td><td>Motor does not run at correct speed. (Speed command does not match actual speed)</td><td>(1) The speed command from the command device is incorrect. The speed command is compounded with noise.
(2) The speed command value does not match the inverter-recognized value.
(3) The number of encoder pulses setting is incorrect.</td><td>(1) Check that a correct speed command comes from the command device.
Decrease Pr. 72 PWM frequency selection.
(2) Readjust speed command bias/gain Pr. 125, Pr. 126, C2 to C7 and C12 to C15.
(3) Check the setting of Pr. 369 Number of encoder pulses. (vector control)</td></tr>
<tr><td>3</td><td>Speed does not rise to the speed command.</td><td>(1) Insufficient torque. Torque limit is actuated.
(2) Only P (proportional) control is selected.</td><td>(1) -1 Increase the torque limit value.
(Refer to torque limit of speed control on page 99)
(1) -2 Insufficient capacity
(2) When the load is heavy, speed deviation will occur under P (proportional) control. Select PI control.</td></tr>
</table>

WWW.BSNEW.IR

	Phenomenon	Cause	Countermeasures
4	Motor speed is unstable.	(1) The speed command varies.	(1) -1 Check that a correct speed command comes from the command device. (Take measures against noises.) (1) -2 Decrease *Pr. 72 PWM frequency selection*. (1) -3 Increase *Pr. 822 Speed setting filter 1*. *(Refer to page 287)*
		(2) Insufficient torque.	(2) Increase the torque limit value. (Refer to torque limit of speed control on *page 99*)
		(3) The speed control gains do not match the machine. (mechanical resonance)	(3) -1 Perform easy gain tuning. *(Refer to page 105)* (3) -2 Adjust *Pr. 820, Pr. 821*. *(Refer to page 107)* (3) -3 Perform speed feed forward/model adaptive speed control.
5	Motor or machine hunts (vibration/noise is produced).	(1) The speed control gain is high.	(1) -1 Perform easy gain tuning. *(Refer to page 105)* (1) -2 Decrease *Pr. 820* and increase *Pr. 821*. (1) -3 Perform speed feed foward control and model adaptive speed control.
		(2) The torque control gain is high.	(2) Decrease the *Pr. 824* value. *(Refer to page 127)*
		(3) The motor wiring is wrong.	(3) Check the wiring
6	Acceleration/deceleration time does not match the setting.	(1) Insufficient torque.	(1) -1 Increase the torque limit value. (Refer to torque limit of speed control on *page 99*) (1) -2 Perform speed feed foward control.
		(2) Large load inertia.	(2) Set the acceleration/deceleration time that meets the load.
7	Machine operation is unstable	(1) The speed control gains do not match the machine.	(1) -1 Perform easy gain tuning. *(Refer to page 105)* (1) -2 Adjust *Pr. 820, Pr. 821*. *(Refer to page 107)* (1) -3 Perform speed feed foward control and model adaptive speed control.
		(2) Slow response because of improper acceleration/ deceleration time of the inverter.	(2) Change the acceleration/deceleration time to an optimum value.
8	Speed fluctuates at low speed.	(1) Adverse effect of high carrier frequency.	(1) Decrease *Pr. 72 PWM frequency selection*.
		(2) Low speed control gain.	(2) Increase *Pr. 820 Speed control P gain 1*.

WWW.BSNEW.IR

4.4.5 Speed feed forward control, model adaptive speed control (Pr. 828, Pr. 877 to Pr. 881)

Vector


- By making parameter setting, select the speed feed forward control or model adaptive speed control.
  The speed feed forward control enhances the trackability of the motor in response to a speed command change.
  The model adaptive speed control enables individual adjustment of speed trackability and motor disturbance torque response.

Parameter Number	Name	Initial Value	Setting Range	Description
828	**Model speed control gain**	60%	0 to 1000%	Set the gain for model speed controller.
877	**Speed feed forward control/model adaptive speed control selection**	0	0	Normal speed control is exercised.
			1	Speed feed forward control is exercised.
			2	Model adaptive speed control is enabled.
878	**Speed feed forward filter**	0s	0 to 1s	Set the primary delay filter for the speed feed forward result calculated using the speed command and load inertia ratio.
879	**Speed feed forward torque limit**	150%	0 to 400%	Limits the maximum value of the speed feed forward torque.
880	**Load inertia ratio**	7 times	0 to 200 times	Set the load intertia ratio to the motor.
881	**Speed feed forward gain**	0%	0 to 1000%	Set the feed forward calculation result as a gain.

POINT

When model adaptive speed control is selected, the data obtained from easy gain tuning is used for *Pr. 828 Model speed control gain*. Perform easy gain tuning also (simultaneously). *(Refer to page 104)*

(1) Block diagram



WWW.BSNEW.IR

(2) Speed feed forward control (*Pr. 877* = "1")

- Calculate required torque in responce to the acceleration/deceleration command for the inertia ratio set in *Pr. 880* and generate torque immediately.
- When the speed feed forward gain is 100%, the calculation result of the speed feed forward is reflected as-is.
- If the speed command changes suddenly, large torque is generated due to the speed feed forward calculation. The maximum value of the speed feed forward is limited using *Pr. 879* .
- Using *Pr.878*, the speed feed forward result can be dulled by the primary delay filter.

(3) Model adaptive speed control (*Pr. 877* = "2")

- The motor's model speed is calculated to feed back the model side speed controller. This model speed is also used as the actual speed controller command.
- The inertia ratio in *Pr. 880* is used for calculation of the torque current command value given by the model side speed controller.
- The torque current command value of the model side speed controller is added to the output of the actual speed controller, and the result is used as the iq current control input.
  Pr. 828 is used for model side speed control (P control), and the first gain in *Pr. 820* is used for the actual speed controller. The model adaptive speed control is valid for the first motor only.
- When *Pr. 877* = 2, switching to the second motor handles the second motor as *Pr. 877* = 0.

CAUTION

The adequate gain value for the model and actual loop parts are set according to the responce setting of easy gain tuning under model adaptive speed control. To increase the responce level, the *Pr. 818 Easy gain tuning response level setting* needs to be changed (increased).

(4) Combination of easy gain tuning

The following table indicates the relationships between the speed feed forward/model adaptive speed control and easy gain tuning function.

	Easy Gain Tuning Selection *(Pr. 819)* Setting		
	0	**1**	**2**
Load inertia ratio *(Pr. 880)*	Manual input	Inertia ratio estimation value found by easy gain tuning is displayed. Manual input enabled only during a stop.	Manual input
Speed control P gain 1 *(Pr. 820)*	Manual input	Tuning results are displayed. Write disabled	Tuning results are displayed. Write disabled
Speed control integral time 1 *(Pr. 821)*	Manual input	Tuning results are displayed. Write disabled	Tuning results are displayed. Write disabled
Model speed control gain *(Pr. 828)*	Manual input	Tuning results are displayed. Write disabled	Tuning results are displayed. Write disabled
Speed feed forward gain *(Pr. 881)*	Manual input	Manual input	Manual input

♦Parameters referred to♦

Pr. 820 Speed control P gain 1, Pr. 830 Speed control P gain 2 ☞ *Refer to page 104*
Pr. 821 Speed control integral time 1, Pr. 831 Speed control integral time 2 ☞ *Refer to page 104*

WWW.BSNEW.IR


4.4.6 Torque biases (Pr. 840 to Pr. 848) Vector

This function accelerates the rise of the torque at a start. Adjust the torque at a motor start using the contact signals or analog signals .

Parameter Number	Name	Initial Value	Setting Range	Description
840	Torque bias selection	9999	0	Set the torque bias amount with the contact signal (X42, X43) using *Pr. 841 to Pr. 843*.
			1	Set the terminal 1-based torque bias amount as desired in *C16 to C19* . (in the case a cage goes up when a motor runs reversely)
			2	Set the terminal 1-based torque bias amount as desired in *C16 to C19* . (in the case a cage goes up when a motor runs forward)
			3	The terminal 1-based torque bias amount can be set automatically in *C16 to C19, Pr. 846* according to the load.
			9999	Without torque bias, rated torque 100%
841	Torque bias 1	9999	600 to 999%	Negative torque bias amount (-400% to -1%)
842	Torque bias 2		1000 to 1400%	Positive torque bias amount (0% to 400%)
843	Torque bias 3		9999	Without torque bias setting
844	Torque bias filter	9999	0 to 5s	Time until torque rises.
			9999	Same operation as when 0s is set.
845	Torque bias operation time	9999	0 to 5s	Time for maintaining torque equivalent to the torque bias amount.
			9999	Same operation as when 0s is set.
846	Torque bias balance compensation	9999	0 to 10V	Set the voltage under balanced load.
			9999	Same operation as when 0V is set.
847	Fall-time torque bias terminal 1 bias	9999	0 to 400%	Set the bias value of the torque command.
			9999	Same as at a rise time *(C16, C17 (Pr. 919))*.
848	Fall-time torque bias terminal 1 gain	9999	0 to 400%	Set the gain value of the torque command.
			9999	Same as at a rise time *(C18, C19 (Pr. 920))*.

The above parameters can be set when the FR-A7AP (option) is mounted.

(1) Block diagram



WWW.BSNEW.IR

(2) Setting torque bias amount with the contact input (*Pr. 840* = "0")

- Select the torque bias amount in the table below according to the combination of contact signals.
- Set "42" in *Pr. 178 to Pr. 189 (input terminal function selection)* for the terminal used for X42 signal input and set "43" for the terminal used for X43 signal input to assign functions.

Torque Bias Selection 1 (X42)	Torque Bias Selection 2 (X43)	Torque Bias Amount
OFF	OFF	0%
ON	OFF	*Pr. 841* -400% to +400% (setting value : 600 to 1400%)
OFF	ON	*Pr. 842* -400% to +400% (setting value : 600 to 1400%)
ON	ON	*Pr. 843* -400% to +400% (setting value : 600 to 1400%)





Example) when *Pr. 841* = 1025, 25% when *Pr. 842* = 975, -25% when *Pr. 843* = 925, -75%

CAUTION

Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

(3) Setting torque bias amount with terminal 1 (*Pr. 840* = "1, 2")

- Calculate torque bias from the load input from terminal 1 as shown in the diagram below and provide torque bias.
- When torque bias amount is set from terminal 1, set "6" in *Pr. 868 Terminal 1 function assignment* .

Pr. 840 Setting	Rise (Motor Forward Rotation)	Fall (Motor Reverse Rotation)
1		
2		


WWW.BSNEW.IR

(4) Setting torque bias amount with terminal 1 (*Pr. 840* = "3")


· *C16 Terminal 1 bias command (torque/magnetic flux), C17 Terminal 1 bias (torque/magnetic flux), C18 Terminal 1 gain command (torque/magnetic flux), C19 Terminal 1 gain (torque/magnetic flux), and Pr. 846 Torque bias balance compensation* can be set automatically according to the load.

· When torque command is set from terminal 1, set "6" in *Pr. 868 Terminal 1 function assignment.*

· Setting *C16, C17 (Pr. 919) , C18, C19 (Pr. 920)*



· Setting *Pr. 846*




CAUTION

When starting torque bias operation after completion of automatic setting, set "1 or 2" in *Pr. 840*.

(5) Torque bias operation

· When a value other than 9999 is set in *Pr. 844 Torque bias filter*, you can slow the rise of torque. At this time, the torque rises according to the time constant of the primary delay filter.

· Set the time for output torque be maintained with the torque bias command value alone in *Pr. 845 Torque bias operation time*.



* When pre-excitation is not made, the torque bias functions simultaneously with the start signal.

CAUTION

· When torque bias is made valid and "6" is set in *Pr. 868* , terminal 1 serves as torque command not as frequency setting auxiliary. When override compensation is set by *Pr. 73* and terminal 1 acts as main speed, no main speed (main speed = 0Hz) is slected.

· Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

Reference parameters

· *Pr. 73 Analog input selection* ☞ *Refer to page 282.*

· *Pr. 178 to Pr. 189 (input terminal function selection)* ☞ *Refer to page 228.*

· *C16 to C19 (torque setting voltage (current) bias and gain)* ☞ *Refer to page 295.*

WWW.BSNEW.IR

4.4.7 Prevent the motor from overrunning (Pr. 285, Pr. 853, Pr. 873) Vector


This function prevents the motor from overrunning when the load torque is too large and incorrect number of encoder is set.

Parameter Number	Name	Initial Value	Setting Range	Description
285	Excessive speed deviation detection frequency *1	9999	9999	Without speed deviation excessive
			0 to 30Hz	If the difference (absolute value) between the speed command value and actual speed during speed control under vector control exceeds the *Pr. 285 Excessive speed deviation detection frequency* for more than the time set in *Pr. 853 Speed deviation time*, speed deviation excessive occurs and inverter error (E. OSD) appears, resulting in a stop.
853 *2	Speed deviation time	1.0s	0 to 100s	
873 *2	Speed limit	20Hz	0 to 120Hz	Frequency is limited at the set frequency + *Pr. 873*.

*1 Acts as Overspeed detection frequency under encoder feed back operation. *(Refer to page 214)*
*2 This parameter can be set when the FR-A7AP (option) is mounted.


(1) Speed deviation excessive *(Pr. 285, Pr. 853)*

When the deviation between the set frequency and actual speed is large, e.g. too large load torque, this function can cause the inverter to provide a speed deviation excessive alarm (E.OSD) and come to an alarm stop.



(2) Speed limit *(Pr. 873)*

This function prevents the motor from overrunning when the setting of number of encoder pulses and the actual number differ.
When the setting of number of encoder pulses is smaller than the actual number, the motor may increase its speed. To prevent this, restrict the output frequency with frequency (obtained by adding the set frequency and *Pr. 873*).



CAUTION

- If automatic restart after instantaneous power failure (*Pr. 57* ≠ 9999) is selected when the setting of number of encoder pulses is smaller than the actual number, the output speed is limited with the synchronous speed obtained by adding the maximum setting *(Pr. 1)* and *Pr. 873* setting.
- When speed limit function is activated due to regenerative torque limit, output torque may suddenly decrease. In addition, output phase error (E.LF) may occur when speed limit function is activated during pre-excitation.
  When the setting of number of encoder pulses are correct, it is recommended to set a mamimum value (120Hz) in *Pr. 873*.

Reference parameters

Pr. 285 Overspeed detection frequency ☞ *Refer to page 214.*

WWW.BSNEW.IR

4.4.8 Notch filter (Pr. 862, Pr. 863)

You can reduce the response level of speed control in the resonance frequency band of the mechanical system to avoid mechanical resonance.

Parameter Number	Name	Initial Value	Setting Range	Description
862	Notch filter time constant	0	0 to 60	Refer to the following table
863	Notch filter depth	0	0 to 3	0 (deep) → 3 (shallow)

(1) *Pr. 862 Notch filter time constant*

- If you do not know the mechanical resonance frequency, decrease notch frequency gradually from the highest value. The point at which the smallest vibration is generated is the notch frequency setting.
- Machine characteristic can be obtained beforehand with machine analyzer by FR-Configurator. Necessary notch frequency can be determined from this.

Setting	0	1	2	3	4	5	6	7	8	9
Frequency	Invalid	1000	500	333.3	250	200	166.7	142.9	125	111.1

Setting	10	11	12	13	14	15	16	17	18	19
Frequency	100	90.9	83.3	76.9	71.4	66.7	62.5	58.8	55.6	52.6

Setting	20	21	22	23	24	25	26	27	28	29
Frequency	50	47.6	45.5	43.5	41.7	40	38.5	37	35.7	34.5

Setting	30	31	32	33	34	35	36	37	38	39
Frequency	33.3	32.3	31.3	30.3	29.4	28.6	27.8	27.0	26.3	25.6

Setting	40	41	42	43	44	45	46	47	48	49
Frequency	25.0	24.4	23.8	23.3	22.7	22.2	21.7	21.3	20.8	20.4

Setting	50	51	52	53	54	55	56	57	58	59
Frequency	20.0	19.6	19.2	18.9	18.5	18.2	17.9	17.5	17.2	16.9

Setting	60
Frequency	16.7

(2) *Pr. 863 Notch filter depth*

- The notch filter with deeper depth has an effect on minimizing mechanical resonance. However, large vibration may be generated adversely due to substantial phase delay. Make adjustment of notch depth in order of the shallower depth.

Setting	3	2	1	0
Depth	Shallow	→	←	Deep
Gain	-4dB	-8dB	-14dB	-40dB

WWW.BSNEW.IR


4.5 Torque control by real sensorless vector control, vector control

Purpose	Parameter that must be Set		Refer to Page
Selection of torque command source and setting of torque command value	**Torque command**	**Pr. 803 to Pr. 806**	122
Prevent the motor overspeed	**Speed limit**	**Pr. 807 to Pr. 809**	124
Improve torque control accuracy	**Gain adjustment for torque control**	**Pr. 824, Pr. 825, Pr. 834, Pr. 835**	127
Stabilize the torque detection signal	**Torque detection filter**	**Pr. 827, Pr. 837**	141


4.5.1 Torque control

- Torque control is exercised to develop torque as set in the torque command.
- The motor speed becomes constant when the motor output torque and load torque are balanced. For torque control, therefore, the speed is determined by the load.
- For torque control, the motor gains speed as the motor output torque becomes greater than the motor load. To prevent overspeed, set the speed limit value so that the motor speed does not increase too high. (Torque control is disabled under speed limit since speed control is exercised.)
- When speed limit is not set, the speed limit value setting is regarded as 0Hz to disable torque control.

(1) Operation transition



· When "0" is set in *Pr. 7* or *Pr. 8* , speed control is exercised upon powering off a start signal and the output torque is limited at the torque limit value.




Item	Description	
Start signal	External operation	STF, STR signal
	PU operation	(FWD) and (REV) of FR-DU07, FR-PU07 or FR-PU04
Torque command	Select the input method of torque command and input the torque command.	
Speed limit	Select the input method of speed limit and input the speed limit value.	

WWW.BSNEW.IR

(2) Operation example (when *Pr. 804* = "0")

Torque control is enabled if the actual speed is less than the speed limit value.
When the actual speed reaches or exceeds the speed limit value, speed limit operation starts, torque control is stopped, and speed control (proportional control) starts.
The following shows the operations in response to the analog input command from terminal 1.



*When the speed limit activates, torque according to the commanded is not developed.

1) When STF signal is turned on, the speed limit value is increased according to the time set in *Pr. 7* .
2) Speed control operation is performed if the actual speed rises to or above the speed limit value.
3) When the STF signal is turned off, the speed limit value is decreased according to the time set in *Pr. 8* .
4) For torque control, the actual speed becomes constant when the torque command and load torque are balanced.
5) The motor torque developing direction is determined by the combination of the torque command input polarity and start signal as indicated in the following table.

Torque Command Polarity	Torque Developing Direction	
	STF signal ON	STR signal ON
Positive torque command	Forward rotation direction (forward rotation driving/reverse rotation regeneration)	Reverse rotation direction (forward rotation regeneration/reverse rotation driving)
Negative torque command	Reverse rotation direction (forward rotation regeneration/reverse rotation driving)	Forward rotation direction (forward rotation driving/reverse rotation regeneration)

REMARKS


- When speed limit operation starts, speed control is exercised to enable internal torque limit (*Pr. 22 torque limit level*) (initial value). Speed control may not be returned to torque control in this case.
  Torque limit be set to external torque limit (terminal 1, 4). (*Refer to page 99*.)
- Undervoltage avoidance function (*Pr. 261* = "11, 12") of power-failure deceleration stop function is made invalid under torque control. When *Pr. 261* = "11 (12)", the inverter operates in the same manner as when "1 (2)" is set in *Pr. 261*.
- Set linear acceleration/deceleration (*Pr. 29* = "0 (initial value)") when torque control is exercised. When acceleration/deceleration patterns other than the linear acceleration/deceleration are selected, the protective function of the inverter may function. *(Refer to page 176)*

CAUTION

- Performing pre-excitation (LX signal and X13 signal) under torque control (real sensorless vector control) may start the motor running at a low speed even when the start command (STF or STR) is not input. The motor may run also at a low speed when the speed limit value = 0 with a start command input. Perform pre-excitation after making sure that there will be no problem in safety if the motor runs.

WWW.BSNEW.IR

4.5.2 Setting procedure of real sensorless vector control (torque control)



CAUTION

- Make sure to perform offline auto tuning before performing real sensorless vector control.
- The carrier frequencies are selectable from among 2k, 6k, 10k, 14kHz for real sensorless vector control.
- Torque control can not be performed in the low speed (approx. 10Hz or less) regeneration range and with light load at low speed (approx. 20% or less of rated torque at approx. 5Hz or less). Choose vector control.
- Performing pre-excitation (LX signal and X13 signal) under torque control may start the motor running at a low speed even when the start command (STF or STR) is not input. The motor may run also at a low speed when the speed limit value = 0 with a start command input. Perform pre-excitation after making sure that there will be no problem in safety if the motor runs.
- Do not switch between the STF (forward rotation command) and STR (reverse rotation command) during operation under torque control. Overcurrent shut-off error (E.OC☐) or opposite rotation deceleration error (E.11) occurs.
- For the FR-A720-00030 to 00175 (FR-A740-00015 to 00090), the speed deviation may become large at 20Hz or less and torque may become insufficient in the low speed region under 1Hz during continuous operation under real sensorless vector control. In this case, stop the inverter once, then start (online auto tuning) again to improve.
- When the inverter is likely to start during motor coasting under real sensorless vector control, set to make frequency search of automatic restart after instantaneous power failure valid (*Pr. 57* ≠ "9999", *Pr. 162* = "10").
- Enough torque may not be generated in the ultra-low speed range less than approx. 2Hz when performing real sensorless vector control.
  The guideline of speed control range is as shown below.

Driving:	1:200	(2, 4, 6 poles)	Can be used at 0.3Hz or more at rated 60Hz
	1:30	(8, 10 poles)	Can be used at 2Hz or more at rated 60Hz
Regeneration:	1:12	(2 to 10 poles)	Can be used at 5Hz or more at rated 60Hz

WWW.BSNEW.IR

4.5.3 Setting procedure of vector control (torque control) Vector

Perform secure wiring. *(Refer to page 39.)*

↓ Mount the FR-A7AP.

Set the motor and encoder. *(Pr. 71, Pr. 359, Pr. 369)*

↓ Set *Pr. 71 Applied motor*, *Pr. 359 Encoder rotation direction* and *Pr. 369 Number of encoder pulses* according to the motor and encoder used. *(Refer to page 41.)*

Set the motor capacity and the number of motor poles. *(Pr. 80, Pr. 81)* *(Refer to page 92.)*

↓ Set the motor capacity (kW) in *Pr. 80 Motor capacity* and set the number of motor poles in *Pr. 81 Number of motor poles*. (V/F control is performed when the setting is "9999" (initial value).)

Select a control method. *(Refer to page 92.)*

↓ Set either "1" (torque control), "2" (speed-torque switchover) or "5" (position-torque switchover) in *Pr. 800* and make torque control valid.

Set the torque command. *(Pr. 804)* *(Refer to page 122.)*

↓

Set the speed limit. *(Pr. 807)* *(Refer to page 124.)*

↓

Test run

As required

- Perform offline auto tuning. *(Pr. 96) (refer to page187).*
- Select online auto tuning. *(Pr. 95) (refer to page 197).*
- Manual input torque control gain adjustment *(refer to page 127)*

CAUTION

- The carrier frequencies are selectable from among 2k, 6k, 10k, 14kHz for vector control. (2k and 6kHz for the FR-A720-02880 (FR-A740-01440) or more)

WWW.BSNEW.IR


4.5.4 Torque command (Pr. 803 to Pr. 806)

Vector


Torque command source for torque control can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description	
803	Constant power range torque characteristic selection	0	0	Constant motor output command	Select the torque command in the constant power region by torque command setting.
			1	Constant torque command	
804	Torque command source selection	0	0	Torque command by terminal1 analog input *(Refer to page 295)*	
			1	Torque command by parameter setting (*Pr. 805* or *Pr. 806*) (-400% to 400%)	
			3	Torque command by parameter setting (*Pr. 805* or *Pr. 806*) (-400% to 400%)	Torque command with using CC-Link communication (FR-A7NC) Setting from the remote resister can be made. (-400% to 400%)
			4	12 bit/16 bit digital input (FR-A7AX)	
			5	Torque command by parameter setting (*Pr. 805* or *Pr. 806*) with using communication other than CC-Link communication (-400% to 400%)	Torque command with using CC-Link communication (FR-A7NC) Setting from the remote resister can be made. (-327.68% to 327.67%)
			6		Torque command with using CC-Link communication (FR-A7NC) (-327.68% to 327.67%)
805	Torque command value (RAM)	1000%	600 to 1400%	Writes the torque command value to the RAM. On the assumption that 1000% is 0%, the torque command is set by an offset from 1000%.	
806	Torque command value (RAM,EEPROM)	1000%	600 to 1400%	Writes the torque command value to the RAM and EEPROM. On the assumption that 1000% is 0%, the torque command is set by an offset from 1000%.	

(1) Control block diagram




(2) Torque command (*Pr. 804* = "0" (initial value)) by analog input (terminal 1)



- Torque command is given by voltage (current) input to terminal 1.
- When torque command is input from terminal 1, set "4 or 3" in *Pr. 868 Terminal 1 function assignment*.
- Torque command by analog input can be calibrated using *calibration parameter C16 (Pr. 919) to C19 (Pr. 920) . (Refer to page 295)*

WWW.BSNEW.IR

(3) Torque command using parameters (*Pr. 804* = "1")



- Torque command value can be set by setting *Pr. 805 Torque command value (RAM)* or *Pr. 806 Torque command value (RAM,EEPROM)* .
- For *Pr. 805* or *Pr. 806*, the torque command is set by an offset from 1000% on the assumption that 1000% is 0%. The relationship between the *Pr. 805* or *Pr. 806* setting and actual torque command value at this time is shown on the left.
- When changing the torque command frequently, write to *Pr. 805*. Performing frequent parameter write to *Pr. 806* will shorten the life of the EEPROM.

REMARKS

- When torque command is set in *Pr. 805* (RAM), powering off the inverter will erase the changed parameter values. Therefore, the parameter value available when power is switched on again is the value set in *Pr. 806* (EEPROM).

CAUTION

- When giving a torque command by parameter setting, set the speed limit value to an appropriate value to prevent overspeed. *(Refer to page 124.)*

(4) Torque command by CC-Link communication (*Pr. 804* = "3, 5, 6")

- Writing a value to *Pr. 805* or *Pr. 806* using the FR-A7NC (communication option) sets the torque command value.
- When "3 or 5" is set in *Pr.804*, torque command can be set in remote resister RWw1 or RWwC using the FR-A7NC (communication option).
- By setting "5, 6" in *Pr.804*, the range of torque command setting from FR-A7NC (communication option) is set from -327.68% to 327.67% (0.01% increments).

Pr. 804 Setting	Torque Command Source	Setting Range	Increments
1	Torque command by parameter setting *(Pr. 805 or Pr. 806)*	600 to 1400 (-400% to 400%)	1%
3	Torque command by parameter setting *(Pr. 805 or Pr. 806)*	600 to 1400 (-400% to 400%)	1%
	Torque command from remote resister (RWw1 or RWwC) with using CC-Link communication (FR-A7NC)		
5	Torque command by parameter setting *(Pr. 805 or Pr. 806)* without using CC-Link communication (FR-A7NC)	600 to 1400 (-400% to 400%)	1%
	Torque command by parameter setting *(Pr. 805 or Pr. 806)* with using CC-Link communication (FR-A7NC)	-32768 to 32767 (two's complement) (-327.68% to 327.67%)	0.01%
	Torque command from remote resister (RWw1 or RWwC) with using CC-Link communication (FR-A7NC)	-32768 to 32767 (two's complement) (-327.68% to 327.67%)	0.01%
6	Torque command by parameter setting *(Pr. 805 or Pr. 806)* without using CC-Link communication (FR-A7NC)	600 to 1400 (-400% to 400%)	1%
	Torque command by parameter setting *(Pr. 805 or Pr. 806)* with using CC-Link communication (FR-A7NC)	-32768 to 32767 (two's complement) (-327.68% to 327.67%)	0.01%

REMARKS

For details of the setting with the FR-A7NC, refer to the FR-A7NC instruction manual.


(5) Torque command by 16 bit digital input (*Pr. 804* = 4)

- Give a torque command by 16 bit or 12 bit digital input using the FR-A7AX (plug-in option).

REMARKS

For details of the setting with the FR-A7AX, refer to the FR-A7AX instruction manual.

(6) Change the torque characteristics in the constant power (*Pr. 803*)



- Due to the motor characteristics, torque is reduced at or above the base frequency. Set "1" in *Pr. 803 Constant power range torque characteristic selection* when you want to keep the torque to be constant even at or above the base frequency.

♦Parameters referred to♦

Pr. 868 Terminal 1 function assignment ☞ *Refer to page 99.*
Calibration parameter C16 (Pr. 919) to C19 (Pr. 920) (terminal 1 bias, gain torque) ☞ *Refer to page 295*


WWW.BSNEW.IR

4.5.5 Speed limit (Pr. 807 to Pr. 809)


Set the speed limit value to prevent overspeed of the motor in case the load torque becomes less than the torque command value, etc. during torque control operation.

Parameter Number	Name	Initial Value	Setting Range	Description
807	Speed limit selection	0	0	Use the speed command value during speed control as speed limit.
			1	According to *Pr. 808* and *Pr. 809* , set the speed limit in forward and reverse rotation directions individually.
			2	Forward/reverse rotation speed limit The analog voltage of the terminal 1 input is used to make speed limit. The speed limit of the forward rotation and reverse rotation is switched according to the polarity.
808	Forward rotation speed limit	60Hz	0 to120Hz	Set the speed limit for the forward rotation direction.
809	Reverse rotation speed limit	9999	0 to120Hz	Set the speed limit of the reverse rotation side.
			9999	As set in *Pr. 808* .

(1) Control block diagram



WWW.BSNEW.IR



(2) Use the speed command for speed control (*Pr. 807* = "0" initial value)

- Set the speed limit in the same method as speed setting for speed control (speed setting by the PU (FR-DU07/ FR-PU07/FR-PU04), multi-speed setting, options, etc.)
- According to the acceleration time set in *Pr. 7 Acceleration time*, the limit level is increased from 0Hz upon turning on of the start signal, and when the start signal turns off, the speed limit level is decreased from the then speed limit level to the DC injection brake operation speed in *Pr. 10* to a stop in accordance with the deceleration time set in *Pr. 8 Deceleration time*.

REMARKS


- When the above speed limit command is greater than the *Pr. 1 Maximum frequency* value, the speed limit value is the *Pr. 1 Maximum frequency* value, and when the speed limit command is less than the *Pr. 2 Minimum frequency* value, the speed limit value is the *Pr. 2 Minimum frequency* value. Similarly when the speed limit command is smaller than *Pr. 13 Starting frequency* , the speed limit value is 0Hz.
- When speed limit is to be made using analog input, perform calibration of the analog input terminal 1, 2 and 4. *(Refer to page 295.)*

CAUTION

When speed limit is to be made using the analog command (terminal 1,2,4), turn off the external signals (RH, RM, RL). If any of external signals (RH, RM, RL) is on, multi-speed limits are made valid.

(3) Set the forward rotation and reverse rotation individually (*Pr. 807* = "1")

Set the speed limit during foward rotation using *Pr. 808 Forward rotation speed limit* and the speed limit during reverse rotation using *Pr. 809 Reverse rotation speed limit*.
The speed during forward and reverse rotation is limited at the setting value of *Pr. 808* when "9999" (initial value) is set in *Pr. 809* .





WWW.BSNEW.IR

(4) Forward rotation/reverse rotation speed limit (*Pr. 807* = "2")


- When making a speed limit using analog input from terminal 1, the speed limit of the forward and reverse rotation can be switched according to the polarity of voltage.
- Forward/reverse rotation speed limit is made valid when *Pr. 868 Terminal 1 function assignment* = "5".
- For 0 to 10V input, set the forward rotation speed limit. The reverse rotation speed limit at this time is the value of *Pr.1 Maximum frequency*.
- For -10 to 0V input, set the reverse rotation speed limit. The forward rotation speed limit at this time is the value of *Pr. 1 Maximum frequency* .
- The maximum speed of both the forward and reverse rotations is *Pr. 1 Maximum frequency* .


●When terminal 1 input is "-10 to 0V"





●When terminal 1 input is "0 to 10V"





REMARKS

- When making speed limit from terminal 1, make calibration of terminal 1. *(Refer to page 295.)*

CAUTION

When the actual speed reaches or exceeds the speed limit value, torque control is switched to speed control to prevent overspeed.

SL (SL) appears on the operation panel during speed limit operation and the OL signal is output.

♦Parameters referred to♦

Pr. 1 Maximum frequency, Pr. 2 Minimum frequency ☞ *Refer to page 157*
Pr. 7 Acceleration time, Pr. 8 Deceleration time ☞ *Refer to page 173*
Pr. 13 Starting frequency ☞ *Refer to page 175*
Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239 (Multi-speed operation) ☞ *Refer to page 166*
Pr. 868 Terminal 1 function assignment ☞ *Refer to page 281*
Pr. 125, Pr. 126, C2 to C7, C12 to C15 (frequency setting voltage (current) bias/gain) ☞ *Refer to page 289*

WWW.BSNEW.IR

4.5.6 Gain adjustment of torque control (Pr. 824, Pr. 825, Pr. 834, Pr. 835)

Vector

Although stable operation is possible with the initial value, make adjustment when any of such phenomena as unusual motor and machine vibration/noise and overcurrent has occurred.

Parameter Number	Name	Initial Value	Setting Range	Description
824	Torque control P gain 1	100%	0 to 200%	Set the current loop proportional gain. 100% is equivalent to 2000rad/s.
825	Torque control integral time 1	5ms	0 to 500ms	Set the current loop integral compensation time.
834	Torque control P gain 2	9999	0 to 200%	Set the current loop proportional gain when the RT signal is on.
			9999	Without torque control P gain 2 function
835	Torque control integral time 2	9999	0 to500ms	Set the current loop integral compensation time when the RT signal is on.
			9999	Without torque control integral time 2 function

(1) Adjustment of current loop proportional (P) gain

- For general adjustment, make setting within the range 50 to 200% as a guideline.
- Set the proportional gain for torque control.
- Increasing the value improves trackability in response to a current command change and reduces current variation with disturbance. However, a too large gain will cause instability, generating harmonic torque pulsation.

(2) Adjustment of current control integral time

- Set the integral time of current control during torque control.
- A small value enhances the torque response level, but a too small value will cause current fluctuation.
- Decreasing the value shortens the time taken to return to the original torque if current variation with disturbance occurs.

(3) Use multiple gains

- When you want to change the gain according to applications, switch multiple motors with one inverter, etc., use *Torque control P gain 2* and *Torque control integral time 2* .
- *Pr. 834 Torque control P gain 2* and *Pr. 835 Torque control integral time 2* are valid when the RT signal is on.

REMARKS

- The RT signal acts as the second function selection signal and makes the other second functions valid. *(Refer to page 232.)*
- The RT signal is assigned to the terminal RT in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* , you can assign the RT signal to the other terminal.

WWW.BSNEW.IR

(4) Adjustment procedure

Make adjustment when any of such phenomena as unusual motor and machine vibration/noise/current and overcurrent has occurred.

1)Check the conditions and simultaneously change the *Pr. 824* value.

2)If you cannot make proper adjustment, change the *Pr. 825* value and repeat step 1).

Adjustment Method	
Set *Pr. 824* a little lower and *Pr. 825* a little higher. First lower *Pr. 824* and check the motor for unusual vibration/noise and overcurrent. If the problem still persists, increase *Pr. 825* .	
Pr. 824	Decrease the value 10% by 10% until just before unusual noise and current are improved, and set about 0.8 to 0.9 of that value. Note that a too low value will produce current ripples, causing the motor to generate sound synchronizing the cycle of current ripples.
Pr. 825	Increase the current value double by double until just before an unusual noise and current does not occur, and set about 0.8 to 0.9 of that value. Note that taking a too long time will produce current ripples, causing the motor to generate sound synchronizing the cycle of current ripples.

(5) Troubleshooting (Torque)

	Phenomenon	Cause	Countermeasures
1	Torque control is not exercised normally.	(1) The phase sequence of the motor or encoder wiring is wrong.	(1) Check the wiring. *(Refer to page 14)*
		(2) The *Pr. 800 Control method selection* setting is improper.	(2) Check the *Pr. 800* setting. *(Refer to page 92)*
		(3) The speed limit value is not input.	(3) Set the speed limit value. (If the speed limit value is not input, the motor will not rotate since the speed limit value is regarded as 0Hz.)
		(4) The torque command varies.	(4)-1 Check that the command device gives a correct torque command. (4)-2 Decrease *Pr. 72 PWM frequency selection* . (4)-3 Increase *Pr. 826 Torque setting filter 1*
		(5) The torque command does not match the inverter-recognized value.	(5) Recalibrate *C16 Terminal 1 bias command (torque/ magnetic flux), C17 Terminal 1 bias (torque/magnetic flux), C18 Terminal 1 gain command (torque/magnetic flux), C19 Terminal 1 gain (torque/magnetic flux). (Refer to page 295)*
		(6) Torque variation due to the change in the motor temperature.	(6) Select magnetic flux observer by setting *Pr. 95 Online auto tuning selection. (Refer to page 197)*
2	When the torque command is small, the motor rotates in the direction opposite to the start signal.	The offset calibration of the torque command does not match.	Recalibrate *C16 Terminal 1 bias command (torque/magnetic flux)* and *C17 Terminal 1 bias (torque/magnetic flux). (Refer to page 295)*
3	Normal torque control cannot be exercised during acceleration/ deceleration. The motor vibrates.	The speed limit is activated. (When *Pr. 807* = "0, 2", the speed limit may be activated since the speed limit value changes with the setting of the acceleration/ deceleration time in *Pr. 7* and *Pr. 8*.)	Reduce the acceleration/deceleration time. Or, set the acceleration/deceleration time to "0". (The speed limit during acceleration/deceleration depends on the speed limit during the constant speed.)
4	Output torque is not linear in response to the torque command.	Insufficient torque.	Return the excitation ratio in *Pr. 854* to the initial value.

♦Parameters referred to♦

Pr. 72 PWM frequency selection ☞ *Refer to page 279*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*
Pr. 800 Control method selection ☞ *Refer to page 92*
Pr. 807 Speed limit selection ☞ *Refer to page 124*
C16 to C19 (torque setting voltage (current) bias and gain) ☞ *Refer to page 295*

WWW.BSNEW.IR

4.6 Position control by vector control

Purpose	Parameter that must be Set		Refer to Page
Conditional position control by parameter setting	**Position command by parameter**	**Pr. 419, Pr. 464 to Pr. 494**	131
Position control by pulse train input of the inverter	**Position command by conditional pulse train**	**Pr. 419, Pr. 428 to Pr. 430**	134
Adjust the gear ratio of motor and machine	**Setting the electronic gear**	**Pr. 420, Pr. 421, Pr. 424**	136
Setting of positioning adjustment parameter	**In-position width Excessive level error**	**Pr. 426, Pr. 427**	137
Improve position control accuracy	**Gain adjustment of position control**	**Pr. 422, Pr. 423, Pr. 425**	138

4.6.1 Position control Vector

- In the position control, the speed command is calculated so that the difference between command pulse (or parameter setting) and the number of feedback pulses from the encoder is zero to run the motor.
- This inverter can perform conditional position feed by contact input and position control by inverter conditional pulse input.

(1) Setting procedure

Perform secure wiring. *(Refer to page 40.)*

↓ Mount the FR-A7AP.

Set the motor and encoder. *(Pr. 71, Pr. 359, Pr. 369)*

↓ Set *Pr. 71 Applied motor*, *Pr. 359 Encoder rotation direction* and *Pr. 369 Number of encoder pulses* according to the motor and encoder used. *(Refer to page 41.)*

Set the motor capacity and the number of motor poles. *(Pr. 80, Pr. 81) (Refer to page 92.)*

↓ Set the motor capacity (kW) in *Pr. 80 Motor capacity* and set the number of motor poles (number of poles) in *Pr. 81 Number of motor poles*. (V/F control is performed when the setting is "9999" (initial value).)

Select a control method. *(Refer to page 92.)*

↓ Make speed control valid by selecting "3" (position control) "4" (speed-position switchover) or "5" (position-torque switchover) for *Pr. 800*.

Selection of position command source. *(Pr. 419)*

↓ Position command by contact input
Set "0" (initial value) in *Pr. 419*.

↓ Position command by inverter pulse train input
Set "2" in *Pr. 419*.

Setting of parameter for position feed *(Pr. 465 to Pr. 494)*. *(Refer to page 131.)*

Selection of command pulse form. *(Pr. 428)* *(Refer to page 134.)*

↓

Test run

As required


- Set the electronic gear. *(refer to page 136)*
- Setting of positioning adjustment parameter *(refer to page 137)*
- Gain adjustment of position control *(refer to page 138)*

CAUTION

- The carrier frequencies are selectable from among 2k, 6k, 10k, 14kHz for vector control. (2k and 6kHz for the FR-A720-02880 (FR-A740-01440) or more)

WWW.BSNEW.IR


(2) Control block diagram



(3) Example of operation

The speed command given to rotate the motor is calculated to zero the difference between the number of internal command pulse train pulses (when *Pr. 419* = 0, the number of pulses set by parameter *(Pr. 465 to Pr. 494)* is changed to the command pulses in the inverter) and the number of pulses fed back from the motor end encoder.

1) When a pulse train is input, pulses are accumulated in the deviation counter and these droop pulses act as position control pulses to give the speed command.
2) As soon as the motor starts running under the speed command of the inverter, the encoder generates feed back pulses and the droop of the deviation counter is counted down. The deviation counter maintains a given droop pulse value to keep the motor running.
3) When the command pulse input stops, the droop pulses of the deviation counter decrease, reducing the speed. The motor stops when there are no droop pulses.
4) When the number of droop pulses has fallen below the value set in *Pr. 426 In-position width* , it is regarded as completion of positioning and the in-position signal (Y36) turns on.



- For conditional position control function by contact input, the STF and STR terminals provide the forward (reverse) command signal. The motor can run only in the direction where the forward (reverse) signal is on. Turning the STF signal off does not run the motor forward and turning the STR signal off does not run the motor reverse.
- The pulse train is rough during acceleration and coarse at the maximum speed. During deceleration the pulse train is rough and at last there are no pulses. The motor stops shortly after the command pulses stop.
  This time lag is necessary for maintaining the stop accuracy and called stop settling time.

REMARKS

- For the servo on signal (LX), set "23" in *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.
- For the in-position signal (Y36), set "36" in *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function.

WWW.BSNEW.IR

CAUTION

Changing the terminal function using any of *Pr. 178 to Pr. 189, 190 to Pr. 196* may affect the other functions. Make setting after confirming the function of each terminal.

♦Parameters referred to♦

Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*
Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*

4.6.2 Conditional position feed function by contact input (Pr. 419, Pr. 464 to Pr. 494)

Vector

Inputting the number of pulses (positions) in the parameters and setting multi-speed and forward (reverse) commands enable position control. The motor does not return to the home position with this conditional position feed function .

Parameter Number	Name	Initial Value	Setting Range	Description
419	Position command source selection	0	0	Conditional position control function by contact input. (position command by parameter settings)
			2	Conditional pulse train position command by inverter pulse train input
464	Digital position control sudden stop deceleration time	0s	0 to 360.0s	Set the time until the inverter stops when the forward rotation (reverse rotation) command is turned off with the position feed forward function.

Parameter Number	Name	Initial Value	Setting Range	Selection Method (OFF: ×, ON: ○)				Position feed frequency
				REX	RH	RM	RL	
465	First position feed amount lower 4 digits	0	0 to 9999	×	○	×	×	High speed *(Pr. 4)*
466	First position feed amount upper 4 digits	0	0 to 9999					
467	Second position feed amount lower 4 digits	0	0 to 9999	×	×	○	×	Middle speed *(Pr. 5)*
468	Second position feed amount upper 4 digits	0	0 to 9999					
469	Third position feed amount lower 4 digits	0	0 to 9999	×	×	×	○	Low speed *(Pr. 6)*
470	Third position feed amount upper 4 digits	0	0 to 9999					
471	Fourth position feed amount lower 4 digits	0	0 to 9999	×	×	○	○	4 speed *(Pr. 24)*
472	Fourth position feed amount upper 4 digits	0	0 to 9999					
473	Fifth position feed amount lower 4 digits	0	0 to 9999	×	○	×	○	5 speed *(Pr. 25)*
474	Fifth position feed amount upper 4 digits	0	0 to 9999					
475	Sixth position feed amount lower 4 digits	0	0 to 9999	×	○	○	×	6 speed *(Pr. 26)*
476	Sixth position feed amount upper 4 digits	0	0 to 9999					
477	Seventh position feed amount lower 4 digits	0	0 to 9999	×	○	○	○	7 speed *(Pr. 27)*
478	Seventh position feed amount upper 4 digits	0	0 to 9999					
479	Eighth position feed amount lower 4 digits	0	0 to 9999	○	×	×	×	8 speed *(Pr. 232)*
480	Eighth position feed amount upper 4 digits	0	0 to 9999					

WWW.BSNEW.IR

Parameter Number	Name	Initial Value	Setting Range	Selection Method (OFF: ×, ON: ○)				Position feed frequency
				REX	RH	RM	RL	
481	Ninth position feed amount lower 4 digits	0	0 to 9999	○	×	×	○	9 Speed *(Pr. 233)*
482	Ninth position feed amount upper 4 digits	0	0 to 9999					
483	Tenth position feed amount lower 4 digits	0	0 to 9999	○	×	○	×	10 speed *(Pr. 234)*
484	Tenth position feed amount upper 4 digits	0	0 to 9999					
485	Eleventh position feed amount lower 4 digits	0	0 to 9999	○	×	○	○	11 speed *(Pr. 235)*
486	Eleventh position feed amount upper 4 digits	0	0 to 9999					
487	Twelfth position feed amount lower 4 digits	0	0 to 9999	○	○	×	×	12 speed *(Pr. 236)*
488	Twelfth position feed amount upper 4 digits	0	0 to 9999					
489	Thirteenth position feed amount lower 4 digits	0	0 to 9999	○	○	×	○	13 speed *(Pr. 237)*
490	Thirteenth position feed amount upper 4 digits	0	0 to 9999					
491	Fourteenth position feed amount lower 4 digits	0	0 to 9999	○	○	○	×	14 speed *(Pr. 238)*
492	Fourteenth position feed amount upper 4 digits	0	0 to 9999					
493	Fifteenth position feed amount lower 4 digits	0	0 to 9999	○	○	○	○	15 speed *(Pr. 239)*
494	Fifteenth position feed amount upper 4 digits	0	0 to 9999					

The above parameters can be set when the FR-A7AP (option) is mounted.

WWW.BSNEW.IR


(1) Setting of position feed amount by parameter

·Set position feed amount in *Pr. 465 to Pr. 494* .
·The feed amount set in each parameter is selected by mult-speed terminal (RH, RM, RL, REX).
·Set (encoder resolution × speed × 4 times) for position feed amount.
·For example, the formula for stopping the motor after 100 rotations using the FR-V5RU is as follows:

2048 (pulse/rev) × 100 (speed) × 4 = 819200 (feed amount)

To set 819200 for the first position feed amount, divide the value into upper four digits and lower four digits and set 81 (decimal) in *Pr. 466* (upper) and 9200 (decimal) in *Pr. 465* (lower).

(2) Position command operation by parameter



· For deceleration by turning the STF(STR) off, use *Pr. 464 Digital position control sudden stop deceleration time* to set deceleration time.

REMARKS

· Acceleration/deceleration time is 0.1s minimum and 360s maximum.
· *Pr. 20 Acceleration/deceleration reference frequency* is clamped at a minimum of 16.66Hz (500r/min).
· The acceleration/deceleration patterns for position control are all linear acceleration and the setting of *Pr. 29 Acceleration/deceleration pattern selection* is invalid.

CAUTION

Information on multi-speed command (position command by RL, RM, RH, and REX signals) is determined at rising of the forward (reverse) command to perform position control. Therefore, set forward (reverse) command after multi-speed command (position command). Position feed is invalid if the multi-speed command is given after forward (reverse) command.

♦Parameters referred to♦

Pr. 20 Acceleration/deceleration reference frequency ☞ *Refer to page 173*
Pr. 29 Acceleration/deceleration pattern selection ☞ *Refer to page 176*

WWW.BSNEW.IR

4.6.3 Position control (Pr. 419, Pr. 428 to Pr. 430) by inverter pulse train input Vector


Conditional position pulse train command can be input by pulse train input and sign signal (NP) from the JOG terminal.

Parameter Number	Name	Initial Value	Setting Range	Description	
419	Position command source selection	0	0	Conditional position control function by contact input. (position command by parameter settings)	
			2	Conditional pulse train position command by inverter pulse train input	
428	Command pulse selection	0	0 to 2	Pulse train + sign	Negative logic
			3 to 5		Positive logic
429	Clear signal selection	1	0	Deviation counter is cleared at edge of turning on of the clear signal (CLR) from off.	
			1	Deviation counter while the clear signal (CLR) is on	
430	Pulse monitor selection	9999	0 to 5	The status of various pulses during runnning is displayed.	
			9999	Frequency monitor is displayed.	

The above parameters can be set when the FR-A7AP (option) is mounted.



(1) Operation

Turning on the servo on signal (LX) cancels the output shut-off and the operation ready signal (RDY) turns on after 0.1s. Turning on the STF (forward stroke end signal) or STR (forward stroke end signal) runs the motor according to the commanded pulse. When the forward (reverse) stroke end signal turns off, the motor does not run in that direction.



(2) Pulse train form type selection (*Pr. 428*, NP signal)

1)Set "2"(conditional pulse train position command) in *Pr. 419*.
2)Set "68" in *Pr. 178 to Pr. 189 (input terminal function selection)* to assign conditional position pulse train sign (NP).
3)Select command pulse train using *Pr. 428*

Pr. 428 Setting	Command Pulse Train Type		At Forward Rotation	At Reverse Rotation
0 to 2	Negative logic	Pulse train + sign		
3 to 5	Positive logic	Pulse train + sign		

4)Select vector control, then select position control.


REMARKS

- When *Pr. 419 Position command source selection* = "2" (conditional pulse train position command), JOG terminal serves as conditional position pulse train input terminal regardless of the *Pr. 291 Pulse train I/O selection* setting.

WWW.BSNEW.IR

(3) Selection of clear signal (*Pr. 429*, CLR signal)

· Use this function to zero the droop pulse for home position operation, etc.
· When "0" is set in *Pr. 429* , the deviation counter is cleared at the edge of truning on of the clear signal (CLR). In addition, the CLR signal turns on in synchronization with zero pulse signal of the encoder at home position operation, etc., deviation counter is cleared.
· For the terminal used for CLR signal, set "69" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.



(4) Pulse monitor selection (*Pr. 430*)

The status of various pulses during running is displayed.
Set "6" in *Pr. 52 DU/PU main display data selection* to display output frequency monitor.

Pr. 430 Setting	Description	Display Range (FR-DU07)	Display Range (FR-PU04/FR-PU07)
0	The cumulative command pulse value is displayed.	Lower 4 digits	Lower 5 digits
1		Upper 4 digits	Upper 5 digits
2	The cumulative feedback pulse value is displayed.	Lower 4 digits	Lower 5 digits
3		Upper 4 digits	Upper 5 digits
4	The droop pulses are monitored.	Lower 4 digits	Lower 5 digits
5		Upper 4 digits	Upper 5 digits
9999	Frequency monitor is displayed. (initial value)		

REMARKS

· Count the number of pulses when the servo is on.
· The cumulative pulse value is cleared when the base is shut off or the clear signal (CLR) is turned on.

CAUTION

· Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

♦Parameters referred to♦

Pr. 52 DU/PU main display data selection ☞ *Refer to page 250*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*

WWW.BSNEW.IR

4.6.4 Setting of the electronic gear (Pr. 420, Pr. 421, Pr. 424) Vector

Set the ratio of the machine side gear and the motor side gear.

Parameter Number	Name	Initial Value	Setting Range	Description
420	Command pulse scaling factor numerator	1	0 to 32767 *	Set the electric gear. *Pr. 420* is a numerator and *Pr. 421* is a denominator.
421	Command pulse scaling factor denominator	1	0 to 32767 *	
424	Position command acceleration/deceleration time constant	0s	0 to 50s	Used when rotation has become unsmooth at a large electronic gear ratio (about 10 times or more) and low speed.

The above parameters can be set when the FR-A7AP (option) is mounted.

* When the operation panel (FR-DU07) is used, the maximum setting is 9999. When a parameter unit is used, up to the maximum value within the setting range can be set.

(1) Calculation of the gear ratio *(Pr. 420, Pr. 421)*

· The position resolution (travel per pulse $\Delta\ell$ [mm]) is determined by the travel per motor revolution Δs [mm] and the feedback pulses Pf [pulse/rev] of the detector, and is represented by the following expression.

$$\Delta\ell = \frac{\Delta s}{Pf}$$

$\Delta\ell$:travel per pulse [mm]
Δs: travel per motor rotation [mm]
Pf: number of feedback pulses [pulse/rev] (number of pulses after multiplying the number of encoder pulses by four)

Using the parameters, the travel per command pulse can be set separately to set the travel per command pulse without a fraction.

$$\Delta\ell = \frac{\Delta s}{Pf} \times \frac{Pr.\ 420}{Pr.\ 421}$$

In addition, the relationship between the motor speed and internal command pulse frequency is as follows:

$$fo \times \frac{Pr.\ 420}{Pr.\ 421} = Pf \times \frac{No}{60}$$

fo : Internal command pulse frequency [pps]
No : Motor speed [r/min]

CAUTION

Set the electronic gear in the range of 1/50 to 20.
Note that too small a value will decrease the speed command and too large a value will increase the speed ripples.

[Setting example 1]

The electronic gear ratio is Δs = 10 (mm) when the travel per pulse $\Delta\ell$ = 0.01 (mm) and the number of feedback pulses Pf = 4000 (pulse/rev) in a drive system where the ballscrew pitch PB = 10 (mm) and the reduction ratio 1/n = 1.
According to the following expression,

$$\Delta\ell = \frac{\Delta s}{Pf} \times \frac{Pr.\ 420}{Pr.\ 421}$$

$$\frac{Pr.\ 420}{Pr.\ 421} = \Delta\ell \times \frac{Pf}{\Delta s}$$

$$= 0.01 \times \frac{4000}{10} = \frac{4}{1}$$

Therefore, set "4" in *Pr. 420* and "1" in *Pr. 421* .

[Setting example 2]

Find the internal command pulse frequency of the dedicated motor rated speed.
Note that the command pulse scaling factor *Pr. 420*/*Pr. 421* = 1.
Assuming that the number of encoder pulses is 2048 (pulses/rev) (feedback pulse Pf = 2048 × 4),

$$fo = 2048 \times \frac{4}{(\text{multiplication})} \times \frac{No}{60} \times \frac{Pr.\ 421}{Pr.\ 420}$$

$$= 204800$$

Therefore, the internal command pulse frequency is 204800 (pps).

WWW.BSNEW.IR

Relationship between position resolution $\Delta\ell$ and overall accuracy
Since overall accuracy (positioning accuracy of machine) is the sum of electrical error and mechanical error, normally take measures to prevent the electrical system error from affecting the overall error. As a guideline, refer to the following relationship.

$$\Delta\ell < \left(\frac{1}{5} \text{ to } \frac{1}{10}\right) \times \Delta\varepsilon$$

$\Delta\varepsilon$:positioning accuracy

<Stopping characteristic of motor>
When parameters are used to run the motor, the internal command pulse frequency and motor speed have the relationship as shown in the chart on *page 130*, and as the motor speed decreases, pulses are accumulated in the deviation counter of the inverter. These pulses are called droop pulses (ε) and the relationship between command frequency (fo) and position loop gain (Kp: *Pr. 422*) is as represented by the following expression.

$$\varepsilon = \frac{fo}{Kp} \text{ [pulse]} \qquad \varepsilon = \frac{204800}{25} \text{ [pulse] (rated motor speed)}$$

When the initial value of Kp is $25s^{-1}$, the droop pulses (ε) are 8192 pulses.

Since the inverter has droop pulses during running, a stop settling time (ts) is needed from when the command has zeroed until the motor stops. Set the operation pattern in consideration of the stop settling time.

$$ts = 3 \times \frac{1}{Kp} \text{ [s]}$$

When the initial value of Kp is $25s^{-1}$, the stop settling time (ts) is 0.12s.
The positioning accuracy $\Delta\varepsilon$ is (5 to 10) $\times \Delta\ell = \Delta\varepsilon$ [mm]

(2) Position command acceleration/deceleration time constant (*Pr. 424*)

- When the electronic gear ratio is large (about 10 or more times) and the speed is low, rotation will not be smooth, resulting in pulse-wise rotation. At such a time, set this parameter to smooth the rotation.
- When acceleration/deceleration time cannot be provided for the command pulses, a sudden change in command pulse frequency may cause an overshoot or error excess alarm. At such a time, set this parameter to provide acceleration/deceleration time.
  Normally set 0.

♦Parameters referred to♦

Pr. 422 Position loop gain ☞ *Refer to page 138*

4.6.5 Setting of positioning adjustment parameter (Pr. 426, Pr. 427) Vector

Parameter Number	Name	Initial Value	Setting Range	Description
426	**In-position width**	100 pulses	0 to 32767 pulses *	When the number of droop pulses has fallen below the setting value, the in-position signal (Y36) turns on.
427	**Excessive level error**	40K	0 to 400K	A position error excessive (E.OD) occurs when the number of droop pulses exceeds the setting.
			9999	Function invalid

The above parameters can be set when the FR-A7AP (option) is mounted.
* When the operation panel (FR-DU07) is used, the maximum setting is 9999. When a parameter unit is used, up to the maximum value within the setting range can be set.

(1) In-position width (*Pr. 426*)

The Y36 signal acts as an in-position signal.
When the number of droop pulses has fallen below the setting value, the in-position signal (Y36) turns on.
For the Y36 signal, assign the function by setting "36" (positive logic) or "136" (negative logic) in any of *Pr. 190 to Pr. 196 (output terminal function selection)* .

(2) Excessive level error (*Pr. 427*)

When droop pulses exceed the value set in *Pr. 427* , position error large occurs and displays an error (E.OD) to stop the inverter. When you decreased the *Pr. 422 Position loop gain* setting, increase the error excessive level setting.
Also decrease the setting when you want to detect an error slightly earlier under large load.
When "9999" is set in *Pr. 427* , position error large (E.OD) does not occur regardless of droop pulses.

WWW.BSNEW.IR

4.6.6 Gain adjustment of position control (Pr. 422, Pr. 423, Pr. 425) Vector

Easy gain tuning is available as an easy tuning method. Refer to *page 104* for easy gain tuning.
If it does not produce any effect, make fine adjustment by using the following parameters.
Set "0" in *Pr. 819 Easy gain tuning selection* before setting the parameters below.

Parameter Number	Name	Initial Value	Setting Range	Description
422	**Position loop gain**	25s^{-1}	0 to 150s^{-1}	Set the gain of the position loop.
423	**Position feed forward gain**	0%	0 to 100%	Function to cancel a delay caused by the droop pulses of the deviation counter.
425	**Position feed forward command filter**	0s	0 to 5s	Enters the primary delay filter in response to the feed forward command.

The above parameters can be set when the FR-A7AP (option) is mounted.

(1) Position loop gain (*Pr. 422*)

- Make adjustment when any of such phenomena as unusual vibration, noise and overcurrent of the motor/machine occurs.
- Increasing the setting improves trackability for the position command and also improves servo rigidity at a stop, but oppositely makes an overshoot and vibration more liable to occur.
- Normally set this parameter within the range about 5 to 50.

Phenomenon/Condition	Adjustment Method	
Slow response	Increase the *Pr. 422* value.	
	Pr. 422	Increase the value 3s^{-1} by 3s^{-1} until just before an overshoot, stop-time vibration or other instable phenomenon occurs, and set about 0.8 to 0.9 of that value.
Overshoot, stop-time vibration or other instable phenomenon occurs.	Decrease the *Pr. 422* value.	
	Pr. 422	Decrease the value 3s^{-1} by 3s^{-1} until just before an overshoot, stop-time vibration or other instable phenomenon does not occur, and set about 0.8 to 0.9 of that value.

(2) Position feed forward gain (*Pr. 423*)

- This function is designed to cancel a delay caused by the droop pulses of the deviation counter.
- When a tracking delay for command pulses poses a problem, increase the setting gradually and use this parameter within the range where an overshoot or vibration will not occur.
- This function has no effects on servo rigidity at a stop.
- Normally set this parameter to 0.

WWW.BSNEW.IR

(3) Troubleshooting


	Phenomenon	Cause	Countermeasures
1	Motor does not rotate.	(1) The phase sequence of the motor or encoder wiring is wrong.	(1) Check the wiring. *(Refer to page 39)*
		(2) The control mode selection *Pr. 800* setting is improper.	(2) Check the *Pr. 800* setting. *(Refer to page 92)*
		(3) The servo on signal or stroke end signal (STF, STR) is not input.	(3) Check that the signals are input normally.
		(4) Command pulse, position pulse sign (NP) are not correctly input.	(4)-1 Check that the command pulses are input normally. (Check the cumulative command pulse value in *Pr. 430*) (4)-2 Check the command pulse form and command pulse selection, *Pr. 428*, setting. (4)-3 Check that the position pulse sign (NP) is assigned to the input terminal. (inverter pulse input)
		(5) *Pr. 419 Position command source selection* setting is not correct.	(5) Check the position command source selection *in Pr. 419*.
		(6) When "0" is set in *Pr. 419 Position command source selection*, the settings of position feed amount in *Pr. 465 to Pr. 494* are not correct.	(6) Check the position feed amount in *Pr. 465 to Pr. 494* .
2	Position shift occurs.	(1) The command pulses are not input correctly.	(1)-1 Check the command pulse form and command pulse selection, *Pr. 428* setting. (1)-2 Check that the command pulses are input normally. (Check the cumulative command pulse value in *Pr. 430*) (1)-3 Check that the position pulse sign (NP) is assigned to the input terminal. (inverter pulse input)
		(2) The command is affected by noise. Or the encoder feedback signal is compounded with noise.	(2)-1 Decrease the *Pr. 72 PWM frequency selection* value. (2)-2 Change the earthing (grounding) point of shielded wire. Or leave the cable suspended.
3	Motor or machine hunts.	(1) The position loop gain is high. (2) The speed gain is high.	(1) Decrease the *Pr. 422* value. (2)-1 Perform easy gain tuning. (2)-2 Decrease *Pr. 820* and increase *Pr. 821* .
4	Machine operation is unstable.	(1) The acceleration/deceleration time setting has adverse effect.	(1) Decrease *Pr. 7* and *Pr. 8* .

♦Parameters referred to♦

Pr. 7 Acceleration time ☞ *Refer to page 173*
Pr. 8 Deceleration time ☞ *Refer to page 173*
Pr. 72 PWM frequency selection ☞ *Refer to page 279*
Pr. 800 Control method selection ☞ *Refer to page 92*
Pr. 802 Pre-excitation selection ☞ *Refer to page 200*
Pr. 819 Easy gain tuning selection ☞ *Refer to page 104*
Pr. 820 Speed control P gain 1 ☞ *Refer to page 104*
Pr. 821 Speed control integral time 1 ☞ *Refer to page 104*

WWW.BSNEW.IR

4.6.7 Trouble shooting for when position control is not exercised normally



REMARKS

The speed command of position control relates to speed control. *(Refer to page 97)*

WWW.BSNEW.IR

4.7 Adjustment of real sensorless vector control, vector control

Purpose	Parameter that should be Set		Refer to Page
Stabilize speed and feedback signal	Speed detection filter Torque detection filter	Pr. 823, Pr. 827, Pr. 833, Pr. 837	141
Change the excitation ratio	Excitation ratio	Pr. 854	142

4.7.1 Speed detection filter and torque detection filter (Pr. 823, Pr. 827, Pr. 833, Pr. 837) Sensorless Vector

Set the time constant of the primary delay filter relative to the speed feedback signal and torque feedback signal. Since this function reduces the speed loop response, use it with the initial value.

Parameter Number	Name	Initial Value	Setting Range	Description
823 *1	Speed detection filter 1	0.001s	0	Without filter
			0.001 to 0.1s	Set the time constant of the primary delay filter relative to the speed feedback signal.
827	Torque detection filter 1	0s	0	Without filter
			0.001 to 0.1s	Set the time constant of the primary delay filter relative to the torque feedback signal.
833 *1	Speed detection filter 2	9999	0 to 0.1s	Second function of *Pr. 823* (valid when RT signal is on)
			9999	Same as the *Pr. 823* setting
837	Torque detection filter 2	9999	0 to 0.1s	Second function of *Pr. 827* (valid when RT signal is on)
			9999	Same as the *Pr. 827* setting

*1 This parameter can be set when the FR-A7AP (option) is mounted.

(1) Stabilize speed detection (*Pr. 823, Pr. 833*)

- Since the current loop response reduces, use it with the initial value.
  Increase the setting value gradually and adjust the value to stabilize the speed when speed ripples occur due to harmonic disturbance, etc. A too large value will run the motor unstably.
- *Pr. 823* and *Pr. 833* are valid only during vector control

(2) Stabilize speed detection (*Pr. 827, Pr. 837*)

- Since the current loop response reduces, use it with the initial value.
  Increase the setting value gradually and adjust the value to stabilize the speed when torque ripples occur due to harmonic disturbance, etc. A too large value will run the motor unstably.

(3) Use multiple primary delay filters.

- Use *Pr. 833* and *Pr. 837* to change the filter accroding to applications. *Pr. 833* and *Pr. 837* are valid when the RT signal is on.

REMARKS

- The RT signal acts as the second function selection signal and makes the other second functions valid. *(Refer to page 232.)*
- The RT signal is assigned to the RT terminal in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* , you can assign the RT signal to the other terminal.


WWW.BSNEW.IR

4.7.2 Excitation ratio (Pr. 854) Sensorless Vector

Decrease the excitation ratio when you want to improve efficiency under light load. (Motor magnetic noise decreases.)

Parameter Number	Name	Initial Value	Setting Range	Description
854	**Excitation ratio**	100%	0 to 100%	Set the excitation ratio under no load.

· Note that the rise of output torque becomes slow if excitation ratio is decreased.
This function is appropriate for applications as machine tools which repeat rapid acceleration/deceleration up to high speed.



REMARKS

· When "1" (magnetic flux with terminal) is set in *Pr. 858 Terminal 4 function assignment* or *Pr. 868 Terminal 1 function assignment*, the *Pr. 854* setting is made invalid.

WWW.BSNEW.IR

4.8 Adjust the output torque of the motor (current)

Purpose	Parameter that must be Set		Refer to Page
Set starting torque manually	**Manual torque boost**	**Pr. 0, Pr. 46, Pr. 112**	143
Automatically control output current according to load	**Advanced magnetic flux vector control**	**Pr. 71, Pr. 80, Pr. 81, Pr. 89, Pr. 450, Pr. 451, Pr. 453, Pr. 454, Pr. 569, Pr. 800**	145
Compensate for motor slip to secure low-speed torque	**Slip compensation**	**Pr. 245 to Pr. 247**	149
Limit output current to prevent inverter trip	**Stall prevention operation**	**Pr. 22, Pr. 23, Pr. 66, Pr. 154, Pr. 156, Pr. 157**	150
Change the overload current rating specifications	**Multiple rating setting**	**Pr. 570**	155


4.8.1 Manual torque boost (Pr. 0, Pr. 46, Pr. 112) V/F

You can compensate for a voltage drop in the low-frequency region to improve motor torque reduction in the low-speed range.
- Motor torque in the low-frequency range can be adjusted to the load to increase the starting motor torque.
- Three types of starting torque boost can be changed by switching terminals.

Parameter Number	Name	Initial Value 200V class (400V class)		Setting Range	Description
0	**Torque boost**	00030, 00050(00015, 00025)	6%	0 to 30%	Set the output voltage at 0Hz as %.
		00080 to 00175 (00040 to 00090)	4%		
		00240, 00330 (00120, 00170)	3%		
		00460 to 02150 (00230 to 01100)	2%		
		02880 (01440) or more	1%		
46	**Second torque boost**	9999		0 to 30%	Set the torque boost value when the RT signal is on.
				9999	Without second torque boost
112	**Third torque boost**	9999		0 to 30%	Set the torque boost value when the X9 signal is on.
				9999	Without third torque boost

(1) Starting torque adjustment

- On the assumption that *Pr. 19 Base frequency voltage* is 100%, set the output voltage at 0Hz in % in *Pr. 0* (*Pr. 46, Pr. 112*).
- Adjust the parameter little by little (about 0.5%), and check the motor status each time. If the setting is too large, the motor will overheat. The guideline is about 10% at the greatest.



WWW.BSNEW.IR

(2) Set multiple torque boost (RT signal, X9 signal, *Pr. 46, Pr. 112*)

- Use the second (third) torque boost when changing the torque boost according to application or when using multiple motors by switching between them by one inverter.
- *Pr. 46 Second torque boost* is made valid when the RT signal turns on.
- *Pr. 112 Third torque boost* is valid when the X9 signal is on. For the terminal used for X9 signal input, set "9" in any of *Pr. 178* to *Pr. 189* (input terminal function selection) to assign the X9 signal function.

REMARKS

- The RT(X9) signal acts as the second (third) function selection signal and makes the other second (third) functions valid. *(Refer to page 232)*
- The RT signal is assigned to the RT terminal in the default setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, you can assign the RT signal to the other terminal.

CAUTION

- Increase the setting when the distance between the inverter and motor is long or when motor torque is insufficient in the low-speed range. If the setting is too large, an overcurrent trip may occur.
- The *Pr. 0, Pr. 46, Pr. 112* settings are valid only when V/F control is selected.
- When using the inverter dedicated motor (constant torque motor) with the FR-A720-00240, FR-A720-00330, FR-A740-00120 or FR-A740-00170, set the torque boost value to 2%. If the initial set *Pr. 71* value is changed to the setting for use with a constant-torque motor, the *Pr. 0* setting changes to the corresponding value in above.
- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 3 Base frequency, Pr. 19 Base frequency voltage ☞ *Refer to page 159*
Pr. 71 Applied motor ☞ *Refer to page 185*
Pr. 178 to Pr. 189 (Input terminal function selection) ☞ *Refer to page 228*

WWW.BSNEW.IR

4.8.2 Advanced magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 89, Pr. 450, Pr. 451, Pr. 453, Pr. 454, Pr. 569, Pr. 800)

Advanced magnetic flux vector control can be selected by setting the capacity, number and type of motor to be used in *Pr. 80* and *Pr. 81*.

●What is advanced magnetic flux vector control?

The low speed torque can be improved by providing voltage compensation so that the motor current which meets the load torque to flow. Output frequency compensation (slip compensation) is made so that the motor actual speed approximates a speed command value. Effective when load fluctuates drastically, etc.

Parameter Number	Name	Initial Value	Setting Range 200V Class (400V Class)		Description	
71	**Applied motor**	0	0 to 8, 13 to 18, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54		By selecting a standard motor or constant torque motor, thermal characteristic and motor constants of each motor are set.	
80	**Motor capacity**	9999	02150(01100) or less	0.4 to 55kW	Set the applied motor capacity.	
			02880(01440) or more	0 to 3600kW		
			9999		V/F control	
81	**Number of motor poles**	9999	2, 4, 6, 8, 10		Set the number of motor poles.	
			12, 14, 16, 18, 20		X18 signal-ON:V/F control *	Set 10 + number of motor poles.
			9999		V/F control	
89	**Speed control gain (magnetic flux vector)**	9999	0 to 200%		Motor speed fluctuation due to load fluctuation is adjusted during advanced magnetic flux vector control. 100% is a referenced value.	
			9999		Gain matching with the motor set in *Pr. 71*.	
450	**Second applied motor**	9999	0 to 8, 13 to 18, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54		Set when using the second motor. (same specifications as *Pr. 71*)	
			9999		Function invalid (*Pr. 71* is valid)	
451	**Second motor control method selection**	9999	10, 11, 12		Real sensorless vector control	
			20, 9999		V/F control (advanced magnetic flux vector control)	
453	**Second motor capacity**	9999	02150(01100) or less	0.4 to 55kW	Set the capacity of the second motor.	
			02880(01440) or more	0 to 3600kW		
			9999		V/F control	
454	**Number of second motor poles**	9999	2, 4, 6, 8, 10		Set the number of poles of the second motor.	
			9999		V/F control	
569	**Second motor speed control gain**	9999	0 to 200%		Second motor speed fluctuation due to load fluctuation is adjusted during advanced magnetic flux vector control. 100% is a referenced value.	
			9999		Gain matching with the motor set in *Pr. 450*.	
800	**Control method selection**	20	0 to 5		Vector control	
			9		Vector control test operation	
			10, 11, 12		Real sensorless vector control	
			20		V/F control (advanced magnetic flux vector control)	

* Use *Pr. 178 to Pr. 189* to assign the terminals used for the X18 and MC signal. *(Refer to page 228)*

WWW.BSNEW.IR

POINT

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.

- The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity should be 0.4kW or more)
- Motor to be used is either Mitsubishi standard motor (SF-JR, SF-HR two-pole, four-pole, six-pole 0.4kW or more) or Mitsubishi constant torque motor (SF-JRCA, SF-HRCA four-pole 0.4kW to 55kW). When using a motor other than the above (SF-TH, other manufacturer's motors, etc.), perform offline auto tuning without fail.
- Single-motor operation (one motor run by one inverter) should be performed.
- The wiring length from inverter to motor should be within 30m (98.4feet). (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m (98.4feet).)
- For FR-A720-02880 (FR-A740-01440) or more, do not use an option sine wave filter (MT-BSL/BSC) between the inverter and motor.

WWW.BSNEW.IR

(1) Selection method of advanced magnetic flux vector control

Perform secure wiring.
(Refer to page 14)

↓

Set the motor. *(Pr. 71)*

Motor		*Pr. 71* Setting *1	REMARKS
Mitsubishi standard motor Mitsubishi high efficiency motor	SF-JR	0 (initial value)	
	SF-JR 4P 1.5kW or less	20	
	SF-HR	40	
	Others	3	Offline auto tuning is necessary. *2
Mitsubishi constant-torque motor	SF-JRCA 4P	1	
	SF-HRCA 4P	50	
	Others (SF-JRC, etc.)	13	Offline auto tuning is necessary. *2
Other manufacturer's standard motor	—	3	Offline auto tuning is necessary. *2
Other manufacturer's constant torque motor	—	13	Offline auto tuning is necessary. *2

*1 For other settings of *Pr. 71* , refer to *page 185*.
*2 Refer to *page 187* for offline auto tuning.

↓

Set the motor capacity and the number of motor poles.
(Pr. 80, Pr. 81) (Refer to page 92)

Set motor capacity (kW) in *Pr. 80 Motor capacity* and the number of motor poles (number of poles) in *Pr. 81 Number of motor poles*. (V/F control is performed when the setting is "9999" (initial value).)

↓

Set the operation command. *(Refer to page 308)*

Select the start command and speed command.

(1) Start command
1. Operation panel :
   Setting by pressing FWD / REV of the operation panel
2. External command : Setting by forward rotation or reverse rotation command (terminal STF or STR)

(2) Speed command
1. Operation panel :
   Setting by of the operation panel
2. External analog command (terminal 2 or 4) :
   Give a speed command using the analog signal input to terminal 2 (or terminal 4).
3. Multi-speed command :
   The external signals (RH, RM, RL) may also be used to give speed command.

↓

Test run

As required

- Perform offline auto tuning. *(Pr. 96) (refer to page 187)*
- Select online auto tuning. *(Pr. 95) (refer to page 197)*

REMARKS

- When higher accuracy operation is necessary, set online auto tuning after performing offline auto tuning and select real sensorless vector control.


WWW.BSNEW.IR

CAUTION

- Uneven rotation slightly increases as compared to the V/F control. (It is not suitable for machines such as grinding machine and wrapping machine which requires less uneven rotation at low speed.)
- When a surge voltage suppression filter (FR-ASF-H) is connected between the inverter and motor, output torque may decrease. (FR-A720-02150 (FR-A740-01100) or less)
- When terminal assignment is changed using *Pr. 178 to Pr. 189 (input terminal function selection)*, the other functions may be affected. Make setting after confirming the function of each terminal.

(2) Adjust the motor speed fluctuation at load fluctuation (speed control gain)

The motor speed fluctuation at load fluctuation can be adjusted using *Pr. 89*. (It is useful when the speed command does not match the motor speed after the FR-A500(L) series inverter is replaced with the FR-A700 series inverter, etc.)



(3) Advanced magnetic flux vector control is performed with two motors

- Turning the RT signal on allows the second motor to be controled.
- Set the second motor in *Pr. 450 Second applied motor*. (Initial setting is "9999" (without second applied motor). *Refer to page 185*.)

Function	RT signal ON (second motor)	RT signal OFF (first motor)
Applied motor	Pr. 450	Pr. 71
Motor capacity	Pr. 453	Pr. 80
Number of motor poles	Pr. 454	Pr. 81
Speed control gain	Pr. 569	Pr. 89
Control method selection	Pr. 451	Pr. 800

REMARKS

- The RT signal acts as the second function selection signal and makes the other second functions valid. *(Refer to page 232)* The RT signal is assigned to the terminal RT in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, the RT signal can be assigned to the other terminal.

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

♦Parameters referred to♦

Pr. 71, Pr. 450 Applied motor ☞ *Refer to page 185*
Pr. 800, Pr. 451 Control method selection ☞ *Refer to page 92*

WWW.BSNEW.IR

4.8.3 Slip compensation (Pr. 245 to Pr. 247) V/F

The inverter output current may be used to assume motor slip to keep the motor speed constant.

Parameter Number	Name	Initial Value	Setting Range	Description
245	Rated slip	9999	0.01 to 50%	Used to set the rated motor slip.
			0, 9999	No slip compensation
246	Slip compensation time constant	0.5s	0.01 to 10s	Used to set the slip compensation response time. When the value is made smaller, response will be faster. However, as load inertia is greater, a regenerative overvoltage (E.OV☐) error is more liable to occur.
247	Constant-power range slip compensation selection	9999	0	Slip compensation is not made in the constant power range (frequency range above the frequency set in *Pr. 3*)
			9999	Slip compensation is made in the constant power range.

· Slip compensation is validated when the motor rated slip calculated by the following formula is set in *Pr. 245*. Slip compensation is not made when *Pr. 245* = "0" or "9999".

$$\text{Rated slip} = \frac{\text{Synchronous speed at base frequency - rated speed}}{\text{Synchronous speed at base frequency}} \times 100[\%]$$

REMARKS

When performing slip compensation, the output frequency may become greater than the set frequency. Set the *Pr. 1 Maximum frequency* value a little higher than the set frequency.

♦ Parameters referred to ♦

Pr. 1 Maximum frequency ☞ *Refer to page 157*
Pr. 3 Base frequency ☞ *Refer to page 159*

WWW.BSNEW.IR


4.8.4 Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 49, Pr. 66, Pr. 114, Pr. 115, Pr. 148, Pr. 149, Pr. 154, Pr. 156, Pr. 157, Pr. 858, Pr. 868)

This function monitors the output current and automatically changes the output frequency to prevent the inverter from coming to an alarm stop due to overcurrent, overvoltage, etc. It can also limit stall prevention and fast response current limit operation during acceleration/deceleration, driving or regeneration. Invalid under real sensorless vector control or vector control.

- Stall prevention
  If the output current exceeds the stall prevention operation level, the output frequency of the inverter is automatically varied to reduce the output current.
  Also the second stall prevention function can restrict the output frequency range in which the stall prevention function is valid. *(Pr. 49)*
- Fast response current limit
  If the current exceeds the limit value, the output of the inverter is shut off to prevent an overcurrent.

Parameter Number	Name	Initial Value	Setting Range	Description	
22	Stall prevention operation level	150% *	0	Stall prevention operation selection becomes invalid.	
			0.1 to 400%	Set the current value at which stall prevention operation will be started.	
23	Stall prevention operation level compensation factor at double speed	9999	0 to 200% *	The stall operation level can be reduced when operating at a high speed above the rated frequency.	
			9999	Constant according to *Pr. 22*	
48	Second stall prevention operation current	150% *	0	Second stall prevention operation invalid	
			0.1 to 220% *	The second stall prevention operation level can be set.	
49	Second stall prevention operation frequency	0Hz	0	Second stall prevention operation invalid	
			0.01 to 400Hz	Set the frequency at which stall prevention operation of *Pr. 48* is started.	
			9999	*Pr. 48* is valid when the RT signal is on.	
66	Stall prevention operation reduction starting frequency	60Hz	0 to 400Hz	Set the frequency at which the stall operation level is started to reduce.	
114	Third stall prevention operation current	150% *	0	Third stall prevention operation invalid	
			0.1 to 220%	Stall prevention operation level can be changed with the X9 signal.	
115	Thrid stall prevention operation frequency	0Hz	0	Third stall prevention operation invalid	
			0.01 to 400Hz	Set the frequency at which stall prevention operation when the X9 signal is on starts.	
148	Stall prevention level at 0V input	150% *	0 to 220% *	Stall prevention operation level can be changed by the analog signal input to terminal 1 (terminal 4).	
149	Stall prevention level at 10V input	200% *	0 to 220% *		
154	Voltage reduction selection during stall prevention operation	1	0	With voltage reduction	You can select whether to use output voltage reduction during stall prevention operation or not.
			1	Without voltage reduction	
156	Stall prevention operation selection	0	0 to 31, 100, 101	You can select whether stall prevention operation and fast response current limit operation will be performed or not.	
157	OL signal output timer	0s	0 to 25s	Set the output start time of the OL signal output when stall prevention is activated.	
			9999	Without the OL signal output	
858	Terminal 4 function assignment	0	0, 1, 4, 9999	By setting "4", the stall prevention operation level can be changed with a signal to terminal 4.	
868	Terminal 1 function assignment	0	0 to 6, 9999	By setting "4", the stall prevention operation level can be changed with a signal to terminal 1.	

* When *Pr. 570 Multiple rating setting* ≠ "2", performing inverter reset and all parameter clear changes the initial value and setting range. *(Refer to page 155)*



Stall prevention operation example

(1) Setting of stall prevention operation level *(Pr. 22)*

- Set in *Pr. 22* the ratio of the output current to the rated inverter current at which stall prevention operation will be performed. Normally set 150% (initial value).
- Stall prevention operation stops acceleration (makes deceleration) during acceleration, makes deceleration during constant speed, and stops deceleration during deceleration.
- When stall prevention operation is performed, the OL signal is output.

CAUTION


- If an overload status lasts long, an inverter trip (e.g. electronic thermal relay function (E.THM)) may occur.
- When *Pr. 156* has been set to activate the fast response current limit (initial setting), the *Pr. 22* setting should not be higher than 170%. The torque will not be developed by doing so. (When *Pr. 570* = "2")
- When real sensorless vector control or vector control is selected using *Pr. 800 Control method selection*, *Pr.22* serves as torque limit level. For the FR-A720-00175 (FR-A740-00090) or less, the *Pr. 22* setting changes from 150% (initial value) to 200%.

WWW.BSNEW.IR

(2) Stall prevention operation signal output and output timing adjustment (OL signal, *Pr. 157*)

- When the output power exceeds the stall prevention operation level and stall prevention is activated, the stall prevention operation signal (OL signal) turns on for longer than 100ms. When the output power falls to or below the stall prevention operation level, the output signal turns off.
- Use *Pr. 157 OL signal output timer* to set whether the OL signal is output immediately or after a preset period of time.
- This operation is also performed when the regeneration avoidance function oL (overvoltage stall) is executed.

Pr. 157 Setting	Description
0 (initial value)	Output immediately
0.1 to 25	Output after the set time (s) has elapsed
9999	Not output




REMARKS


- The OL signal is assigned to the terminal OL in the initial setting. The OL signal can also be assigned to the other terminal by setting "3 (positive logic) or 103 (negative logic)" to any of *Pr. 190 to Pr. 196 (output terminal function selection)*.

CAUTION

- If the frequency has fallen to 0.5Hz by stall prevention operation and remains for 3s, an alarm (E.OLT) appears to shutoff the inverter output.
- When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions may be affected. Please make setting after confirming the function of each terminal.

(3) Setting of stall prevention operation in high frequency range *(Pr. 22, Pr. 23, Pr. 66)*





- During high-speed operation above the rated motor frequency, acceleration may not be made because the motor current does not increase. If operation is performed in a high frequency range, the current at motor lockup becomes smaller than the rated output current of the inverter, and the protective function (OL) is not executed if the motor is at a stop.
  To improve the operating characteristics of the motor in this case, the stall prevention level can be reduced in the high frequency range. This function is effective for performing operation up to the high-speed range on a centrifugal separator etc. Normally, set 60Hz in *Pr. 66* and 100% in *Pr. 23*.
- Formula for stall prevention operation level


$$\text{Stall prevention operation level in high frequency range (\%)} = A + B \times \left[\frac{Pr.\,22 - A}{Pr.\,22 - B}\right] \times \left[\frac{Pr.\,23 - 100}{100}\right]$$

$$\text{However, } A = \frac{Pr.\,66(\text{Hz}) \times Pr.\,22(\%)}{\text{Output frequency (H)}},\quad B = \frac{Pr.\,66(\text{Hz}) \times Pr.\,22(\%)}{400\text{Hz}}$$


- When *Pr. 23 Stall prevention operation level compensation factor at double speed* = "9999" (initial value), the stall prevention operation level is kept constant at the *Pr. 22* setting up to 400Hz.

WWW.BSNEW.IR


(4) Set multiple stall prevention operation levels *(Pr. 48, Pr. 49, Pr. 114, Pr. 115)*



Set frequency exceeds *Pr. 49(Pr.115)*



Set frequency is *Pr. 49 (Pr.115)* or less



- Setting "9999" in *Pr. 49 Second stall prevention operation frequency* and turning the RT signal on make *Pr. 48 Second stall prevention operation current* valid.
- In *Pr. 48 (Pr. 114)*, you can set the stall prevention operation level at the output frequency from 0Hz to that set in *Pr. 49 (Pr. 115)*.
  During acceleration, however, the operation level is as set in *Pr. 22*.
- This function can also be used for stop-on-contact or similar operation by decreasing the *Pr. 48 (Pr. 114)* setting to weaken the deceleration torque (stopping torque).
- *Pr. 114* and *Pr. 115* are made valid when the X9 signal is on. For the terminal used for X9 signal input, set "9" in any of *Pr. 178 to Pr. 189* input terminal function selection to assign the X9 signal function.

Pr. 49 Setting	*Pr. 115* Setting	Operation
0 (initial value)		The second (third) stall prevention operation is not performed.
0.01Hz to 400Hz		The second (third) stall prevention operation is performed according to the frequency.*1
9999 *2	Setting can not be made.	The second (third) stall prevention function is performed according to the RT signal. RT signal ON ... Stall level *Pr. 48* RT signal OFF ... Stall level *Pr. 22*

*1 The smaller setting of the stall prevention operation levels set in *Pr. 22* and *Pr. 48* has a higher priority.

*2 When *Pr. 868* = "4" (Stall prevention operation level analog input), the stall prevention operation level also switches from the analog input (terminal 1 input) to the stall prevention operation level of *Pr. 48* when the RT signal turns on.
(The second stall prevention operation level cannot be input in an analog form.)

REMARKS


- When *Pr. 49* ≠ "9999" (level changed according to frequency) and *Pr. 48* = "0%", the stall prevention operation level is 0% at or higher than the frequency set in *Pr. 49*.
- In the initial setting, the RT signal is assigned to the RT terminal. By setting "3" to any of *Pr. 178 to Pr. 189 (input terminal function selection)*, you can assign the RT signal to the other terminal.

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.
- The RT(X9) signal acts as the second (third) function selection signal and makes the other second (third) functions valid. *(Refer to page 232)*

WWW.BSNEW.IR

(5) Stall prevention operation level setting by terminal 1 (terminal 4) (analog variable) *(Pr. 148, Pr. 149, Pr. 858, Pr. 868)*



- To set the stall prevention operation level using terminal 1 (analog input), set *Pr. 868 Terminal 1 function assignment* to "4".
- Input 0 to 5V (or 0 to 10V) to terminal 1. Select 5V or 10V using *Pr. 73 Analog input selection*. When *Pr. 73* = "1" (initial value), 0 to ±10V is input.
- To set stall prevention operation level using terminal 4 (analog current input), set "4" in *Pr. 858 Terminal 4 function assignment*.
  Input 0 to 20mA to terminal 4. The AU signal need not be turned on.
- Set the current limit level at the input voltage of 0V (0mA) in *Pr. 148 Stall prevention level at 0V input*
- Set the current limit level at the input voltage of 10V/ 5V (20mA) in *Pr. 149 Stall prevention level at 10V input.*

Pr. 858 Setting	*Pr. 868* Setting	V/F, Advanced Magnetic Flux Vector Control	
		Terminal 4 function	Terminal 1 function
0 (initial value)	0 (initial value)	Frequency command (AU signal-ON)	Frequency auxiliary
	1		Magnetic flux command
	2		—
	3		—
	4 *1		Stall prevention
	5		—
	6		Torque bias
	9999		—
1	0 (initial value)	Magnetic flux command	—
	1	—	Magnetic flux command
	2	Magnetic flux command	—
	3		—
	4 *1		Stall prevention
	5		—
	6		Torque bias
	9999		—
4 *2	0 (initial value)	Stall prevention	Frequency auxiliary
	1		Magnetic flux command
	2		—
	3	—	—
	4 *1	—*3	Stall prevention
	5	Stall prevention	—
	6		Torque bias
	9999		—
9999	—	—	—

*1 When *Pr. 868* = "4" (analog stall prevention), other functions of terminal 1 (auxiliary input, override function, PID control) do not function.
*2 When *Pr. 858* = "4" (analog stall prevention), PID control and speed command from terminal 4 do not function even if the AU signal turns on.
*3 When "4" (stall prevention) is set in both *Pr. 858* and *Pr. 868*, function of terminal 1 has higher priority and terminal 4 has no function.

REMARKS

- The fast response current limit level cannot be set.

(6) To further prevent an alarm stop *(Pr. 154)*

- When *Pr. 154* is set to "0", the output voltage reduces during stall prevention operation. By making setting to reduce the output voltage, an overcurrent trip can further become difficult to occur.
- Use this function where a torque decrease will not pose a problem.

Pr. 154 Setting	Description
0	Output voltage reduced
1 (initial value)	Output voltage not reduced

WWW.BSNEW.IR

(7) Limit the stall prevention operation and fast response current limit operation according to the operating status *(Pr. 156)*

· Refer to the following table and select whether fast response current limit operation will be performed or not and the operation to be performed at OL signal output.

Pr. 156 Setting	Fast response Current Limit ○: Activated ●: Not activated	Stall Prevention Operation Selection ○:Activated ●:Not activated			OL Signal Output ○:Operation continued ●:Operation not continued *1
		Acceleration	Constant speed	Deceleration	
0 (initial value)	○	○	○	○	○
1	●	○	○	○	○
2	○	●	○	○	○
3	●	●	○	○	○
4	○	○	●	○	○
5	●	○	●	○	○
6	○	●	●	○	○
7	●	●	●	○	○
8	○	○	○	●	○
9	●	○	○	●	○
10	○	●	○	●	○
11	●	●	○	●	○
12	○	○	●	●	○
13	●	○	●	●	○
14	○	●	●	●	○
15	●	●	●	●	— *2
16	○	○	○	○	●
17	●	○	○	○	●
18	○	●	○	○	●
19	●	●	○	○	●
20	○	○	●	○	●
21	●	○	●	○	●
22	○	●	●	○	●
23	●	●	●	○	●
24	○	○	○	○	●
25	●	○	○	●	●
26	○	●	○	●	●
27	●	●	○	●	●
28	○	○	●	●	●
29	●	○	●	●	●
30	○	●	●	●	●
31	●	●	●	●	— *2
100 *3 Driving	○	○	○	○	○
100 *3 Regeneration	●	●	●	●	— *2
101 *3 Driving	●	○	○	○	○
101 *3 Regeneration	●	●	●	●	— *2

*1 When "Operation not continued for OL signal output" is selected, the " E.OLT " alarm code (stopped by stall prevention) is displayed and operation stopped.
*2 Since both fast response current limit and stall prevention are not activated, OL signal and E.OLT are not output.
*3 The settings "100" and "101" allow operations to be performed in the driving and regeneration modes, respectively. The setting "101" disables the fast response current limit in the driving mode.

CAUTION

· When the load is heavy, when the lift is predetermined, or when the acceleration/deceleration time is short, stall prevention is activated and acceleration/deceleration may not be made according to the preset acceleration/deceleration time. Set *Pr. 156* and stall prevention operation level to the optimum values.
· In vertical lift applications, make setting so that the fast response current limit is not activated. Torque may not be produced, causing a drop due to gravity.

⚠ CAUTION

⚠ Do not set a small value as the stall prevention operation current.
Otherwise, torque generated will reduce.

⚠ Always perform test operation.
Stall prevention operation during acceleration may increase the acceleration time.
Stall prevention operation performed during constant speed may cause sudden speed changes.
Stall prevention operation during deceleration may increase the deceleration time, increasing the deceleration distance.

♦ Parameters referred to ♦

· *Pr. 22 Torque limit level* ☞ *Refer to page 99*
· *Pr. 73 Analog input selection* ☞ *Refer to page 282*
· *Pr. 178 to Pr. 189 (Input terminal function selection)* ☞ *Refer to page 228*
· *Pr. 190 to Pr. 196 (output terminal function selection)* ☞ *Refer to page 236*
· *Pr. 570 Multiple rating setting* ☞ *Refer to page 155*
· *Pr. 858 Terminal 4 function assignment, Pr. 868 Terminal 1 function assignment* ☞ *Refer to page 281*

WWW.BSNEW.IR

4.8.5 Multiple rating (Pr. 570)

You can use the inverter by changing the overload current rating specifications according to load applications. Note that the control rating of each function changes.

Parameter Number	Name	Initial Value	Setting Range	Description
570	Multiple rating setting	2	0 *	SLD Ambient temperature 40°C (104°F), Overload current rating 110% 60s, 120% 3s (Inverse time characteristics)
			1 *	LD Ambient temperature 50°C (122°F), Overload current rating 120% 60s, 150% 3s (Inverse time characteristics)
			2	ND Ambient temperature 50°C (122°F), Overload current rating 150% 60s, 200% 3s (Inverse time characteristics)
			3	HD Ambient temperature 50°C (122°F), Overload current rating 200% 60s, 250% 3s (Inverse time characteristics)

* This function is valid for V/F control only. This parameter can be set only when "9999" is set in *Pr. 80, Pr. 81, Pr. 453*, and *Pr. 454*.

(1) Parameters whose initial value and setting range are changed by *Pr. 570 Multiple rating setting*

- The initial value and setting range of the following parameters are changed by performing reset and all parameter clear after changing this parameter setting.
- Reflect the *Pr. 570* setting in the following procedure.
  1) Change the *Pr. 570* setting.
  2) Reset the inverter.
  3) Perform all parameter clear.

Parameter Number	Name		*Pr. 570* Setting				Refer to Page
			0	1	2 (initial value)	3	
9	Electronic thermal O/L relay	Initial Value	SLD rated current *1	LD rated current *1	ND rated current *1	HD rated current *1	181
22	Stall prevention operation level	Setting Range	0 to 400%	0 to 400%	0 to 400%	0 to 400%	99, 150
		Initial Value	110%	120%	150%	200%	
23	Stall prevention operation level compensation factor at double speed	Setting Range	0 to 150%, 9999	0 to 200%, 9999	0 to 200%, 9999	0 to 200%, 9999	150
		Initial Value	9999	9999	9999	9999	
48	Second stall prevention operation current	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	150
		Initial Value	110%	120%	150%	200%	
56	Current monitoring reference	Initial Value	SLD rated current *1	LD rated current *1	ND rated current *1	HD rated current *1	255
62	Reference value at acceleration	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	179
		Initial Value	9999	9999	9999	9999	
63	Reference value at deceleration	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	179
		Initial Value	9999	9999	9999	9999	
114	Third stall prevention operation current	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	150
		Initial Value	110%	120%	150%	200%	
148	Stall prevention level at 0V input	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	150
		Initial Value	110%	120%	150%	200%	
149	Stall prevention level at 10V input	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	150
		Initial Value	120%	150%	200%	250%	
150	Output current detection level	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	245
		Initial Value	110%	120%	150%	200%	

WWW.BSNEW.IR

Parameter Number	Name		*Pr. 570* Setting				Refer to Page
			0	1	2 (initial value)	3	
152	Zero current detection level	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	245
		Initial Value	5%	5%	5%	5%	
165	Stall prevention operation level for restart	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	261
		Initial Value	110%	120%	150%	200%	
271	High-speed setting maximum current	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	368
		Initial Value	50%	50%	50%	50%	
272	Middle-speed setting minimum current	Setting Range	0 to 120%	0 to 150%	0 to 220%	0 to 280%	368
		Initial Value	100%	100%	100%	100%	
279	Brake opening current	Setting Range	0 to 220%	0 to 220%	0 to 220%	0 to 280%	214
		Initial Value	130%	130%	130%	130%	
557	Current average value monitor signal output reference current	Initial Value	SLD rated current *1	LD rated current *1	ND rated current *1	HD rated current *1	384
893	Energy saving monitor reference (motor capacity)	Initial Value	SLD value of applied motor capacity *1	LD value of applied motor capacity *1	ND value of applied motor capacity *1	HD value of applied motor capacity *1	274

*1 The rated current differs according to the inverter capacity. *Refer to rated specifications (page 432)*.

CAUTION

- When *Pr. 570* = "0 or 1", *Pr. 260 PWM frequency automatic switchover* becomes valid. *(Refer to page 279.)*
- When using the FR-A720-02150 with LD or SLD set, always use a DC reactor (option FR-HEL-75K).
- When using the FR-A740-01100 with LD or SLD set, always use a DC reactor (option FR-HEL-H90K).

(2) Precautions for the FR-A720-02150 (FR-A740-01100) or less and FR-A720-02880 (FR-A740-01440) or more

If *Pr. 570* is set to "0 (SLD) or 1 (LD)" when using FR-A720-02150 (FR-A740-01100), specifications of the inverter change to that of the FR-A720-02880 (FR-A740-01440). Setting change of *Pr. 570* is made valid after inverter reset and all parameter clear.

Inverter	Multiple Rating Setting	Parameter Setting
A720-02150	SLD	The inverter operates in the same manner as the FR-A720-02880 or more. Parameter setting range, minimum setting increments, initial values, etc. change to those of the 02880 or more. *Refer to the parameter list* for parameters whose values change.
	LD	
	ND	No change
	HD	
A720-02880	SLD	No change
	LD	
	ND	
	HD	
A740-01100	SLD	The inverter operates in the same manner as the FR-A740-01440 or more. Parameter setting range, minimum setting increments, initial values, etc. change to those of the 01440 or more. *Refer to the parameter list* for parameters whose values change.
	LD	
	ND	No change
	HD	
A740-01440	SLD	No change
	LD	
	ND	
	HD	

For example, when using the FR-A740-01100, setting "0" in *Pr. 570* and performing all parameter clear after inverter reset will change the setting range of *Pr. 9* from "0 to 500A" to "0 to 3600A" and the minimum setting increments from "0.01A" to "0.1A". (*Refer to the parameter list* for other parameters.)

WWW.BSNEW.IR


4.9 Limit the output frequency

Purpose	Parameter that must be Set		Refer to Page
Set upper limit and lower limit of output frequency	**Maximum/minimum frequency**	**Pr. 1, Pr. 2, Pr. 18**	157
Perform operation by avoiding mechanical resonance points	**Frequency jump**	**Pr. 31 to Pr. 36**	158

4.9.1 Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)

You can limit the motor speed. Clamp the upper and lower limits of the output frequency.

Parameter Number	Name	Initial Value 200V class (400V class)		Setting Range	Description
1	**Maximum frequency**	02150 (01100) or less	120Hz	0 to 120Hz	Set the upper limit of the output frequency.
		02880 (01440) or more	60Hz		
2	**Minimum frequency**	0Hz		0 to 120Hz	Set the lower limit of the output frequency.
18	**High speed maximum frequency**	02150 (01100) or less	120Hz	120 to 400Hz	Set when performing the operation at 120Hz or more.
		02880 (01440) or more	60Hz		



(1) Set maximum frequency

- Set the upper limit of the output frequency in *Pr. 1 Maximum frequency*. If the frequency of the frequency command entered is higher than the setting, the output frequency is clamped at the maximum frequency.
- When you want to perform operation above 120Hz, set the upper limit of the output frequency to *Pr. 18 High speed maximum frequency*. (When *Pr. 18* is set, *Pr. 1* automatically switches to the frequency of *Pr. 18*. When *Pr. 18* is set, *Pr. 18* automatically switches to the frequency of *Pr. 1*.)

REMARKS

- When performing operation above 60Hz using the frequency setting analog signal, change *Pr. 125 (Pr. 126) (frequency setting gain)*. If only *Pr. 1* or *Pr. 18* is changed, operation above 60Hz cannot be performed.

(2) Set minimum frequency

- Use *Pr. 2 Minimum frequency* to set the lower limit of the output frequency.
- The output frequency is clamped by the *Pr. 2* setting even if the set frequency is equal to or less than the *Pr. 2* setting (The frequency will not decrease to the *Pr. 2* setting.)

REMARKS

- When *Pr. 15 Jog frequency* is equal to or less than *Pr. 2*, the *Pr. 15* setting has precedence over the *Pr. 2* setting.
- When stall prevention is activated to decrease the output frequency, the output frequency may drop to *Pr. 2* or below.

⚠ CAUTION

⚠ Note that when *Pr. 2* is set to any value equal to or more than *Pr. 13 Starting frequency*, simply turning on the start signal will run the motor at the preset frequency according to the set acceleration time even if the command frequency is not input.

♦ Parameters referred to ♦


Pr. 13 Starting frequency ☞ *Refer to page 175*
Pr. 15 Jog frequency ☞ *Refer to page 168*
Pr. 125 Terminal 2 frequency setting gain frequency, Pr. 126 Terminal 4 frequency setting gain frequency ☞ *Refer to page 289*

WWW.BSNEW.IR


4.9.2 Avoid mechanical resonance points (Frequency jump) (Pr. 31 to Pr. 36)

When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped.


Parameter Number	Name	Initial Value	Setting Range	Description
31	**Frequency jump 1A**	9999	0 to 400Hz, 9999	1A to 1B, 2A to 2B, 3A to 3B is frequency jumps 9999: Function invalid
32	**Frequency jump 1B**	9999	0 to 400Hz, 9999	
33	**Frequency jump 2A**	9999	0 to 400Hz, 9999	
34	**Frequency jump 2B**	9999	0 to 400Hz, 9999	
35	**Frequency jump 3A**	9999	0 to 400Hz, 9999	
36	**Frequency jump 3B**	9999	0 to 400Hz, 9999	



- Up to three areas may be set, with the jump frequencies set to either the top or bottom point of each area.
- The settings of frequency jumps 1A, 2A, 3A are jump points, and operation is performed at these frequencies in the jump areas.



Example 1 To fix the frequency to 30Hz in the range 30Hz to 35Hz, set 35Hz in *Pr. 34* and 30Hz in *Pr. 33*.



Example 2 To jump the frequency to 35Hz in the range 30Hz to 35Hz, set 35Hz in *Pr. 33* and 30Hz in *Pr. 34*.

CAUTION

- During acceleration/deceleration, the running frequency within the set area is valid.

WWW.BSNEW.IR


4.10 Set V/F pattern

Purpose	Parameter that must be Set		Refer to Page
Set motor ratings	**Base frequency, base frequency voltage**	**Pr. 3, Pr. 19, Pr. 47, Pr. 113**	159
Select a V/F pattern according to applications	**Load pattern selection**	**Pr. 14**	161
Automatically set a V/F pattern for elevators	**Elevator mode (automatic acceleration/deceleration)**	**Pr. 61, Pr. 64, Pr. 292**	163
Use special motor	**Adjustable 5 points V/F**	**Pr. 71, Pr. 100 to Pr. 109**	165

4.10.1 Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47, Pr. 113) V/F

Used to adjust the inverter outputs (voltage, frequency) to the motor rating.

Parameter Number	Name	Initial Value	Setting Range	Description
3	**Base frequency**	60Hz	0 to 400Hz	Set the frequency when the motor rated torque is generated. (50Hz/60Hz)
19	**Base frequency voltage**	9999	0 to 1000V	Set the base voltage.
			8888	95% of power supply voltage
			9999	Same as power supply voltage
47	**Second V/F (base frequency)**	9999	0 to 400Hz	Set the base frequency when the RT signal is on.
			9999	Second V/F invalid
113	**Third V/F (base frequency)**	9999	0 to 400Hz	Set the base frequency when the X9 signal is ON.
			9999	Third V/F is invalid



(1) Setting of base frequency *(Pr. 3)*

- When operating a standard motor, generally set the rated frequency of the motor to *Pr. 3 Base frequency*. When running the motor using bypass operation, set *Pr. 3* to the same value as the power supply frequency.
- If the frequency given on the motor rating plate is "50Hz" only, always set to "50Hz". Leaving the base frequency unchanged from "60Hz" may make the voltage too low and the torque insufficient. It may result in an inverter trip due to overload. Special care must be taken when “1“ (reduced torque load) is set in *Pr. 14 Load pattern selection*.
- When using the Mitsubishi constant-torque motor, set *Pr. 3* to 60Hz.

(2) Set multiple base frequencies *(Pr. 47, Pr. 113)*

- When you want to change the base frequency when switching two motors with one inverter, use the *Pr. 47 Second V/F (base frequency)*.
- *Pr. 47 Second V/F (base frequency)* is made valid when the RT signal in ON and *Pr. 113 Third V/F (base frequency)* is made valid when the X9 signal is on. Assign the terminal for X9 signal input using any of *Pr. 178 to Pr. 189 (input terminal function selection)*.

REMARKS

- The RT(X9) signal acts as the second (third) function selection signal and makes the other second (third) functions valid. *(Refer to page 232)*
- In the initial setting, the RT signal is assigned to the RT terminal. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, you can assign the RT signal to the other terminal.

WWW.BSNEW.IR

(3) Base frequency voltage setting *(Pr. 19)*

- Use *Pr. 19 Base frequency voltage* to set the base voltage (e.g. rated motor voltage).
- If the setting is less than the power supply voltage, the maximum output voltage of the inverter is as set in *Pr. 19*.
- *Pr. 19* can be utilized in the following cases.
  (a) When regeneration frequency is high (e.g. continuous regeneration)
  During regeneration, the output voltage becomes higher than the reference and may cause an overcurrent trip (E.OC☐) due to an increased motor current.
  (b) When power supply voltage variation is large
  When the power supply voltage exceeds the rated voltage of the motor, speed variation or motor overheat may be caused by excessive torque or increased motor current.
  (c) When you want to expand constant-power characteristic range
  To expand the constant-power range at the base frequency or less, set a value greater than the power supply voltage to *Pr. 19*.
- Set parameters as below when running the vector control dedicated motor (SF-V5RU, SF-VR) under V/F control.

Motor Type	*Pr. 19* Setting	*Pr. 3* Setting
SF-V5RU-3.7kW or less	170V	50Hz
SF-V5RU-5.5kW or more	160V	
SF-V5RUH-3.7kW or less	340V	
SF-V5RUH-5.5kW or more	320V	
SF-VR	160V	
SF-VRH	320V	

REMARKS

When operation is discontinued under vector control due to failure of an encoder, etc., setting "9999" in *Pr. 80 Motor capacity* or *Pr. 81 Number of motor poles* enables V/F control operation.

CAUTION

- When advanced magnetic flux vector control mode, real sensorless vector control or vector control is selected, *Pr. 3, Pr. 47, Pr. 113* and *Pr. 19* are made invalid and *Pr. 83* and *Pr. 84* are made valid.
  Note that *Pr. 3* or *Pr. 47* and *Pr. 113* values are made valid as inflection points of S-pattern when *Pr. 29 Acceleration/deceleration pattern selection* = "1" (S-pattern acceleration/deceleration A).
- When *Pr. 71 Applied motor* is set to "2" (adjustable 5 points V/F characteristic), the *Pr. 47* and *Pr. 113* setting becomes invalid. In addition, you cannot set "8888" or "9999" in *Pr. 19*.
- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 14 Load pattern selection ☞ *Refer to page 161*
Pr. 29 Acceleration/deceleration pattern selection ☞ *Refer to page 176*
Pr. 71 Applied motor ☞ *Refer to page 185*
Pr. 80 Motor capacity ☞ *Refer to page 92.*
Pr. 83 Motor rated voltage, Pr. 84 Rated motor frequency ☞ *Refer to page 187.*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228.*
Advanced magnetic flux vector control ☞ *Refer to page 145.*
Real sensorless vector control ☞ *Refer to page 92.*


WWW.BSNEW.IR

4.10.2 Load pattern selection (Pr. 14) V/F

You can select the optimum output characteristic (V/F characteristic) for the application and load characteristics.

Parameter Number	Name	Initial Value	Setting Range	Description
14	Load pattern selection	0	0	For constant torque load
			1	For reduced-torque load
			2	For constant torque elevators (at reverse rotation boost of 0%)
			3	For constant torque elevators (at forward rotation boost of 0%)
			4	RT signal on ...for constant torque load RT signal off ...for constant torque elevators at reverse rotation boost of 0%
			5	RT signal on ...for constant torque load RT signal off ...for constant torque elevators at forward rotation boost of 0%

Pr.14=0




(1) For constant-torque load (setting "0", initial value)

- At or less than the base frequency, the output voltage varies linearly with the output frequency.
- Set this value when driving the load whose load torque is constant even if the speed varies, e.g. conveyor, cart or roll drive.

POINT

If the load is a fan or pump, select "for rated torque load (setting "0")" in any of the following cases.
- When a blower of large moment of inertia (J) is accelerated in a short time
- For constant-torque load such as rotary pump or gear pump
- When load torque increases at low speed, e.g. screw pump

Pr.14=1




(2) For variable-torque load (setting "1")

- At or less than the base frequency, the output voltage varies with the output frequency in a square curve.
- Set this value when driving the load whose load torque varies in proportion to the square of the speed, e.g. fan or pump.

(3) Vertical lift load applications (setting values "2, 3")


Pr.14=2

For vertical lift loads
At forward rotation boost...*Pr.0* setting
At reverse rotation boost...0%



Pr.14=3

For vertical lift loads
At forward rotation boost...0%
At reverse rotation boost...*Pr.0* setting



- Set "2" when a vertical lift load is fixed as power driving load at forward rotation and regenerative load at reverse rotation.
- *Pr. 0 Torque boost* is valid during forward rotation and torque boost is automatically changed to "0%" during reverse rotation.
- Set "3" for an elevated load that is in the driving mode during reverse rotation and in the regenerative load mode during forward rotation according to the load weight, e.g. counterweight system.

REMARKS

- When torque is continuously regenerated as vertical lift load, it is effective to set the rated voltage in *Pr. 19 Base frequency voltage* to prevent trip due to current at regeneration.

WWW.BSNEW.IR

Pr. 14 Setting	RT(X17) Signal	Output Characteristics
4	ON	For constant torque load (same as when the setting is "0")
	OFF	For elevators at reverse rotation boost of 0% (same as when the setting is "2")
5	ON	For constant torque load (same as when the setting is "0")
	OFF	For elevators at forward rotation boost of 0% (same as when the setting is "3")

(4) Change load pattern selection using terminal (setting values are "4, 5")

· Output characteristic can be switched between for constant torque load and for elevator using the RT signal or X17 signal.

· For the terminal used for X17 signal input, set "17" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.
When X17 is assigned, switchover by the RT signal is made invalid.

REMARKS

· The RT signal is assigned to the terminal RT in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, the RT signal can be assigned to the other terminal.

CAUTION

· When advanced magnetic flux vector control, real sensorless vector control or vector control is selected, this parameter setting is ignored.

· Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal. When the RT signal is on, the other second functions are also valid.

♦ Parameters referred to ♦

Pr. 0 Torque boost ☞ *Refer to page 143*
Pr. 3 Base frequency ☞ *Refer to page 159*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*
Advanced magnetic flux vector control ☞ *Refer to page 145.*
Real sensorless vector control ☞ *Refer to page 92.*

WWW.BSNEW.IR

4.10.3 Elevator mode (automatic acceleration/deceleration) (Pr. 61, Pr. 64, Pr. 292)


Operation matching a load characteristic of elevator with counterweight can be performed.

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description	
61	Reference current	9999	02150 (01100) or less	0 to 500A	Set the reference current for elevator mode.	
			02880 (01440) or more	0 to 3600A		
			9999		Rated inverter current value reference	
64	Starting frequency for elevator mode	9999	0 to 10%		Set the starting frequency for the elevator mode.	
			9999		Starting frequency 2Hz	
292	Automatic acceleration/ deceleration	0	0		Normal mode	
			1		Minimum acceleration/ deceleration (without brake)	*(Refer to page 179.)*
			11		Minimum acceleration/ deceleration (with brake)	
			3		Optimum acceleration/ deceleration	
			5		Elevator mode 1 (stall prevention operation level 150%)	
			6		Elevator mode 2 (stall prevention operation level 180%)	
			7, 8		Brake sequence mode 1, 2 *(Refer to page 214.)*	

(1) Elevator mode

- When "5" or "6" is set in *Pr. 292 Automatic acceleration/deceleration* , elevator mode is selected and each setting is changed as in the table below.
- Enough torque is generated during power driving and the torque boost value is automatically changed during regeneration and operation without load so that overcurrent protection function does not activate due to over excitation.

	Normal Mode	Elevator Mode	
		***Pr. 292* = 5**	***Pr. 292* = 6**
Torque boost	Pr. 0 (6/4/3/2/1%)	Changes according to the output current (right chart)	
Starting frequency	Pr. 13 (0.5Hz)	Pr. 64 (2Hz) Accelerate after maintaining 100ms	
Base frequency voltage	Pr. 19 (9999)	220V (440V)	
Stall prevention operation level	Pr. 22 (150%) etc.	150%	180%



- When operating the elevator with load more than the rated inverter current, the maximum torque may become insufficient. For the elevator without counterweight, setting "2 or 3" (for elevator load) in *Pr. 14 Load pattern selection* and an appropriate value in *Pr. 19 Base frequency voltage* will generate larger maximum torque than when elevator mode is selected.

REMARKS

- Stall prevention operation level automatically decreases according to the electronic thermal relay function cumulative value, to prevent inverter overload shut-off (E.THT, E.THM).
- When elevator mode (*Pr. 292* = 5, 6) is set with automatic acceleration / deceleration set, the stall prevention operation level is changed as shown below.

		SLD	LD	ND	HD
		***Pr. 570* = 0**	***Pr. 570* = 1**	***Pr. 570* = 2**	***Pr. 570* = 3**
Stall prevention operation level	***Pr. 292* = 5**	110%	120%	150%	200%
	***Pr. 292* = 6**	115%	140%	180%	230%

WWW.BSNEW.IR

(2) Adjustment of elevator mode *(Pr. 61, Pr. 64)*

· By setting the adjustment parameters *Pr. 61* and *Pr. 64*, the application range can be made wider.

Parameter Number	Name	Setting Range 200V class (400V class)		Description
61	Reference current	02150 (01100) or less	0 to 500A	For example, when the motor and inverter are different in capacity, set the rated motor current value. Set reference current (A) of the stall prevention operation level
		02880 (01440) or more	0 to 3600A	
		9999 (initial value)		The rated inverter output current is defined as reference.
64	Starting frequency for elevator mode	0 to 10Hz		Set the starting frequency for the elevator mode.
		9999 (initial value)		Starting frequency 2Hz

REMARKS

· Even if elevator mode has been selected, inputting the jog signal (jog operation), RT signal (second function selection) or X9 signal (third function selection) during an inverter stop will switch to the normal operation and give priority to jog operation or second and third function selection. Note that JOG and RT signal input is invalid even if JOG signal and RT signal are input during operation with acceleration/deceleration selected.
· Elevator mode is invalid when advanced magnetic flux vector, real sensorless vector control or vector control is selected.
· Since the *Pr. 61* and *Pr. 64* settings automatically return to the initial value (9999) if the *Pr. 292* setting is changed, set *Pr. 292* first when you need to set *Pr. 61* and *Pr. 64*.

♦ Parameters referred to ♦


Pr. 570 Multiple rating setting ☞ *Refer to page 155*

WWW.BSNEW.IR

4.10.4 Adjustable 5 points V/F (Pr. 71, Pr. 100 to Pr. 109)

A dedicated V/F pattern can be made by freely setting the V/F characteristic between a startup and the base frequency and base voltage under V/F control (frequency voltage/frequency).
The torque pattern that is optimum for the machine's characteristic can be set.

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0 to 8, 13 to 18, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54	Set "2" for adjustable 5 points V/F control.
100	V/F1(first frequency)	9999	0 to 400Hz, 9999	Set each points (frequency, voltage) of V/F pattern. 9999: No V/F setting
101	V/F1(first frequency voltage)	0V	0 to 1000V	
102	V/F2(second frequency)	9999	0 to 400Hz, 9999	
103	V/F2(second frequency voltage)	0V	0 to 1000V	
104	V/F3(third frequency)	9999	0 to 400Hz, 9999	
105	V/F3(third frequency voltage)	0V	0 to 1000V	
106	V/F4(fourth frequency)	9999	0 to 400Hz, 9999	
107	V/F4(fourth frequency voltage)	0V	0 to 1000V	
108	V/F5(fifth frequency)	9999	0 to 400Hz, 9999	
109	V/F5(fifth frequency voltage)	0V	0 to 1000V	



- Any V/F characteristic can be provided by presetting the parameters of *V/F1 (first frequency voltage/first frequency) to V/F5*.
- For a machine of large static friction coefficient and small dynamic static friction coefficient, for example, set a V/F pattern that will increase the voltage only in a low-speed range since such a machine requires large torque at a start.

(Setting procedure)

1)Set the rated motor voltage in *Pr. 19 Base frequency voltage*. (No function at the setting of "9999" (initial value) or "8888".)
2)Set *Pr. 71 Applied motor* to "2" (Adjustable 5 points V/F characteristic).
3)Set the frequency and voltage you want to set in *Pr. 100 to Pr. 109*.

⚠ CAUTION

⚠ Set this parameter correctly according to the motor used.
Incorrect setting may cause the motor to overheat and burn.

CAUTION

- Adjustable 5 points V/F characteristics function only under V/F control. They do not function under advanced magnetic flux vector control, real sensorless vector control or vector control.
- When *Pr. 19 Base frequency voltage* = "8888" or "9999", *Pr. 71* cannot be set to "2". To set *Pr. 71* to "2", set the rated voltage value in *Pr. 19*.
- When the frequency values at each point are the same, a write disable error (Er1) appears.
- Set the points (frequencies, voltages) of *Pr. 100 to Pr. 109* within the ranges of *Pr. 3 Base frequency* and *Pr. 19 Base frequency voltage*.
- When "2" is set in *Pr. 71*, *Pr. 47 Second V/F (base frequency)* and *Pr. 113 Third V/F (base frequency)* will not function.
- When *Pr. 71* is set to "2", the electronic thermal relay function makes calculation as a standard motor.

REMARKS

- A greater energy saving effect can be expected by combining *Pr. 60 Energy saving control selection* and adjustable 5 points V/F.
- For the FR-A720-00240, 00330 and FR-A740-00120, 00170, the *Pr. 0 Torque boost* and *Pr. 12 DC injection brake operation voltage* settings are automatically changed according to the *Pr. 71* setting as follows.

Pr. 71	Standard Motor Setting 0, 2, 3 to 8, 20, 23, 24, 40, 43, 44	Constant Torque Motor Setting 1, 13 to 18, 50, 53, 54
Pr. 0	3%	2%
Pr. 12	4%	2%

♦ Parameters referred to ♦

- *Pr. 3 Base frequency, Pr. 19 Base frequency voltage* ☞ *Refer to page 159*
- *Pr. 12 DC injection brake operation voltage* ☞ *Refer to page 200*
- *Pr. 47 Second V/F (base frequency), Pr. 113 Third V/F (base frequency)* ☞ *Refer to page 159*
- *Pr. 60 Energy saving control selection* ☞ *Refer to page 273*
- *Pr. 71 Applied motor, Pr. 450 Second applied motor* ☞ *Refer to page 185*
- *Advanced magnetic flux vector control* ☞ *Refer to page 145*
- *Real sensorless vector control* ☞ *Refer to page 92*
- *Vector control* ☞ *Refer to page 92*

WWW.BSNEW.IR

4.11 Frequency setting by external terminals


Purpose	Parameter that must be Set		Refer to Page
Make frequency setting by combination of terminals	**Multi-speed operation**	**Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239**	166
Perform jog operation	**Jog operation**	**Pr. 15, Pr. 16**	168
Added compensation for multi-speed setting and remote setting	**Multi-speed input compensation selection**	**Pr. 28**	170
Infinitely variable speed setting by terminals	**Remote setting function**	**Pr. 59**	170

4.11.1 Multi-speed setting operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)

Can be used to change the preset speed in the parameter with the contact terminals.
Any speed can be selected by merely turning on-off the contact signals (RH, RM, RL, REX signals).

Parameter Number	Name	Initial Value	Setting Range	Description
4	**Multi-speed setting (high speed)**	60Hz	0 to 400Hz	Set the frequency when RH turns on.
5	**Multi-speed setting (middle speed)**	30Hz	0 to 400Hz	Set the frequency when RM turns on.
6	**Multi-speed setting (low speed)**	10Hz	0 to 400Hz	Set the frequency when RL turns on.
24	**Multi-speed setting (speed 4)**	9999	0 to 400Hz, 9999	Frequency from speed 4 to speed 15 can be set according to the combination of the RH, RM, RL and REX signals. 9999: not selected
25	**Multi-speed setting (speed 5)**	9999	0 to 400Hz, 9999	
26	**Multi-speed setting (speed 6)**	9999	0 to 400Hz, 9999	
27	**Multi-speed setting (speed 7)**	9999	0 to 400Hz, 9999	
232	**Multi-speed setting (speed 8)**	9999	0 to 400Hz, 9999	
233	**Multi-speed setting (speed 9)**	9999	0 to 400Hz, 9999	
234	**Multi-speed setting (speed 10)**	9999	0 to 400Hz, 9999	
235	**Multi-speed setting (speed 11)**	9999	0 to 400Hz, 9999	
236	**Multi-speed setting (speed 12)**	9999	0 to 400Hz, 9999	
237	**Multi-speed setting (speed 13)**	9999	0 to 400Hz, 9999	
238	**Multi-speed setting (speed 14)**	9999	0 to 400Hz, 9999	
239	**Multi-speed setting (speed 15)**	9999	0 to 400Hz, 9999	

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.



(1) Multi-speed setting *(Pr. 4 to Pr. 6)*

· Operation is performed at the frequency set in *Pr. 4* when the RH signal turns on, *Pr. 5* when the RM signal turns on, and *Pr. 6* when the RL signal turns on.

REMARKS

· In the initial setting, if two or three speeds are simultaneously selected, priority is given to the set frequency of the lower signal. For example, when the RH and RM signals turn on, the RM signal *(Pr. 5)* has a higher priority.

· The RH, RM, RL signals are assigned to the terminal RH, RM, RL in the initial setting.
By setting "0 (RL)", "1 (RM)", "2 (RH)" in any of *Pr.178 to Pr.189 (input terminal function assignment)*, the signals can be assigned to other terminals.


(2) Multi-speed setting higher than speed 4 *(Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)*

· Frequency from speed 4 to speed 15 can be set according to the combination of the RH, RM, RL and REX signals. Set the running frequencies in *Pr. 24 to Pr. 27, Pr. 232 to Pr. 239*. (In the initial value setting, speed 4 to speed 15 are unavailable.).

· For the terminal used for REX signal input, set "8" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.

* When "9999" is set in *Pr. 232 Multi-speed setting (speed 8)*, operation is performed at frequency set in *Pr. 6* when RH, RM and RL are turned off and REX is turned on.

WWW.BSNEW.IR



Multi-Speed Operation Connection Example

REMARKS

- The priorities of the frequency commands by the external signals are "jog operation > multi-speed operation > terminal 4 analog input > terminal 2 analog input". (Refer to *page 289* for the frequency command by analog input)
- Valid in external operation mode or PU/external combined operation mode (*Pr. 79* = "3" or "4").
- Multi-speed parameters can also be set in the PU or external operation mode.
- *Pr. 24 to Pr. 27* and *Pr. 232 to Pr. 239* settings have no priority between them.
- When a value other than "0" is set in *Pr. 59 Remote function selection*, the RH, RM and RL signals are used as the remote setting signals and the multi-speed setting becomes invalid.
- When making analog input compensation, set "1" in *Pr. 28 Multi-speed input compensation selection*.

CAUTION

- Changing the terminal assignment using *Pr. 178* to *Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 15 Jog frequency ☞ *Refer to page 168*
Pr. 28 Multi-speed input compensation selection ☞ *Refer to page 170*
Pr. 59 Remote function selection ☞ *Refer to page 170*
Pr. 79 Operation mode selection ☞ *Refer to page 308*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*

WWW.BSNEW.IR

4.11.2 Jog operation (Pr. 15, Pr. 16)

You can set the frequency and acceleration/deceleration time for jog operation. Jog operation can be performed from either the outside or PU.
Can be used for conveyor positioning, test operation, etc.


Parameter Number	Name	Initial Value	Setting Range	Description
15	**Jog frequency**	5Hz	0 to 400Hz	Set the frequency for jog operation.
16	**Jog acceleration/ deceleration time**	0.5s	0 to 3600/360s*	Set the acceleration/deceleration time for jog operation. Set the time taken to reach the frequency (Initial value is 60Hz) set in *Pr. 20 Acceleration/deceleration reference frequency* for acceleration/ deceleration time. The acceleration and deceleration time cannot be set separately.


The above parameters are displayed as simple mode parameters only when the parameter unit (FR-PU04/FR-PU07) is connected. When the operation panel (FR-DU07) is connected, the above parameters can be set only when *Pr. 160 User group read selection* = "0". *(Refer to page 306)*

* When the setting of *Pr. 21 Acceleration/deceleration time increments* is "0" (initial value), the setting range is "0 to 3600s" and the setting increments are "0.1s", and when the setting is "1", the setting range is "0 to 360s" and the setting increments are "0.01s"

(1) Jog operation from outside

· When the jog signal is on, a start and stop can be made by the start signal (STF, STR). (The jog signal is assigned to the terminal JOG in the initial setting)





Connection diagram for external jog operation


Operation

1. Screen at powering on
   - Confirm that the external operation mode is selected. ([EXT] lit)
     If not displayed, press (PU/EXT) to change to the external [EXT] operation mode.
     If the operation mode still does not change, set Pr. 79 to change to the external operation mode.

Indication



2. Turn the JOG switch on.





3. Turn the start switch (STF or STR) on.
   - The motor rotates while start switch (STF or STR) is ON.
   - Rotates at 5Hz. (Initial value of *Pr. 15*)



Rotates while ON

4. Turn the start switch (STF or STR) off.





Stop


REMARKS


· When you want to change the running frequency, change *Pr. 15 Jog frequency* . (initial value "5Hz")
· When you want to change the acceleration/deceleration time change *Pr. 16 Jog acceleration/deceleration time* . (initial value "0.5s")

WWW.BSNEW.IR

(2) Jog operation from PU

· Set the PU (FR-DU07/FR-PU07/FR-PU04) to the jog operation mode. Operation is performed only while the start button is pressed.



Operation	Indication
1. Confirmation of the RUN indication and operation mode indication • The monitor mode should have been selected. • The inverter should be at a stop.	
2. Press PU/EXT to choose the PU JOG operation mode.	PU/EXT ⇨ 
3. Press FWD (or REV). • While FWD (or REV) is pressed, the motor rotates. • Rotates at 5Hz. (initial value of Pr. 15)	FWD ⇨  Hold down.
4. Release FWD (or REV).	FWD ⇨ Release  Stop
[When changing the frequency of PU JOG operation]	
5. Press MODE to choose the parameter setting mode.	MODE ⇨  The parameter number read previously appears.
6. Turn dial until *Pr. 15 JOG frequency* appears.	dial ⇨ 
7. Press SET to show the currently set value. (5Hz)	SET ⇨ 
8. Turn dial to set the value to "10.00". (10Hz)	dial ⇨ 
9. Press SET to set.	SET ⇨  Flicker · · · Parameter setting complete!!
10. Perform the operations in steps 1 to 4. The motor rotates at 10Hz.	

CAUTION

- When *Pr. 29 Acceleration/deceleration pattern selection*= "1" (S-pattern acceleration/deceleration A), the acceleration/deceleration time is the period of time required to reach *Pr. 3 Base frequency*.
- The *Pr. 15* setting should be equal to or higher than the *Pr. 13 Starting frequency* setting.
- The JOG signal can be assigned to the input terminal using any of *Pr. 178 to Pr. 189 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.
- During jog operation, the second acceleration/deceleration via the RT signal cannot be selected. (The other second functions are valid. *(Refer to page 232)*)
- When *Pr. 79 Operation mode selection* = "4", push FWD/REV of the PU (FR-DU07/FR-PU04/FR-PU07) to make a start or push STOP RESET to make a stop.
- This function is invalid when *Pr. 79* = "3" or "6".
- Jog operation is invalid under position control.

♦ Parameters referred to ♦

- *Pr. 13 Starting frequency* ☞ *Refer to page 175*
- *Pr. 29 Acceleration/deceleration pattern selection* ☞ *Refer to page 176*
- *Pr. 20 Acceleration/deceleration reference frequency, Pr. 21 Acceleration/deceleration time increments* ☞ *Refer to page 173*
- *Pr. 79 Operation mode selection* ☞ *Refer to page 308*
- *Pr. 178 to Pr. 189 (input terminal function selection)* ☞ *Refer to page 228*

WWW.BSNEW.IR

4.11.3 Input compensation of multi-speed and remote setting (Pr. 28)

By inputting the frequency setting compensation signal (terminal 1, 2), the speed (frequency) can be compensated for relative to the multi-speed setting or the speed setting by remote setting function.

Parameter Number	Name	Initial Value	Setting Range	Description
28	Multi-speed input compensation selection	0	0	Without compensation
			1	With compensation

REMARKS

- Select the terminal (terminal 1, 2) used for compensation input voltage (0 to ±5V, 0 to ±10) using *Pr. 73 Analog input selection*.
- When using terminal 1 for compensation input, set "0" (initial value) in *Pr. 868 Terminal 1 function assignment*.


♦ Parameters referred to ♦

Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239 (multi-speed operation) ☞ *Refer to page 166*
Pr. 73 Analog input selection ☞ *Refer to page 282*
Pr. 59 Remote function selection ☞ *Refer to page 170*
Pr. 868 Terminal 1 function assignment ☞ *Refer to page 281*

4.11.4 Remote setting function (Pr. 59)

- Even if the operation panel is located away from the enclosure, you can use contact signals to perform continuous variable-speed operation, without using analog signals.

Parameter Number	Name	Initial Value	Setting Range	Description	
				RH, RM, RL signal function	Frequency setting storage function
59	Remote function selection	0	0	Multi-speed setting	—
			1	Remote setting	Yes
			2	Remote setting	No
			3	Remote setting	No (Turning STF/STR off clears remotely- set frequency.)



* External operation frequency (other than multi-speed) or PU running frequency

(1) Remote setting function

- Use *Pr. 59* to select whether the remote setting function is used or not and whether the frequency setting storage function in the remote setting mode is used or not.
  When *Pr. 59* is set to any of "1 to 3" (remote setting function valid), the functions of the RH, RM and RL signals are changed to acceleration (RH), deceleration (RM) and clear (RL).
- When the remote function is used, the output frequency of the inverter can be compensated for as follows:
  External operation .. Frequency set with RH and RM operation + external operation frequency other than multi-speed (PU operation frequency when *Pr. 79* = "3" (external, PU combined)) and terminal 4 input.
  (When making analog input compensation, set "1" in *Pr. 28 Multi-speed input compensation selection*.
  When *Pr. 28* is set to "0" and acceleration/deceleration is made to reach the set frequency of the analog voltage input (terminal 2 or terminal 4) by RH/RM, the auxiliary input by terminal 1 becomes invalid.)
  PU operation .....Frequency set by RH/RM operation + PU running frequency

WWW.BSNEW.IR

(2) Frequency setting storage

· The frequency setting storage function stores the remotely-set frequency (frequency set by RH/RM operation) into the memory (EEPROM). When power is switched off once, then on, operation is resumed with that output frequency value. (*Pr. 59* = 1)


<Frequency setting storage conditions>

· Frequency at the point when the start signal (STF or STR) turns off

· The remotely-set frequency is stored every one minute after one minute has elapsed since turn off (on) of both the RH (acceleration) and RM (deceleration) signals. (The frequency is written if the present frequency setting compared with the past frequency setting every one minute is different. The state of the RL signal does not affect writing.)

CAUTION

· The range of frequency changeable by RH (acceleration) and RM (deceleration) is 0 to maximum frequency (*Pr. 1 or Pr. 18* setting). Note that the maximum value of set frequency is (main speed + maximum frequency).



· When the acceleration or deceleration signal switches on, acceleration/deceleration time is as set in *Pr. 44 Second acceleration/deceleration time* and *Pr. 45 Second deceleration time*. Note that when long time has been set in *Pr. 7* or *Pr. 8*, the acceleration/deceleration time is as set in *Pr. 7* or *Pr. 8*. (when RT signal is off)
When the RT signal is on, acceleration/deceleration is made in the time set to *Pr. 44* and *Pr. 45*, regardless of the *Pr. 7* or *Pr. 8* setting.

· Even if the start signal (STF or STR) is off, turning on the acceleration (RH) or deceleration (RM) signal varies the preset frequency.

· When switching the start signal from ON to OFF, or changing frequency by the RH or RM signal frequently, set the frequency setting value storage function (write to EEPROM) invalid (*Pr. 59* = "2, 3"). If set valid (*Pr. 59* = "1"), frequency is written to EEPROM frequently, this will shorten the life of the EEPROM.

· The RH, RM, RL signals can be assigned to the input terminal using any *Pr. 178 to Pr. 189 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.

· Also available for the network operation mode.


WWW.BSNEW.IR

REMARKS


During jog operation or PID control operation, the remote setting function is invalid.

Setting frequency is "0"

- Even when the remotely-set frequency is cleared by turning on the RL (clear) signal after turn off (on) of both the RH and RM signals, the inverter operates at the remotely-set frequency stored in the last operation if power is reapplied before one minute has elapsed since turn off (on) of both the RH and RM signals



- When the remotely-set frequency is cleared by turning on the RL (clear) signal after turn off (on) of both the RH and RM signals, the inverter operates at the frequency in the remotely-set frequency cleared state if power is reapplied after one minute has elapsed since turn off (on) of both the RH and RM signals.



⚠ CAUTION

⚠ When selecting this function, re-set the maximum frequency according to the machine.

♦ Parameters referred to ♦

Pr. 1 Maximum frequency, Pr. 18 High speed maximum frequency ☞ *Refer to page 157*
Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 44 Second acceleration/deceleration time, Pr. 45 Second deceleration time ☞ *Refer to page 173*
Pr. 28 Multi-speed input compensation selection ☞ *Refer to page 170*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*

WWW.BSNEW.IR

4.12 Setting of acceleration/deceleration time and acceleration/deceleration pattern


Purpose	Parameter that must be Set		Refer to Page
Motor acceleration/deceleration time setting	**Acceleration/deceleration time**	**Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 110, Pr. 111**	173
Starting frequency	**Starting frequency and start-time hold**	**Pr. 13, Pr. 571**	175
Set acceleration/deceleration pattern suitable for application	**Acceleration/deceleration pattern and backlash measures**	**Pr. 29, Pr. 140 to Pr. 143, Pr. 380 to Pr. 383, Pr. 516 to Pr. 519**	176
Automatically set appropriate acceleration/deceleration time	**Automatic acceleration/ deceleration**	**Pr. 61 to Pr. 63, Pr. 292**	179

4.12.1 Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 110, Pr. 111)

Used to set motor acceleration/deceleration time.
Set a larger value for a slower speed increase/decrease or a smaller value for a faster speed increase/decrease.
For the acceleration time at automatic restart after instantaneous power failure, refer to *Pr. 611 Acceleration time at a restart (page 261)*.

Parameter Number	Name	Initial Value 200V class (400V class)		Setting Range	Description	
7	**Acceleration time**	00330 (00170) or less	5s	0 to 3600/360s *1	Set the motor acceleration time.	
		00460 (00230) or more	15s			
8	**Deceleration time**	00330 (00170) or less	5s	0 to 3600/360s *1	Set the motor deceleration time.	
		00460 (00230) or more	15s			
20	**Acceleration/ deceleration reference frequency**	60Hz		1 to 400Hz	Set the frequency that will be the basis of acceleration/deceleration time. As acceleration/deceleration time, set the frequency change time from stop to *Pr. 20*.	
21	**Acceleration/ deceleration time increments**	0		0	Increments: 0.1s Range: 0 to 3600s	Increments and setting range of acceleration/ deceleration time setting can be changed.
				1	Increments: 0.01s Range: 0 to 360s	
44	**Second acceleration/ deceleration time**	5s		0 to 3600/360s *1	Set the acceleration/deceleration time when the RT signal is on.	
45	**Second deceleration time**	9999		0 to 3600/360s *1	Set the deceleration time when the RT signal is on.	
				9999	Acceleration time = deceleration time	
110	**Third acceleration/ deceleration time**	9999		0 to 3600/360s *1	Set the acceleration/deceleration time when the X9 signal is on.	
				9999	Without the third acceleration/deceleration function.	
111	**Third deceleration time**	9999		0 to 3600/360s *1	Set the deceleration time when the X9 signal is on.	
				9999	Acceleration time = deceleration time	

*1 Depends on the *Pr. 21 Acceleration/deceleration time increments* setting. The initial value for the setting range is "0 to 3600s" and the setting increments is "0.1s".



(1) Acceleration time setting *(Pr. 7, Pr. 20)*

- Use *Pr. 7 Acceleration time* to set the acceleration time required to reach *Pr. 20 Acceleration/deceleration reference frequency* from 0Hz.
- Set the acceleration time according to the following formula.

$$\text{Acceleration time setting} = \frac{Pr.\ 20}{\text{Maximum operating frequency - } Pr.\ 13} \times \text{Acceleration time from stop to maximum operating frequency}$$

Example) When *Pr. 20* = 60Hz (initial value), *Pr. 13* = 0.5Hz, and acceleration can be made up to the maximum operating frequency of 50Hz in 10s

$$Pr.\ 7 = \frac{60\text{Hz}}{50\text{Hz} - 0.5\text{Hz}} \times 10\text{s} \fallingdotseq 12.1\text{s}$$

WWW.BSNEW.IR

(2) Deceleration time setting *(Pr. 8, Pr. 20)*

- Use *Pr. 8 Deceleration time* to set the deceleration time required to reach 0Hz from *Pr. 20 Acceleration/deceleration reference frequency*.
- Set the deceleration time according to the following formula.

$$\text{Deceleration time setting} = \frac{Pr.\ 20}{\text{Maximum operating frequency - } Pr.\ 10} \times \text{Deceleration time from maximum operating frequency to stop.}$$

Example)When the frequency can be decelerated down to the maximum operating frequency of 50Hz in 10s with 120Hz set in *Pr. 20* and 3Hz set in *Pr. 10*

$$Pr.\ 8 = \frac{120\text{Hz}}{50\text{Hz} - 3\text{Hz}} \times 10\text{s} \fallingdotseq 25.5\text{s}$$

(3) Change the setting range and increments of the acceleration/deceleration time *(Pr. 21)*

- Use *Pr. 21* to set the acceleration/deceleration time and minimum setting range.
  Setting "0" (initial value).....0 to 3600s (minimum setting increments 0.1s)
  Setting "1" .....0 to 360s (minimum setting increments 0.01s)

CAUTION

- Changing the *Pr. 21* setting changes the acceleration/deceleration time setting *(Pr. 7, Pr. 8, Pr. 16, Pr. 44, Pr. 45, Pr. 110, Pr. 111, Pr. 264, Pr. 265)*.
  (The *Pr. 611 Acceleration time at a restart* setting is not affected.)
  <Example>
  When *Pr. 21* = "0", setting "5.0" s in *Pr. 7* and "1" in *Pr. 21* automatically changes the *Pr. 7* setting to "0.5" s.

(4) Set multiple acceleration/deceleration time (RT signal, *Pr. 44, Pr. 45, Pr. 110, Pr. 111*)

- *Pr. 44* and *Pr. 45* are valid when the RT signal is on, and *Pr. 110* and *Pr. 111* are valid when the X9 signal is on. When both the RT and X9 are on, *Pr. 110* and *Pr. 111* are valid.
- For the terminal used for X9 signal input, set "9" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.
- When "9999" is set in *Pr. 45* or *Pr. 111*, the deceleration time becomes equal to the acceleration time *(Pr. 44, Pr. 110)*.
- When *Pr. 110* = "9999", third acceleration/deceleration time is invalid.

CAUTION

- In S-shaped acceleration/deceleration pattern A *(refer to page 176)*, the set time is the period required to reach the base frequency set in *Pr. 3 Base frequency*.
- Acceleration/deceleration time formula when the set frequency is the base frequency or higher

$$t = \frac{4}{9} \times \frac{T}{(Pr.\ 3)^2} \times f^2 + \frac{5}{9} T$$

T: Acceleration/deceleration time setting value(s)
f : Set frequency(Hz)

- Guideline for acceleration/deceleration time when *Pr. 3 Base frequency* = 60Hz (0Hz to set frequency)

Frequency setting (Hz) / Acceleration/deceleration time (s)	60	120	200	400
5	5	12	27	102
15	15	35	82	305

- The RT, X9 signal can be assigned to the input terminal using any of *Pr. 178 to Pr. 189 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.

REMARKS

- The RT (X9) signal acts as the second (third) function selection signal and makes the other second (third) function valid. *(Refer to page 232)*
- The RT signal is assigned to the RT terminal in the default setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, you can assign the RT signal to the other terminal.
- If the *Pr. 20* setting is changed, the *Pr. 125* and *Pr. 126 (frequency setting signal gain frequency)* settings do not change. Set *Pr. 125 and Pr. 126* to adjust the gains.
- When the *Pr. 7, Pr. 8, Pr. 44, Pr. 45, Pr. 110* and *Pr. 111* settings are 0.03s or less, the acceleration/deceleration time is 0.04s (under V/F control, advanced magnetic flux vector control). At that time, set *Pr. 20* to "120Hz" or less.
- If the acceleration/deceleration time is set, the actual motor acceleration/deceleration time cannot be made shorter than the shortest acceleration/deceleration time determined by the mechanical system J (moment of inertia) and motor torque.

♦ Parameters referred to ♦


Pr. 3 Base frequency ☞ *Refer to page 159*
Pr. 10 DC injection brake operation frequency ☞ *Refer to page 200*
Pr. 29 Acceleration/deceleration pattern selection ☞ *Refer to page 176*
Pr. 125, Pr. 126 (frequency setting gain frequency) ☞ *Refer to page 289*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*

WWW.BSNEW.IR

4.12.2 Starting frequency and start-time hold function (Pr. 13, Pr. 571)

You can set the starting frequency and hold the set starting frequency for a certain period of time.
Set these functions when you need the starting torque or want to smooth motor drive at a start.

Parameter Number	Name	Initial Value	Setting Range	Description
13	**Starting frequency**	0.5Hz	0 to 60Hz	Frequency at start can be set in the range 0 to 60Hz. You can set the starting frequency at which the start signal is turned on.
571	**Holding time at a start**	9999	0.0 to 10.0s	Set the holding time of *Pr. 13 Starting frequency*.
			9999	Holding function at a start is invalid




(1) Starting frequency setting *(Pr. 13)*

- Frequency at start can be set in the range 0 to 60Hz.
- You can set the starting frequency at which the start signal is turned on.

CAUTION

The inverter will not start if the frequency setting signal is less than the value set in *Pr. 13*.
For example, when 5Hz is set in *Pr. 13*, the motor will not start running until the frequency setting signal reaches 5Hz.



(2) Start-time hold function *(Pr. 571)*

- This function holds the time set in *Pr. 571* and the output frequency set in *Pr. 13 Starting frequency*.
- This function performs initial excitation to smooth the motor drive at a start.

REMARKS

When *Pr. 13* = "0Hz", the starting frequency is held at 0.01Hz.

CAUTION

- When the start signal was turned off during start-time hold, deceleration is started at that point.
- At switching between forward rotation and reverse rotation, the starting frequency is valid but the start-time hold function is invalid.

⚠ CAUTION

⚠ Note that when *Pr. 13* is set to any value equal to or less than *Pr. 2 Minimum frequency*, simply turning on the start signal will run the motor at the preset frequency even if the command frequency is not input.

♦ Parameters referred to ♦


Pr. 2 Minimum frequency ☞ *Refer to page 157*

WWW.BSNEW.IR

4.12.3 Acceleration/deceleration pattern (Pr. 29, Pr. 140 to Pr. 143, Pr. 380 to Pr. 383, Pr. 516 to Pr. 519)


You can set the acceleration/deceleration pattern suitable for application.
You can also set the backlash measures that stop acceleration/deceleration once at the parameter-set frequency and time during acceleration/deceleration.

Parameter Number	Name	Initial Value	Setting Range	Description
29	Acceleration/deceleration pattern selection	0	0	Linear acceleration/ deceleration
			1	S-pattern acceleration/deceleration A
			2	S-pattern acceleration/deceleration B
			3	Backlash measures
			4	S-pattern acceleration/deceleration C
			5	S-pattern acceleration/deceleration D
140	Backlash acceleration stopping frequency	1Hz	0 to 400Hz	Set the stopping frequency and time for backlash measures. Valid when *Pr. 29* = 3
141	Backlash acceleration stopping time	0.5s	0 to 360s	
142	Backlash deceleration stopping frequency	1Hz	0 to 400Hz	
143	Backlash deceleration stopping time	0.5s	0 to 360s	
380	Acceleration S-pattern 1	0	0 to 50%	Valid when S-pattern acceleration/ deceleration C (*Pr. 29* = 4) is set. Set the time taken for S-pattern from starting of acceleration/deceleration to linear acceleration as % to the acceleration/deceleration time (*Pr. 7, Pr. 8* etc.). An acceleration/deceleration pattern can be changed with the X20 signal.
381	Deceleration S-pattern 1	0	0 to 50%	
382	Acceleration S-pattern 2	0	0 to 50%	
383	Deceleration S-pattern 2	0	0 to 50%	
516	S-pattern time at a start of acceleration	0.1s	0.1 to 2.5s	Valid when S-pattern acceleration/ deceleration D (*Pr. 29* = 5) is set. Set the time taken for S-pattern acceleration/deceleration (S-pattern operation).
517	S-pattern time at a completion of acceleration	0.1s	0.1 to 2.5s	
518	S-pattern time at a start of deceleraiton	0.1s	0.1 to 2.5s	
519	S-pattern time at a completion of deceleraiton	0.1s	0.1 to 2.5s	



(1) Linear acceleration/ deceleration (*Pr. 29* = "0", initial value)

· When the frequency is changed for acceleration, deceleration, etc. in inverter operation, the output frequency is changed linearly (linear acceleration/ deceleration) to reach the set frequency without straining the motor and inverter. Linear acceleration/deceleration has a uniform frequency/time slope.




(2) S-pattern acceleration/deceleration A (*Pr. 29* = "1")

· For machine tool spindle applications, etc.
Used when acceleration/deceleration must be made in a short time to a high-speed range of not lower than the base frequency. In this acceleration/ deceleration pattern, *Pr. 3 Base frequency* (fb) is the inflection point of the S pattern and you can set the acceleration/deceleration time appropriate for motor torque reduction in a constant-power operation region of *Pr. 3 Base frequency* (initial value = 60Hz) or higher.

CAUTION


· As the acceleration/deceleration time of S-pattern acceleration/deceleration A, set the time taken until *Pr. 3 Base frequency* is reached, not *Pr. 20 Acceleration/deceleration reference frequency*.

WWW.BSNEW.IR



(3) S-pattern acceleration/deceleration B (*Pr. 29* = "2")

· For prevention of load shifting in conveyor and other applications
Since acceleration/deceleration is always made in an S shape from current frequency (f2) to target frequency (f1), this function eases shock produced at acceleration/deceleration and is effective for load collapse prevention, etc.




(4) Backlash measures (*Pr. 29* = "3", *Pr. 140 to Pr. 143*)

· What is backlash?
Reduction gears have an engagement gap and have a dead zone between forward rotation and reverse rotation. This dead zone is called backlash, and this gap disables a mechanical system from following motor rotation.
More specifically, a motor shaft develops excessive torque when the direction of rotation changes or when constant-speed operation shifts to deceleration, resulting in a sudden motor current increase or regenerative status.
· To avoid backlash, acceleration/deceleration is temporarily stopped.
Set the acceleration/deceleration stopping frequency and time in *Pr. 140 to Pr. 143*.

CAUTION

Setting the backlash measures increases the acceleration/deceleration time by the stopping time.




(5) S-pattern acceleration/deceleration C (*Pr. 29* = "4", *Pr. 380 to Pr. 383*)

· With the S-pattern acceleration/deceleration C switch signal (X20), an acceleration/deceleration curve S-pattern 1 or S-pattern 2 can be selected.
· For the terminal used for X20 signal input, set "20" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.

Operation / X20 signal	During Acceleration	During Deceleration
OFF	*Pr. 380 Acceleration S-pattern 1*	*Pr. 381 Deceleration S-pattern 1*
ON	*Pr. 382 Acceleration S-pattern 2*	*Pr. 383 Deceleration S-pattern 2*

Parameter setting (%) Ts / T × 100%



· Set % of time taken for forming an S-pattern in *Pr. 380 to Pr. 383* as acceleration time is 100%.

REMARKS


· At a start, the motor starts at *Pr. 13 Starting frequency* when the start signal turns on.
· If there is a difference between the speed command and speed at a start of deceleration due to torque limit operation etc., the speed command is matched with the speed to make deceleration.


CAUTION

· Change the S pattern acceleration/deceleration C switch (X20 signal) after the speed becomes constant.
· S pattern operation before switching continues even if the X20 signal is changed during acceleration or deceleration.
· The X20 signal can be assigned to the input terminal using any of *Pr. 178 to Pr. 189 (input terminal function selection)*. Changing the terminal assignment may affect the other functions. Make setting after confirming the function of each terminal.

WWW.BSNEW.IR

(6) S-pattern acceleration/deceleration D (*Pr. 29* = "5", *Pr. 516 to Pr. 519*)





- Set the time taken for S-pattern operation of S-pattern acceleration/deceleration using *Pr. 516 to Pr. 519*.
  Set each S-pattern operation time for acceleration start *(Pr. 516)*, acceleration completion *(Pr. 517)*, deceleration start *(Pr. 518)* and deceleration completion *(Pr. 519)*.
- When S-pattern acceleration/deceleration D is set, acceleration/deceleration time will become longer as follows:

Actual acceleration time T2 = set acceleration time T1 + (S-pattern time at a start of acceleration+S-pattern time at a completion of acceleration) /2 Actual deceleration time T2 = set deceleration time T1 + (S-pattern time at a start of deceleration+S-pattern time at a completion of deceleration) /2

Set acceleration/deceleration time T1 indicates the actual time taken for linear acceleration/deceleration calculated based on the *Pr. 7, Pr. 8, Pr. 44, Pr. 45, Pr. 110* and *Pr. 111* setting.

CAUTION

- Even if the start signal is turned off during acceleration, the inverter will not decelerate immediately to avoid sudden frequency change. (Likewise, the inverter will not immediately accelerate when deceleration is changed to reacceleration by turning the start signal on during deceleration, etc.)

- For example, the actual acceleration time when starting the inverter with an S-pattern acceleration/deceleration pattern D selected for a stop to 60Hz in the parameter initial setting is as shown left:

Set acceleration time T1 = (Set frequency - *Pr. 13)* × *Pr. 7/Pr. 20* Actual acceleration time T2 = set acceleration time T1 + (*Pr. 516* + *Pr. 517*) /2

Therefore,

Set acceleration time T1 = (60Hz - 0.5Hz) × 5s/60Hz ≒ 4.96s (actual acceleration time at linear acceleration) Actual acceleration time T2 = 4.96s + (0.1s + 0.1s)/2 = 5.06s (acceleration time at S-pattern acceleration)

CAUTION

- When the acceleration/deceleration time (*Pr. 7, Pr. 8,* etc.) setting under real sensorless vector control or vector control is 0s, the S-pattern acceleration/deceleration A to D (*Pr. 29* = "1, 2, 4, 5") is linear acceleration/deceleration.
- Set linear acceleration/deceleration (*Pr. 29* = "0 (initial value)") when torque control is exercised under real sensorless vector control or vector control. When acceleration/deceleration patterns other than the linear acceleration/deceleration are selected, the protective function of the inverter may function.

♦ Parameters referred to ♦

Pr. 3 Base frequency ☞ *Refer to page 159*
Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 20 Acceleration/deceleration reference frequency ☞ *Refer to page 173*
Pr. 178 to Pr. 189 (Input terminal function selection) ☞ *Refer to page 228*

WWW.BSNEW.IR

4.12.4 Shortest acceleraiton/deceleration and optimum acceleration/deceleration (automatic acceleration/deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293)

The inverter operates in the same conditions as when appropriate values are set in each parameter even if acceleration/deceleration time and V/F pattern are not set. This function is useful when you just want to operate, etc. without fine parameter setting.

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
61	Reference current	9999	02150(01100) or less	0 to 500A	Set the reference current during shortest/ optimum acceleration/deceleration.
			02880(01440) or more	0 to 3600A	
			9999		Rated inverter output current value is reference
62	Reference value at acceleration	9999	0 to 220% *		Set the limit value/optimum value during shortest/ optimum acceleration.
			9999		Shortest acceleration/deceleration: 150% is a limit value Optimum acceleration/deceleration: 100% is an optimum value
63	Reference value at deceleration	9999	0 to 220% *		Set the limit value/optimum value during shortest/ optimum deceleration.
			9999		Shortest acceleration/deceleration: 150% is a limit value Optimum acceleration/deceleration: 100% is an optimum value
292	Automatic acceleration/ deceleration	0	0		Normal mode
			1		Shortest acceleration/deceleration (without brake)
			11		Shortest acceleration/deceleration (with brake)
			3		Optimum acceleration/deceleration
			5, 6		Elevator mode1, 2 *(refer to page 163)*
			7, 8		Brake sequence mode 1, 2 *(Refer to page 214.)*
293	Acceleration/ deceleration separate selection	0	0		Both acceleration and deceleration are made in the shortest/optimum acceleration/deceleration mode
			1		Only acceleration is made in the shortest/optimum acceleration/deceleration mode
			2		Only deceleration is made in the shortest/optimum acceleration/deceleration mode

* When *Pr. 570 Multiple rating setting* ≠ "2", performing inverter reset and all parameter clear changes the setting range. *(Refer to page 155)*

(1) Shortest acceleration/deceleration mode (*Pr. 292* = "1, 11", *Pr. 293*)

- Set when you want to accelerate/decelerate the motor for the shortest time. It is desired to make acceleration/ deceleration in a shorter time for a machine tool etc. but the design values of machine constants are unknown.
- Acceleration/deceleration speed is automatically adjusted at a start of acceleration/deceleration so that acceleration/deceleration is made with the maximum torque the inverter can output according to the setting value of *Pr. 7 Acceleration time* and *Pr. 8 Deceleration time*. (The setting values of *Pr. 7* and *Pr. 8* are not changed)
- Either acceleration or deceleration can be made in the shortest time using *Pr. 293 Acceleration/deceleration separate selection*.
  When the setting value is "0" (initial value), both acceleration and deceleration can be made in the shortest time.
- Since the FR-A720-00330 (FR-A740-00170) or less inverter has a built-in brake resistor, set *Pr. 292* to "11". Set "11" also when a high-duty brake resistor or brake unit is connected. Deceleration time can be further shortened.
- When the shortest acceleration/deceleration mode is selected under V/F control and advanced magnetic flux vector control, the stall prevention operation level during acceleration/deceleration becomes 150% (adjustable using *Pr. 61* to *Pr. 63*). The setting of *Pr. 22 Stall prevention operation level* and stall level by analog input are used only during a constant speed operation.
  Adjustment using *Pr. 61* to *Pr. 63* can not be made under real sensorless vector control or vector control since torque limit level (*Pr. 22* etc.) is used during acceleration/deceleration.
- It is inappropriate to use for the following applications.
  a)Machine with a large inertia such as a fan (more than 10 times). Since stall prevention operation will be activated for a long time, this type of machine may be brought to an alarm stop due to motor overloading, etc. .
  b)It is desired to always perform operation with a constant acceleration/deceleration time.
  c)It is desired to perform operation making sure the inverter and motor have enough capability.

REMARKS

- Even if automatic acceleration/deceleration mode has been selected, inputting the jog signal (jog operation), RT signal (second function selection) or X9 signal (third function selection) during an inverter stop will switch to the normal operation and give priority to jog operation, second function selection or third function selection. Note that JOG and RT signal input is invalid even if JOG signal and RT signal are input during operation in automatic acceleration/deceleration mode.
- Since acceleration/deceleration is made with the stall prevention operation being activated, the acceleration/deceleration speed always varies according to the load conditions.
- Note that when proper values are set in *Pr. 7* and *Pr. 8* , acceleration/deceleration time may be shorter than selecting shortest acceleration/deceleration mode.

WWW.BSNEW.IR

(2) Optimum acceleration/deceleration mode (*Pr. 292* = "3")

- The optimum operation within the rating range where the inverter can be continuously used regardless of the inverter capability is performed.
  Automatically set torque boost and acceleration/deceleration time so that the average current during acceleration/deceleration is the rated current by the self-learning of the inverter.
  It is appropriate for applications such as automatic transfer machine, etc. which is small in load change and is operated in a predetermined pattern.
- At the initial time when the optimum acceleration/deceleration mode has been selected, operation is performed at the values set in *Pr. 0 Torque boost*, *Pr. 7 Acceleration time* and *Pr. 8 Deceleration time*. After operation, the average current and peak current are calculated from the motor current during acceleration/deceleration.These values are compared with the reference current (initial value is rated inverter current) and calculated, then more appropriate values are set in *Pr. 0, Pr. 7* and *Pr. 8* .
  After that, operation is performed under the conditions of *Pr. 0, Pr. 7* and *Pr. 8* set, and more appropriate values are calculated. Note that the *Pr. 0* value will not change under advanced magnetic flux vector control, real sensorless vector control or vector control.
- Storage of parameters
  The optimum values of *Pr. 0, Pr. 7* and *Pr. 8* are written to both the parameter RAM and EEPROM only three times of acceleration/deceleration after the optimum acceleration/deceleration mode has been selected or after the power is switched on or the inverter is reset. At of after the fourth attempt, they are not stored into EEPROM. Hence, after power-on or inverter reset, the values changed at the third time are valid. Note that the values changed at the fourth or later time are calculated to optimum and the values of *Pr. 0, Pr. 7* and *Pr. 8* are set to RAM, the values can be stored into EEPROM by reading and writting the values with the operation panel and paramter unit.

Number of Optimum Value Changes	*Pr. 0, Pr. 7, Pr. 8*		Optimum Conditions
	EEPROM value	RAM value	
1 to 3 times	Updated	Updated	Updated
4 or more times	Unchanged from third value	Updated	Updated

- Either acceleration or deceleration can be made in the optimum acceleration/deceleration mode using *Pr. 293 Acceleration/deceleration separate selection*.
  When the setting value is "0" (initial value), both acceleration and deceleration are made in the optimum acceleration/deceleration mode.
- It is inappropriate for machines which change in load and operation conditions.
  Since the stored optimum values are used for the next operation, faults, e.g. acceleration/deceleration is not made if conditons change, alarm stop is made due to overcurrent protective function, may occur.

REMARKS

- If shortest acceleration/deceleration mode has been selected, inputting the jog signal (jog operation), RT signal (second function selection) or X9 signal (third function selection) during an inverter stop will switch to the normal operation and give priority to jog operation, second function selection or third function selection. Note that JOG and RT signal input is invalid even if JOG signal and RT signal are input during operation in shortest/optimum acceleration/deceleration mode.
- Because of the learning system, this mode is not valid at the first operation after the optimum acceleration/deceleration mode is set.
- The optimum value are operated on only when acceleration is made from a stop to 30Hz or more or when deceleration is made from 30Hz or more to stop.
- When the motor is not connected or output current is less than 5% of the rated inverter current, optimum acceleration/deceleration mode will not function.

(3) Adjustment of shortest and optimum acceleration/deceleration mode *(Pr. 61 to Pr. 63)*

- By setting the adjustment parameters *Pr. 61 to Pr. 63*, the application range can be made wider.

Parameter Number	Name	Setting Range 200V class (400V class)		Description
61	Reference current	02150 (01100) or less	0 to 500A	For example, when the motor and inverter are different in capacity, set the rated motor current value. Shortest acceleration/deceleration: Set reference current (A) of the stall prevention operation level during acceleration/deceleration Optimum acceleration/deceleration: Set reference current (A) of the optimum current during acceleration/deceleration
		02880 (01440) or more	0 to 3600A	
		9999 (initial value)		The rated inverter current is defined as reference.
62	Reference value at acceleration	0 to 220%		Set when it is desired to change the reference level of acceleration and deceleration. Shortest acceleration/deceleration: Set the stall prevention operation level (ratio to the current value of *Pr. 61*) during acceleration/deceleration. Optimum acceleration/deceleration: Set the optimum current level (ratio to the current value of *Pr. 61*) during acceleration/deceleration.
63	Reference value at deceleration	9999 (initial value)		Shortest acceleration/deceleration: The 150% value during shortest acceleration/deceleration is judged as the stall prevention operation level. Optimum acceleration/deceleration: 100% is the optimum value

REMARKS

- *Pr. 61 to Pr. 63* are invalid when real sensorless vector control or vector control is selected in the shortest acceleration/deceleration mode.
- Since the *Pr. 61 to Pr. 63* settings automatically return to the initial value (9999) if the *Pr. 292* setting is changed, set *Pr. 292* first when you need to set *Pr. 61 to Pr. 63*.

♦ Parameters referred to ♦

Pr. 0 Torque boost ☞ *Refer to page 143*
Pr. 7 Acceleration time, Pr. 8 Deceleration time ☞ *Refer to page 173*
Pr. 22 Stall prevention operation level ☞ *Refer to page 150*
Pr. 22 Torque limit level ☞ *Refer to page 99*

WWW.BSNEW.IR

4.13 Selection and protection of a motor

Purpose	Parameter that must be Set		Refer to Page
Motor protection from overheat	**Electronic thermal O/L relay**	**Pr. 9, Pr. 51**	181
Use the constant torque motor	**Applied motor**	**Pr. 71**	185
The motor performance can be maximized for operation in magnetic flux vector control system	**Offline auto tuning**	**Pr. 82 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96**	187
High accuracy operation unaffected by the motor temperature and stable operation with high torque down to ultra low speed are performed	**Online auto tuning**	**Pr. 95, Pr. 574**	197

4.13.1 Motor protection from overheat (Electronic thermal relay function) (Pr. 9, Pr. 51)


Set the current of the electronic thermal O/L relay to protect the motor from overheat. This feature provides the optimum protective characteristics, including reduced motor cooling capability, at low speed.

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
9	**Electronic thermal O/L relay**	Rated inverter current *1	02150 (01100) or less	0 to 500A	Set the rated motor current.
			02880 (01440) or more	0 to 3600A	
51	**Second electronic thermal O/L relay** *2	9999	02150 (01100) or less	0 to 500A	Made valid when the RT signal is on. Set the rated motor current.
			02880 (01440) or more	0 to 3600A	
			9999		Second electronic thermal O/L relay invalid

*1 The initial value of the FR-A720-00030 and 00050 (FR-A740-00015 and 00025) is set to 85% of the rated inverter current.
*2 When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.

(1) Electronic thermal relay function operation characteristic (THM)

[Electronic thermal relay function operation characteristic (E.THM)]



This function detects the overload (overheat) of the motor, stops the operation of the inverter's output transistor, and stops the output. (The operation characteristic is shown on the left)

- Set the rated current [A] of the motor in *Pr. 9*. (When the power supply specification is 200V/220V(400V/440V) 60Hz, set the 1.1 times the rated motor current.)
- Set "0" in *Pr. 9* when you do not want to activate the electronic thermal relay function, e.g. when using an external thermal relay with the motor. (Note that the output transistor protection of the inverter functions (E.THT).)
- When using the Mitsubishi constant-torque motor
  1) Set "1" or any of "13" to "18", "50", "53", "54" in *Pr. 71*. (This provides a 100% continuous torque characteristic in the low-speed range.)
  2) Set the rated current of the motor in *Pr. 9*.

*1 When a value 50% of the rated inverter current (current value) is set in *Pr. 9*
*2 The % value denotes the percentage to the rated inverter current. It is not the percentage to the motor rated current.
*3 When you set the electronic thermal relay function dedicated to the Mitsubishi constant-torque motor, this characteristic curve applies to operation at 6Hz or higher.





CAUTION

- Protective function by electronic thermal relay function is reset by inverter power reset and reset signal input. Avoid unnecessary reset and power-off.
- When multiple motors are operated by a single inverter, protection cannot be provided by the electronic thermal relay function. Install an external thermal relay to each motor.
- When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In this case, use an external thermal relay.
- A special motor cannot be protected by the electronic thermal relay function. Use the external thermal relay.

WWW.BSNEW.IR

(2) Electronic thermal relay function operation characteristic (THT)

Electronic thermal relay function (transistor protection thermal) operation characteristics of the inverter when the ratio of the motor current to the inverter rated current is presented as transverse is shown. Transverse is calculated as follows: (motor current [A]/inverter rated current [A]) × 100 [%].

Optimum Conditions	Inverter Capacity	
	FR-A720-02150 (FR-A740-01100) or less	FR-A720-02880 (FR-A740-01440) or more
Running frequency : 1Hz or more Carrier frequency: 2kHz		
Running frequency : 1Hz or less Carrier frequency: 2kHz		

CAUTION


- Protective function by electronic thermal relay function is reset by inverter power reset and reset signal input. Avoid unnecessary reset and power-off.
- The operation time of the transistor protection thermal relay shortens when the *Pr. 72 PWM frequency selection* setting increases.
- Since a thermal protector is built in a motor dedicated for vector control (SF-V5RU), set "0" in *Pr. 9* to use the motor.

WWW.BSNEW.IR

(3) Set multiple electronic thermal relay functions *(Pr. 51)*

Use this function when rotating two motors of different rated currents individually by a single inverter. (When rotating two motors together, use external thermal relays.)

- Set the rated current of the second motor in *Pr. 51*.
- When the RT signal is on, thermal protection is provided based on the *Pr. 51* setting.



Pr. 450 *Second applied motor*	*Pr. 9* *Electronic thermal O/L relay*	*Pr. 51* *Second electronic thermal O/L relay*	RT = OFF		RT = ON	
			First motor	Second motor	First motor	Second motor
9999	0	9999	×	×	×	×
		0	×	×	×	×
		0.01 to 500 (0.1 to 3600)	×	★	×	○
9999	Other than 0	9999	○	×	○	×
		0	○	×	★	×
		0.01 to 500 (0.1 to 3600)	○	★	★	○
Other than 9999	0	9999	×	×	×	×
		0	×	×	×	×
		0.01 to 500 (0.1 to 3600)	×	★	×	○
Other than 9999	Other than 0	9999	○	★	★	○
		0	○	×	★	×
		0.01 to 500 (0.1 to 3600)	○	★	★	○


○ Output current value is used to perform integration processing.
★ Output current is assumed as 0A to perform integration processing. (cooling processing)
× Electronic thermal relay function is not activated.

REMARKS

- The RT signal acts as the second function selection signal and makes the other second functions valid. *(Refer to page 232)*
- The RT signal is assigned to the RT terminal in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, you can assign the RT signal to the other terminal.

(4) Electronic thermal relay function alarm output and alarm signal (THP signal)

100%: Electronic thermal relay function alarm operation value




- The alarm signal (THP) is output when the electronic thermal relay function cumulative value reaches 85% of the level set in *Pr. 9* or *Pr. 51*. If it reaches 100% of the *Pr. 9 Electronic thermal O/L relay* setting, electronic thermal relay function protection (E.THM/E.THT) occurs.
- The inverter does not shut off the output if the alarm signal is output.
- For the terminal used for the THP signal output, assign the function by setting "8" (positive logic) or "108" (negative logic) in any of *Pr. 190 to Pr. 196 (output terminal function selection)*.

CAUTION

- Changing the terminal assignment using *Pr. 190 to Pr. 196 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.


(5) External thermal relay input (OH signal)



External thermal relay input connection example

- To protect the motor against overheat, use the OH signal when using an external thermal relay or the built-in thermal protector of the motor.
- When the thermal relay operates, the inverter shuts off the output and outputs the alarm signal (E.OHT).
- For the terminal used for OH signal input, assign the function by setting "7" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*


WWW.BSNEW.IR



Connection of the thermal protector of the SF-V5RU

· A thermal protector is provided for a vector control dedicated motor (SF-V5RU).


* Assign OH (external thermal input) signal to the CS terminal.
(*Pr. 186* = "7")
Connect a 2W1kΩ resistor between the terminal PC and CS(OH).
Install the resistor pushing it against the bottom part of the terminal block so as to avoid a contact with other cables.
Refer to *page 228* for details of *Pr. 186 CS terminal function selection.*




CAUTION

· Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

(6) PTC thermistor input (PTC signal)



PTC thermistor input connection example



AU/PTC switchover switch
Factory-set to "AU".
Set to the "PTC" position to validate the PTC signal input.

Built-in PTC thermistor of the motor can be input to the PTC signal (AU terminal).

· For the terminal used for PTC signal input, assign the function by setting "63" in *Pr. 184 AU terminal function selection* and also set the AU/PTC switchover switch to the PTC terminal function. (The initial setting is the AU terminal function.)

· If a motor overheat state is detected for more than 10s according to the input from the PTC thermistor, the inverter shuts off the output and outputs the PTC thermal alarm signal (E.PTC).

· The input specifications of the PTC thermistor are shown on the right.

Motor Temperature	PTC Thermistor Resistance Value (Ω)
Normal	0 to 500
Boundary	500 to 4k
Overheat	4k or higher

CAUTION

· When the PTC signal was not assigned to *Pr. 184* and the AU/PTC switchover switch was set to the PTC terminal function, the function assigned to the AU terminal is always off. Reversely, when the PTC signal was assigned to *Pr. 184* and the AU/PTC switchover switch was set to the AU terminal function, a PTC thermal error (E.PTC) occurs since the function is always in a motor overheat state.
· When you want to input a current, assign the AU signal to the other signal.
· When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of the AU terminal.

♦ Parameters referred to ♦

Pr. 71 Applied motor ☞ *Refer to page 185*
Pr. 72 PWM frequency selection ☞ *Refer to page 279*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*
Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*
Specifications of the AU terminal ☞ *Refer to page 28*

WWW.BSNEW.IR

4.13.2 Applied motor (Pr. 71, Pr. 450)

Setting of the used motor selects the thermal characteristic appropriate for the motor.
Setting is necessary when using a constant-torque motor. Thermal characteristic of the electronic thermal relay function suitable for the motor is set.
When advanced magnetic flux vector, real sensorless vector control or vector control is selected, the motor constants (SF-JR, SF-HR, SF-JRCA, SF-HRCA, SF-V5RU) necessary for control are selected as well.

Parameter Number	Name	Initial Value	Setting Range	Description
71	**Applied motor**	0	0 to 8, 13 to 18, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54	Selecting the standard motor or constant-torque motor sets the corresponding motor thermal characteristic.
450	**Second applied motor**	9999	0 to 8, 13 to 18, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54	Set when using the second motor. (same specifications as *Pr. 71*)
			9999	Not function

(1) Set the motor to be used

Refer to the following list and set this parameter according to the motor used.

Pr. 71 (Pr. 450) Setting		Thermal Characteristic of the Electronic Thermal Relay Function			Motor (○ : used motor)		
Pr. 71	*Pr. 450*				Standard (SF-JR etc.)	Constant torque (SF-JRCA etc.)	Vector (SF-V5RU)
0 (*Pr. 71* initial value)		Thermal characteristics of a standard motor			○		
1		Thermal characteristics of the Mitsubishi constant-torque motor				○	
2		Thermal characteristics of a standard motor Adjustable 5 points V/F *(Refer to page 165)*			○		
20		Mitsubishi standard motor (SF-JR 4P 1.5kW(2HP) or less) thermal characteristic for the constant-torque motor			○		
30		Vector control dedicated motor (SF-V5RU)					○
40		Thermal characteristic of Mitsubishi high efficiency motor SF-HR			○*1		
50		Thermal characteristic of Mitsubishi constant-torque motor SF-HRCA				○*2	
3		Standard motor	Select "offline auto tuning setting"		○		
13		Constant-torque motor				○	
23		Mitsubishi standard motor (SF-JR 4P 1.5kW or less)			○		
33		Vector control dedicated motor (SF-V5RU, SF-THY)					○
43		Mitsubishi High efficiency motor (SF-HR)			○*1		
53		Mitsubishi constant-torque motor (SF-HRCA)				○*2	
4		Standard motor	Auto tuning data can be read, changed, and set		○		
14		Constant-torque motor				○	
24		Mitsubishi standard motor (SF-JR 4P 1.5kW or less)			○		
34		Vector control dedicated motor (SF-V5RU, SF-THY)					○
44		Mitsubishi High efficiency motor (SF-HR)			○*1		
54		Mitsubishi constant-torque motor (SF-HRCA)				○*2	
5		Standard motor	Star connection	Direct input of motor constants is enabled	○		
15		Constant-torque motor				○	
6		Standard motor	Delta connection		○		
16		Constant-torque motor				○	
7		Standard motor	Star connection	Motor constants direct input + offline auto tuning	○		
17		Constant-torque motor				○	
8		Standard motor	Delta connection		○		
18		Constant-torque motor				○	
—	9999 (initial value)	Without second applied motor					

*1 Motor constants of Mitsubishi high efficiency motor SF-HR.
*2 Motor constants of Mitsubishi constant-torque motor SF-HRCA.

WWW.BSNEW.IR

REMARKS

- When performing offline auto tuning, set "3, 7, 8, 13, 17, 18, 23, 33, 43, 53" in *Pr. 71*.
  (Refer to *page 187* for offline auto tuning)
- For the FR-F720-00240, 00330 and FR-F740-00120, 00170, the *Pr. 0 Torque boost* and *Pr. 12 DC injection brake operation voltage* settings are automatically changed according to the *Pr. 71* setting as follows.

Pr. 71	Standard Motor Setting 0, 2, 3 to 8, 20, 23, 24, 40, 43, 44	Constant Torque Motor Setting 1, 13 to 18, 50, 53, 54
Pr. 0	3%	2%
Pr. 12	4%	2%

(2) Use two types motors *(Pr. 450)*

- Set *Pr. 450 Second applied motor* to use two types motors with one inverter.
- When "9999" (initial value) is set, no function is selected.
- When *Pr. 450* ≠ 9999, turning the RT signal on makes the following parameter valid.

Function	RT Signal ON (second motor)	RT Signal OFF (first motor)
Applied motor	Pr. 450	Pr. 71
Control method selection	Pr. 451	Pr. 800
Motor capacity	Pr. 453	Pr. 80
Number of motor poles	Pr. 454	Pr. 81
Motor excitation current	Pr. 455	Pr. 82
Motor rated voltage	Pr. 456	Pr. 83
Rated motor frequency	Pr. 457	Pr. 84
Motor constant (R1)	Pr. 458	Pr. 90

Function	RT Signal ON (second motor)	RT Signal OFF (first motor)
Motor constant (R2)	Pr. 459	Pr. 91
Motor constant (L1)	Pr. 460	Pr. 92
Motor constant (L2)	Pr. 461	Pr. 93
Motor constant (X)	Pr. 462	Pr. 94
Auto tuning setting/status	Pr. 463	Pr. 96
Online auto tuning selection	Pr. 574	Pr. 95
Torque current	Pr. 860	Pr. 859

REMARKS

- The RT signal acts as the second function selection signal and makes the other second functions valid. *(Refer to page 232)*
- The RT signal is assigned to the terminal RT in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, you can assign the RT signal to the other terminal.

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

⚠ CAUTION

⚠ Set this parameter correctly according to the motor used.
Incorrect setting may cause the motor to overheat and burn.

♦ Parameters referred to ♦

Pr. 0 Torque boost ☞ *Refer to page 143*
Pr. 12 DC injection brake operation voltage ☞ *Refer to page 200*
Pr. 80 Motor capacity, Pr. 81 Number of motor poles, Pr. 453 Second motor capacity, Pr. 454 Number of second motor poles ☞ *Refer to page 145*
Pr. 82 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 455 to Pr. 463, Pr. 859, Pr. 860 (Motor constant) ☞ *Refer to page 187*
Pr. 95 Online auto tuning selection, Pr. 574 Second motor online auto tuning ☞ *Refer to page 197*
Pr. 451 Second motor control method selection, Pr. 800 Control method selection ☞ *Refer to page 92*
Pr. 100 to Pr. 109 (Adjustable 5 points V/F) ☞ *Refer to page 165*

WWW.BSNEW.IR

4.13.3 Offline auto tuning (Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 450, Pr. 453 to Pr. 463, Pr. 684, Pr. 859, Pr. 860)

The motor performance can be maximized with offline auto tuning.

- What is offline auto tuning?
  When performing advanced magnetic flux vector control, real sensorless vector control or vector control, the motor can be run with the optimum operating characteristics by automaticaly measuring the motor constants (offline auto tuning) even when each motor constants differs, other manufacturer's motor is used, or the wiring length is long.

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
71	Applied motor	0	0 to 8, 13 to 18, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54		By selecting a standard motor or constant torque motor, thermal characteristic and motor constants of each motor are set.
80	Motor capacity	9999	02150 (01100) or less	0.4 to 55kW	Set the applied motor capacity.
			02880 (01440) or more	0 to 3600kW	
			9999		V/F control
81	Number of motor poles	9999	2, 4, 6, 8, 10		Set the number of motor poles.
			12, 14, 16, 18, 20		X18 signal-ON:V/F control Set 10 + number of motor poles.
			9999		V/F control
82	Motor excitation current	9999	02150 (01100) or less	0 to 500A	Tuning data (The value measured by offline auto tuning is automatically set.)
			02880 (01440) or more	0 to 3600A	
			9999		Use the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA, SF-V5RU) constants
83	Motor rated voltage	200/400V *	0 to 1000V		Set the rated motor voltage(V). * The initial value differs according to the voltage level. (200V/400V)
84	Rated motor frequency	60Hz	10 to 120Hz		Set the rated motor frequency (Hz).
90	Motor constant (R1)	9999	02150 (01100) or less	0 to 50Ω, 9999	Tuning data (The value measured by offline auto tuning is automatically set.) 9999: Use the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA, SF-V5RU) constants
			02880 (01440) or more	0 to 400mΩ, 9999	
91	Motor constant (R1)	9999	02150 (01100) or less	0 to 50Ω, 9999	
			02880 (01440) or more	0 to 400mΩ, 9999	
92	Motor constant (L1)	9999	02150 (01100) or less	0 to 50Ω, (0 to 1000mH), 9999	
			02880 (01440) or more	0 to 3600mΩ (0 to 400mH), 9999	
93	Motor constant (L2)	9999	02150 (01100) or less	0 to 50Ω (0 to 1000mH), 9999	
			02880 (01440) or more	0 to 3600mΩ (0 to 400mH), 9999	
94	Motor constant (X)	9999	02150 (01100) or less	0 to 500Ω (0 to 100%), 9999	
			02880 (01440) or more	0 to 100Ω (0 to 100%), 9999	

WWW.BSNEW.IR

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
96	Auto tuning setting/ status	0	0		Offline auto tuning is not performed
			1		Offline auto tuning is performed without motor running
			101		Offline auto tuning is performed with motor running
450	Second applied motor	9999	0 to 8, 13 to 18, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54		Set when using the second motor. (same specifications as *Pr. 71*)
			9999		Not function
453	Second motor capacity	9999	02150 (01100) or less	0.4 to 55kW	Set the capacity of the second motor.
			02880 (01440) or more	0 to 3600kW	
			9999		V/F control
454	Number of second motor poles	9999	2, 4, 6, 8, 10		Set the number of poles of the second motor.
			9999		V/F control
455	Second motor excitation current	9999	02150 (01100) or less	0 to 500A	Tuning data of the second motor (The value measured by offline auto tuning is automatically set.)
			02880 (01440) or more	0 to 3600A	
			9999		Use the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA, SF-V5RU) constants
456	Rated second motor voltage	200/400V *	0 to 1000V		Set the rated voltage (V) of the second motor. * The initial value differs according to the voltage level. (200V/400V)
457	Rated second motor frequency	60Hz	10 to 120Hz		Set the rated motor frequency (Hz) of the second motor.
458	Second motor constant (R1)	9999	02150 (01100) or less	0 to 50Ω, 9999	Tuning data of the second motor (The value measured by offline auto tuning is automatically set.) 9999: Use the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA, SF-V5RU) constants
			02880 (01440) or more	0 to 400mΩ, 9999	
459	Second motor constant (R2)	9999	02150 (01100) or less	0 to 50Ω, 9999	
			02880 (01440) or more	0 to 400mΩ, 9999	
460	Second motor constant (L1)	9999	02150 (01100) or less	0 to 50Ω (0 to 1000mH), 9999	
			02880 (01440) or more	0 to 3600mΩ (0 to 400mH), 9999	
461	Second motor constant (L2)	9999	02150 (01100) or less	0 to 50Ω (0 to 1000mH), 9999	
			02880 (01440) or more	0 to 3600mΩ (0 to 400mH), 9999	
462	Second motor constant (X)	9999	02150 (01100) or less	0 to 500Ω (0 to 100%), 9999	
			02880 (01440) or more	0 to 100Ω (0 to 100%), 9999	
463	Second motor auto tuning setting/status	0	0		Second motor auto tuning is not performed
			1		Offline auto tuning is performed without second motor running
			101		Offline auto tuning is performed with second motor running
684	Tuning data unit switchover	0	0		Internal data converted value
			1		Displayed in "A, Ω, mH, %"

WWW.BSNEW.IR

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
859	Torque current	9999	02150 (01100) or less	0 to 500A	Tuning data (The value measured by offline auto tuning is automatically set.)
			02880 (01440) or more	0 to 3600A	
			9999		Use the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA, SF-V5RU) constants
860	Second motor torque current	9999	02150 (01100) or less	0 to 500A	Tuning data of the second motor (The value measured by offline auto tuning is automatically set.)
			02880 (01440) or more	0 to 3600A	
			9999		Use the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA, SF-V5RU) constants

POINT

- This function is made valid only when a value other than "9999" is set in *Pr. 80* and *Pr. 81* and advanced magnetic flux vector control, real sensorless vector control or vector control is selected.
- You can copy the offline auto tuning data (motor constants) to another inverter with the PU (FR-DU07/FR-PU07).
- Even when motors (other manufacturer's motor, SF-JRC, SF-TH, etc.) other than Mitsubishi standard motor, high efficiency motor (SF-JR SF-HR 0.4kW or more), Mitsubishi constant-torque motor (SF-JRCA SF-HRCA four-pole 0.4kW to 55kW) and vector control dedicated motor (SF-V5RU) are used or the wiring length is long, using the offline auto tuning function runs the motor with the optimum operating characteristics.
- Tuning is enabled even when a load is connected to the motor. (As the load is lighter, tuning accuracy is higher. Tuning accuracy does not change even if the inertia is large.)
- For the offline auto tuning, you can select either the motor non-rotation mode (*Pr. 96* = "1") or rotation mode (*Pr. 96* = "101").
- The rotation mode has higher tuning accuracy than the non-rotation mode.
- Reading/writing/copy of motor constants tuned by offline auto tuning are enabled.
- The offline auto tuning status can be monitored with the PU (FR-DU07/FR-PU07/FR-PU04).
- Do not connect a surge voltage suppression filter (FR-ASF-H) to the FR-A720-02150 (FR-A740-01100) or less and sine wave filter (MT-BSL/BSC) to the FR-A720-02880 (FR-A740-01440) or more between the inverter and motor.

WWW.BSNEW.IR

(1) Before performing offline auto tuning

Check the following before performing offline auto tuning.

- Make sure advanced magnetic flux vector control *(Pr. 80, Pr. 81)*, real sensorless vector control or vector control *(Pr. 800)* is selected.
- A motor should be connected. Note that the motor should be at a stop at a tuning start.
- The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity is 0.4kW or more)
- The maximum frequency is 120Hz.
- Motors such as high-slip motor, high-speed motor and special motor cannot be tuned.
- Even if tuning is performed without motor running (*Pr. 96 Auto tuning setting/status* = "1"), the motor may run slightly. Therefore, fix the motor securely with a mechanical brake, or before tuning, make sure that there will be no problem in safety if the motor runs. (Caution is required especially in vertical lift applications). Note that if the motor runs slightly, tuning performance is unaffected.
- Note the following when selecting offline auto tuning performed with motor running (*Pr. 96 Auto tuning setting/status* = "101").
  Torque is not enough during tuning.
  The motor may be run at nearly its rated speed.
  The brake is open.
  No external force is applied to rotate the motor.
- Offline auto tuning will not be performed properly if it is performed with a surge voltage suppression filter (FR-ASF-H) connected to the FR-A720-02150 (FR-A740-01100) or less and sine wave filter (MT-BSL/BSC) connected to the FR-A720-02880 (FR-A740-01440) or more between the inverter and motor. Remove it before starting tuning.
- When exercising vector control, use the encoder that is coupled directly to the motor shaft without looseness. Speed ratio should be 1:1.

(2) Setting

1) Select the advanced magnetic flux vector control, real sensorless vector control or vector control *(refer to page 92)*.
2) Set "1" or "101" in *Pr. 96 Auto tuning setting/status* .
   · When the setting is "1" . . . . . Tuning is performed without motor running.
   It takes approximately 25 to 120s * until tuning is completed.
   (Excitation noise is produced during tuning.)
   *Tuning time differs according to the inverter capacity and motor type.
   · When the setting is "101" . . . . . Tuning is performed with motor running.
   It takes approximately 40s until tuning is completed.
   The motor runs at nearly its rated frequency.
3) Set the rated motor current (initial value is rated inverter current) in *Pr. 9 Electronic thermal O/L relay* *(refer to page 181)*.
4) Set the rated voltage of motor (initial value is 200V/400V) in *Pr. 83 Motor rated voltage* and rated frequency of motor (initial value is 60Hz) in *Pr. 84 Rated motor frequency* .
   (For a Japanese standard motor, etc. which has both 50Hz and 60Hz rated values, set 200V/60Hz or 400V/60Hz).)

REMARKS

When using the vector control dedicated motor SF-V5RU and SF-THY, setting 33 and 34 in *Pr. 71* selects internal constants appropriate for dedicated motors. Therefore, *Pr. 83* and *Pr. 84* settings are unnecessary.

5) Set *Pr. 71 Applied motor* according to the motor used.

Motor		*Pr. 71* Setting *
Mitsubishi standard motor Mitsubishi high efficiency motor	SF-JR, SF-TH	3
	SF-JR 4P-1.5kW or less	23
	SF-HR	43
	Others	3
Mitsubishi constant-torque motor	SF-JRCA 4P, SF-TH (constant torque)	13
	SF-HRCA 4P	53
	Others (SF-JRC, etc.)	13
Vector control dediated motor	SF-V5RU SF-THY	33
Other manufacturer's standard motor	–	3
Other manufacturer's constant torque motor	–	13

* For other settings of *Pr. 71* , refer to *page 185*.

WWW.BSNEW.IR

(3) Execution of tuning

CAUTION

· Before performing tuning, check the monitor display of the operation panel (FR-DU07) or parameter unit (FR-PU04/FR-PU07) if the inverter is in the state ready for tuning. (Refer to 2) below) When the start command is turned on under V/F control, the motor starts.

1)When performing PU operation, press FWD / REV of the operation panel.
For external operation, turn on the start command (STF signal or STR signal). Tuning starts.

CAUTION

· When selecting offline auto tuning performed with motor running (*Pr. 96 Auto tuning setting/status* = "101"), caution must be taken since the motor runs.

· To force tuning to end, use the MRS or RES signal or press STOP RESET of the operation panel.
(Turning the start signal (STF signal or STR signal) off also ends tuning.)

· During offline auto tuning, only the following I/O signals are valid: (initial value)
· Input signals <valid signal> STOP, OH, MRS, RT, CS, RES, STF, STR
· Output terminal RUN, OL, IPF, FM, AM, A1B1C1
Note that the progress status of offline auto tuning is output from AM and FM when speed and output frequency are selected.

· Since the RUN signal turns on when tuning is started, caution is required especially when a sequerence which releases a mechanical brake by the RUN signal has been designed.

· When executing offline auto tuning, input the run command after switching on the main circuit power (R/L1, S/L2, T/L3) of the inverter.

· Do not perform ON/OFF switching of the second function selection signal (RT) during execution of offline auto tuning. Auto tuning is not excecuted properly.

· Setting offline auto tuning (*Pr. 96 Auto tuning setting/status* = "1 or 101") will make pre-excitation invalid.

2)Monitor is displayed on the operation panel (FR-DU07) and parameter unit (FR-PU07/FR-PU04) during tuning as below.

	Parameter Unit (FR-PU07/FR-PU04) Display		Operation Panel (FR-DU07) Display	
Pr. 96 setting	1	101	1	101
(1) Setting	1 --- STOP PU	101 --- STOP PU		
(2) Tuning in progress	TUNE 2 STF FWD PU	TUNE 102 STF FWD PU		
(3) Normal end	TUNE COMPLETION 3 STF STOP PU	TUNE COMPLETION 103 STF STOP PU	 Flickering	 Flickering
(4) Error end (when the inverter protective function is activated)	TUNE ERROR 9 STF STOP PU			

· Reference: Offline auto tuning time (when the initial value is set)

Offline Auto Tuning Setting	Time
Non-rotation mode (*Pr. 96* = "1")	Approximately 25 to 120s (Tuning time differs according to the inverter capacity and motor type.)
Rotation mode (*Pr. 96* = "101")	Approximately 40s (Offline auto tuning time varies with the acceleration and deceleration time settings as indicated below. Offline auto tuning time = acceleration time + deceleration time + approx. 30s)

WWW.BSNEW.IR

3)When offline auto tuning ends, press STOP RESET of the operation panel during PU operation. For external operation, turn off the start signal (STF signal or STR signal).
This operation resets the offline auto tuning and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)

REMARKS

- Do not change the *Pr. 96* setting after completion of tuning (3 or 103).
  If the *Pr. 96* setting is changed, tuning data is made invalid.
  If the *Pr. 96* setting is changed, tuning must be performed again.

4)If offline auto tuning ended in error (see the table below), motor constants are not set.
Perform an inverter reset and restart tuning.

Error Display	Error Cause	Remedy
8	Forced end	Set "1" or "101" in *Pr. 96* and perform tuning again.
9	Inverter protective function operation	Make setting again.
91	Current limit (stall prevention) function was activated.	Increase acceleration/deceleration time. Set "1" in *Pr. 156* .
92	Converter output voltage reached 75% of rated value.	Check for fluctuation of power supply voltage.
93	Calculation error A motor is not connected.	Check the motor wiring and make setting again.

5)When tuning is ended forcibly by pressing STOP RESET or turning off the start signal (STF or STR) during tuning, offline auto tuning does not end normally. (The motor constants have not been set.)
Perform an inverter reset and restart tuning.

CAUTION

- The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again.
- An instantaneous power failure occurring during tuning will result in a tuning error.
  After power is restored, the inverter goes into the normal operation mode. Therefore, when STF (STR) signal is on, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the ordinary mode. Note that if an error retry has been set, retry is ignored.
- The set frequency monitor displayed during the offline auto tuning is 0Hz.

⚠ CAUTION

⚠ Note that the motor may start running suddenly.

⚠ When the offline auto tuning is used in vertical lift application, e.g. a lifter, it may drop due to insufficient torque.

WWW.BSNEW.IR

(4) Utilizing or changing offline auto tuning data for use

The data measured in the offline auto tuning can be read and utilized or changed.

<Operating procedure>

1)Set *Pr. 71* according to the motor used.

Motor		*Pr. 71* Setting*
Mitsubishi standard motor Mitsubishi high efficiency motor	SF-JR, SF-TH	4
	SF-JR 4P 1.5kW or less	24
	SF-HR	44
	Others	4
Mitsubishi constant-torque motor	SF-JRCA 4P SF-TH (constant torque)	14
	SF-HRCA 4P	54
	Others (SF-JRC, etc.)	14
Vector control dedicated motor	SF-V5RU SF-THY	34
Other manufacturer's standard motor	–	4
Other manufacturer's constant torque motor	–	14

*1 For other settings of *Pr. 71*, refer to the *page 185*.

2)In the parameter setting mode, read the following parameters and set desired values.

Parameter Number	Name	Setting Range	Setting Increments	Initial Value
82	Motor excitation current	0 to ***, 9999	1	9999
90	Motor constant (R1)	0 to ***, 9999	1	9999
91	Motor constant (R2)	0 to ***, 9999	1	9999
92	Motor constant (L1)	0 to ***, 9999	1	9999
93	Motor constant (L2)	0 to ***, 9999	1	9999
94	Motor constant (X)	0 to ***, 9999	1	9999
859	Torque current	0 to ***, 9999	1	9999

REMARKS

· The display units of the motor constants read using *Pr. 684 Tuning data unit switchover* can be changed. Note that parameter values can not be changed.

Pr. 684 Setting 200V class (400V class)		*Pr. 82, Pr. 455*	*Pr. 90, Pr. 458*	*Pr. 91, Pr. 459*	*Pr. 92, Pr. 460*	*Pr. 93, Pr. 461*	*Pr. 94, Pr. 462*	*Pr. 859, Pr. 860*
0		Internal data converted value						
1	02150 (01100) or less	0.01A	0.001Ω	0.001Ω	0.1mH	0.1mH	0.1%	0.01A
	02880 (01440) or more	0.1A	0.01mΩ	0.01mΩ	0.01mH	0.01mH	0.01%	0.1A

· When "9999" is set in *Pr. 82, Pr. 90* to *Pr. 94, Pr. 455, Pr. 458* to *Pr. 462, Pr. 859, Pr. 860,* Mitsubishi motor (SF-JR, SF-HR,SF-JRCA, SF-HRCA, SF-V5RU) constants are used.

· As the motor constants measured in the offline auto tuning have been converted into internal data (****), refer to the following setting example when making setting:

Setting example To slightly increase *Pr. 90* value (5%)
When *Pr. 90* is displayed "2516",
set 2642, i.e. 2516 × 1.05 = 2641.8, in *Pr. 90* .
(The value displayed has been converted into a value for internal use. Hence, simple addition of a given value to the displayed value has no significance.)

WWW.BSNEW.IR

(5) Method to set the motor constants without using the offline auto tuning data

The *Pr. 92* and *Pr. 93* motor constants may either be entered in [Ω] or in [mH]. Before starting operation, confirm which motor constant unit is used.

- To enter the *Pr. 92* and *Pr. 93* motor constants in [Ω]

<Operating procedure>

1) Set *Pr. 71* according to the motor used.

		Star Connection Motor	Delta Connection Motor
Setting	Standard motor	5	6
	Constant-torque motor	15	16

2) In the parameter setting mode, read the following parameters and set desired values.

Iq = torque current, I_{100} = rated current, I_0 = no load current

$$Iq = \sqrt{I_{100}^2 - I_0^2}$$

Parameters Number	Name	Setting Range 200V class (400V class)		Setting Increments	Initial Value
82	Motor excitation current (no load current)	02150 (01100) or less	0 to 500A, 9999	0.01A	9999
		02880 (01440) or more	0 to 3600A, 9999	0.1A	
90	Motor constant (r1)	02150 (01100) or less	0 to 50Ω, 9999	0.001Ω	9999
		02880 (01440) or more	0 to 400mΩ, 9999	0.01mΩ	
91	Motor constant (r2)	02150 (01100) or less	0 to 50Ω, 9999	0.001Ω	9999
		02880 (01440) or more	0 to 400mΩ, 9999	0.01mΩ	
92	Motor constant (x1)	02150 (01100) or less	0 to 50Ω, 9999	0.001Ω	9999
		02880 (01440) or more	0 to 3600mΩ, 9999	0.01mΩ	
93	Motor constant (x2)	02150 (01100) or less	0 to 50Ω, 9999	0.001Ω	9999
		02880 (01440) or more	0 to 3600mΩ, 9999	0.01mΩ	
94	Motor constant (xm)	02150 (01100) or less	0 to 500Ω, 9999	0.01Ω	9999
		02880 (01440) or more	0 to 100Ω, 9999		
859	Torque current	02150 (01100) or less	0 to 500A, 9999	0.01A	9999
		02880 (01440) or more	0 to 3600A, 9999	0.1A	

3)Refer to the following table and set *Pr. 83* and *Pr. 84* .

Parameter Number	Name	Setting Range	Setting Increments	Initial Value
83	Motor rated voltage	0 to 1000V	0.1V	400V
84	Rated motor frequency	10 to 120Hz	0.01Hz	Hz

* The initial value differs according to the voltage level. (200V/400V)

REMARKS

· When "9999" is set in *Pr. 82*, *Pr. 90 to Pr. 94*, *Pr. 859*, Mitsubishi motor (SF-JR, SF-HR,SF-JRCA, SF-HRCA, SF-V5RU) constants are used.

CAUTION

· If "star connection" is mistaken for "delta connection" or vice versa during setting of *Pr. 71*, advanced magnetic flux vector control, real sensorless vector control and vector control cannot be exercised properly.

WWW.BSNEW.IR

- To enter the *Pr. 92* and *Pr. 93* motor constants in [mH]

<Operating procedure>

1) Set *Pr. 71* according to the motor used.


Motor		*Pr.71* Setting*
Mitsubishi standard motor Mitsubishi high efficiency motor	SF-JR	0
	SF-JR 4P 1.5kW or less	20
	SF-HR	40
Mitsubishi constant-torque motor	SF-JRCA 4P SF-TH (constant torque)	1
	SF-HRCA 4P	50
Vector control dedicated motor	SF-V5RU	30

*1 For other settings of *Pr. 71*, refer to the *page 185*.

2) In the parameter setting mode, read the following parameters and set desired values.

Calculate the *Pr. 94* value from the following formula.

$$Pr.\ 94 \text{ setting} = \left(1 - \frac{M^2}{L1 \times L2}\right) \times 100\ (\%)$$



R1: Primary resistance
R2: Secondary resistance
I1: Primary leakage inductance
I2: Secondary leakage inductance
M: Excitation inductance
S: Slip

L1= I1+ M: Primary inductance
L2= I2+ M: Secondary inductance

Motor equivalent circuit diagram

Parameter Number	Name	Setting Range 200V class (400V class)		Setting Increments	Initial Value
82	Motor excitation current (no load current)	02150 (01100) or less	0 to 500A, 9999	0.01A	9999
		02880 (01440) or more	0 to 3600A, 9999	0.1A	
90	Motor constant (R1)	02150 (01100) or less	0 to 50Ω, 9999	0.001Ω	9999
		02880 (01440) or more	0 to 400mΩ, 9999	0.01mΩ	
91	Motor constant (R2)	02150 (01100) or less	0 to 50Ω, 9999	0.001Ω	9999
		02880 (01440) or more	0 to 400mΩ, 9999	0.01mΩ	
92	Motor constant (L1)	02150 (01100) or less	0 to 1000mH, 9999	0.1mH	9999
		02880 (01440) or more	0 to 400mH, 9999	0.01mH	
93	Motor constant (L2)	02150 (01100) or less	0 to 1000mH, 9999	0.1mH	9999
		02880 (01440) or more	0 to 400mH, 9999	0.01mH	
94	Motor constant (X)	02150 (01100) or less	0 to 100%, 9999	0.1%	9999
		02880 (01440) or more	0 to 100%, 9999	0.01%	
859	Torque current	02150 (01100) or less	0 to 500A, 9999	0.01A	9999
		02880 (01440) or more	0 to 3600A, 9999	0.1A	

3)Refer to the following table and set *Pr. 83* and *Pr. 84* .

Parameter Number	Name	Setting Range	Setting Increments	Initial Value
83	Motor rated voltage	0 to 1000V	0.1V	400V
84	Rated motor frequency	10 to 120Hz	0.01Hz	Hz

* The initial value differs according to the voltage level. (200V/400V)

REMARKS

· When "9999" is set in *Pr. 82*, *Pr. 90 to Pr. 94*, *Pr. 859*, Mitsubishi motor (SF-JR, SF-HR,SF-JRCA, SF-HRCA, SF-V5RU) constants are used.

WWW.BSNEW.IR

(6) Tune second applied motor

· When you want to switch two motors with one inverter, set the second motor in *Pr. 450 Second applied motor (refer to page 185)*. Initial setting is without second applied motor.
· Turning the RT signal on makes the following parameters for the second parameters valid.

Functions	RT Signal ON (second motor)	RT Signal OFF (first motor)
Motor capacity	Pr. 453	Pr. 80
Number of motor poles	Pr. 454	Pr. 81
Motor excitation current	Pr. 455	Pr. 82
Motor rated voltage	Pr. 456	Pr. 83
Rated motor frequency	Pr. 457	Pr. 84
Motor constant (R1)	Pr. 458	Pr. 90
Motor constant (R2)	Pr. 459	Pr. 91
Motor constant (L1)	Pr. 460	Pr. 92
Motor constant (L2)	Pr. 461	Pr. 93
Motor constant (X)	Pr. 462	Pr. 94
Auto tuning setting/status	Pr. 463	Pr. 96

REMARKS

· The RT signal is assigned to the terminal RT in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, you can assign the RT signal to the other terminal.

CAUTION

· Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 7 Acceleration time, Pr. 8 Deceleration time ☞*Refer to page 173*
Pr. 9 Electronic thermal O/L relay ☞*Refer to page 181*
Pr. 71 Applied motor ☞*Refer to page 185*
Pr. 80 Motor capacity, Pr. 81 Number of motor poles ☞*Refer to page 92*
Pr. 95 Online auto tuning selection ☞*Refer to page 197*
Pr. 156 Stall prevention operation selection ☞*Refer to page 150*
Pr. 178 to Pr. 189 (input terminal function selection) ☞*Refer to page 228*
Pr. 190 to Pr. 196 (output terminal function selection) ☞*Refer to page 236*
Pr. 800 Control method selection ☞*Refer to page 92*

WWW.BSNEW.IR

4.13.4 Online auto tuning (Pr. 95, Pr. 574)

When online auto tuning is selected under advanced magnetic flux vector control, real sensorless vector control or vector control, excellent torque accuracy is provided by temperature compensation even if the secondary resistance value of the motor varies with the rise of the motor temperature.

Parameter Number	Name	Initial Value	Setting Range	Description
95	Online auto tuning selection	0	0	Online auto tuning is not performed
			1	Start-time online auto tuning
			2	Magnetic flux observer (normal tuning)
574	Second motor online auto tuning	0	0, 1	Select the second motor online auto tuning. (same as *Pr. 95*)

(1) Start-time online auto tuning (setting is "1")

- By quickly tuning the motor constants at a start, high accuracy operation unaffacted by the motor temperature and stable operation with high torque down to ultra low speed can be performed.
- Make sure advanced magnetic flux vector control (*Pr. 80, Pr. 81*), real sensorless vector control or vector control (*Pr. 800*) is selected.
- Before performing online auto tuning, perform offline auto tuning without fail.

<Operation method>

1) Refer to *page 187* to perform offline auto tuning.
2) Check that "3" or "103" (offline auto tuning completion) is set in *Pr. 96 Auto tuning setting/status*.
3) Set "1" (start-time online auto tuning) in *Pr. 95 Online auto tuning selection*.
   Online auto tuning is performed from the next starting.
4) Before starting operation, check that the following parameters have been set.

Parameter Number	Description
9	Used as rated motor current and electronic thermal relay parameters.
71	Applied motor
80	Motor capacity (down to one rank lower than the inverter capacity, note that the capacity should be 0.4kW or more)
81	Number of motor poles

5) When performing PU operation, press FWD / REV of the operation panel.
   For external operation, turn on the run command (STF signal or STR signal).

CAUTION

- For using start-time online auto tuning in elevator, examine the utilization of a brake sequence for the brake opening timing at a start. Though the tuning ends in about a maximum of 500ms after a start, torque is not provided fully during that period. Therefore, note that there may be a possibility of drop due to gravity. *(Refer to page 198.)*
  It is recommended to perform tuning using a start time tuning signal (X28). *(Refer to page 198.)*

WWW.BSNEW.IR

(2) Magnetic flux observer (normal tuning) (setting value is "2")

· When exercising vector control using a motor with encoder, it is effective for torque accuracy improvement.
The current flowing in the motor and the inverter output voltage are used to estimate/observe the magnetic flux in the motor.
The magnetic flux of the motor is always detected with high accuracy so that an excellent characteristic is provided regardless of the change in the temperature of the secondary resistance.
· Vector control *(Pr. 80, Pr. 81, Pr. 800)* should be selected. *(Refer to page 92.)*


CAUTION

· For the SF-V5RU, SF-JR (with encoder), SF-HR (with encoder), SF-JRCA (with encoder) or SF-HRCA (with encoder), it is not necessary to perform offline auto tuning to select adaptive magnetic flux observer. (Note that it is necessary to perform offline auto tuning (non-rotation mode) for the wiring length resistance to be reflected on the control when the wiring length is long (30m (98.4feet) or longer as reference).

REMARKS

· Online auto tuning does not operate if the MRS signal is input, if the preset speed is less than the *Pr. 13 Starting frequency* (V/F control or advanced magnetic flux vector control), or if the starting conditions of the inverter are not satisfied, e.g. inverter error.
· Online auto tuning does not operate during deceleration or at a restart during DC brake operation.
· Invalid for jog operation.
· Automatic restart after instantaneous power failure overrides when automatic restart after instantaneous power failure is selected. (Start-time online auto tuning is not performed at frequency search.)
Perform online auto tuning at a stop with the X28 signal when using automatic restart after instantaneous power failure together. (Refer to *the following* for details.)
· Zero current detection and output current detection are valid during online auto tuning.
· The RUN signal is not output during online auto tuning. The RUN signal turns on at a start.
· If the period from an inverter stop to a restart is within 4s, start-time tuning is performed but the tuning results are not reflected.

(3) Start-time online auto tuning from external terminal (X28 signal, Y39 signal)



· By turning on the start-time tuning signal (X28) before the start signal (STF or STR) turns on (at a stop), online tuning is performed and a starting delay after start signal turns on due to tuning can be avoided.
· Perform offline auto tuning and set "1" (start-time tuning) in *Pr. 95*.
· When the start-time tuning completion signal (Y39) is off, start-time tuning with the X28 signal is performed.
· Start-time tuning ends within 500ms maximum.
· When using the X28 signal, set "28" in *Pr. 178 to Pr. 189 (input terminal function selection)* and assign functions to the input terminal.
· When using the Y39 signal, set "39 (positive logic) or 139 (negative logic)" in *Pr. 190 to Pr. 196 (output terminal function selection)* and assign functions to the output terminal.

REMARKS

· Start-time tuning is performed when the start signal is turned on during zero speed control also.
· The Y39 signal is in on status while secondary magnetic flux exists after the motor stop.
· While the Y39 signal is on, the X28 signal is not valid.
· The STF, STR signals are valid after completion of the start-time tuning.
· Only the output signals below are valid during tuning.
IPF, THP, PU, Y12, RY, ER, LF, MT, , AM, A1, B1, C1, A2, B2, C2
· Tuning is invalid during V/F control.

CAUTION

· Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection) or Pr. 190 to Pr. 196 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

WWW.BSNEW.IR

(4) Tune second applied motor

· When you want to switch two motors with one inverter, set the second motor in *Pr. 450 Second applied motor*.(Initial setting is without second applied motor. *(Refer to page 185)*)
Perform tuning using *Pr. 574 Second motor online auto tuning*.
Pr. 574 Second motor online auto tuning is made valid when the RT signal turns on.

Parameter Number	Description
51	Used as rated motor current and electronic thermal relay parameters.
450	Applied motor
453	Motor capacity (down to one rank lower than the inverter capacity, note that the capacity should be 0.4kW or more)
454	Number of motor poles

REMARKS

· The RT signal acts as the second function selection signal and makes the other second functions valid. *(Refer to page 232.)*
The RT signal is assigned to the terminal RT in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, you can assign the RT signal to the other terminal.

CAUTION

· Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 9 Electronic thermal O/L relay ☞ *Refer to page 181*
Pr. 71 Applied motor ☞ *Refer to page 185*
Pr. 80 Motor capacity ☞ *Refer to page 92*
Pr. 81 Number of motor poles ☞ *Refer to page 92*
Pr. 96 Auto tuning setting/status ☞ *Refer to page 187*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*
Pr. 190 to Pr .196 (output terminal function selection) ☞ *Refer to page 236*

WWW.BSNEW.IR

4.14 Motor brake and stop operation

Purpose	Parameter that must be Set		Refer to Page
Motor braking torque adjustment	**DC injection brake and zero speed control, servo lock**	**Pr. 10 to Pr. 12, Pr. 802, Pr. 850**	200
Improve the motor braking torque with an option	**Selection of a regenerative brake**	**Pr. 30, Pr. 70**	204
Performing operation by DC current input	**DC current feeding mode**	**Pr. 30**	204
Coast the motor to a stop	**Selection of motor stopping method**	**Pr. 250**	210
Used to stop the motor with a mechanical brake (vibration restraint at stop-on-contact)	**Stop-on-contact control**	**Pr. 270, Pr. 275, Pr. 276**	211
Used to stop the motor with a mechanical brake (operation timing of a mechanical brake)	**Brake sequence function**	**Pr. 278 to Pr. 285, Pr. 292**	214
Perform position stop (orientation) control of the rotation shaft	**Orientation control**	**Pr. 350 to Pr. 366, Pr. 369, Pr. 393, Pr. 396 to Pr. 399**	217

4.14.1 DC injection brake and zero speed control, servo lock (LX signal, X13 signal, Pr. 10 to Pr. 12, Pr. 802, Pr. 850)


The DC injection brake can be operated at a motor stop to adjust the stop timing and braking torque.
Zero speed control can be selected during real sensorless vector control and either zero speed control or servo lock can be selected under vector control.
In DC injection brake operation, DC voltage is directly applied to the motor to prevent the motor shaft from rotating when a motor decelerates to stop. While, in zero speed control, vector control is performed to maintain 0r/min. In either control, the motor will not return to the original position if the motor shaft rotates due to external force.
The motor shaft position is maintained with servo lock. The motor will return to the original position if the motor shaft rotates due to external force.

Parameter Number	Name	Initial Value 200V class (400V class)		Setting Range	Description
10	**DC injection brake operation frequency**	3Hz		0 to 120Hz	Set the operation frequency of the DC injection brake (zero speed control, servo lock).
				9999	Operated at *Pr. 13* or less.
11	**DC injection brake operation time**	0.5s		0	DC injection brake (zero speed control) disabled
				0.1 to 10s	Set the operation time of the DC injection brake (zero speed control, servo lock).
				8888	Operate when X13 signal is on
12	**DC injection brake operation voltage**	00330 (00170) or less	4%	0 to 30%	Set the DC injection brake voltage (torque). When "0" is set, DC injection brake is disabled.
		00460(00230) to 02150(01100)	2%		
		02880 (01440) or more	1%		
802 *	**Pre-excitation selection**	0		0	Zero speed control
				1	Servo lock
850	**Brake operation selection**	0		0	DC injection brake operation
				1	Zero speed control


* This parameter can be set when the FR-A7AP (option) is mounted.

WWW.BSNEW.IR

When *Pr. 11* = "0.1 to 10s"



When *Pr. 11* = "8888"



(1) Operation frequency setting *(Pr. 10)*

- When the frequency at which the DC injection brake (zero speed control, servo lock) operates is set in *Pr. 10*, the DC injection brake (zero speed control, servo lock) is operated when this frequency is reached during deceleration.
- At the *Pr. 10* setting of "9999", the DC injection brake (zero speed control, servo lock) is operated when deceleration is made to the frequency set in *Pr. 13 Starting frequency*.

REMARKS

- Performing pre-excitation (zero speed control) under real sensorless vector may cause motor vibration, etc. at deceleration to stop. To prevent this, set *Pr.10 DC injection brake operation frequency* to 0.5Hz or less.
- The initial value of *Pr. 10* automatically changes to 0.5Hz during vector control.

(2) Operation time setting *(X13 signal, Pr. 11)*

- Use *Pr. 11* to set the duration period the DC injection brake (zero speed control, servo lock) is applied.
- When the motor does not stop due to large load moment (J), increasing the setting produces an effect.
- When *Pr. 11* = "0s", the DC injection brake (zero speed control, servo lock) is not operated. (At a stop, the motor coasts.)
- When *Pr. 11* = "8888", the DC injection brake (zero speed control, servo lock) is applied when X13 signal is turned on.
- For the terminal used for X13 signal input, set "13" in any of *Pr. 178 to Pr. 189* to assign the function. *(Refer to page 228)*

REMARKS

- When the X13 signal is turned on with *Pr. 11* = "8888", zero speed control is activated regardless of setting of *Pr. 850 Brake operation selection*.
- Under vector control, zero speed control or servo lock is activated depending on the *Pr. 802* setting.

WWW.BSNEW.IR

(3) Operation voltage (torque) setting *(Pr. 12)*

· Use *Pr. 12* to set the percentage to the power supply voltage. (This parameter is not used during zero speed control or servo lock.)
· When *Pr. 12* = "0%", the DC injection brake is not operated. (At a stop, the motor coasts.)
· When using the constant-torque motor (SF-JRCA) and energy saving motor (SF-HR, SF-HRCA), change the *Pr. 12* setting as follows.
SF-JRCA: FR-A720-00175 (FR-A740-00090) or less ...4%,
FR-A720-00240 to 02150 (FR-A740-00120 to 01100)...2%
SF-HR, SF-HRCA: FR-A720-00175 (FR-A740-00090) or less...4%,
FR-A720-00240 and 00330 (FR-A740-00120 and 00170)...3%,
FR-A720-00460 to 02150 (FR-A740-00230 to 01100)...2%
(FR-A720-01150 (FR-A740-00570)...1.5%)

REMARKS

· For the FR-A720-00240, 00330 and FR-A740-00120, 00170, when the *Pr. 12* setting is as below, changing the *Pr. 71 Applied motor* setting changes the *Pr. 12* setting automatically, it is not necessary to change the *Pr. 12* setting.
(a) When *Pr. 12* is 4% (initial value)
The *Pr. 12* setting is automatically changed to 2% if the *Pr. 71* value is changed from the value selecting the standard motor (0, 2 to 8, 20, 23, 24, 40, 43, 44) to the value selecting the constant torque motor (1, 13 to 18, 50, 53, 54).
(b) When *Pr. 12* is 2%
The *Pr. 12* setting is automatically changed to 4% (initial value) if the *Pr. 71* value is changed from the value selecting the constant torque motor (1, 13 to 18, 50, 53, 54) to the value selecting the standard motor (0, 2 to 8, 20, 23, 24, 40, 43, 44).

(4) Brake operation selection during real sensorless vector control *(Pr. 850)*

· You can select DC injection brake (initial value) or zero speed control for brake operation during real sensorless vector control.
When *Pr. 850* = "1", zero speed control is exercised when the frequency reaches or decreases below the frequency set in *Pr. 10*.

REMARKS

· When the X13 signal is on with *Pr. 11* = "8888", zero speed control is activated regardless of setting of *Pr. 850 Brake operation selection*.
· When restarting from brake operation during real sensorless vector control, set "1" (zero speed control) in *Pr. 850*. When the setting value is "0" (DC injection brake), it may take approx. 2s until frequency is actually output from when the start command is input.

(5) Brake operation selection under vector control *(Pr. 802)*

· When pre-excitation is performed, select zero speed control or servo lock using *Pr. 802*.

Pr. 802 Setting	Pre-excitation	Description
0 (initial value)	Zero speed control	Even under load, an attempt is made to maintain 0r/min to keep the motor shaft stopped. Note that if the shaft is overcome and turned by external force, it does not return to the original position. Position control is not exercised and only speed control is carried out to perform operation.
1	Servo lock	Even under load, an attempt is made to maintain the motor shaft position. Note that if the shaft is turned by external force, it returns to the original position after the external force has gone away. Since position control is exercised, you can adjust this position loop gain using *Pr. 422 Position loop gain*.


· The relationship between the DC injection brake operation and pre-excitation operation under each control

Control Method	Control Mode	*Pr. 802*	*Pr. 850*	Decelerates to Stop	LX-ON	X13-ON (*Pr. 11* = "8888")
V/F control	—	—	—	DC Injection brake	—	DC Injection brake
Advanced magnetic flux vector control	—	—	—	DC Injection brake	—	DC Injection brake
Real sensorless vector control	Speed	—	0	DC Injection brake	Zero speed	Zero speed
		—	1	Zero speed		
	Torque	—	0	DC Injection brake	Zero speed	Zero speed
		—	1	Zero speed		
Vector control	Speed	0	—	Zero speed	Zero speed	Zero speed
		1	—	Servo lock	Servo lock	Servo lock
	Torque	—	—	Zero speed	Zero speed	Zero speed
	Position	—	—	—	Servo lock	—

WWW.BSNEW.IR

(6) Pre-excitation signal (LX signal)

- When the LX signal is turned on under real sensorless vector control or vector control, pre-excitation (zero speed control or servo lock) is exercised during a stop.
- For the terminal used for LX signal input, set "23" in any of *Pr. 178 to Pr. 186* to assign the function.



CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.
- Performing pre-excitation (LX signal and X13 signal) under torque control (real sensorless vector control) may start the motor running at a low speed even when the start command (STF or STR) is not input.The motor may run also at a low speed when the speed limit value=0 with a start command input. Perform pre-excitation after making sure that there will be no problem in safety if the motor runs.
- Although FWD/REV of the operation panel is not lit during pre-excitation, note that voltage is applied to the motor.
- Note that when offline auto tuning (*Pr. 96 Auto tuning setting/status* = "1 or 101") is performed during pre-excitation, offline auto tuning is not executed but the motor starts.

⚠ CAUTION

⚠ Do not set *Pr. 11* to "0, 8888" and *Pr. 12* to "0" under orientation operation. Otherwise, the motor will not stop properly.

⚠ As stop holding torque is not produced, install a mechanical brake.
After the machine stops fully and the mechanical brake is applied, switch the LX signal (pre-excitation) off.

♦ Parameters referred to ♦

Pr. 13 Starting frequency ☞ *Refer to page 175*
Pr. 71 Applied motor ☞ *Refer to page 185*
Pr. 178 to Pr. 189 (Input terminal function selection) ☞ *Refer to page 228*
Pr. 422 Position loop gain ☞ *Refer to page 138*

WWW.BSNEW.IR

4.14.2 Selection of regenerative brake and DC feeding (Pr. 30, Pr. 70)

- When making frequent starts/stops, use the optional high-duty brake resistor (FR-ABR), brake unit (FR-BU2, BU, FR-BU, MT-BU) to increase the regenerative brake duty.
- Use a power regeneration common converter (FR-CV) or power regeneration converter (MT-RC) for continuous operation in regenerative status.
  Use a high power factor converter (FR-HC, MT-HC) to reduce harmonics, improve the power factor, or continuously use the regenerative mode.
- You can select either DC feeding mode 1 in which operation is performed with DC power (terminal P/+, N/-) or DC feeding mode 2 in which operation is performed normally with the AC power (terminal R/L1, S/L2, T/L3) and performed with DC power such as battery at occurrence of power failure.

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description	
					Regeneration unit	Terminal for power supply to the inverter
30	Regenerative function selection	0	0		Built-in brake resistor, without regenerative function, brake unit (FR-BU2 [other than MT-BU5 mode], FR-BU, BU type)	R/L1, S/L2, T/L3
			10			P/+, N/- (DC feeding mode 1)
			20			R/L1, S/L2, T/L3 - P/+, N/- (DC feeding mode 2)
			1		High-duty brake resistor, brake unit (FR-BU2 [MT-BU5 mode], MT-BU5), power regeneration converter (MT-RC)	R/L1, S/L2, T/L3
			11			P/+, N/- (DC feeding mode 1)
			21			R/L1, S/L2, T/L3 - P/+, N/- (DC feeding mode 2)
			2		High power factor converter (FR-HC, MT-HC), power regeneration common converter (FR-CV)	P/+, N/-
70	Special regenerative brake duty	0%	02150 (01100) or less	0 to 30%	Set the %ED of the built-in brake transistor operation.	
			02880 (01440) or more	0 to 10%		

<FR-A720-02150(FR-A740-01100) or less>

Regeneration Unit	Power Supply to the Inverter	*Pr. 30* Setting	*Pr. 70* Setting	Remarks
Built-in brake (FR-A720-00330 (FR-A740-00170) or less), brake unit (FR-BU2, FR-BU, BU)	R/L1, S/L2, T/L3	0 (initial value)	—	The regenerative brake duty is as follows. · FR-A720-00030 to 00175 . . . 3% · FR-A720-00240, 00330 . . . . 2% · FR-A740-00015 to 00170 . . . 2% · Other than the above . . . . . 0% (without built-in brake resistor)
	P/+, N/-	10		
	R/L1, S/L2, T/L3 - P/+, N/-	20		
High-duty brake resistor (FR-ABR) (FR-A720-00900 (FR-A740-00440) or less)	R/L1, S/L2, T/L3	1	10/6%	Change the setting according to the capacity. (FR-A720-00330(FR-A740-00170) or less / FR-A720-00460(FR-A740-00230) or more)
	P/+, N/-	11		
	R/L1, S/L2, T/L3 - P/+, N/-	21		
High power factor converter (FR-HC), power regeneration common converter (FR-CV)	P/+, N/-	2	0 (initial value)	

WWW.BSNEW.IR

<FR-A720-02880(FR-A740-01440) or more>

Regeneration Unit	Power Supply to the Inverter	*Pr. 30* Setting	*Pr. 70* Setting
Brake unit (FR-BU2 [other than MT-BU5 mode])	R/L1, S/L2, T/L3	0 (initial value)	—
	P/+, N/-	10	
	R/L1, S/L2, T/L3 - P/+, N/-	20	
Power regeneration converter (MT-RC)	R/L1, S/L2, T/L3	1	0% (initial value)
Brake unit (FR-BU2 [MT-BU5 mode], MT-BU5)	R/L1, S/L2, T/L3	1	10%
	P/+, N/-	11	
	R/L1, S/L2, T/L3 - P/+, N/-	21	
High power factor converter (FR-HC)	P/+, N/-	2	—

(1) When the built-in brake resistor, the brake unit (FR-BU2 [other than MT-BU5 mode], BU, FRBU) is used

· Set "0 (initial value), 10 or 20" in *Pr. 30*. The *Pr. 70* setting is made invalid.
At this time, the regenerative brake duty is as follows. (The built-in brake resistor is provided for the FR-A720-00330(FR-A740-00170) or less.)
  · FR-A720-00030 to 00175 ..3%
  · FR-A720-00240, 00330 .... 2%
  · FR-A740-00015 to 00170 . 2%
  · Other than the above..... 0% (without built-in brake resistor)

CAUTION

· When replacing the existing MT-BU5 type brake unit with the FR-BU2 type brake unit, set "2" in *Pr. 0 Brake mode selection* of the FR-BU2, "1" in *Pr. 30 Regenerative function selection* and "10%" in *Pr. 70 Special regenerative brake duty* of the inverter.
· Do not operate the MT-BU5 type brake unit and FR-BU2 in parallel. Doing so could cause an alarm or brake unit failure. Use the FR-BU2 only when performing parallel operation.

(2) When using the high-duty brake resistor (FR-ABR) (FR-A720-00900 (FR-A740-00440) or less)

· Set "1, 11 or 21" in *Pr. 30*.
· Set *Pr. 70* as follows.
FR-A720-00330(FR-A740-00170) or less 10%
FR-A720-00460(FR-A740-00230) or more ... 6%

(3) When using a brake unit (FR-BU2 [MT-BU5 mode], MT-BU5) and power regeneration converter (MT-RC)

· Set "1, 11 or 21" in *Pr. 30*.
· Set "10%" in *Pr. 70* when using a brake unit (FR-BU2 [MT-BU5 mode], MT-BU5).
· Set "0%" in *Pr. 70* when using a power regeneration converter (MT-RC).


(4) When using the high power factor converter (FR-HC, MT-HC) or power regeneration common converter (FR-CV)

· Set "2" in *Pr. 30*. The *Pr. 70* setting is made invalid.
· Use any of *Pr. 178 to Pr. 189 (input terminal function assignment)* to assign the following signals to the contact input terminals.
  (a)X10 signal: FR-HC, MT-HC connection, FR-CV connection (inverter operation enable signal)
  To make protective coordination with the FR-HC, MT-HC or FR-CV, use the inverter operation enable signal to shut off the inverter output. Input the RDY signal of the FR-HC, MT-HC (RDYB signal of the FR-CV).
  (b)X11 signal: FR-HC, MT-HC connection (instantaneous power failure detection signal)
  When the setting has been made to hold the mode at occurrence of an instantaneous power failure for RS-485 communication operation, use this signal to hold the mode. Input the Y1 or Y2 signal (instantaneous power failure detection signal) of the FR-HC, MT-HC.
· For the terminal used for X10 or X11 signal input, assign its function by setting "10" (X10) or "11" (X11) in any of *Pr. 178 to Pr. 189*.

WWW.BSNEW.IR

(5) DC feeding mode 1 (*Pr. 30* = "10, 11")

- Setting "10, 11" in *Pr. 30* enables DC power supply operation.
- Leave the AC power supply connection terminal R/L1, S/L2, and T/L3 open and connect the DC power supply to terminal P/+ and N/-. Also, remove jumpers across terminal R/L1-R1/L11 and S/L2-S1/L21, and connect terminals R1/L11 and S1/L21 to terminal P/+ and N/-.
- The diagram below is a connection example.




WWW.BSNEW.IR

(6) DC feeding mode 2 (*Pr. 30* = "20, 21")

- When "20 or 21" is set in *Pr. 30*, operation is performed with AC power normally and with DC power such as battery at power failure.
- Connect the AC power supply to terminal R/L1, S/L2, and T/L3 and connect the DC power supply to terminal P/+ and N/-. Also, remove jumpers across terminal R/L1-R1/L11 and S/L2-S1/L21, and connect terminals R1/L11 and S1/L21 to terminal P/+ and N/-.
- Turning on the DC feeding operation permission signal (X70) enables DC power supply operation. Refer to the table below for I/O signals.

Signal		Name	Description	Parameter Setting
Input	X70	DC feeding operation permission signal	When performing operation with DC feeding, turn on the X70 signal. When the inverter output is shut off because of power failure, the inverter can be started in about 150ms after switching off the X70 signal then on again. (When automatic restart operation is valid, the inverter starts after additional *Pr. 57* set time has elapsed.) When the X70 signal turns off during inverter operation, output is shutoff (*Pr .261* = 0) or the inverter is decelerated to a stop (*Pr. 261* ≠ 0).	Set 70 in any of *Pr. 178* to *Pr. 189*.
	X71	DC feeding cancel signal	Turn this signal on to stop DC feeding. When the X71 signal is turned on during inverter operation with turning on the X70 signal, output is shutoff (*Pr. 261* = 0) or the inverter is decelerated to a stop (*Pr. 261* ≠ 0), then the X85 signal turns off after the inverter stop. After turning on of the X71 signal, operation can not be performed even if the X70 signal is turned on.	Set 71 in any of *Pr. 178* to *Pr. 189*.
Output	Y85	DC feeding signal	This signal turns on during power failure or under voltage of AC power. The signal turns off when the X71 signal turns on or power is restored. The Y85 signal does not turn off during inverter operation even if the power is restored and turns off after an inverter stop. When the Y85 signal turns on because of undervoltage, the Y85 signal does not turn off even if undervoltage is eliminated. ON/OFF status is retained at an inverter reset.	Set "85 (positive logic) or 185 (negative logic)" in any of *Pr. 190* to *Pr. 196*

- The following shows the connection diagram when switching to a DC power using inverter power failure detection.




*1 Assign the function using *Pr. 178 to Pr. 189 (input terminal function selection)*.


*2 Assign the function using *Pr. 190 to Pr. 196 (output terminal function selection)*.

WWW.BSNEW.IR


· Operation example 1 at power failure



· Operation example 2 at power failure (when DC power is restored)



· Operation example 3 at power failure (when continuous operation is performed)



WWW.BSNEW.IR

(7) Power supply specification at DC feeding


200V class	Rated input DC voltage	283VDC to 339VDC
	Permissible fluctuation	240VDC to 373VDC
400V class	Rated input DC voltage	537VDC to 679VDC
	Permissible fluctuation	457VDC to 740VDC

CAUTION

- As voltage between P/+, N/- becomes 415V (830V) or more temporarily at regeneration, make selection of DC power supply carefully.

(8) Regenerative brake duty alarm output and alarm signal (RBP signal)

100%: regenerative overvoltage protection operation value



- [RB] appears on the operation panel and an alarm signal (RBP) is output when 85% of the regenerative brake duty set in *Pr. 70* is reached. If the regenerative brake duty reaches 100% of the *Pr. 70* setting, a regenerative overvoltage (E.OV1 to E.OV3) occurs.
- The inverter does not shut off the output when the alarm signal is output.
- For the terminal used for the RBP signal output, assign the function by setting "7" (positive logic) or "107" (negative logic) in any of *Pr. 190 to Pr. 196 (output terminal function selection)*.

REMARKS

- The MRS signal can also be used instead of the X10 signal. *(Refer to page 231.)*
- Refer to *pages 43 to 52* for the connection of high-duty brake resistor (FR-ABR), brake unit, high power factor converter (FR-HC, MT-HC) and power regeneration common converter (FR-CV).
- When AC power is connected to terminal R/L1, S/L2, T/L3 during DC feeding with "2, 10 or 11" (DC feeding) set in *Pr. 30*, an option alarm (E.OPT) occurs.
- When DC feeding operation is performed with "2, 10, 11, 20, or 21" (DC deeding) set in *Pr. 30*, undervoltage protection (E.UVT) and instantaneous power failure (E.IPF) are not detected.

CAUTION

- The brake resister is not connectable to the FR-A720-01150 (FR-A740-00570) or more inverter, the *Pr. 70* setting is invalid.
- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* or *Pr. 190 to Pr. 196 (output terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal. *(Refer to page 228)*

⚠ WARNING

⚠ The value set in *Pr. 70* must not exceed the setting of the brake resistor used.
Otherwise, the resistor can overheat.

♦ Parameters referred to ♦


Pr. 57 Restart coasting time ☞ *Refer to page 261*
Pr. 178 to Pr.189 (input terminal function selection) ☞ *Refer to page 228*
Pr. 190 to Pr.196 (output terminal function selection) ☞ *Refer to page 236*
Pr. 261 Power failure stop selection ☞ *Refer to page 265*


WWW.BSNEW.IR

4.14.3 Stop selection (Pr. 250)

Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns off. Used to stop the motor with a mechanical brake, etc. together with switching off of the start signal.
You can also select the operations of the start signals (STF/STR). (Refer to *page 233* for start signal selection)

Parameter Number	Name	Initial Value	Setting Range	Description	
				Start signal (STF/STR) *(Refer to page 233)*	Stop operation
250	Stop selection	9999	0 to 100s	STF signal: Forward rotation start STR signal: Reverse rotation start	The motor is coasted to a stop when the preset time elapses after the start signal is turned off.The motor is coasted to a stop (*Pr. 250* - 1000)s after the start signal is turned off.
			1000s to 1100s	STF signal: Start signal STR signal: Forward/ reverse signal	
			9999	STF signal: Forward rotation start STR signal: Reverse rotation start	When the start signal is turned off, the motor decelerates to stop.
			8888	STF signal: Start signal STR signal: Forward/ reverse signal	





(1) Decelerate the motor to a stop

- Set *Pr. 250* to "9999" (initial value) or "8888".
- The motor decelerates to a stop when the start signal (STF/STR) turns off.

(2) Coast the motor to a stop

- Use *Pr. 250* to set the time from when the start signal turns off until the output is shut off. When any of "1000" to "1100" is set, the output is shut off after (*Pr. 250* – 1000)s.
- The output is shut off when the time set in *Pr. 250* has elapsed after the start signal had turned off. The motor coasts to a stop.
- The RUN signal turns off when the output stops.

REMARKS

Stop selection is invalid when the following functions are activated.
- Position control (*Pr. 419* = 0)
- Power failure stop function *(Pr. 261)*
- PU stop *(Pr. 75)*
- Deceleration stop because of fault definition *(Pr. 875)*
- Deceleration stop because of communication error *(Pr. 502)*
- Offline auto tuning (with motor running)
- Emergency stop by LONWORKS communication

CAUTION

- When the start signal is turned on again during motor coasting, the motor starts at *Pr. 13 Starting frequency*.


♦ Parameters referred to ♦

Pr. 7 Acceleration time , Pr. 8 Deceleration time ☞ *Refer to page 173*
Pr. 13 Starting frequency ☞ *Refer to page 175*

WWW.BSNEW.IR

4.14.4 Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270, Pr. 275, Pr. 276)


To ensure accurate positioning at the upper limit etc. of a lift, stop-on-contact control causes a mechanical brake to be closed while the motor is developing a holding torque to keep the load in contact with a mechanical stopper etc.
This function suppresses vibration which is liable to occur when the load is stopped upon contact in vertical motion applications, ensuring steady precise positioning.




Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
6	Multi-speed setting (low speed)	10Hz	0 to 400Hz		Set the output frequency for stop-on-contact control.
22	Stall prevention operation level	150% *	0 to 400%		Set the stall prevention operation level for stop-on-contact control. The smaller value set in either *Pr. 22* or *Pr. 48* has a priority.
48	Second stall prevention operation current	150% *	0 to 220% *		
270	Stop-on contact/ load torque high-speed frequency control selection	0	0		Normal operation
			1		Stop-on-contact control
			2		Load torque high speed frequency control *(Refer to page 368)*
			3		Stop-on-contact+load torque high speed frequency control *(Refer to page 368)*
275	Stop-on contact excitation current low-speed multiplying factor	9999	0 to 1000%		Set the force (holding torque) for stop-on-contact control. Normally set 130% to 180%. Valid only during advanced magnetic flux vector control
			9999		No compensation.
276	PWM carrier frequency at stop-on contact	9999	02150(01100) or less	0 to 9	Set a PWM carrier frequency for stop-on-contact control. For real sensorless vector control, carrier frequency is always 2Hz when a setting value is 0 to 5 and always 6Hz when a setting value is 6 to 9. (Valid at the frequency of 3Hz or less.)
			02880(01440) or more	0 to 4	
			9999		As set in *Pr. 72 PWM frequency selection* .

* When *Pr. 570 Multiple rating setting* ≠ "2", performing inverter reset and all parameter clear changes the initial value and setting range. (*Refer to page 155*)

<Connection and operation example>



* The input terminal used differs according to the *Pr. 180 to Pr. 189* settings.



Goes into stop-on-contact control mode when both RL and RT switch on.
*RL and RT may be switched on in any order with any time difference
(a):Acceleration time (*Pr. 7*)
(b):Deceleration time (*Pr. 8*)
(c):Second deceleration time (*Pr. 44/Pr. 45*)

WWW.BSNEW.IR

(1) Set stop-on-contact control

- Make sure that the inverter is in external operation mode. *(Refer to page 308)*
- Select either real sensorless vector control or advanced magnetic flux vector control.
- Set"1 or 3" in *Pr. 270 Stop-on contact/load torque high-speed frequency control selection* .
- Set output frequency during stop-on-contact control in *Pr. 6 Multi-speed setting (low speed)*.
  The frequency should be as low as possible (about 2Hz). If it is set to more than 30Hz, the operating frequency will be 30Hz.
- When both the RT and RL signals are switched on, the inverter enters the stop-on-contact mode, in which operation is performed at the frequency set in *Pr. 6* independently of the preceding speed.

CAUTION

- By increasing the *Pr. 275* setting, the low-speed (stop-on-contact) torque increases, but overcurrent alarm (E.OCT) may occur or the machine may oscillate in a stop-on-contact state.
- The stop-on-contact function is diferent from servo-lock function, and if used to stop or hold a load for an extended period, this function can cause the motor to overheat.
  After a stop, immediately reset this function and use a mechanical brake to hold the load.
- Under the following operating conditions, the stop-on-contact function is made invalid:
  PU operation *(Pr. 79)*・JOG operation (JOG signal)・PU+external operation *(Pr. 79)*・PID control function operation *(Pr. 128)*
  ・Remote setting function operation *(Pr. 59)*・Start time tuning・Orientation control function operation
- When performing stop-on-contact control during encoder feedback control, encoder feedback control is made invalid due to a mode shift to the stop-on-contact control mode.

(2) Function switching of stop-on-contact control selection

Useful Functions	Normal Operation (either RL or RT is off or both are off)		With Stop-on-Contact Control (both RL and RT are on)	
	Real sensorless vector control	Advanced magnetic flux vector control	Real sensorless vector control	Advanced magnetic flux vector control
Output frequency	Multi-speed 0 to 5V, 0 to 10V 4 to 20mA etc.		*Pr. 6* setting	
Stall prevention operation level	—	*Pr. 22* setting	—	The smaller value set in either *Pr. 22* or *Pr. 48*. *
Torque limit level	*Pr. 22* setting	—	*Pr. 22* setting	—
Excitation current low speed scaling factor	—		—	The current is compensated for by *Pr. 275* (0 to 1000%) settings before RL and RT are switched on.
Carrier frequency	*Pr. 72* setting		*Pr. 276* setting when output frequency is 3Hz or less (*Pr. 72* when *Pr. 276* = "9999")	
Fast response current limit	—	Valid	—	Invalid

* When RL and RT are on, *Pr. 49 Second stall prevention operation frequency* is invalid.

WWW.BSNEW.IR

(3) Set frequency when stop-on-contact control (*Pr. 270* = 1, 3) is selected

- The following table lists the frequencies set when the input terminals (RH, RM, RL, RT, JOG) are selected together. Bold frame indicates stop-on-contact control is valid.
- Stop-on-contact control is disabled when remote setting function is selected (*Pr. 59* = 1 to 3).

Input Signal (○ = on)					Set Frequency
RH	RM	RL	RT	JOG	
○					*Pr. 4 Multi-speed setting (high speed)*
	○				*Pr. 5 Multi-speed setting (middle speed)*
		○			*Pr. 6 Multi-speed setting (low speed)*
			○		By 0 to 5V(0 to 10V), 4 to 20mA input
				○	*Pr. 15 Jog frequency*
○	○				*Pr. 26 Multi-speed setting (speed 6)*
○		○			*Pr. 25 Multi-speed setting (speed 5)*
○			○		*Pr. 4 Multi-speed setting (high speed)*
○				○	*Pr. 15 Jog frequency*
	○	○			*Pr. 24 Multi-speed setting (speed 4)*
	○		○		*Pr. 5 Multi-speed setting (middle speed)*
	○			○	*Pr. 15 Jog frequency*
		○	○		*Pr. 6 Multi-speed setting (low speed)*
		○		○	*Pr. 15 Jog frequency*
			○	○	*Pr. 15 Jog frequency*
		○	○	○	*Pr. 15 Jog frequency*

Input Signal (○ = on)					Set Frequency
RH	RM	RL	RT	JOG	
	○		○	○	*Pr. 15 Jog frequency*
	○	○		○	*Pr. 15 Jog frequency*
	○	○	○		*Pr. 6 Multi-speed setting (low speed)*
○			○	○	*Pr. 15 Jog frequency*
○		○		○	*Pr. 15 Jog frequency*
○		○	○		*Pr. 6 Multi-speed setting (low speed)*
○	○			○	*Pr. 15 Jog frequency*
○	○		○		*Pr. 26 Multi-speed setting (speed 6)*
○	○	○			*Pr. 27 Multi-speed setting (speed 7)*
	○	○	○	○	*Pr. 15 Jog frequency*
○		○	○	○	*Pr. 15 Jog frequency*
○	○		○	○	*Pr. 15 Jog frequency*
○	○	○		○	*Pr. 15 Jog frequency*
○	○	○	○		*Pr. 6 Multi-speed setting (low speed)*
○	○	○	○	○	*Pr. 15 Jog frequency*
					By 0 to 5V(0 to 10V), 4 to 20mA input

CAUTION

- Changing the terminal function using any of *Pr. 178 to Pr. 189* may affect the other functions. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 4 to Pr. 6, Pr. 24 to Pr. 27 (multi-speed setting) ☞ *Refer to page 166*
Pr. 15 Jog frequency ☞ *Refer to page 168*
Pr. 22 Stall prevention operation level, Pr. 48 Second stall prevention operation current ☞ *Refer to page 150*
Pr. 22 Torque limit level ☞ *Refer to page 99*
Pr. 59 Remote function selection ☞ *Refer to page 170*
Pr. 72 PWM frequency selection ☞ *Refer to page 279*
Pr. 79 Operation mode selection ☞ *Refer to page 308*
Pr. 95 Online auto tuning selection ☞ *Refer to page 197*
Pr. 128 PID action selection ☞ *Refer to page 355*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*
Pr. 270 = 2, 3 (load torque high speed frequency control) ☞ *Refer to page 368*

WWW.BSNEW.IR

4.14.5 Brake sequence function (Pr. 278 to Pr. 285, Pr. 292)


This function is used to output from the inverter the mechanical brake operation timing signal in vertical lift and other applications.
This function prevents the load from dropping with gravity at a start due to the operation timing error of the mechanical brake or an overcurrent alarm from occurring at a stop, ensuring secure operation.

Parameter Number	Name	Initial Value	Setting Range	Description
278	**Brake opening frequency**	3Hz	0 to 30Hz	Set to the rated slip frequency of the motor + about 1.0Hz. This parameter may be only set if *Pr. 278 ≤ Pr. 282*.
279	**Brake opening current**	130%	0 to 220% *2	Generally, set this parameter to about 50 to 90%. If the setting is too low, the load is liable to drop due to gravity at start. Suppose that the rated inverter current is 100%.
280	**Brake opening current detection time**	0.3s	0 to 2s	Generally, set this parameter to about 0.1 to 0.3s.
281	**Brake operation time at start**	0.3s	0 to 5s	Set the mechanical delay time until the brake is loosened. Set the mechanical delay time until the brake is loosened + about 0.1 to 0.2s when *Pr. 292* = "8".
282	**Brake operation frequency**	6Hz	0 to 30Hz	Set the frequency to activate the mechanical brake by turning off the brake opening request signal (BOF). Generally, set this parameter to the *Pr. 278* setting + 3 to 4Hz. Setting is enabled only when *Pr. 282 ≥ Pr. 278*.
283	**Brake operation time at stop**	0.3s	0 to 5s	Set the mechanical delay time until the brake is closed + 0.1s when *Pr. 292*=7. Set the mechanical delay time until the brake is closed + 0.2 to 0.3s when *Pr. 292* = 8.
284	**Deceleration detection function selection**	0	0	Deceleration is not detected.
			1	If deceleration is not normal during deceleration operation, the inverter alarm is provided.
285	**Overspeed detection frequency** *1	9999	0 to 30Hz	If (detected frequency) - (output frequency) ≥ *Pr. 285* during encoder feedback control, the inverter alarm (E.MB1) is provided.
			9999	Overspeed is not detected.
292	**Automatic acceleration/ deceleration**	0	0	Normal operation mode
			1, 11	Shortest acceleration/deceleration mode *(Refer to page 179)*
			3	Optimum acceleration/deceleration mode *(Refer to page 180)*
			5, 6	Elevator mode *(Refer to page 163)*
			7	Brake sequence mode 1
			8	Brake sequence mode 2

*1 When exercising vector control with the FR-A7AP, this parameter changes to excessive speed deviation detection frequency (For details, refer to *page 116*)
*2 When *Pr. 570 Multiple rating setting* ≠ "2", performing inverter reset and all parameter clear changes the setting range. (*Refer to page 155*)

<Connection diagram>

- Sink logic
- *Pr.184* = 15
- *Pr.190* = 20



*1 The input signal terminal used differs according to the *Pr. 178 to Pr. 189* settings.
*2 The output signal terminal used differs according to the *Pr. 190 to Pr. 196* settings.
*3 The current should be within the permissible current of transistor in the inverter. (24V 0.1ADC)


CAUTION

- When brake sequence mode is selected, automatic restart after instantaneous power failure is invalid.
- When using this function, set the acceleration time to 1s or longer.
- Changing the terminal function using any of *Pr. 178 to Pr. 189*, *Pr. 190 to Pr. 196* may affect the other functions. Please make setting after confirming the function of each terminal.

WWW.BSNEW.IR


(1) Set the brake sequence mode

- Select either real sensorless vector control, vector control (speed control) or advanced magnetic flux vector control. The brake sequence function is valid only when the external operation mode, external/PU combined operation mode 1 or network operation mode is selected.
- Set "7 or 8" (brake sequence mode) in *Pr. 292* .
  To ensure more complete sequence control, it is recommended to set "7" (brake opening completion signal input) in *Pr. 292* .
- Set "15" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* and assign the brake opening completion signal (BRI) to the input terminal.
- Set "20 (positive logic)" or "120 (negative logic)" in any of *Pr. 190 to Pr. 196 (output terminal function selection)* and assign the brake opening request signal (BOF) to the output terminal.



(2) With brake opening completion signal input *(Pr. 292* = "7")

- When the start signal is input to the inverter, the inverter starts running. When the internal speed command reaches the value set in *Pr. 278* and the output current is not less than the value set in *Pr. 279* , the inverter outputs the brake opening request signal (BOF) after the time set in *Pr. 280* has elapsed.
  When the time set in *Pr. 281* elapses after the brake opening completion signal (BRI) was activated, the inverter increases the output frequency to the set speed.
- When the speed has decreased to the frequency set in *Pr. 282* during deceleration, the BOF signal is turned off. When the time set in *Pr. 283* elapses after the electromagnetic brake operation was completed and the BRI signal was turned off, the inverter output is switched off.



(3) Without brake opening completion signal input *(Pr. 292* = "8")

- When the start signal is input to the inverter, the inverter starts running. When the internal speed command reaches the value set in *Pr. 278* and the output current is not less than the value set in *Pr. 279* , the inverter outputs the brake opening request signal (BOF) after the time set in *Pr. 280* has elapsed.
  When the time set in *Pr. 281* elapses after the BOF signal is output, the inverter increases the output frequency to the set speed.
- When the speed has decreased to the frequency set in *Pr. 282* during deceleration, the brake opening request signal (BOF) is turned off. When the time set in *Pr. 283* has elapsed after the BOF signal is turned off, the inverter output is switched off.

REMARKS

- Even if brake sequence mode has been selected, inputting the jog signal (jog operation), RT signal (second function selection) or X9 signal (third function selection) during an inverter stop will switch to the normal operation and give priority to jog operation or second and third function selection. Note that JOG and RT signal input is invalid even if JOG signal and RT signal are input during automatic acceleration/deceleration operation.

WWW.BSNEW.IR

(4) Protective functions

If any of the following errors occurs in the brake sequence mode, the inverter results in an alarm, shuts off the output, and turns off the brake opening request signal (BOF).

Error Display	Description
E.MB1	(Detection frequency) - (output frequency) > *Pr. 285* during encoder feedback control When *Pr. 285 Overspeed detection frequency* = 9999, overspeed is not detected.
E.MB2	Deceleration is not normal during deceleration operation from the set frequency to the frequency set in *Pr. 282*. (when *Pr. 284* =1) (except stall prevention operation)
E.MB3	Brake opening request signal (BOF) turned on though the motor is at a stop. (gravity drop prevention function)
E.MB4	Although more than 2s have elapsed after the start command (forward or reverse rotation) is input, the brake opening request signal (BOF) does not turn on.
E.MB5	Although more than 2s have elapsed after the brake opening request signal (BOF) turned on, the brake opening completion signal (BRI) does not turn on.
E.MB6	Though the inverter had turned on the brake opening request signal (BOF), the brake opening completion signal (BRI) turned off midway.
E.MB7	Although more than 2s have elapsed after the brake opening request signal (BOF) turned off at a stop, the brake opening completion signal (BRI) does not turn off.

CAUTION

- Overspeed detection *(Pr. 285)* is valid under encoder feedback control (used with the FR-A7AP option) even if a value other than "7 or 8" is set in *Pr. 292*.
- A too large setting of *Pr. 278 Brake opening frequency* activates stall prevention operation and may cause E.MB4.

♦ Parameters referred to ♦



Pr. 80 Motor capacity, Pr. 81 Number of motor poles ☞ *Refer to page 92*
Pr. 180 to Pr. 186 (input terminal function selection) ☞ *Refer to page 228*
Pr. 190 to Pr. 195 (output terminal function selection) ☞ *Refer to page 236*
Pr. 800 Control method selection ☞ *Refer to page 92*
Encoder feedback control ☞ *Refer to page 375*

WWW.BSNEW.IR

4.14.6 Orientation control (Pr. 350 to Pr. 366, Pr. 369, Pr. 393, Pr. 396 to Pr. 399)

V/F | Vector

This function is used with a position detector (encoder) installed to the spindle of a machine tool, etc. to allow a rotation shaft to be stopped at the specified position (oriented).
Option FR-A7AP is necessary.
Pr. 350 Stop position command selection is initially set to "9999", orientation control function is invalid.

Parameter Number	Name	Initial Value	Setting Range	Description
350	**Stop position command selection**	9999	0	Internal stop position command *(Pr. 356)*
			1	External stop position command (FR-A7AX 16-bit data)
			9999	Orientation control invalid
351	**Orientation speed**	2Hz	0 to 30Hz	Decrease the motor speed to the set value when the orientation command (X22) is given.
352	**Creep speed**	0.5Hz	0 to 10Hz	After the speed reaches the orientation speed, the speed decreases to the creep speed set in *Pr. 352* as soon as the current position pulse reaches the creep switchover position set in *Pr. 353*.
353	**Creep switchover position**	511	0 to 16383*	
354	**Position loop switchover position**	96	0 to 8191	As soon as the current position pulse reaches the set position loop switchover position, control is changed to position loop.
355	**DC injection brake start position**	5	0 to 255	After changed to position loop, DC injection brake is applied and the motor stops as soon as the current position pulse reaches the set DC injection brake start position.
356	**Internal stop position command**	0	0 to 16383*	When "0" is set in *Pr. 350*, the internal position command is activated and the setting value of *Pr. 356* becomes a stop position.
357	**Orientation in-position zone**	5	0 to 255	Set the in-position zone at a stop of the orientation.
358	**Servo torque selection**	1	0 to 13	Functions at orientation completion can be selected.
359	**Encoder rotation direction**	1	0	 Clockwise direction as viewed from A is forward rotation
			1	 Counter clockwise direction as viewed from A is forward rotation
360	**16 bit data selection**	0	0	Speed command When 1 is set in *Pr. 350* and the FR-A7AX is mounted, set a stop position using 16-bit data. Stop position command is input as binary regardless of the *Pr. 304* setting.
			1	16 bit data is used as external position command as is.
			2 to 127	Set the stop position dividing up to 128 stop positions at regular intervals.
361	**Position shift**	0	0 to 16383*	Shift the origin using a compensation value without changing the origin of the encoder. The stop position is a position obtained by adding the setting value of *Pr. 361* to the position command.
362	**Orientation position loop gain**	1	0.1 to 100	When servo torque function is selected using *Pr. 358*, output frequency for generating servo torque increases to the creep speed of *Pr. 352* gradually according to the slope set in *Pr. 362*. Although the operation becomes faster when the value is increased, a machine may hunt, etc.
363	**Completion signal output delay time**	0.5s	0 to 5.0s	The orientation complete signal is output delaying the set time after in-position zone is entered. Also, the signal turns off delaying the set time after in-position zone is out.

WWW.BSNEW.IR


Parameter Number	Name	Initial Value	Setting Range	Description
364	**Encoder stop check time**	0.5s	0 to 5.0s	Orientation fault signal (ORM) is output when the encoder remains stopped for the set time without orientation completion in the state where no orientation complete signal (ORA) is output. ORM signal is output when orientation is not completed again in the set time in the state where ORA signal is output.
365	**Orientation limit**	9999	0 to 60.0s	Measure the time taken after passing the creep switchover position and output the orientation fault signal (ORM) if orientation is not completed within the set time.
			9999	Set to 120s.
366	**Recheck time**	9999	0 to 5.0s	Turning off the start signal with orientation command (X22) on after stopping the motor by orientation control, the present position is checked again after the set time elapses and the orientation complete signal (ORA) or orientation fault signal (ORM) is output.
			9999	Not checked.
369	**Number of encoder pulses**	1024	0 to 4096	Set the number of pulses of the encoder. Set the number of pulses before multiplied by four.
393	**Orientation selection**	0	0	Orientation is executed from the current rotation direction.
			1	Orientation is executed from the forward rotation direction.
			2	Orientation is executed from the reverse rotation direction.
396	**Orientation speed gain (P term)**	60	0 to 1000	Response level during position control loop (servo rigidity) at orientation stop can be adjusted.
397	**Orientation speed integral time**	0.333	0 to 20.0s	
398	**Orientation speed gain (D term)**	1	0 to 100.0	Lag/advance compensation gain can be adjusted.
399	**Orientation deceleration ratio**	20	0 to 1000	Make adjustment when the motor runs back at orientation stop or the orientation time is long.

The above parameters can be set when the FR-A7AP (option) is mounted.

* When the operation panel (FR-DU07) is used, the maximum setting is 9999. When a parameter unit is used, up to the maximum value within the setting range can be set.

WWW.BSNEW.IR

(1) Connection example



*1 The pin number differs according to the encoder used.

*2 Use *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function to any of terminal. *(Refer to page 228.)*

*3 Use *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function to any of terminal. *(Refer to page 236.)*

*4 Connect the encoder so that there is no looseness between the motor and motor shaft. Speed ratio should be 1:1.

*5 Earth (Ground) the shielded cable of the encoder cable to the enclosure with a P clip, etc. *(Refer to page 41.)*

*6 For the differential line driver, set the terminating resistor selection switch to on position (initial status) to use. *(Refer to page 37.)*
Note that the terminating resistor switch should be set to off position when sharing the same encoder with other unit (NC, etc) or a terminating resistor is connected to other unit.
For the complementary, set the switch to off position.


*7 For terminal compatibility of the FR-JCBL, FR-V7CBL and FR-A7AP, *refer to page 38*.

*8 A separate power supply of 5V/12V/15V/24V is necessary according to the encoder power specification.
When performing encoder feedback control and vector control together, an encoder and power supply can be shared.

*9 When a stop position command is input from outside, a plug-in option FR-A7AX is necessary. Refer to *page 220* for external stop position command.)

*10 For the fan of the 7.5kW or less dedicated motor, the power supply is single phase. (200V/50Hz, 200 to 230V/60Hz)

*11 Assign OH (external thermal input) signal to the terminal CS. (Set "7" in *Pr. 186*)
Connect a 2W1kΩ resistor between the terminal PC and CS(OH).
Install the resistor pushing it against the bottom part of the terminal block so as to avoid a contact with other cables.



<Setting>

If the orientation command signal (X22) is turned on during operation after the various parameters have been set, the speed will decelerate to the "orientation switchover speed". After the "orientation stop distance" is calculated, the speed will further decelerate, and the "orientation state" (servo lock) will be entered. The "orientation complete signal" (ORA) will be output when the "orientation complete width" is entered.

(2) Setting I/O singals

Terminal	Terminal Name	Application Explanation
X22*1	Orientation command input	Used to enter an orientation signal for orientation. For the terminal used for X22 signal input, set "22" in any of *Pr. 178 to Pr. 189* to assign the function.
SD	Contact input common	Common terminal for the orientation signal.
ORA*2	Orientaiton complete signal output	Switched low if the orientation has stopped within the in-position zone while the start and orientation signals are input. For the terminal used for the ORA signal output, assign the function by setting "27 (positive logic) or 127 (negative logic)" in any of *Pr. 190 to Pr. 196*.
ORM*2	Orientation fault signal output	Switched low if the orientation has not stopped within the in-position zone while the start and orientation signals are input. For the terminal used for the ORM signal output, assign the function by setting "28 (positive logic) or 128 (negative logic)" in any of *Pr. 190 to Pr. 196*.
SE	Open collector output common	Common terminal for the ORA and ORM open collector output terminals.

*1 For X22 signals, assign functions to any of terminal using *Pr. 178 to Pr. 189 (ouput terminal function selection)*. *(Refer to page 228)*

*2 For ORA and ORM signals, assign functions to any of terminal using *Pr. 190 to Pr. 196 (ouput terminal function selection)*. *(Refer to page 236)*


WWW.BSNEW.IR

(3) Selecting stop position command (*Pr. 350 Stop position command selection*)

· Select either the internal stop position command *(Pr. 356)* or the external stop position command (16-bit data using the FR-A7AX).




Pr. 350 Setting	Stop Position Command Source
0	Internal stop position command (*Pr. 356*: 0 to 16383)
1	External stop position command (FR-A7AX) 16-bit data
9999 (Initial value)	Orientation control invalid

1) Internal stop position command (*Pr. 350* = "0")
The value set in *Pr. 356* is the stop position.
When the number of encoder pulses is 1024p/r, one revolution of the encoder is divided into 4096 positions, i.e. 360°/4096 pulses = 0.0879°/pulses per address, as shown on the right. The stop positions (addresses) are indicated in parentheses.



2) External stop position command (*Pr. 350* = "1")
Mount the option FR-A7AX and set a stop position using 16-bit data (binary input).
· The value set in *Pr. 360 16 bit data selection* should be the number of stop positions less 1.

Pr. 360 Setting	Description
0	External position command is made invalid (speed command or torque command with the FR-A7AX)
1	Position command direct input The 16-bit digital signal from the FR-A7AX is directly serves as stop position command. <Example> When the *Pr. 369 Number of encoder pulses* setting is 1024, stop position command from 0 to 4095 can be directly input using the FR-A7AX and input digital signal of 2048 (H800) to stop the motor at 180° position. The command more than 4096 is considered as 4095.
2 to 127	Set the stop position command dividing up to 128 stop positions at regular intervals. If the external stop command entered is greater than the setting, the stop positions are the same as those in the maximum external stop command value. <Example> When the number of stop positions is 90 (divided at intervals of 4°), 90 - 1 = 89. Hence, set "89".

[Example] When *Pr. 369* = "1024"	[Example 2] 8 stop positions	[Example 3] 120 stop positions
		
Pr. 360 = "1"	*Pr. 360* = "7"	*Pr. 360* = "119"

CAUTION

· Values in parentheses indicate binary data entered from the terminals. Even if the position pulse monitor (*Pr. 52 DU/PU main display data selection* = 19) is selected, the data monitored is not the number of stop positions but is 0 to 65535 pulses.
· FR-A7AX parameters *(Pr. 300 to Pr. 305)* are invalid. (Valid when *Pr. 360* = "0")
· Terminal DY (data read timing input signal) is made invalid during vector control. (The position data is downloaded at the start of orientation.)
· Internal stop position command is given even if "1" (external stop position command) is set in *Pr. 350* when an option card (FR-A7AX) is not mounted or *Pr. 360* = "0".

WWW.BSNEW.IR

• Relationship between stop position command and 16-bit data

Pr. 350 Stop position command selection	*Pr. 360 16 bit data selection*	Operation		
		Stop position command	**16 bit data (FR-A7AX)**	**Speed command**
0:internal	0: speed command	Internal *(Pr. 356)*	Speed command	16 bit data
	1, 2 to 127: position command	Internal *(Pr. 356)*	Invalid	External command (or PU)
1: external	0: speed command	Internal *(Pr. 356)*	Speed command	16 bit data
	1, 2 to 127: position command	External (Internal when the FR-A7AX is not mounted *(Pr. 356)*)	Position command	External command (or PU)

3) *Pr. 361 Position shift* (initial value "0")

The stop position is a position obtained by adding the setting value of *Pr. 361* to the position command.

<Position shift function>

Shift the origin using a compensation value without changing the origin of the poisition detector (encoder).

REMARKS

• When orientation control is made valid using *Pr. 350 Stop position command selection* with the FR-A7AP mounted, the rotation direction of encoder is displayed on the rotation direction display of the PU (FR-DU07/FR-PU04/FR-PU07).
Set the parameter so that turning on the STF signal displays FWD or turning on the STR signal displays REV.

(4) Monitor display change

Monitor	REMARKS
Position pulse monitor	When "19" is set in *Pr. 52* , position pulse monitor is displayed instead of output voltage monitor of the PU. (Displayed only when the FR-A7AP is mounted.)
Orientation status*	When "22" is set in *Pr. 52* , orientation status is displayed instead of output voltage monitor of the PU. (Displayed only when the FR-A7AP is mounted.) 0-Other than orientation operation or orientation speed is not reached 1-Orientation speed is reached 2-Creep speed is reached 3-Position loop is reached 4-Orientation complete 5-Orientatino fault (pulse stop) 6-Orientatino fault (orientation limit) 7-Orientation fault (recheck) 8-Continuous multi-point orientation


* Invalid during vector control. ("0" is always displayed)

(5) *Pr. 357 Orientation in-position zone* (initial value "5")

• The positioning width for orientation stop can be set. The initial setting of *Pr. 357* is "5". To change the $\Delta\theta$ value, finely adjust with $\pm$10 increments, and make fine adjustment.

• If the position detection value from the encoder enters $\pm\Delta\theta$ during orientation stop, the orientation complete signal (ORA) will be output.

Example of operation



$$\Delta\theta = \frac{360^\circ}{\frac{Pr.369}{\text{Number of encoder pulses}} \times \text{four times}} \times Pr.357$$

WWW.BSNEW.IR


(6) Orientation operation (under V/F control, advanced magnetic flux vector control)

● Orientation during running

1) When the orientation command (X22) is input, the motor speed decreases to the orientation speed set in *Pr. 351 Orientation speed* . (*Pr. 351* initial value: 2Hz)
2) After the speed reaches the orientation speed, the speed decreases to the creep speed set in *Pr. 352 Creep speed* as soon as the current position pulse reaches the creep switchover position set in *Pr. 353 Creep switchover position* (*Pr. 352* initial value:0.5Hz, *Pr. 353* initial value: 511)
3) Moreover, as soon as the current position pulse reaches the set position loop switchover position in *Pr. 354 Position loop switchover position* , control is changed to position loop. (*Pr. 354* initial value: 96)
4) After switching to position loop, the inverter decelerates and stops with DC injection brake as soon as the current position pulse has rached the DC injection brake start position set in *Pr. 355 DC injection brake start position*. (*Pr. 355* initial value: 5)
5) When the position pulse has stopped within the in-position zone set in *Pr. 357 Orientation in-position zone* , the orientation completion signal (ORA) is output after the comletion signal output delay time set in *Pr. 363 Completion signal output delay time* has elapsed. If the motor does not stop within the in-position zone due to external force, etc., the orientation completion signal is turned off after the time set in *Pr. 363 Completion signal output delay time* has elapsed. (*Pr. 357* initial value: 5)
6) If the orientation is not completed continusouly for the time set in *Pr. 365 Orientation limit* after passing the creep switchover position, the orientation fault signal (ORM) is output.
7) When the motor stops before the position pulse reaching the in-position zone due to external force after orientation start and orientation completion signal (ORA) is not output, orientation fault signal (ORM) is output after the time set in encoder stop check time set in *Pr. 364 Encoder stop check time* has elapsed. Moreover, the orientation complete signal (ORA) is turned off after the time set in *Pr. 363 Completion signal output delay time* has elapsed if the position pulse is outside the in-position zone due to external force, etc. after outputting the orientation complete signal (ORA), and the orientation fault signal (ORM) is output if the orientation has not completed within the time set in *Pr. 364 Encoder stop check time* .
8) When the start signal (STF or STR) is turned off with the orientation command on after outputting the orientation completion signal (ORA) and orientation fault signal (ORM), the orientation complete signal (ORM) or orientation fault signal (ORM) is output again after recheck time set in *Pr. 366 Recheck time* has elapsed.
9) The orientation completion signal (ORA) and orientation fault signal (ORM) are not output when the orientation command is off.


REMARKS

- When the orientation command is off with the start signal on, the speed accelerates to the command speed.



- If the motor shaft hants, set a larger value in *Pr. 354 Position loop switchover position* or a smaller value in *Pr. 352 Creep speed* to prevent it.


- Action time chart



WWW.BSNEW.IR


● Orientation from stop

After turning on the orientation command (X22), turning on the start signal will increase the motor speed to the orientation speed set in *Pr. 351 Orientation speed*, then orientation operation same as when "orientation during running" is performed.
Note that, DC injection brake is operated if the position signal is within the DC injection brake start position.
• Action time chart



● Continuous multi-point orientation

Orientation command and orientation with STF/STR on
(Orientation in servo in status)



- Read the position data at starting up of DY (refer to *the FR-A7AX instruction manual*).
- When the position signal is within the creep switchover position, the speed starts up to the creep speed not to the orientation speed.
- When the position signal is not within the creep switchover position, the speed starts up tp the orientation speed.
- The DC injection brake is operated if the position signal is within the DC injection brake start position.
- 16-bit data with the FR-A7AX is valid only when the DY signal is on.

CAUTION

- The encoder should be coupled with the motor shaft or main spindle oriented with a speed ratio of 1 to 1 without any mechanical looseness.
- DC injection brake operates when orientation stop is made. Release the DC injection brake in a time as short as possible (within several seconds) since continuous operation of the DC injection brake will cause the motor to overheat, leading to burnout.
- Since no servo lock function is available after orientation stop, provide a holding mechanism such as mechanical brake or knock pin when secure holding of a main spindle is required.
- To ensure correct positioning, the encoder must be set in the proper rotation direction and the A and B phases connected correctly.
- When the pulse signal from the encoder stops due to the encoder signal loss, etc. during orientation, the orientation fault signal (ORM) may be output.
- When the DC injection brake is set to disabled using parameter for DC injection brake adjustment (voltage, frequency, speed, time) when performing orientation control, orientation operation can not be completed. Always set the DC injection brake enabled.
- To terminate orientation, the start signal (STF or STR) must be first switched off and the orientation signal (X22) must be switched off. As soon as this orientation signal is switched off, orientation control ends.(Depending on the *Pr. 358 Servo torque selection* setting, orientation status continues if the orientation signal remains on even if DC injection brake is released at turning off of the start signal. Therefore, the orientation status of the monitor function is not 0.)
- When retry function of *Pr. 358 Servo torque selection* is selected, this retry function is performed three times including the first orientation.
- When performing orientation control, make proper setting of *Pr. 350 Stop position command selection* and *Pr. 360 16 bit data selection (external position command selection)*. If the values set are incorrect, proper orientation control will not be performed.
- When *Pr. 11 DC injection brake operation time* = "8888" (DC injection brake external selection), DC injection brake does not operate if the X13 signal is not turned on. Note that the DC injection brake is applied under orientation control regardless of the X13 signal status.
- When orientation control is exercised, PID control is invalid.

WWW.BSNEW.IR

● Servo torque selection (*Pr. 358*)

Valid only under V/F control and advanced magnetic flux vector control.

Function \ *Pr. 358* Setting	0	1	2	3	4	5	6	7	8	9	10	11	12	13	Remarks
1) Servo torque function selection until output of the orientation completion signal (ORA)	×	○	○	○	○	×	○	×	○	×	○	×	×	○	○: With servo torque function ×: Without servo torque function
2) Retry function selection	×	×	×	×	×	×	×	○	×	×	×	○	×	×	○: With retry function ×: Without retry function
3) Output frequency is compensated when the motor stops outside the in-position zone	×	×	○	○	×	○	○	×	×	×	×	×	○	○	○: With frequency compensation ×: Without frequency compensation
4) DC injection brake and servo torque selection when the position pulse comes off the in-position zone after output of the orientation completion signal (ORA)	○	×	×	×	×	○	○	○	○	○	○	○	○	○	○: With DC injection brake ×: With servo torque
5) End switch selection of the DC injection brake and orientation completion signal (ORA)	○	○	○	×	×	○	○	○	○	×	×	×	×	×	○: When the start signal (STF, STR) or orientation command is turned off ×: When the orientation command is turned off
6) Completion signal off selection when the position pulse comes off the in-position zone after output of the orientation completion signal (ORA)	○	○	○	○	○	×	×	×	×	×	×	×	×	×	○: Turnes off the completion signal when the motor stops outside of the in-position zone ×: Completion signal remains on even if the position pulse comes off the completion zone (orientation fault singal (ORM) is not output)

REMARKS

- When the orientation command is off with the start signal on, the speed accelerates to the command speed.
- When the motor shaft stops outside of the set setting range of stop position, the motor shaft is returned to the stop position by servo torque function (if enough torque is generated).

1) Servo torque function selection until output of the orientation completion signal

Whether servo torque is available or not is selected using *Pr. 358 Servo torque selection*. Servo torque is not generated if the current position pulse is in between the orientation stop position and DC injection brake start position. Although, the shaft is retained by the DC injection brake, servo torque is generated to return the shaft within the width if the shaft moves out of the width by external force, etc. Once the orientation completion signal (ORA) is output, the motor runs according to the setting made in 4).

2) Retry function selection

Select retry function using *Pr. 358 Servo torque selection* . Note that servo torque function can not be used together. When the motor shaft is not stopped within the in-position zone when the motor stop is checked, orientation operation is performed again by retry function.

With this retry function, three orientations including the first one are performed. More than three times retry operations are not made. (The orientation fault signal (ORM) is not output during retry operation)

3) Frequency compensation function when the motor stops outside the orinetation in-position zone

When the motor stops before entering the in-position zone due to external force, etc., output frequency is increased to move the shaft to the orientation stop position. The output frequency is gradually increased to the creep speed of *Pr. 352 Creep speed* .

Note that retry function can not be used together.

4) DC injection brake and servo torque selection when the position pulse comes off the in-position zone after output of the orientation completion signal (ORA)

If the position pulse comes off the orientation in-position width, you can select a setting either fixing a shaft with the DC injection brake or returning the motor to the orientation stop position with servo torque.

5) Orientation operation end switch operation selection between DC injection brake or servo torque

When ending the orientation operation, turn off the start signal (STF or STR), then turn off the orientation command (X22). At this time, you can select when to turn off the orientation completion signal (ORA) from between at turning off of the start signal or turning off of the orientation command signal.

6) Selection of completion signal off or on when the motor stops outside of the in-position zone after output of the orientation completion signal (ORA)

You can select the mode to turn off the completion signal or keep the completion signal on (orientation fault signal (ORM) is not output) when the motor stops outside of the in-position zone.

WWW.BSNEW.IR

● **Position loop gain (*Pr. 362*)**

When servo torque function is selected using *Pr. 358 Servo torque selection* , output frequency for generating servo torque increases to the creep speed of *Pr. 352 Creep speed* gradually according to the slope set in *Pr. 362 Orientation position loop gain* .
Although the operation becomes faster when the value is increased, a machine may hunt, etc.


(7) Orientation operation explanation (during vector control)

● **Setting the rotation direction (*Pr. 393 Orientation selection*)**

Pr. 393 Setting	Rotation Direction	Remarks
0 (initial value)	Pre-orientation	Orientation is executed from the current rotation direction.
1	Forward rotation orientation	Orientation is executed from the forward rotation direction. (If the motor is running in reverse, orientation is executed from the forward rotation direction after deceleration.)
2	Reverse rotation orientation	Orientation is executed from the reverse rotation direction. (If the motor is running in forward, orientation is executed from the reverse rotation direction after deceleration.)

1) Orientation from the current rotation direction

- When the orientation command (X22) is input, the motor speed will decelerate from the runnig speed to *Pr. 351 Orientation speed*.
  At the same time, the orientation stop position command will be read in.
  (The stop position command is determined by the setting of *Pr. 350 and Pr. 360*. Refer to *the right chart*.)
- When the orientation switchover speed is reached, the encoder Z phase pulse will be confirmed, and the mode will change from speed control to position control (*Pr. 362 Orientation position loop gain*).
- The distance to the orientation stop position is calculated at switching of the control, and the motor decelerates and stops with a set deceleration pattern *(Pr. 399)* and the orientation (servo lock) state will be entered.
- When entered in the *Pr. 357 Orientation in-position zone*, the orientation completion signal (ORA) will be output.
- The zero point position (origin) can be moved using *Pr. 361 Position shift* .




⚠WARNING

⚠ If the orientation command (X22) is turned off while the start signal is input, the motor will accelerate toward the speed of the current speed command. Thus, to stop, turn the forward rotation (reverse rotation) signal off.

2) Orientation from the forward rotation direction


- This method is used to improve the stopping precision and maintain the mechanical precision when the backlash is large.
- If the motor is running in the forward rotation direction, it will make an orientation stop with the same method as "orientation from the current rotation direction".
- If the motor is running in reverse, it will decelerate, the rotation direction will be changed to forward run, and then orientation stop will be executed.



WWW.BSNEW.IR

3) Orientation from the reverse rotation direction

- If the motor is running in the reverse rotation direction, it will make an orientation stop with the same method as "orientation from the current rotation direction".
- If the motor is running in forward, it will decelerate, the rotation direction will be changed to reverse run, and then orientation stop will be executed.



CAUTION

- The encoder should be coupled with the motor shaft oriented with a speed ratio of 1 to 1 without any mechanical looseness.
- To ensure correct positioning, the encoder must be set in the proper rotation direction and the A and B phases connected correctly.
- Orientation may not be completed if the pulse signals are not received from the encoder during orientation due to a break in the cable or the like.
- To terminate orientation, the start signal (STF or STR) must be first switched off and the orientation signal (X22) must be switched off. As soon as this orientation signal is switched off, orientation control ends.
- When performing orientation control, make proper setting of *Pr. 350 Stop position command selection* and *Pr. 360 16 bit data selection*. If the values set are incorrect, proper orientation control will not be performed.
- When orientation control is exercised, PID control is invalid.

REMARKS

If "E.ECT" (no encoder signal) is displayed causing the inverter to trip when the orient signal (X22) is ON, check for a break in the cable of the Z phase of the encoder.

● Servo rigidity adjustment *(Pr. 362, Pr. 396 to Pr. 398)*

•To increase the servo rigidity *1 during orientation stop using *Pr. 396 or Pr. 397* , adjust with the following procedures.

1) Increase the *Pr. 362 Orientation position loop gain* value to the extent that rocking *2 does not occur during orientation stop.
2) Increase *Pr. 396 and Pr. 397* at the same rate.
   Generally adjust *Pr. 396* in the range from 10 to 100, and *Pr. 397* from 0.1 to 1.0s.
   (Note that these do not need to be set to the same rate.)

<Example>
When the *Pr. 396* value is multiplied by 1.2, divide the *Pr. 397* value by 1.2.
If vibration occurs during orientation stop, the scale cannot be raised any higher.

3) *Pr. 398* is the lag/advance compensation gain.
   The limit cycle *3 can be prevented by increasing the value, and the running can be stopped stably. However, the torque in regard to the position deviation will drop, and the motor will stop with deviation.

POINT

Application of lag/advance control and PI control
PI control can be applied by setting *Pr. 398* to 0. Normally, the lag/advance control is selected. Note that PI control shoud be used when using a machine with a high spindle stationary friction torque and requires a stopping position precision.

*1 Servo rigidity: This is the response when a position control loop is configured.
When the servo rigidity is raised, the holding force will increase, the running will stabilize, but vibration will occur easily.
When the servo rigidity is lowered, the holding force will drop, and the setting time will increase.
*2 Rocking: Movement in which return occurs if the stopping position is exceeded.
*3 Limit cycle: This is a phenomenon that generates ± continuous vibration centering on the target position.

WWW.BSNEW.IR

● *Pr. 399 Orientation deceleration ratio* (initial value is 20)

• Make adjustments as shown below according to the orientation status.
(Refer to the *Pr. 396 and Pr. 397* details also.)
Generally adjust *Pr. 362* in the range from 5 to 20, and *Pr. 399* from 5 to 50.

Phenomenon	Adjustment Procedure			
	Pr. 396	*Pr. 397*	*Pr. 362*	*Pr. 399*
Rocking occurs during stopping	3) ↗	3) ↗	2) ↘	1) ↘
The orientation time is long	→	→	2) ↗	1) ↗
Hunting occurs when stopping	2) ↘	2) ↗	1) ↘	→
The servo rigidity during stopping is low	1) ↗	1) ↘	2) ↗	→

REMARKS


1. ↗:Increase the parameter setting value.
→:Do not change the parameter setting value.
↘:Decrease the parameter setting value.
2. The numbers 1) , 2) and 3) in the table show the order of priority for changing the parameters setting value.

CAUTION

Or, if the motor does forward/reverse reciprocation operation ↻, the parameter setting value for the orientation detector installation direction may be incorrect. Review *Pr. 393 Orientation selection (refer to page 218) and Pr. 359 Encoder rotation direction (refer to page 217)*.

● *Pr. 351 Orientation speed* (initial value: 2Hz)

• Set the speed when switching beween the speed control mode and the position control mode is performed under orientation operation.
Decreasing the set speed enables stable orientation stop. Note that the orientation time will increase.



REMARKS

When "19" is set in *Pr. 52 DU/PU main display data selection* , position pulse monitor is displayed instead of PU output voltage monitor.

WWW.BSNEW.IR

4.15 Function assignment of external terminal and control

Purpose	Parameter that must be Set		Refer to Page
Assign function to input terminal	**Input terminal function selection**	**Pr. 178 to Pr. 189**	228
Set MRS signal (output shutoff) to normally closed contact specification	**MRS input selection**	**Pr. 17**	231
Make the second (third) function valid only during constant speed operation	**RT reflection time selection**	**Pr. 155**	232
Assign start signal and forward/ reverse command to other signals	**Start signal (STF/STR) operation selection**	**Pr. 250**	233
Assign function to output terminal	**Output terminal function assignment**	**Pr. 190 to Pr. 196**	236
Detect output frequency	**Up-to-frequency sensitivity Output frequency detection Low speed detection**	**Pr. 41 to Pr. 43, Pr. 50, Pr. 116, Pr. 865**	243
Detect output current	**Output current detection Zero current detection**	**Pr. 150 to Pr. 153, Pr. 166, Pr. 167**	245
Remote output function	**Remote output**	**Pr. 495 to Pr. 497**	247
Detect output torque	**Output torque detection**	**Pr. 864**	246

4.15.1 Input terminal function selection (Pr. 178 to Pr. 189)

Use these parameters to select/change the input terminal functions.

Parameter Number	Name	Initial Value	Initial Signal	Setting Range
178	**STF terminal function selection**	60	STF (forward rotation command)	0 to 20, 22 to 28, 42 to 44, 50, 60, 62, 64 to 71, 74, 9999
179	**STR terminal function selection**	61	STR (reverse rotation command)	0 to 20, 22 to 28, 42 to 44, 50, 61, 62, 64 to 71, 74, 9999
180	**RL terminal function selection**	0	RL (low-speed operation command)	0 to 20, 22 to 28, 42 to 44, 50, 62, 64 to 71, 74, 9999
181	**RM terminal function selection**	1	RM (middle-speed operation command)	
182	**RH terminal function selection**	2	RH (high speed operation command)	
183	**RT terminal function selection**	3	RT (second function selection)	
184	**AU terminal function selection**	4	AU (terminal 4 input selection)	0 to 20, 22 to 28, 42 to 44, 50, 62 to 71, 74, 9999
185	**AM terminal function selection**	5	JOG (Jog operation selection)	0 to 20, 22 to 28, 42 to 44, 50, 62, 64 to 71, 74, 9999
186	**CS terminal function selection**	6	CS (selection of automatic restart after instantaneous power failure)	
187	**MRS terminal function selection**	24	MRS (output stop)	
188	**STOP terminal function selection**	25	STOP (start self-holding selection)	
189	**RES terminal function selection**	62	RES (inverter reset)	

(1) Input terminal function assignment

- Use *Pr. 178 to Pr. 189* to set the functions of the input terminals.
- Refer to the following table and set the parameters:

Setting	Signal Name	Function		Related Parameters	Refer to Page
0	RL	*Pr. 59* = 0 (initial value)	Low-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	166
		Pr. 59 = 1, 2 *1	Remote setting (setting clear)	Pr. 59	170
		Pr. 270 = 1, 3 *2	Stop-on-contact selection 0	Pr. 270, Pr. 275, Pr. 276	211
1	RM	*Pr. 59* = 0 (initial value)	Middle-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	166
		Pr. 59 = 1, 2 *1	Remote setting (deceleration)	Pr. 59	170
2	RH	*Pr. 59* = 0 (initial value)	High-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	166
		Pr. 59 = 1, 2 *1	Remote setting (acceleration)	Pr. 59	170

WWW.BSNEW.IR

Setting	Signal Name	Function	Related Parameters	Refer to Page
3	RT	Second function selection	Pr. 44 to Pr. 51, Pr. 450 to Pr. 463, Pr. 569, Pr. 832, Pr. 836, etc.	232
		Pr. 270 = 1, 3 *2 | Stop-on-contact selection 1	Pr. 270, Pr. 275, Pr. 276	211
4	AU	Terminal 4 input selection	Pr. 267	282
5	JOG	Jog operation selection	Pr. 15, Pr. 16	168
6	CS	Selection of automatic restart after instantaneous power failure, flying start	Pr. 57, Pr. 58, Pr.162 to Pr.165, Pr. 299, Pr. 611	261
		Commercial power supply-inverter switchover function	Pr. 57, Pr. 58, Pr.135 to Pr.139, Pr. 159	363
7	OH	External thermal relay input *3	Pr. 9	181
8	REX	15 speed selection (combination with three speeds RL, RM, RH)	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr.232 to Pr.239	166
9	X9	Third function selection	Pr. 110 to Pr. 116	232
10	X10	Inverter operation enable signal (FR-HC, MT-HC, FR-CV connection)	Pr. 30, Pr. 70	204
11	X11	FR-HC or MT-HC connection, instantaneous power failure detection	Pr. 30, Pr. 70	204
12	X12	PU operation external interlock	Pr. 79	308
13	X13	External DC injection brake operation start	Pr. 10 to Pr. 12	200
14	X14	PID control valid terminal	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577	355
15	BRI	Brake opening completion signal	Pr. 278 to Pr. 285	214
16	X16	PU-external operation switchover (turning on X16 selects external operation)	Pr. 79, Pr. 340	314
17	X17	Load pattern selection forward/reverse rotation boost (turning on X17 changes the output characteristics to constant torque load)	Pr. 14	161
18	X18	turning on X18 selects V/F control	Pr. 80, Pr. 81, Pr. 800	92, 145
19	X19	Load torque high-speed frequency	Pr. 270 to Pr. 274	368
20	X20	S-shaped acceleration/deceleration C switching terminal	Pr. 380 to Pr. 383	176
22	X22	Orientation command *4, *6	Pr. 350 to Pr. 369	217
23	LX	Pre-excitation/servo on *5	Pr. 850	200
24	MRS	Output stop	Pr. 17	231
		Commercial power supply-inverter switchover function	Pr. 57, Pr. 58, Pr.135 to Pr.139, Pr. 159	363
25	STOP	Start self-holding selection	—	233
26	MC	Control mode changing	Pr. 800	92
27	TL	Torque limit selection	Pr. 815	99
28	X28	Start-time tuning start external input	Pr. 95	197
42	X42	Torque bias selection 1 *6	Pr. 840 to Pr. 845	113
43	X43	Torque bias selection 2 *6	Pr. 840 to Pr. 845	113
44	X44	P/PI control switchover (turning on X44 selects P control)	Pr. 820, Pr. 821, Pr. 830, Pr. 831	104
50	SQ	Sequence start	Pr. 414 to Pr. 417, Pr. 498, Pr. 506 to Pr. 515	353
60	STF	Forward rotation command (assigned to STF terminal *(Pr. 178)* only)	—	233
61	STR	Reverse rotation command (assigned to STR terminal *(Pr. 179)* only)	—	233
62	RES	Inverter reset	—	—
63	PTC	PTC thermistor input (assigned to AU terminal *(Pr. 184)* only)	Pr. 9	181
64	X64	PID forward/reverse action switchover	Pr. 127 to Pr. 134, Pr. 5	355
65	X65	PU-NET operation switchover (turning on X65 selects PU operation)	Pr. 79, Pr. 340	315
66	X66	External-NET operation switchover (turning on X66 selects NET operation)	Pr. 79, Pr. 340	315
67	X67	Command source switchover (turning on X67 makes *Pr. 338* and *Pr. 339* commands valid)	Pr. 338, Pr. 339	317
68	NP	Conditional position pulse train sign *6	Pr. 291, Pr. 419 to Pr. 430, Pr. 464	134
69	CLR	Conditional position droop pulse clear *6	Pr. 291, Pr. 419 to Pr. 430, Pr. 464	134
70	X70	DC feeding operation permission	Pr. 30, Pr. 70	204
71	X71	DC feeding cancel	Pr. 30, Pr. 70	204
74	X74	Magnetic flux decay output shutoff signal	—	235
9999	—	No function	—	—

*1 When *Pr. 59 Remote function selection* = "1 or 2", the functions of the RL, RM and RH signals change as listed above.
*2 When *Pr. 270 Stop-on contact/load torque high-speed frequency control selection* = "1 or 3", the functions of the RL and RM signals change as listed above.
*3 The OH signal turns on when the relay contact "opens".
*4 The FR-A7AX (16-bit digital input) is needed to externally input a stop position under orientation control.
*5 Servo ON is made valid during position control under vector control operation.
*6 Available only when used with the FR-A7AP (option).

WWW.BSNEW.IR

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.
- One function can be assigned to two or more terminals. In this case, the terminal inputs are ORed.
- The priorities of the speed commands are in order of jog, multi-speed setting (RH, RM, RL, REX) and PID (X14).
- When the X10 signal (FR-HC, MT-HC, FR-CV connection - inverter operation enable signal) is not set or when the PU operation external interlock (X12) signal is not assigned at the *Pr. 79 Operation mode selection* setting of "7", the MRS signal shares this function.
- Use common terminals to assign multi-speeds (speed 7) and remote setting. They cannot be set individually. (Common terminals are used since these functions are designed for speed setting and need not be set at the same time.)
- When V/F switching (X18) signal and load pattern selection forward rotation reverse rotation boost (X17) signal are not assigned, the RT signal shares this function. (*Pr. 81 Number of motor poles* = "12, 14, 16, 18, 20") In this case, V/F control is controlled by the second function.

(2) Response time of each signal

- The response time of the X10 signal is within 2ms. However, when the X10 signal is not assigned at the *Pr. 30 Regenerative function selection* setting of "2" (FR-HC, MT-HC/FR-CV connection), the response time of the MRS signal is within 2ms.
  Pr. 17 MRS input selection is made invalid.


Pr. 30 Setting	MRS Assignment	X10 Assignment	Response Time		*Pr. 17*
			MRS	X10	
2	○	×	Within 2ms	—	Invalid
	×	○	—	Within 2ms	—
	○	○	Within 20ms	Within 2ms	Valid
Other than 2	○	×	Within 20ms	—	Valid
	×	○	—	—	—
	○	○	Within 20ms	—	Valid

WWW.BSNEW.IR

4.15.2 Inverter output shutoff signal (MRS signal, Pr. 17)

The inverter output can be shut off from the MRS signal. The logic of the MRS signal can also be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
17	MRS input selection	0	0	Normally open input
			2	Normally closed input (NC contact input specifications)
			4	External terminal: Normally closed input (NC contact input specifications) Communication: Normally open input



(1) Output shutoff signal (MRS signal)

- Turning on the output shutoff signal (MRS) during inverter running shuts off the output immediately.
- Terminal MRS may be used as described below.

(a) When mechanical brake (e.g. electromagnetic brake) is used to stop motor
The inverter output is shut off when the mechanical brake operates.

(b) To provide interlock to disable operation by the inverter
With the MRS signal on, the inverter cannot be operated if the start signal is entered into the inverter.

(c) Coast the motor to a stop
When the start signal is turned off, the inverter decelerates the motor to a stop in the preset deceleration time, but when the MRS signal is turned on, the motor coasts to a stop

(2) MRS signal logic inversion (*Pr. 17* = "2")

- When *Pr. 17* is set to "2", the MRS signal (output stop) can be changed to the normally closed (NC contact) input specification. When the MRS signal turns on (opens), the inverter shuts off the output.

(3) Assign a different action for each MRS signal input from communication and external terminal (*Pr. 17* = "4")

- When *Pr. 17* is set to "4", the MRS signal from external terminal (output stop) can be changed to the normally closed (NC contact) input, and the MRS signal from communication can be changed to the normally open (NO contact) input.
  This function is useful to perform operation by communication with MRS signal from external terminal remained on. MRS operation from PLC function is changed to NO contact as same as the communication.

External MRS	Communication MRS	*Pr. 17* Setting		
		0	2	4
OFF	OFF	Operation enabled	Output shutoff	Output shutoff
OFF	ON	Output shutoff	Output shutoff	Output shutoff
ON	OFF	Output shutoff	Output shutoff	Operation enabled
ON	ON	Output shutoff	Operation enabled	Output shutoff

REMARKS

- The MRS signal is assigned to the terminal MRS in the initial setting. By setting "24" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, the MRS signal can be assigned to the other terminal.
- The MRS signal can shut off the output, independently of the PU, external or network operation mode.

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 178 to Pr. 189 (Input terminal function selection) ☞ *Refer to page 228*

WWW.BSNEW.IR


4.15.3 Condition selection of function validity by the second function selection signal (RT) and third function selection signal (X9) (RT signal, X9 signal, Pr. 155)

You can select the second (third) function using the RT(X9) signal.
You can also set the condition (reflection conditon) where the second function and third function become valid.


Parameter Number	Name	Initial Value	Setting Range	Description
155	RT signal function validity condition selection	0	0	Second (third) function is immediately made valid with on of the RT(X9) signal.
			10	Second (third) function is valid only during the RT (X9) signal is on and constant speed operation. (invalid during acceleration/deceleration)

- When the RT signal turns on, the second function becomes valid.
- When the X9 signal turns on, the third function becomes valid.
  For the X9 signal, set "9" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.
- The second (third) function has the following applications.
  (a)Switching between normal use and emergency use
  (b)Switching between heavy load and light load
  (c)Changing of acceleration/deceleration time by broken line acceleration/deceleration
  (d)Switching of characteristic between main motor and sub motor

Second function connection diagram



Second acceleration/deceleration time example



- Functions that can be set as second and third functions

Function	First Function Parameter Number	Second Function Parameter Number	Third Function Parameter Number	Refer to Page
Torque boost	Pr. 0	Pr. 46	Pr. 112	143
Base frequency	Pr. 3	Pr. 47	Pr. 113	159
Acceleration time	Pr. 7	Pr. 44	Pr. 110	173
Deceleration time	Pr. 8	Pr. 44, Pr. 45	Pr. 110, Pr. 111	173
Electronic thermal relay function	Pr. 9	Pr. 51	—	181
Stall prevention	Pr. 22	Pr. 48, Pr. 49	Pr. 114, Pr. 115	150
Applied motor	Pr. 71	Pr. 450	—	185
Motor constant	Pr. 80 to Pr. 84, Pr. 89, Pr. 90 to Pr. 94, Pr. 96, Pr. 859	Pr. 453 to Pr. 457, Pr. 569, Pr. 458 to Pr. 462, Pr. 463, Pr. 860	—	187
Online auto tuning selection	Pr. 95	Pr. 574	—	197
Motor control method	Pr. 800	Pr. 451	—	92
Speed control gain	Pr. 820, Pr. 821	Pr. 830, Pr. 831	—	104
Analog input filter	Pr. 822, Pr. 826	Pr. 832, Pr. 836	—	287
Speed detection filter	Pr. 823	Pr. 833	—	141
Torque control gain	Pr. 824, Pr. 825	Pr. 834, Pr. 835	—	127
Torque detection filter	Pr. 827	Pr. 837	—	141

REMARKS

- The RT signal is assigned to the RT terminal in the initial setting. By setting "3" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, the RT signal can be assigned to the other terminal.

CAUTION

- When the RT (X9) signal is on, the other functions such as the second (third) are also selected.
- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 178 to Pr.189 (input terminal function selection) ☞ *Refer to page 228*

WWW.BSNEW.IR


4.15.4 Start signal operation selection (STF, STR, STOP signal, Pr. 250)

You can select the operation of the start signal (STF/STR).
Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns off.
Used to stop the motor with a mechanical brake, etc. together with switching off of the start signal.
(Refer to *page 210* for stop selection)


Parameter Number	Name	Initial Value	Setting Range	Description	
				Start signal (STF/STR)	Stop operation *(Refer to page 210)*
250	Stop selection	9999	0 to 100s	STF signal: Forward rotation start STR signal: Reverse rotation start	The motor is coasted to a stop when the preset time elapses after the start signal is turned off. When the setting is any of 1000s to 1100s, the inverter coasts to a stop in (*Pr. 250* - 1000)s.
			1000s to 1100s	STF signal: Start signal STR signal: Forward/reverse rotation signal	
			9999	STF signal: Forward rotation start STR signal: Reverse rotation start	When the start signal is turned off, the motor decelerates to stop.
			8888	STF signal: Start signal STR signal: Forward/reverse rotation signal	

(1) 2-wire type (STF, STR signal)

- A two-wire type connection is shown below.
- In the initial setting, the forward/reverse rotation signals (STF/STR) are used as start and stop signals. Turn on either of the forward and reverse rotation signals to start the motor in the corresponding direction. If both are turned off (or on) during operation, the inverter decelerates to a stop.
- The speed setting signal may either be given by entering 0 to 10VDC across the speed setting input terminal 2-5, by setting the required values in *Pr. 4 to Pr. 6 Multi-speed setting (high, middle, low speeds)*, etc. (For multi-speed operation, refer to *page 166*)
- When *Pr. 250* is set to any of "1000 to 1100, 8888", the STF signal becomes a start command and the STR signal a forward/reverse command.



2-wire connection example (*Pr. 250* = "9999")



2-wire connection example (*Pr. 250* = "8888")


REMARKS

- When *Pr. 250* is set to any of "0 to 100, 1000 to 1100", the motor coasts to a stop if the start command is turned off. *(Refer to page 210)*
- The STF and STR signals are assigned to the STF and STR terminals in the initial setting. The STF signal can be assigned to *Pr. 178 STF terminal function selection* and the STR signal to *Pr. 179 STR terminal function selection* only.


WWW.BSNEW.IR

(2) 3-wire type (STF, STR, STOP signal)

- A three-wire type connection is shown below.
- The start self-holding selection becomes valid when the STOP signal is turned on. In this case, the forward/reverse rotation signal functions only as a start signal.
- If the start signal (STF or STR) is turned on and then off, the start signal is held and makes a start. When changing the direction of rotation, turn STR (STF) on once and then off.
- To stop the inverter, turning off the STOP signal once decelerates it to a stop.



Three-Wire Type Connection Example (*Pr. 250* = "9999")



Three-Wire Type Connection Example (*Pr. 250* = "8888")

REMARKS

- The STOP signal is assigned to the terminal STOP in the initial setting. By setting "25" in *Pr. 178 to Pr. 189*, the STOP signal can also be assigned to the other terminal.
- When the JOG signal is turned on to enable jog operation, the STOP signal becomes invalid.
- If the MRS signal is turned on to stop the output, the self-holding function is not canceled.

(3) Start signal selection

STF	STR	*Pr. 250* Setting Inverter Status	
		0 to 100s, 9999	1000s to 1100s, 8888
OFF	OFF	Stop	Stop
OFF	ON	Reverse rotation	
ON	OFF	Forward rotation	Forward rotation
ON	ON	Stop	Reverse rotation

♦ Parameters referred to ♦

Pr. 4 to Pr. 6 (Multi-speed setting) ☞ *Refer to page 166*
Pr. 178 to Pr. 189 (Input terminal function selection) ☞ *Refer to page 228*


WWW.BSNEW.IR

4.15.5 Magnetic flux decay output shutoff signal (X74 signal)

Performing frequent start/stop (inching operation) with mechanical brake using output shutoff signal (MRS) during real sensorless vector control may cause an inverter alarm (electronic thermal realy function alarm: E.THT, etc) due to residual magnetic flux and an error in monitor output (running speed, motor torque, load meter, torque command, torque current command, motor output).
In such a case, use magnetic flux decay output shutoff signal (X74) as output shutoff signal.
Turning X74 signal on shuts off output after decaying motor residual magnetic flux.

- For the X74 signal, set "74" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.
- Operate a mechanical brake after turning X74 signal on.
- When the MC is provided on the inverter output side, turn X74 signal on and open the MC after magnetic flux decay operation time (refer to below) has elapsed.

Inverter output voltage shutoff timing



* Maximum time of magnetic flux decay operation

Motor Capacity (*Pr. 80* setting)	2.2kW or less	3.7kW to 11kW	15kW to 30kW	37kW to 55kW	75kW or more
Magnetic flux decay processing time	250ms	500ms	800ms	900ms	1100ms

REMARKS

- When performing operation other than real sensorless vector control, turning X74 signal on immediately shuts off inverter output.
- During an automatic restart after instantaneous power failure or start-time online auto tuning under real sensorless vector control, turning X74 signal on immediately shuts off inverter output.
- When some other factor affecting output shutoff (inverter alarm, MRS signal on, etc.) occurs during magnetic flux decay operation, magnetic flux decay operation is stopped to immideately shut off output.
- X74 signal can be used with the inverter assembled in and after July 2006. Check the serial number for date of manufacture. (Refer to *page 471* .)

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.
- Different from MRS signal, voltage is output during magnetic flux decay processing even if X74 signal turns on.

WWW.BSNEW.IR

4.15.6 Output terminal function selection (Pr. 190 to Pr. 196)

You can change the functions of the open collector output terminal and relay output terminal.

Parameter Number	Name		Initial Value	Initial Signal	Setting Range
190	RUN terminal function selection	Open collector output terminal	0	RUN (inverter running)	0 to 8, 10 to 20, 25 to 28, 30 to 36, 39, 41 to 47, 64, 70, 84, 85, 90 to 99, 100 to 108, 110 to 116, 120, 125 to 128, 130 to 136, 139, 141 to 147, 164, 170, 184, 185, 190 to 199, 9999
191	SU terminal function selection		1	SU (up to frequency)	
192	IPF terminal function selection		2	IPF (instantaneous power failure, undervoltage)	
193	OL terminal function selection		3	OL (overload alarm)	
194	FU terminal function selection		4	FU (output frequency detection)	
195	ABC1 terminal function selection	Relay output terminal	99	ALM (alarm output)	0 to 8, 10 to 20, 25 to 28, 30 to 36, 39, 41 to 47, 64, 70, 84, 85, 90, 91, 94 to 99, 100 to 108, 110 to 116, 120, 125 to 128, 130 to 136, 139, 141 to 147, 164, 170, 184, 185, 190, 191, 194 to 199, 9999
196	ABC2 terminal function selection		9999	No function	

(1) Output signal list

· You can set the functions of the output terminals.
· Refer to the following table and set the parameters: (0 to 99: Positive logic, 100 to 199: Negative logic)

Setting		Signal Name	Function	Operation	Related Parameters	Refer to Page
Positive Logic	Negative Logic					
0	100	RUN	Inverter running	Output during operation when the inverter output frequency rises to or above *Pr. 13 Starting frequency*.	—	239
1	101	SU	Up to frequency *1	Output when the output frequency is reached to the set frequency. *3	Pr. 41	243
2	102	IPF	Instantaneous power failure/undervoltage	Output at occurrence of an instantaneous power failure or when undervoltage protection is activated.	Pr. 57	261
3	103	OL	Overload alarm	Output while stall prevention function is activated.	Pr. 22, Pr. 23, Pr. 66, Pr. 148, Pr. 149, Pr. 154	150
4	104	FU	Output frequency detection	Output when the output frequency reaches the frequency set in *Pr. 42* (*Pr. 43* for reverse rotation). *3	Pr. 42, Pr. 43	243
5	105	FU2	Second output frequency detection	Output when the output frequency reaches the frequency set in *Pr. 50*. *3	Pr. 50	243
6	106	FU3	Third output frequency detection	Output when the output frequency reaches the frequency set in *Pr. 116*. *3	Pr. 116	243
7	107	RBP	Regenerative brake prealarm	Output when 85% of the regenerative brake duty set in *Pr. 70* is reached.	Pr. 70	204
8	108	THP	Electronic thermal relay function prealarm	Output when the electronic thermal relay function cumulative value reaches 85%. (Electronic thermal relay function protection (E.THT/E.THM) activates, when the value reached 100%.)	Pr. 9	183
10	110	PU	PU operation mode	Output when the PU operation mode is selected.	Pr. 79	308
11	111	RY	Inverter operation ready	Output when the inverter power is turned on, then output after reset process is completed (when the inverter can be started by switching the start signal on or while it is running).	—	239
12	112	Y12	Output current detection	Output when the output current is higher than the *Pr. 150* setting for longer than the time set in *Pr. 151*.	Pr. 150, Pr. 151	245
13	113	Y13	Zero current detection	Output when the output power is lower than the *Pr. 152* setting for longer than the time set in *Pr. 153*.	Pr. 152, Pr. 153	245

WWW.BSNEW.IR

Setting		Signal Name	Function	Operation	Related Parameters	Refer to Page
Positive Logic	Negative Logic					
14	114	FDN	PID lower limit	Output when the feedback value falls below the lower limit of PID control.	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577	355
15	115	FUP	PID upper limit	Output when the feedback value rises above the upper limit of PID control		
16	116	RL	PID forward/reverse rotation output	Output when forward rotation is performed in PID control.		
17	—	MC1	Electronic bypass MC1	Used when the commercial power supply-inverter switchover function is used.	Pr. 135 to Pr. 139, Pr. 159	363
18	—	MC2	Electronic bypass MC2			
19	—	MC3	Electronic bypass MC3			
20	120	BOF	Brake opening request	Output to open the brake when the brake sequence function is selected.	Pr. 278 to Pr. 285, Pr. 292	214
25	125	FAN	Fan fault output	Output at the time of a fan fault.	Pr. 244	379
26	126	FIN	Heatsink overheat pre-alarm	Output when the heatsink temperature reaches about 85% of the heatsink overheat protection providing temperature.	—	406
27	127	ORA	Orientation in-position	When orientation is valid *4	Pr. 350 to Pr. 366, Pr. 369, Pr. 393, Pr. 396 to Pr. 399	217
28	128	ORM	Orientation error			
30	130	Y30	Forward rotation output	Output when the motor is running in forward direction. *4	—	241
31	131	Y31	Reverse rotation output	Output when the motor is running in reverse direction. *4		241
32	132	Y32	Regenerative status output	Output in the regenerative status under vector control operation. *4		241
33	133	RY2	Operation ready 2	Output during pre-exitation or operation under real sensorless vector control.	—	239
34	134	LS	Low speed output	Output when the output frequency reduces below the *Pr. 865* setting.	Pr. 865	243
35	135	TU	Torque detection	Output when the motor torque rises above the *Pr. 864* value.	Pr. 864	246
36	136	Y36	In-position	Output when the number of droop pulses has fallen below the setting value.	Pr. 426	137
39	139	Y39	Start time tuning completion	Output on completion of start-time tuning.	Pr. 95, Pr. 574	197
41	141	FB	Speed detection	Output when the actual motor speed (estimated actual speed value) reaches the *Pr. 42* (*Pr. 50*, *Pr.116*) setting.	Pr. 42, Pr. 50, Pr. 116	243
42	142	FB2	Second speed detection			
43	143	FB3	Third speed detection			
44	144	RUN2	Inverter running 2	· Output during forward rotation or the reverse rotation signal is on. · Output at deceleration even during forward rotation or the reverse rotation signal is off. (Does not output during pre-excitation LX is on.) · Output during the orientation command signal (X22) is on. · Switched on when the servo is on (LX-ON) under position control. (Switched off when tne servo is off (LX-OFF))	—	239
45	145	RUN3	Inverter running and start command is on	Output when the inverter is running and start command is on.	—	239
46	146	Y46	During deceleration at occurrence of power failure (retained until release)	Output when the power failure-time deceleration function is executed.	Pr. 261 to Pr. 266	265
47	147	PID	During PID control activated	Output during PID control.	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577	355
64	164	Y64	During retry	Output during retry processing.	Pr. 65 to Pr. 69	268
70	170	SLEEP	PID output interruption	Output when the PID output interruption function is executed.	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577	355
84	184	RDY	Position control preparation ready	Output when the servo is on (LX-ON) and ready to operate. *4	Pr. 419, Pr. 428 to Pr. 430	134
85	185	Y85	DC feeding	Output during power failure or under voltage of AC power.	Pr. 30, Pr. 70	204

WWW.BSNEW.IR

Setting		Signal Name	Function	Operation	Related Parameters	Refer to Page
Positive Logic	Negative Logic					
90	190	Y90	Life alarm	Output when any of the control circuit capacitor, main circuit capacitor and inrush current limit circuit or the cooling fan approaches the end of its service life.	Pr. 255 to Pr. 259	380
91	191	Y91	Alarm output 3 (power-off signal)	Output when an error occurs due to the circuit failure or connection alarm of the inverter.	—	242
92	192	Y92	Energy saving average value updated timing	Turned on and off alternately every time the power saving average value is updated when the power saving monitor is used. Cannot be set to *Pr. 195* and *Pr. 196* (relay output terminal).	Pr. 52, Pr. 54, Pr. 158, Pr. 891 to Pr. 899	274
93	193	Y93	Current average value monitor signal	Average current value and maintenance timer value are output as pulses. Cannot be set to *Pr. 195* and *Pr. 196* (relay output terminal).	Pr. 555 to Pr. 557	384
94	194	ALM2	Alarm output 2	Output when the inverter protective function is activated to stop the output (major fault). Continue outputting the signal during inverter reset and stop outputting after reset is cancelled. *2	—	242
95	195	Y95	Maintenance timer signal	Output when *Pr. 503* rises to or above the *Pr. 504* setting.	Pr. 503, Pr. 504	383
96	196	REM	Remote output	Output to the terminal when a value is set to the parameter.	Pr. 495 to Pr. 497	247
97	197	ER	Minor fault output 2	When *Pr. 875* = "0" (initial value), the signal is output when the inverter protective function is activated to stop the output (major fault). When *Pr. 875* = "1", the signal is output when the inverter protective function is activated at occurrence of OHT/THM/PTC error and deceleration is started. Output when other protective functions are activated to stop output.	Pr. 875	272
98	198	LF	Minor fault output	Output when a minor fault (fan failure or communication error warning) occurs.	Pr. 121, Pr. 244	327, 379
99	199	ALM	Alarm output	Output when the inverter protective function is activated to stop the output (major fault). The signal output is stopped when a reset turns on.	—	242
9999		—	No function	—	—	—

*1 Note that when the frequency setting is varied using an analog signal or of the operation panel (FR-DU07), the output of the SU (up to frequency) signal may alternate on and off depending on that varying speed and the timing of the varying speed due to acceleration/deceleration time setting. (The output will not alternate on and off when the acceleration/deceleration time setting is "0s".)

*2 When a power supply reset is performed, the alarm output 2 signal (ALM2) turns off as soon as the power supply switches off.

*3 Up to frequency SU, frequency detection FU, FU2, FU3 under encoder feed back control or vector control (option FR-A7AP is mounted) signals are as below.
SU, FU: Output when the actual speed (frequency) by the encoder feedback signal exceeds detected specification frequency.
FU2, FU3: Output when the inverter output frequency exceeds detected specification frequency.

*4 This function is valid when the FR-A7AP (option) is mounted.

REMARKS

- The same function may be set to more than one terminal.
- When the function is executed, the terminal conducts at the setting of any of "0" to "99", and does not conduct at the setting of any of "100" to "199".
- The signal will not function if a value other than the above is set to any of *Pr. 190 to Pr. 196*.
- When *Pr. 76 Alarm code output selection* = "1", the output signals of the terminals SU, IPF, OL and FU are switched as set in *Pr. 76*. (When an inverter alarm occurs, the signal output is switched to the alarm output.)
- The output assignment of the terminal RUN and alarm output relay are as set above regardless of *Pr. 76*.


CAUTION

- When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions may be affected. Please make setting after confirming the function of each terminal.
- Do not assign signals which repeat frequent ON/OFF to A1, B1, C1, A2, B2, C2. Otherwise, the life of the relay contact decreases.

WWW.BSNEW.IR

(2) Inverter operation ready signal (RY, RY2 signal) and inverter running signal (RUN, RUN2, RUN3 signal)

Under V/F control, advanced magnetic flux vector control




- When the inverter is ready to operate, the output of the operation ready signal (RY) is on. (It is also on during inverter running.)
- When the output frequency of the inverter rises to or above *Pr. 13 Starting frequency*, the output of the inverter running signals (RUN, RUN2) is turned on. During an inverter stop or DC injection brake operation, the output is off.
- For the RUN3 signal, output is on while the inverter running and the start signal is on.
  (For the RUN3 signal, output is on if the starting command is on even when the inverter protective function is activated or the MRS signal is on.)
  The output is on during DC injection brake operation and off during an inverter stop.

Inverter Status / Output Signal	Start Signal is OFF (during stop)	Start Signal is ON (during stop)	Start Signal is ON (during running)	Under DC Injection Brake	At Alarm Occurrence or MRS Signal is on (output shutoff)		Automatic Restart after Instantaneous Power Failure		
							Coasting		Restarting
					Start signal is ON	Start signal is OFF	Start signal is ON	Start signal is OFF	
RY	ON	ON	ON	ON	OFF		ON *1		ON
RY2	OFF	OFF	OFF	OFF	OFF		OFF		OFF
RUN	OFF	OFF	ON	OFF	OFF		OFF		ON
RUN2	OFF	OFF	ON	OFF	OFF		OFF		ON
RUN3	OFF	ON	ON	ON	ON	OFF	ON	OFF	ON

*1 This signal turns off during power failure or undervoltage.

WWW.BSNEW.IR


Under real sensor less vector control, vector control



- When the inverter is ready to operate, the output of the operation ready signal (RY) is on.
  (It is also on during inverter running.)
- When the inverter output frequency rises to or above the *Pr. 13 Starting frequency* setting, the output of the inverter running signal (RUN) is turned on. During an inverter stop, DC injection brake operation, start time tuning or pre-excitation, the output is off.
- For the RUN2 signal, the output is on while the inverter is running and the start signal is on. (For the RUN2 signal, the output is off when the inverter protective function is activated and the MRS signal is on.)
- For the RUN3 signal, the output is on while the inverter is running and the start signal is on.
- The RUN2 and RUN3 signals are on when the start command is on and even during pre-excitation with "0" set in speed command. (Note that the RUN2 signal turns off during pre-excitation by turning the LX signal on.)
- The RY2 signal turns on at the start of pre-excitation.
  The signal is on while pre-excitation is activated even during an inverter stop. The signal turns off while the output is shut off (MRS signal).

REMARKS

For pre-excitation by pre-excitation signal (LX), the RY2 signal turns on when 100ms has elapsed after LX signal turn on (500ms for the FR-A720-02880(FR-A740-01440) or more).



Inverter Status / Output Signal	Start Signal is OFF (during stop)	Start Signal is ON *1 (pre-excitation)	Start Signal is ON (during running)	LX Signal is ON (pre-excitation)	DC Injection Brake Operation (pre-excitation)	At Alarm Occurrence or MRS Signal is on (output shutoff)		Automatic Restart after Instantaneous Power Failure		
								Coasting		Restarting
						Start signal is ON	Start signal is OFF	Start signal is ON	Start signal is OFF	
RY	ON	ON	ON	ON	ON	OFF		ON *2		ON
RY2	OFF	ON	ON	ON *3	ON	OFF		OFF		OFF
RUN	OFF	OFF	ON	OFF	OFF	OFF		OFF		ON
RUN2	OFF	ON	ON	OFF *4	OFF	OFF		OFF		ON
RUN3	OFF	ON	ON	ON	ON	ON	OFF	ON	OFF	ON

*1 Pre-excitation is made when the start signal is ON and frequency command is 0Hz.
*2 This signal turns OFF during power failure or undervoltage.
*3 There is a delay of 100ms (500ms for the FR-A720-02880 (FR-A740-01440) or more) when the signal is ON.
*4 This signal turns ON during servo ON (LX signal is ON) under position control.

Output Signal	*Pr. 190 to Pr. 196* Setting	
	Positive logic	Negative logic
RY	11	111
RY2	33	133
RUN	0	100
RUN2	44	144
RUN3	45	145


- When using the RY, RY2, RUN, RUN2 and RUN3 signals, assign functions to *Pr. 190 to Pr. 196 (output terminal selection function)* referring to the table on the left.

REMARKS

- The RUN signal is assigned to the terminal RUN in the initial setting.

WWW.BSNEW.IR

(3) Forward rotation and reverse rotation signal (Y30, Y31 signal)




- The status during forward rotation (Y30) and reverse rotation (Y31) are output from the actual motor speed under vector control.
- Y30 and Y31 signals turn off during pre-excitation (zero speed, servo lock) under speed control or torque control operation. Note that signals are output according to the motor rotation during servo lock under position control as same as inverter running.
- When using the Y30 signal, set "30 (positive logic) or 130 (negative logic)" to any of *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function to the output terminal.
- When using the Y31 signal, set "31 (positive logic) or 131 (negative logic)" to any of *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function to the output terminal.

REMARKS

- This signal is always off during V/F control, advanced magnetic flux vector control or real sensorless vector control.
- If the motor is made to run by external force, etc. during an inverter stop, Y30 and Y31 remain OFF.
- The FR-A7AP (option) is necessary for vector control.

(4) Regenerative mode output signal (Y32 signal)




- While the motor is in regenerative status (motor is in power regenerative status), the regenerative status output signal (Y32) is turned on.
  If the signal is turned on once, it will be retained for at least 100ms.
- It turns off while the inverter is stopped and during pre-excitation.
- When using the Y32 signal, set "32 (positive logic) or 132 (negative logic)" to any of *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function to the output terminal.

REMARKS

- This signal is always off during V/F control, advanced magnetic flux vector control or real sensorless vector control.
- The FR-A7AP (option) is necessary for vector control.

WWW.BSNEW.IR

(5) Alarm output signal (ALM, ALM2 signal)



- If the inverter comes to an alarm stop, the ALM and ALM2 signals are output.
- The ALM2 signal remains on during a reset period after alarm occurrence.
- When using the ALM2 signal, set "94 (positive logic)" or "194 (negative logic)" to any of *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function to the output terminal.
- The ALM signal is assigned to the A1B1C1 contact in the initial setting.

REMARKS

Refer to *page 400* for the inverter alarm description.

(6) Input MC shutoff signal (Y91 signal)

- The Y91 signal is output at occurrence of an alarm attributable to the failure of the inverter circuit or an alarm caused by a wiring mistake.
- When using the Y91 signal, set "91 (positive logic)" or "191 (negative logic)" to any of *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function to the output terminal.
- The following table indicates the alarms that will output the Y91 signal. (Refer to *page 400* for the alarm description.)

No.	Alarm Description
1	Inrush current limit circuit alarm (E.IOH)
2	CPU error (E.CPU)
3	CPU error (E.6)
4	CPU error (E.7)
5	Parameter storage device alarm (E.PE)
6	Parameter storage device alarm (E.PE2)
7	24VDC power output short circuit (E.P24)
8	Operation panel power supply short circuit, RS-485 terminal power supply short circuit(E.CTE)
9	Output side earth(ground) fault overcurrent protection(E.GF)
10	Output phase failure (E.LF)
11	Brake transistor alarm detection (E.BE)

♦ Parameters referred to ♦

Pr. 13 Starting frequency ☞ *Refer to page 175 .*


Pr. 76 Alarm code output selection ☞ *Refer to page 270*

WWW.BSNEW.IR

4.15.7 Detection of output frequency (SU, FU, FU2 , FU3, FB, FB2, FB3, LS signal, Pr. 41 to Pr. 43, Pr. 50, Pr. 116, Pr. 865)

The inverter output frequency is detected and output to the output signal.

Parameter Number	Name	Initial Value	Setting Range	Description
41	Up-to-frequency sensitivity	10%	0 to 100%	Set the level where the SU signal turns on.
42	Output frequency detection	6Hz	0 to 400Hz	Set the frequency where the FU (FB) signal turns on.
43	Output frequency detection for reverse rotation	9999	0 to 400Hz	Set the frequency where the FU (FB) signal turns on in reverse rotation.
			9999	Same as *Pr. 42* setting
50	Second output frequency detection	30Hz	0 to 400Hz	Set the frequency where the FU2 (FB2) signal turns on.
116	Third output frequency detection	60Hz	0 to 400Hz	Set the frequency where the FU3 (FB3) signal turns on.
865	Low speed detection	1.5Hz	0 to 400Hz	Set the frequency where the LS signal turns on.




(1) Up-to-frequency sensitivity (SU signal, *Pr. 41*)

- When the output frequency reaches the set frequency, the up-to-frequency signal (SU) is output.
- The *Pr. 41* value can be adjusted within the range ±1% to ±100% on the assumption that the set frequency is 100%.
- This parameter can be used to ensure that the set frequency has been reached to provide the operation start signal etc. for related equipment.


(2) Output frequency detection (FU (FB) signal, FU2 (FB2) signal, FU3 (FB3) signal, *Pr. 42, Pr. 43, Pr. 50, Pr. 116*)

- When the output frequency rises to or above the *Pr. 42* setting, the output frequency detection signal (FU, FB) is output.
- This function can be used for electromagnetic brake operation, open signal, etc.
- The FU (FU2, FU3) signal is output when the output frequency reaches the set frequency. While the FB (FB2, FB3) signal is output when the actual rotation detection speed (during real sensorless vector control : speed estimated value, during vector control : feedback value) of the motor reaches the set frequency. The FU signal and FB signal are output simultaneously during V/F control and advanced magnetic flux vector control.
- When the detection frequency is set in *Pr. 43*, frequency detection used exclusively for reverse rotation can also be set. This function is effective for switching the timing of electromagnetic brake operation between forward rotation (rise) and reverse rotation (fall) during elevator operation, etc.
- When *Pr. 43* ≠ "9999", the *Pr. 42* setting applies to forward rotation and the *Pr. 43* setting applies to reverse rotation.
- When outputting a frequency detection signal besides the FU signal, set the detection frequency in *Pr. 50 or Pr. 116*. The FU2 (FB2) signal (FU3(FB3) signal if *Pr. 116* or more) is output when the output frequency reaches or exceeds the *Pr. 50* setting.
- For each signal, assign functions to *Pr. 190 to Pr. 196 (output terminal function selection)* referring to the table below.



Parameter Number	Output Signal	*Pr. 190 to Pr. 196* Setting	
		Positive logic	Negative logic
42, 43	FU	4	104
	FB	41	141
50	FU2	5	105
	FB2	42	142
116	FU3	6	106
	FB3	43	143

WWW.BSNEW.IR



(3) Low speed detection (LS signal, *Pr. 865*)

- The low speed detection signal (LS) is output when the output frequency reduces below the *Pr. 865 Low speed detection* setting.
- When speed control is performed by real sensorless vector control or vector control, an alarm (E.OLT) is displayed and the inverter output is stopped if frequency drops to the *Pr. 865* setting by torque limit operation and the output torque exceeds *Pr. 874 OLT level setting* and remains for more than 3s.
- For the LS signal, set "34 (positive logic) or 134 (negative logic)" in *Pr. 190 to Pr. 196 (output terminal function selection)* and assign functions to the output terminal.

REMARKS

- The FU signal is assigned to the terminal FU and the SU signal is assigned to the terminal SU in the initial setting.
- All signals are OFF during DC injection brake, pre-excitation (zero speed control, servo lock), or start time tuning.
- The output frequency to be compared with the set frequency at the SU signal and LS signal differs according to the control method.

Control Method	Compared Output Frequency
V/F control	Output frequency
Advanced magnetic flux vector control	Output frequency before slip compensation
Real sensorless vector control	Frequency (actual motor speed) estimated value
Encoder feedback control, vector control	Value of actual motor rotation represented in terms of frequency setting

CAUTION

- When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions may be affected. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*
Pr. 874 OLT level setting ☞ *Refer to page 99*


WWW.BSNEW.IR

4.15.8 Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153, Pr. 166, Pr. 167)

The output power during inverter running can be detected and output to the output terminal.

Parameter Number	Name	Initial Value	Setting Range	Description
150	**Output current detection level**	150%*	0 to 220%*	Set the output current detection level. 100% is the rated inverter current.
151	**Output current detection signal delay time**	0s	0 to 10s	Set the output current detection period. Set the time from when the output current has risen above the setting until the output current detection signal (Y12) is output.
152	**Zero current detection level**	5%	0 to 220% *	Set the zero current detection level. The rated inverter current is assumed to be 100%.
153	**Zero current detection time**	0.5s	0 to 1s	Set this parameter to define the period from when the output current drops below the *Pr. 152* value until the zero current detection signal (Y13) is output.
166	**Output current detection signal retention time**	0.1s	0 to 10s	Set the retention time when the Y12 signal is on.
			9999	The Y12 signal on status is retained. The signal is turned off at the next start.
167	**Output current detection operation selection**	0	0	Operation continues when the Y12 signal is on
			1	The inverter is brought to an alarm stop when the Y12 signal is on. (E.CDO)

* When *Pr. 570 Multiple rating setting* ≠ "2", performing inverter reset and all parameter clear changes the initial value and setting range. *(Refer to page 155.)*




(1) Output current detection (Y12 signal, *Pr. 150, Pr. 151, Pr. 166, Pr. 167*)

- The output current detection function can be used for excessive torque detection, etc.
- If the output current remains higher than the *Pr. 150* setting during inverter operation for longer than the time set in *Pr. 151*, the output current detection signal (Y12) is output from the inverter's open collector or relay output terminal.
- When the Y12 signal turns on, the ON state is held for the time set in *Pr. 166* .
- When *Pr. 166* = "9999", the ON state is held until a next start.
- At the *Pr. 167* setting of "1", the inverter output is stopped and the output current detection alarm (E.CDO) is displayed when the Y12 signal turns on. When an alarm stop occurs, the Y12 signal is on for the time set in *Pr. 166* at the *Pr. 166* setting of other than 9999, and remains on until a reset is made at the *Pr. 166* setting of 9999. E.CDO does not occur even if "1" is set in *Pr. 167* while Y12 is ON. The *Pr. 167* setting is made valid after Y12 turns OFF.
- Set "12 (positive logic)" or "112 (negative logic)" to any of *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function of the Y12 signal to the output terminal.

WWW.BSNEW.IR

(2) Zero current detection (Y13 signal, *Pr. 152, Pr. 153*)



* Once turned on, the zero current detection time signal (Y13) is held on for at least 100ms.

- If the output current remains lower than the *Pr. 152* setting during inverter operation for longer than the time set in *Pr. 153*, the zero current detection (Y13) signal is output from the inverter's open collector or relay output terminal.
- When the inverter's output current falls to "0", torque will not be generated. This may cause a drop due to gravity when the inverter is used in vertical lift application. To prevent this, the Y13 signal can be output from the inverter to close the mechanical brake when the output current has fallen to "zero".
- Set "13 (positive logic)" or "113 (negative logic)" in any of *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function of the Y13 signal to the output terminal.

CAUTION

- This function is also valid during execution of the online or offline auto tuning.
- The response time of Y12 and Y13 signals is approximately 350ms.
- When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions may be affected. Please make setting after confirming the function of each terminal.

⚠ CAUTION

⚠ The zero current detection level setting should not be too high, and the zero current detection time setting not too long. Otherwise, the detection signal may not be output when torque is not generated at a low output current.

⚠ To prevent the machine and equipment from resulting in hazardous conditions by use of the zero current detection signal, install a safety backup such as an emergency brake.


♦ Parameters referred to ♦

Online auto tuning ☞ *Refer to page 197*
Offline auto tuning ☞ *Refer to page 187*
Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*

4.15.9 Detection of output torque (TU signal, Pr. 864)

Output the signal when the motor torque rises above the setting value.
This function can be used for electromagnetic brake operation, open signal, etc.

Parameter Number	Name	Initial Value	Setting Range	Description
864	**Torque detection**	150%	0 to 400%	Set the torque value where the TU signal turns on.



- When the output torque reaches or exceeds the detected torque value set in *Pr. 864* under real sensorless vector control, advanced magnetic flux vector control or vector control, the torque detection signal (TU) turns on.
  It turns off when the torque falls below the detection torque value.
- For the TU signal, set "35 (positive logic) or 135 (negative logic)" in *Pr. 190 to Pr. 196 (output terminal function selection)* and assign functions to the output terminal.

CAUTION

- When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions maybe affected. Please make setteing after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*

WWW.BSNEW.IR

4.15.10 Remote output function (REM signal, Pr. 495 to Pr. 497)

You can utilize the on/off of the inverter's output signals instead of the remote output terminal of the programmable logic controller.

Parameter Number	Name	Initial Value	Setting Range	Description	
495	Remote output selection	0	0	Remote output data clear at powering off	Remote output data clear at inverter reset
			1	Remote output data retention even at powering off	
			10	Remote output data clear at powering off	Remote output data retention even at inverter reset
			11	Remote output data retention even at powering off	
496 *	Remote output data 1	0	0 to 4095	Refer to the following diagram.	
497 *	Remote output data 2	0	0 to 4095		

* The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

<Remote output data>

Pr. 496

b11											b0
*1	*1	*1	*1	*1	ABC2	ABC1	FU	OL	IPF	SU	RUN

Pr. 497


b11											b0
*1	*1	RA3 *3	RA2 *3	RA1 *3	Y6 *2	Y5 *2	Y4 *2	Y3 *2	Y2 *2	Y1 *2	Y0 *2

*1 As desired
*2 Y0 to Y6 are available only when the extension output option (FR-A7AY) is fitted
*3 RA1 to RA3 are available only when the relay output option (FR-A7AR) is fitted

- The output terminal can be turned on/off depending on the *Pr. 496* or *Pr. 497* setting. The remote output selection can be controlled on/off by computer link communication from the PU connector or RS-485 port or by communication from the communication option.
- Set "96" (positive logic) or "196" (negative logic) to any of *Pr. 190 to Pr. 196 (output terminal function selection)*, and assign the remote output (REM) signal to the terminal used for remote output,
- When you refer to the diagram on the left and set 1 to the terminal bit (terminal where the REM signal has been assigned) of *Pr. 496* or *Pr. 497*, the output terminal turns on (off for negative logic). By setting 0, the output terminal turns off (on for negative logic).

Example)When "96" (positive logic) is set in *Pr. 190 RUN terminal function selection* and "1" (H01) is set in *Pr. 496*, the terminal RUN turns on.

ON/OFF example for positive logic



- When *Pr. 495* = "0 (initial value), 10", performing a power supply reset (including a power failure) clears the REM signal output. (The ON/OFF status of the terminals are as set in *Pr. 190 to Pr. 196*.) The *Pr. 496* and *Pr. 497* settings are also "0".
  When *Pr. 495* = "1, 11", the remote output data before power supply-off is stored into the EEPROM, so the signal output at power recovery is the same as before power supply-off. However, it is not stored when the inverter is reset (terminal reset, reset request through communication).
  (See the chart on the left)
- When *Pr. 495* = "10, 11", the signal before reset is held even an inverter reset is made.

REMARKS

- The output terminal where the REM signal is not assigned using any of *Pr. 190 to Pr. 196* does not turn on/off if 0/1 is set to the terminal bit of *Pr. 496* or *Pr. 497* . (It turns on/off with the assigned function.)
- When the inverter is reset (terminal reset, reset request through communication), *Pr. 496* and *Pr. 497* values turn to "0". When *Pr. 495* = "1, 11", however, they are the settings at power supply-off. (The settings are stored at power supply-off.) When *Pr. 495* = "10, 11", they are the same as before an inverter reset is made.

CAUTION

- When *Pr. 495* = "1" (remote output data retention even at powering off), take such a step as to connect R1/L11, S1/L21 and P/+, N/- to ensure that control power will be retained to some degree. If you do not take such a step, the output signals provided after power-on are not guaranteed.

♦ Parameters referred to ♦

- *Pr. 190 to Pr. 196 (output terminal function selection)* ☞ *Refer to page 236*

WWW.BSNEW.IR

4.16 Monitor display and monitor output signal

Purpose	Parameter that must be Set		Refer to Page
Display motor speed Set speed	**Speed display and speed setting**	**Pr. 37, Pr. 144, Pr. 505, Pr. 811**	248
Change PU monitor display data	**DU/PU main display data selection Cumulative monitor clear**	**Pr. 52, Pr. 170, Pr. 171, Pr. 268, Pr. 891**	250
Change of the monitor output from terminal FM and AM	**Terminal , AM function selection**	**Pr. 54, Pr. 158, Pr. 291, Pr. 866, Pr. 867**	250
Set the reference of the monitor output from terminal FM and AM	**Setting of reference of terminal FM and AM**	**Pr. 55, Pr. 56, Pr. 291, Pr. 866, Pr. 867**	255
Adjust terminal FM, AM outputs	**Terminal , AM calibration**	**Pr. 900, Pr. 901**	258

4.16.1 Speed display and speed setting (Pr. 37, Pr. 144, Pr. 505, Pr. 811)

You can change the PU (FR-DU07/FR-PU04/FR-PU07) monitor display or frequency setting to motor speed or machine speed.

Parameter Number	Name	Initial Value	Setting Range	Description	
37	**Speed display**	0	0	Frequency display, setting	
			1 to 9998*	Set the machine speed at *Pr. 505*.	
144	**Speed setting switchover**	4	0, 2, 4, 6, 8, 10, 102, 104, 106, 108, 110	Set the number of motor poles when displaying the motor speed.	
505	**Speed setting reference**	60Hz	1 to 120Hz	Set the reference speed for *Pr. 37*.	
811	**Set resolution switchover**	0		Speed setting and running speed monitor increments from the PU, RS-485 communication or communication option.	Torque limit setting increments *Pr. 22, Pr. 812 to Pr. 817*
			0	1r/min	0.1%
			1	0.1r/min	
			10	1r/min	0.01%
			11	0.1r/min	

* The maximum value of the setting range differs according to the *Pr. 1 Maximum frequency* and *Pr. 505 Speed setting reference* settings and it can be calculated from the following formula.

$$\text{Maximum setting value of } Pr.\ 37 < \frac{65535 \times Pr.\ 505}{\text{Setting value of } Pr.\ 1\ (\text{Hz})}$$

Note that the maximum setting value of *Pr. 37* is 9998 if the result of the above formula exceeds 9998.

WWW.BSNEW.IR

- To display the machine speed, set in *Pr. 37* the machine speed for operation with frequency set in *Pr. 505*.
  For example, when *Pr. 505* = "60Hz" and *Pr. 37* = "1000", "1000" is displayed on the running speed monitor when the running frequency is 60Hz. When running frequency is 30Hz, "500" is displayed.
- When displaying the motor speed, set the number of motor poles (2, 4, 6, 8, 10) or number of motor poles + 100 (102, 104, 106, 108, 110) in *Pr. 144*.
- The *Pr. 144* setting is automatically changed if the number of motor poles is set in *Pr. 81 Number of motor poles*. The *Pr. 81* setting is not automatically changed even if the setting of *Pr. 144* is changed.
  Example 1) When the initial setting of *Pr. 81* is changed to "2" or "12", the *Pr. 144* setting changes from "4" to "2".
  Example 2) When *Pr. 144* = "104", setting "2" in *Pr. 81* changes the *Pr. 144* setting from "104" to "102".
- When "1, or 11" is set in *Pr. 811*, the setting increments of speed setting from the PU, speed setting from RS-485 communication or communication options (other than FR-A7ND, FR-A7NL) and running speed monitor is 0.1r/min.
- When both *Pr. 37* and *Pr. 144* have been set, their priorities are as given below.
  Pr. 144, 102 to 110 > *Pr. 37*, 1 to 9998 > *Pr. 144*, 2 to 10
- When the running speed monitor is selected, each monitor and setting are determined by the combination of *Pr. 37* and *Pr. 144* as listed below. (The units within the thick frame are the initial values.)

Pr. 37 Setting	*Pr. 144* Setting	Output Frequency Monitor	Set Frequency Monitor	Running Speed Monitor	Frequency Setting Parameter Setting
0 (initial value)	0	Hz	Hz	r/min *1	Hz
	2 to 10	Hz	Hz	r/min *1	Hz
	102 to 110	r/min *1	r/min *1	r/min *1	r/min *1
1 to 9998	0	Hz	Hz	Machine speed *1	Hz
	2 to 10	Machine speed *1	Machine speed *1	Machine speed *1	Machine speed *1
	102 to 110	Hz	Hz	r/min *1	Hz

*1 Motor speed r/min conversion formula..... frequency × 120/number of motor poles (*Pr. 144*)
Machine speed conversion formula..... *Pr. 37* × frequency/*Pr. 505*
For *Pr. 144* in the above formula, the value is "*Pr. 144* - 100" when "102 to 110" is set in *Pr. 144* and the value is "4" when *Pr. 37* = 0 and *Pr. 144* = 0.
*2 Hz is in 0.01Hz increments, machine speed is in 1 increments, and r/min is in 1r/min increments (depending on *Pr. 811*).
*3 *Pr. 505* is always set as frequency (Hz).

CAUTION

- In the V/F control mode, the output frequency of the inverter is displayed in terms of synchronous speed, and therefore, it is unequal to the actual speed by motor slip. This display changes to the actual speed (estimated value calculated based on the motor slip) when the advanced magnetic flux vector control or real sensorless vector control is selected, and actual speed from the encoder when encoder feed back control or vector control is performed.
- When the running speed display is selected at the setting of *Pr. 37* = "0" and *Pr. 144* = "0", the monitor display is provided on the assumption that the number of motor poles is 4. (1800r/min is displayed at 60Hz)
- Refer to *Pr. 52* when you want to change the PU main monitor (PU main display).
- Since the panel display of the operation panel (FR-DU07) is 4 digits in length, the monitor value of more than "9999" is displayed "----".
- After setting the running speed in 0.1r/min increments (*Pr. 811* = "1, 11"), changing the setting increments to 1r/min increments (*Pr. 811* = "0, 10") changes the speed resolution from 0.1r/min to 0.3r/min (four poles), which may round down 0.1r/min increments.
- When the machine speed is displayed on the FR-PU04/FR-PU07, do not change the speed by using an up/down key in the state where the set speed exceeding 65535 is displayed. The set speed may become arbitrary value.
- When an optional FR-A7ND or FR-A7NL card is mounted, frequency is displayed regardless of *Pr. 37* and *Pr. 144* setting.

⚠ CAUTION

⚠ Make sure that the settings of the running speed and number of motor poles are correct. Otherwise, the motor might run at extremely high speed, damaging the machine.

♦ Parameters referred to ♦

Pr. 1 Maximum frequency ☞ *Refer to page 157*
Pr. 52 DU/PU main display data selection ☞ *Refer to page 250*
Pr. 80 Motor capacity, Pr. 81 Number of motor poles ☞ *Refer to page 145*
Pr. 800 Control system selection ☞ *Refer to page 92*
Pr. 811 Set resolution switchover ☞ *Refer to page 99*

WWW.BSNEW.IR

4.16.2 DU/PU, FM, AM terminal monitor display selection (Pr. 52, Pr. 54, Pr. 158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891)

The monitor to be displayed on the main screen of the operation panel (FR-DU07)/parameter unit (FR-PU04/FR-PU07) can be selected.
In addition, signals to be output from the terminal FM (pulse train output) and AM (analog voltage output) can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
52*	**DU/PU main display data selection**	0 (output frequency)	0, 5 to 14, 17 to 20, 22 to 25, 32 to 35, 50 to 57, 100	Select the monitor to be displayed on the operation panel and parameter unit. Refer to the following table for monitor description.
54*	**FM terminal function selection**	1 (output frequency)	1 to 3, 5 to 14, 17, 18, 21, 24, 32 to 34, 50, 52, 53, 70	Select the monitor output to terminal FM.
158*	**AM terminal function selection**			Select the monitor output to terminal AM.
170	**Watt-hour meter clear**	9999	0	Set “0” to clear the watt-hour meter monitor.
			10	Set the maximum value when monitoring from communication to 0 to 9999kWh.
			9999	Set the maximum value when monitoring from communication to 0 to 65535kWh.
171	**Operation hour meter clear**	9999	0, 9999	Set “0” in the parameter to clear the watt-hour monitor. Setting “9999” has no effect.
268*	**Monitor decimal digits selection**	9999	0	Display as integral value
			1	Display in 0.1 increments
			9999	No function
563	**Energization time carrying-over times**	0	0 to 65535 (reading only)	The numbers of cumulative energization time monitor exceeded 65535h is displayed. Reading only
564	**Operating time carrying-over times**	0	0 to 65535 (reading only)	The numbers of operation time monitor exceeded 65535h is displayed. Reading only
891	**Cumulative power monitor digit shifted times**	9999	0 to 4	Set the number of times to shift the cumulative power monitor digit. Clamp the monitoring value at maximum.
			9999	No shift Clear the monitor value when it exceeds the maximum value.

* The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

(1) Monitor description list *(Pr. 52)*

- Set the monitor to be displayed on the operation panel (FR-DU07) and parameter unit (FR-PU04/FR-PU07) in *Pr. 52 DU/PU main display data selection*.
- Set the monitor to be output to the terminal FM (pulse train output) in *Pr. 54 FM terminal function selection*.
- Set the monitor to be output to the terminal AM (analog voltage output (0 to 10VDC voltage output)) in *Pr. 158 AM terminal function selection*.
- Refer to the following table and set the monitor to be displayed. (The signals marked × cannot be selected for monitoring)

Types of Monitor	Increments	*Pr. 52* Setting		*Pr. 54* (FM) *Pr. 158* (AM) Setting	Full-scale Value of the Terminal FM and AM	Description
		DU LED	PU main monitor			
Output frequency	0.01Hz	0/100		1	*Pr. 55*	Display the inverter output frequency.
Output current	0.01A/0.1A *7	0/100		2	*Pr. 56*	Display the inverter output current effective value.
Output voltage	0.1V	0/100		3	200V class: 400V 400V class: 800V	Display the inverter output voltage.
Alarm display	—	0/100		×	—	Display 8 past alarms individually.
Frequency setting	0.01Hz	5	*1	5	*Pr. 55*	Display the set frequency.

WWW.BSNEW.IR

Types of Monitor	Increments	*Pr. 52* Setting		*Pr. 54* (FM) *Pr. 158* (AM) Setting	Full-scale Value of the Terminal FM and AM	Description
		DU LED	PU main monitor			
Running speed	1(r/min)	6	*1	6	The value converted with the *Pr. 37* value from *Pr. 55*	Display the motor speed (The display differs depending on the *Pr. 37* and *Pr. 144* settings. The running speed is the actual speed by the encoder signal during encoder feedback control and vector control. For details, refer to *page 248*.)
Motor torque	0.1%	7	*1	7	*Pr. 866*	Display the motor torque in percentage on the assumption that the rated motor torque is 100% (0% is displayed during V/F control)
Converter output voltage	0.1V	8	*1	8	200V class: 400V 400V class: 800V	Display the DC bus voltage value.
Regenerative brake duty	0.1%	9	*1	9	*Pr. 70*	Brake duty set in *Pr. 30* and *Pr. 70*
Electronic thermal relay function load factor	0.1%	10	*1	10	100%	Display the motor thermal cumulative value on the assumption that the thermal operation level is 100%.
Output current peak value	0.01A/0.1A *7	11	*1	11	*Pr. 56*	Retain the peak value of the output current monitor and display (clears at every start)
Converter output voltage peak value	0.1V	12	*1	12	200V class: 400V 400V class: 800V	Retain the peak value of the DC bus voltage value and display (clears at every start)
Input power	0.01kW/ 0.1kW *7	13	*1	13	Rated inverter power × 2	Display power on the inverter input side
Output power	0.01kW/ 0.1kW *7	14	*1	14	Rated inverter power × 2	Display power on the inverter output side
Load meter	0.1%	17		17	*Pr. 866*	Torque current is displayed in % on the assumption that the *Pr. 56* setting is 100% (displayed on the assumption that rated motor torque is 100% during sensorless vector and vector control)
Motor excitation current	0.01A/0.1A *7	18		18	*Pr. 56*	Display the excitation current of the motor
Position pulse *2	—	19		×	—	Display the number of pulses per rotation of the motor when orientation control is valid
Cumulative energization time *4, *8	1h	20		×	—	Cumulative energization time since the inverter shipment is displayed. You can check the numbers of the monitor value exceeded 65535h with *Pr. 563*.
Reference voltage output	—	—		21	—	Terminal CA : 20mA is output Terminal AM: 10V is output
Orientation status *2	1	22		×	—	Display only when orientation control is valid *(Refer to page 217)*
Actual operation time *4, *5, *8	1h	23		×	—	Cumulative inverter running time is displayed. You can check the numbers of the monitor value exceeded 65535h with *Pr. 564*. Use *Pr. 171* to clear the value. *(Refer to page 254)*
Motor load factor	0.1%	24		24	200%	On the assumption that the rated inverter current value is 100%, the output current value is displayed in %. Monitor value = output current monitor value/ rated inverter current × 100 [%]
Cumulative power *8	0.01kWh/ 0.1kWh *6 *7	25		×	—	Cumulative power amount is displayed according to the output power monitor. Use *Pr. 170* to clear the value. *(Refer to page 254)*
Torque command	0.1%	32		32	*Pr. 866*	Display torque command value obtained from vector control
Torque current command	0.1%	33		33	*Pr. 866*	Display torque current command value
Motor output	0.01kW/ 0.1kW *7	34		34	Rated motor capacity	Multiply the motor speed by the then output torque and display the machine output of the motor shaft end

WWW.BSNEW.IR

Types of Monitor	Increments	*Pr. 52* Setting		*Pr. 54* (FM) *Pr. 158* (AM) Setting	Full-scale Value of the Terminal FM and AM	Description
		DU LED	PU main monitor			
Feedback pulse *3, *8	—	35		×	—	Display the number of pulses fed back from the encoder during one sampling (display during a stop).
Power saving effect	Variable according to parameters	50		50	Inverter capacity	Display energy saving effect monitor You can change the monitor to power saving, power saving average value, charge display and % display using parameters. (For details, refer to *page 275*)
Cumulative saving power *8		51		×	—	
PID set point	0.1%	52		52	100%	Display the set point, measured value and deviation during PID control (For details, refer to *page 360*)
PID measured value	0.1%	53		53	100%	
PID deviation	0.1%	54		×	—	
Input terminal status	—	55	*1	×	—	Display the input terminal ON/OFF status on the PU (refer to *page 253* for DU display)
Output terminal status	—		*1	×	—	Display the output terminal ON/OFF status on the PU (refer to *page 253* for DU display)
Option input terminal status	—	56	×	×	—	Display the input terminal ON/OFF status of the digital input option (FR-A7AX) on the DU (refer to *page 253* for details)
Option output terminal status	—	57	×	×	—	Display the output terminal ON/OFF states of the digital output option (FR-A7AY) or relay output option (FR-A7AR) on the DU (refer to *page 253* for details)
PLC function output	0.1%	×		70	100%	Desired values can be output from terminal FM and AM using the PLC function. Refer to the FR-A700 PLC function programming manual for details of the PLC function.


*1 Frequency setting to output terminal status on the PU main monitor are selected by "other monitor selection" of the parameter unit (FR-PU04, FR-PU07).
*2 Position pulse and orientation status function when used with an option (FR-A7AP). When orientation control is invalid, "0" remains displayed and these functions are invalid.
*3 Feedback pulse functions when the option (FR-A7AP) is used and vector control is performed.
*4 The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0. When the operation panel (FR-DU07) is used, the time is displayed up to 65.53 (65530h) on the assumption that 1h = 0.001, and thereafter, it is added up from 0.
*5 The actual operation time is not added up if the cumulative operation time before power supply-off is less than 1h.
*6 When using the parameter unit (FR-PU04/FR-PU07), "kW" is displayed.
*7 The setting depends on the inverter capacity. (FR-A720-02150(FR-A740-01100) or less / FR-A720-02880(FR-A740-01440) or more)
*8 Since the panel display of the operation panel (FR-DU07) is 4 digits in length, the monitor value of more than "9999" is displayed "----".

REMARKS


- By setting "0" in *Pr. 52*, the monitoring of output frequency to alarm display can be selected in sequence by (SET).
- When the operation panel (FR-DU07) is used, the displayed units are Hz, V and A only and the others are not displayed.
- The monitor set in *Pr. 52* is displayed in the third monitor position (The output voltage monitor is changed).
  Note that load meter, motor excitation current, and motor load factor are displayed in the second monitor (output current).

Initial value

* The monitor displayed at powering on is the first monitor. Display the monitor you want to display on the first monitor and hold down (SET) for 1s. (To return to the output frequency monitor, hold down (SET) for 1s after displaying the output frequency monitor.)



Example)When *Pr. 52* is set to "20" (cumulative energization time), the monitor is displayed on the operation panel as described below.



WWW.BSNEW.IR

(2) Display set frequency during stop *(Pr. 52)*

- When *Pr. 52* is set to "100", the set frequency monitor is displayed during a stop and the output frequency monitor is displayed during operation. (LED of Hz flickers during stop and is lit during running.)
- When *Pr. 52* = "100", the set frequency displayed at a stop indicates frequency to be output when the start command is on.
  Different from the frequency setting displayed when *Pr. 52* = "5", the value based on maximum/minimum frequency and frequency jump is displayed.

Type of Monitor	*Pr. 52*		
	0	100	
	During running/stop	During stop	During running
Output frequency	Output frequency	Set frequency	Output frequency
Output current	Output current		
Output voltage	Output voltage		
Alarm display	Alarm display		

REMARKS

- During an error, the output frequency at error occurrence appears.
- During MRS, the values displayed are the same as during a stop.
- During offline auto tuning, the tuning status monitor has priority.


(3) Operation panel (FR-DU07) I/O terminal monitor *(Pr. 52)*


- When *Pr. 52* is set to any of "55 to 57", the I/O terminal states can be monitored on the operation panel (FR-DU07).
- The I/O terminal monitor is displayed on the third monitor.
- The LED is on when the terminal is on, and the LED is off when the terminal is off. The center line of LED is always on.

Pr. 52 Setting	Monitor Description
55	Display the I/O and output terminal ON/OFF status of the inverter unit.
56 *	Display the input terminal ON/OFF status of the digital input option (FR-A7AX).
57 *	Display the output terminal ON/OFF status of the digital output option (FR-A7AY) or relay output option (FR-A7AR).


* You can set "56" or "57" even if the option is not fitted. When the option is not fitted, the monitor displays are all off.

- On the unit I/O terminal monitor (*Pr. 52* = "55"), the upper LEDs denote the input terminal status and the lower the output terminal status.






- On the input option terminal monitor (*Pr. 52* = "56"), the decimal point LED of the first digit LED is on.



- On the input option terminal monitor (*Pr. 52* = "57"), the decimal point LED of the second digit LED is on.



WWW.BSNEW.IR

(4) Cumulative power monitor and clear *(Pr. 170, Pr. 891)*

- On the cumulative power monitor (*Pr. 52* = "25"), the output power monitor value is added up and is updated in 1h increments.
- The operation panel (FR-DU07), parameter unit (FR-PU04, FR-PU07) and communication (RS-485 communication, communication option) display increments and display ranges are as indicated below.

Operation Panel *1		Parameter Unit *2		Communication		
Range	Increments	Range	Increments	Range		Increments
				Pr. 170 = 10	*Pr. 170* = 9999	
0 to 99.99kWh	0.01kWh	0 to 999.99kWh	0.01kWh	0 to 9999kWh	0 to 65535kWh (initial value)	1kWh
100.0 to 999.9kWh	0.1kWh	1000.0 to 9999.9kWh	0.1kWh			
1000 to 9999kWh	1kWh	10000 to 99999kWh	1kWh			

*1 Power is measured in the range 0 to 9999.99kWh, and displayed in 4 digits.
When the monitor value exceeds "99.99", a carry occurs, e.g. "100.0", so the value is displayed in 0.1kWh increments.
*2 Power is measured in the range 0 to 99999.99.99kWh, and displayed in 5 digits.
When the monitor value exceeds "999.99", a carry occurs, e.g. "1000.0", so the value is displayed in 0.1kWh increments.

- The monitor data digit can be shifted to the right by the number of *Pr. 891* settings.
  For example, if the cumulative power value is 1278.56kWh when *Pr. 891* = "2", the PU/DU display is 12.78 (display in 100kWh increments) and the communication data is 12.
- If the maximum value is exceeded at *Pr. 891* = "0 to 4", the power is clamped at the maximum value, indicating that a digit shift is necessary. If the maximum value is exceeded at *Pr. 891* = "9999", the power returns to 0 and is recounted.
  If the maximum value is exceeded at *Pr. 891* = "9999", the power returns to 0 and is recounted.
- Writing "0" in *Pr. 170* clears the cumulative power monitor.

REMARKS

- If "0" is written in *Pr. 170* and *Pr. 170* is read again, "9999" or "10" is displayed.

(5) Cumulative energization time and actual operation time monitor *(Pr. 171, Pr. 563, Pr. 564)*

- On the cumulative energization time monitor (*Pr. 52* = "20"), the inverter running time is added up every hour.
- On the actual operation time monitor (*Pr. 52* = "23"), the inverter running time is added up every hour. (Time is not added up during a stop.)
- If the numbers of monitor value exceeds 65535, it is added up from 0. You can check the numbers of cumulative energization time monitor exceeded 65535h with *Pr. 563* and the numbers of actual operation time monitor exceeded 65535h with *Pr. 564*.
- Writing "0" in *Pr. 171* clears the actual operation time monitor. (Energization time monitor can not be cleared.)

REMARKS

- The actual operation time is not added up unless the inverter is operated one or more hours continuously.
- If "0" is written in *Pr. 171* and *Pr. 171* is read again, "9999" is always displayed. Setting "9999" does not clear the actual operation time meter.

(6) You can select the decimal digits of the monitor *(Pr. 268)*

- As the operation panel (FR-DU07) display is 4 digits long, the decimal places may vary at analog input, etc. The decimal places can be hidden by selecting the decimal digits.
  In such a case, the decimal digits can be selected by *Pr. 268*.

Pr. 268 Setting	Description
9999 (initial value)	No function
0	When 1 or 2 decimal places (0.1 increments or 0.01 increments) are monitored, the decimal places are dropped and the monitor displays an integer value (1 increments). The monitor value of 0.99 or less is displayed as 0.
1	When 2 decimal places (0.01 increments) are monitored, the 0.01 decimal place is dropped and the monitor displays the first decimal place (0.1 increments). When the monitor display digit is originally in 1 increments, it is displayed unchanged in 1 increments.

REMARKS

- The number of display digits on the cumulative energization time (*Pr. 52* = "20"), actual operation time (*Pr. 52* = "23"), cumulative power (*Pr. 52* = "25") or cumulative saving power monitor (*Pr. 52* = "51") does not change.

♦ Parameters referred to ♦

Pr. 37 Speed display, Pr. 144 Speed setting switchover ☞ *Refer to page 248*
Pr. 55 Frequency monitoring reference, Pr. 56 Current monitoring reference, Pr. 866 Torque monitoring reference ☞ *Refer to page 255*
Pr. 291 Pulse train I/O selection ☞ *Refer to page 255*

WWW.BSNEW.IR

4.16.3 Reference of the terminal FM (pulse train output) and AM (analog voltage output) (Pr. 55, Pr. 56, Pr. 291, Pr. 866, Pr. 867)

Two types of monitor output, pulse train output from the terminal FM and analog voltage output from the terminal AM, are available. In addition, pulse train output by voltage output and by open collector output can be selected for terminal FM.
Set the reference of the signal output from terminal FM and AM.


Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description	
55 *	**Frequency monitoring reference**	60Hz	0 to 400Hz		Set the full-scale value to output the output frequency monitor value to terminal FM and AM.	
56 *	**Current monitoring reference**	Rated inverter current	02150 (01100) or less	0 to 500A	Set the full-scale value to output the output current monitor value to terminal FM and AM.	
			02880 (01440) or more	0 to 3600A		
291	**Pulse train I/O selection**	0	0		Pulse train input	Pulse train output
			1		Terminal JOG	FM output
			10		Pulse train input	FM output
			11		Terminal JOG	High speed pulse train output (50%Duty)
			20		Pulse train input	High speed pulse train output (50%Duty)
			21		Terminal JOG	High speed pulse train output (ON width is always same)
			100		Pulse train input	High speed pulse train output (ON width is always same)
						The inverter outputs the signal input as pulse train as is
866 *	**Torque monitoring reference**	150%	0 to 400%		Set the full-scale value to output the torque monitor value to terminal FM and AM.	
867	**AM output filter**	0.01s	0 to 5s		Set the output filter of terminal AM.	

* The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.


(1) Pulse train output of the terminal FM *(Pr. 291)*

- Two types of pulse train can be output to the terminal FM.

FM output circuit



- When *Pr. 291 Pulse train I/O selection* = "0 (initial value) or 1", FM output is selected and pulse train with maximum of 8VDC 2400pulses/s is output.
  The pulse width can be adjusted by calibration *parameter C0 (Pr. 900) FM terminal calibration* using the operation panel and parameter unit.
- Output frequency, etc. of the inverter can be indicated by connecting a DC ammeter of full-scale 1mA, digital indicator, etc.




Pulse width T1: Adjust using calibration parameter C0
Pulse cycle T2: Set with *Pr. 55* (frequency monitor)
Set with *Pr.56* (current monitor)

*1 Not needed when the operation panel (FR-DU07) or parameter unit (FR-PU04/FR-PU07) is used for calibration.
This resistor is used when calibration must be made near the frequency meter for such a reason as a remote frequency meter.
Note that the needle of the frequency meter may not deflect to full-scale when the calibration resistor is connected. In this case, use this resistor and operation panel or parameter unit together.


*2 The initial setting is 1mA full-scale and 1440 pulse/s teminal FM frequency at 60Hz.

WWW.BSNEW.IR


High speed pulse train output circuit (connection example with a pulse counter)



Pulse when *Pr. 291* = "10, 11"



Pulse when *Pr. 291* = "20, 21, 100"



- When *Pr. 291 Pulse train I/O selection* = "10, 11, 20, 21, 100", high speed pulse train is output by open collector output. Pulse train of maximum of 55k pulses/s is output.
  Two types of pulse width, 50% Duty and fixed ON width, are available. Adjustment by calibration *parameter C0 (Pr. 900) FM terminal calibration* can not be performed.

* When the output wiring length is long, a pulse shape is deformed due to the stray capacitances of the wiring and output pulse can not be recognized. If the wiring length is long, connect the open collector output signal and the power supply using an external pull up resistance.
Check specifications of a pulse counter for a resistance value to pull up. Select an appropriate resistance value so that the load current is 80mA or less.

- When *Pr. 291* = "10, 11", the pulse cycle is 50% Duty (ON width and OFF width are the same).
- When *Pr. 291* = "20, 21, 100", fixed ON width of pulse is output (approx. 10μs).
- When the setting value is "100", the pulse train from the pulse train input (terminal JOG) is output as is. Use this value for synchronous speed operation of multiple inverters. (Refer to *page 372*)

* Hi indicates that the open collector output transistor is on.


● High speed pulse train output specifications

Item	Specifications
Output method	NPN open collector output
Voltage between a collector and emitter	30V (max)
Maximum permissible load current	80mA
Output pulse rate	0 to 55kpps *
Output resolution	3pps (excluding a jitter)

* The output pulse rate is 50kpps when a monitor output value is 100%.

CAUTION


- Input specifications of terminal JOG (pulse train input or contact input) can be selected with *Pr. 291*.
  Change the setting value using care not to change input specifications of terminal JOG. (Refer to *page 372* for pulse train input.)
- After changing a setting value of *Pr. 291*, connect a meter between terminal FM and SD. Take care that a voltage should not be applied to terminal FM when FM output (voltage output) pulse train is selected.
- The FM output of the inverter can not be connected to devices which have source logic type pulse input.
- When high speed pulse train output (*Pr. 291* = "10, 11, 20, 21, 100") is selected, performing parameter all clear returns the *Pr. 291* setting to the initial value of "0", changing the terminal FM output from high speed pulse train output to FM output (voltage output).




WWW.BSNEW.IR

(2) Frequency monitoring reference *(Pr. 55)*


- Set the frequency to be based when the frequency is selected as the output of the terminal FM and terminal AM.
- Set the inverter output frequency (set frequency) at which the pulse speed of the terminal FM is 1440 pulses/s (50K pulses/s). The pulse speed and inverter output frequency are proportional to each other. Note that the maximum pulse train output is 2400 pulses/s (55K pulses/s).
- Set the reference value of the frequency at which the output voltage of the terminal AM is 10VDC.
- The output voltage and frequency are proportional to each other. (The maximum output voltage is 10VDC.)






(3) Current monitoring reference *(Pr. 56)*


- Set the current at which the pulse speed of the terminal FM is 1440 pulses/s (50K pulses/s).
- The pulse speed and current value are proportional to each other. (The maximum pulse train output is 2400 pulses/s (55K pulses/s).)
- Set the reference value of the current at which the output voltage of the terminal AM is 10VDC.
- The output voltage and current value are proportional to each other. (The maximum output voltage is 10VDC.)






(4) Reference of torque monitor (*Pr. 866*)

- Set the torque at which the pulse speed of the terminal FM is 1440 pulses/s (50k pulses/s).
- Pulse speed and torque monitor value are proportional. (The maximum pulse train output is 2400 pulses/s (55k pulses/s).
- Set the torque reference value at which the output voltage of the terminal AM is 10VDC.
- Output voltage and torque monitor value are proportional. (The maximum output voltage is 10VDC.)





(5) Terminal AM response adjustment *(Pr. 867)*

- Using *Pr. 867*, the output voltage response of the terminal AM can be adjusted within the range 0 to 5s.
- Increasing the setting stabilizes the terminal AM output more but reduces the response level. (Setting "0" sets the response level to 4ms)

WWW.BSNEW.IR

4.16.4 Terminal FM, AM calibration (Calibration parameter C0 (Pr. 900), C1 (Pr. 901))


By using the operation panel or parameter unit, you can calibrate terminal FM and terminal AM to full scale deflection.

Parameter Number	Name	Initial Value	Setting Range	Description
C0(900)	FM terminal calibration	—	—	Calibrate the scale of the meter connected to terminal FM.
C1(901)	AM terminal calibration	—	—	Calibrate the scale of the analog meter connected to terminal AM.

*1 The parameter number in parentheses is the one for use with the parameter unit (FR-PU04/FR-PU07).
*2 The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

(1) FM terminal calibration *(C0(Pr. 900))*

- The terminal FM is preset to output pulses. By setting the *Calibration parameter C0 (Pr. 900)*, the meter connected to the inverter can be calibrated by parameter setting without use of a calibration resistor.
- Using the pulse train output of the terminal FM, a digital display can be provided by a digital counter. The monitor value is 1440 pulses/s output at the full-scale value of the table on the previous page *(Pr. 54 FM terminal function selection)*.



Pulse width T1: Adjust using calibration parameter C0
Pulse cycle T2: Set with *Pr. 55* (frequency monitor)
Set with *Pr.56* (current monitor)

- Calibrate the terminal FM in the following procedure.
  1) Connect an indicator (frequency meter) across the terminals FM-SD of the inverter. (Note the polarity. The terminal FM is positive.)
  2) When a calibration resistor has already been connected, adjust the resistance to "0" or remove the resistor.
  3) Refer to the output signal list *(page 250)* and set *Pr. 54*. When you selected the running frequency or inverter output current as the output signal, preset the running frequency or current value, at which the output signal will be 1440 pulses/s, to *Pr. 55 Frequency monitoring reference* or *Pr. 56 Current monitoring reference*. At 1440 pulses/s, the meter generally deflects to full-scale.

REMARKS


- When outputting such an item as the output current, which cannot reach a 100% value easily by operation, set *Pr. 54* to "21" (reference voltage output) and make calibration. 1440 pulses/s are output from the terminal FM.
- The wiring length of the terminal FM should be 200m maximum.

CAUTION

- The initial value of *the calibration parameter C0 (Pr. 900)* is set to 1mA full-scale and 1440 pulses/s FM output frequency at 60Hz. The maximum pulse train output of terminal FM is 2400 pulses/s.
- When a frequency meter is connected to across terminals FM-SD to monitor the running frequency, the FM terminal output is filled to capacity at the initial setting if the maximum output frequency reaches or exceeds 100Hz. In this case, the *Pr. 55* setting must be changed to the maximum frequency.
- When *Pr. 291 Pulse train I/O selection* = "10, 11, 20, 21, 100" (high speed pulse train output), calibration using *calibration parameter C0 (Pr. 900)* can not be made.

WWW.BSNEW.IR

(2) AM terminal calibration *(C1 (Pr. 901))*



· Terminal AM is factory-set to provide a 10VDC output in the full-scale status of the corresponding monitor item. *Calibration parameter C1 (Pr. 901)* allows the output voltage ratios (gains) to be adjusted according to the meter scale. Note that the maximum output voltage is 10VDC.

· Calibrate the AM terminal in the following procedure.




1) Connect a 0-10VDC meter (frequency meter) to across inverter terminals AM-5. (Note the polarity. The terminal AM is positive.)
2) Refer to the monitor description list *(page 250)* and set *Pr. 158*.
   When you selected the running frequency, inverter output current, etc. as monitor, preset in *Pr. 55* or *Pr. 56* the running frequency or current value at which the output signal will be 10V.
3) When outputting the item that cannot achieve a 100% value easily by operation, e.g. output current, set "21" (reference voltage output) in *Pr. 158* and perform the following operation. After that, set "2" (output current, for example) in *Pr. 158*.

REMARKS

· When outputting such an item as the output current, which cannot reach a 100% value easily by operation, set *Pr. 54* to "21" (reference voltage output) and make calibration. 10VDC is output from the terminal AM.

WWW.BSNEW.IR

(3) How to calibrate the terminal FM when using the operation panel (FR-DU07)

Operation	Display (When Pr. 54=1)
1. Confirmation of the RUN indication and operation mode indication	
2. Press (MODE) to choose the parameter setting mode.	(MODE) ⇨  (The parameter number read previously appears.)
3. Turn dial until C. . . appears.	 ⇨  (C0 to C41 setting is enabled.)
4. Press (SET) to display C - - -.	(SET) ⇨ 
5. Turn dial until C 0 appears. Set to *C0 FM terminal calibration*.	 ⇨ 
6. Press (SET) to enable setting.	(SET) ⇨  (The monitor set to *Pr. 54 FM terminal function selection* is displayed.)
7. If the inverter is at a stop, (press (FWD) or (REV)) to start the inverter. (Motor needs not be connected.)	(FWD) / ((REV)) ⇨ 
8. Turn dial to adjust the indicator needle to the desired position.	 ⇨  Analog indicator
9. Press (SET). Setting is complete.	(SET) ⇨ 

Flicker...Parameter setting complete!!

- By turning dial, you can read another parameter.
- Press (SET) to return to the C - - - indication (step 4).
- Press (SET) twice to show the next parameter (Pr.CL).

REMARKS

- Calibration can also be made for external operation. Set the frequency in external operation mode, and make calibration in the above procedure.
- Calibration can be made even during operation.
- For the operation procedure using the parameter unit (FR-PU04/FR-PU07), refer to the parameter unit instruction manual.

♦ Parameters referred to ♦

Pr. 54 FM terminal function selection ☞ *Refer to page 250*
Pr. 55 Frequency monitoring reference ☞ *Refer to page 255*
Pr. 56 Current monitoring reference ☞ *Refer to page 255*
Pr. 158 AM terminal function selection ☞ *Refer to page 250*

WWW.BSNEW.IR

4.17 Operation selection at power failure and instantaneous power failure

Purpose	Parameter that must be Set		Refer to Page
At instantaneous power failure occurrence, restart inverter without stopping motor	**Automatic restart operation after instantaneous power failure/flying start**	**Pr. 57, Pr. 58, Pr. 162 to Pr. 165, Pr. 299, Pr. 611**	261
When undervoltage or a power failure occurs, the inverter can be decelerated to a stop.	**Power failure-time deceleration-to-stop function**	**Pr. 261 to Pr. 266, Pr. 294**	265

4.17.1 Automatic restart after instantaneous power failure/flying start (Pr. 57, Pr. 58, Pr. 162 to Pr. 165, Pr. 299, Pr. 611)


You can restart the inverter without stopping the motor in the following cases.
- when commercial power supply operation is switched to inverter operation
- when power comes back on after an instantaneous power failure
- when motor is coasting at start

Parameter Number	Name	Initial Value 200V class (400V class)	Setting Range 200V class (400V class)		Description
57	**Restart coasting time**	9999	0		· FR-A720-00080 (FR-A740-00040) or less ..... 0.5s, · FR-A720-00110 to 00330 (FR-A740-00060 to 00170)..... 1s, · FR-A720-00460 to 02150 (FR-A740-00230 to 01100) ..... 3.0s, · FR-A720-02880 (FR-A740-01440) or more..... 5.0s, The above times are coasting time.
			02150 (01100) or less	0.1 to 5s	Set the waiting time for inverter-triggered restart after an instantaneous power failure.
			02880 (01440) or more	0.1 to 30s	
			9999		No restart
58	**Restart cushion time**	1s	0 to 60s		Set a voltage starting time at restart.
162	**Automatic restart after instantaneous power failure selection**	0	0		With frequency search
			1		Without frequency search (reduced voltage system)
			2		Encoder detection frequency search
			10		Frequency search at every start
			11		Reduced voltage system at every start
			12		Encoder detection frequency search at every start
163	**First cushion time for restart**	0s	0 to 20s		Set a voltage starting time at restart. Consider using these parameters according to the load (moment of inertia, torque) magnitude.
164	**First cushion voltage for restart**	0%	0 to 100%		
165	**Stall prevention operation level for restart**	150%*1	0 to 220%*1		Consider the rated inverter current as 100% and set the stall prevention operation level during restart operation.
299	**Rotation direction detection selection at restarting**	0	0		Without rotation direction detection
			1		With rotation direction detection
			9999		When *Pr. 78* = "0", the rotation direction is detected. When *Pr. 78* = "1","2", the rotation direction is not detected.
611	**Acceleration time at a restart**	02150 (01100) or less	0 to 3600s, 9999	5s	Set the acceleration time to reach the set frequency at a restart. Acceleration time for restart is the normal acceleration time (e.g. *Pr. 7*) when "9999" is set.
		02880 (01440) or more		15s	

*1 When *Pr. 570 Multiple rating setting* ≠ "2", performing inverter reset and all parameter clear changes the initial value and setting range. *(Refer to page 155.)*


WWW.BSNEW.IR

(1) Automatic restart after instantaneous power failure operation



- When instantaneous power failure protection (E.IPF) and undervotage protection (E.UVT) are activated, the inverter output is shut off. (Refer to *page 406* for E.IPF and E.UVT.)
  When automatic restart after instantaneous power failure operation is set, the motor can be restarted if power is restored after an instantaneous power failure or undervoltage is corrected. (E.IPF and E.UVT are not activated.)
- When E.IPF and E.UVT are activated, instantaneous power failure/under voltage signal (IPF) is output.
- The IPF signal is assigned to the terminal IPF in the initial setting. The IPF signal can also be assigned to the other terminal by setting "2 (positive logic) or 102 (negative logic)" to any of *Pr. 190 to Pr. 196 (output terminal function selection)*.

(2) Connection (CS signal)



- When the automatic restart after instantaneous power failure selection signal (CS) is turned on, automatic restart operation is enabled.
- When *Pr. 57* is set to other than "9999" (automatic restart operation enabled), the inverter will not operate if used with the CS signal remained off.


REMARKS

- The CS signal is assigned to the terminal CS in the initial setting. By setting "6" in any of *Pr. 178 to Pr. 189 (input terminal function selection)*, you can assign the CS signal to the other terminal.

(3) Automatic restart operation selection *(Pr. 162, Pr. 299)*


● When *Pr. 162* = 0, 10 (with frequency search)

V/F control, advanced magnetic flux vector control



* The output shut off timing differs according to the load condition.

Real sensorless vector control



* The output shut off timing differs according to the load condition.

● **With frequency search**

When "0 (initial value), 10" is set in *Pr. 162*, the inverter smoothly starts after detecting the motor speed upon power restoration.

- During reverse rotation, the inverter can be restarted smoothly as the direction of rotation is detected.
- You can select whether to make rotation direction detection or not with *Pr. 299 Rotation direction detection selection at restarting*. When capacities of the motor and inverter differ, set "0" (without rotation direction detection) in *Pr. 299*.

Pr. 299 Setting	*Pr. 78* Setting		
	0	1	2
9999	○	×	×
0 (initial value)	×	×	×
1	○	○	○

○:with rotation direction detection
×:without rotation direction detection


REMARKS

- Speed detection time (frequency search) changes according to the motor speed. (maximum 500ms)
- When the inverter capacity is two rank or more larger than the motor capacity, the inverter may not start due to overcurrent (OCT) alarm.
- If two or more motors are connected to one inverter, the inverter functions abnormally. (The inverter does not start smoothly.)
- Since the DC injection brake is operated instantaneously when the speed is detected at a restart, the speed may reduce if the inertia moment (J) of the load is small.
- When reverse rotation is detected when *Pr. 78* = "1" (reverse rotation disabled), the rotation direction is changed to forward rotation after decelerates in reverse rotation when the start command is forward rotation. The inverter will not start when the start command is reverse rotation.

WWW.BSNEW.IR


● When *Pr. 162* = 1, 11 (without frequency serch)

V/F control, advanced magnetic flux vector control




* The output shut off timing differs according to the load condition.

Real sensorless vector control



* The output shut off timing differs according to the load condition.

● When *Pr. 162* = 2, 12 (encoder detection frequency search)



* The output shut off timing differs according to the load condition.

● Without frequency search

When *Pr. 162* = "1" or "11", automatic restart operation is performed in a reduced voltage system, where the voltage is gradually risen with the output frequency unchanged from prior to an instantaneous power failure independently of the coasting speed of the motor.
For real sensorless vector control, output frequency and voltage before instantaneous power failure are output. (*Pr. 58* is made invalid.)

REMARKS

· This system stores the output frequency prior to an instantaneous power failure and increases the voltage. Therefore, if the instantaneous power failure time exceeds 0.2s, the inverter starts at *Pr. 13 Starting frequency* (initial value = 0.5Hz) since the stored output frequency cannot be retained.

● Encoder detection frequency search

· When "2 or 12" is set in *Pr. 162* under encoder feedback control, the motor starts at the motor speed and in the rotation direction detected from the encoder at power restoration.
· Encoder detection frequency search is performed regardless of the *Pr. 162* setting under vector control.
· The *Pr. 58* and *Pr. 299* settings are invalid for encoder detection frequency search.

REMARKS

· When encoder feedback control is invalid, setting "2 or 12" in *Pr. 162* enables frequency search (*Pr. 162* = "0, 10").

● Restart operation at every start

When *Pr. 162* = "10, 11 or 12", automatic restart operation is also performed every start, in addition to the automatic restart after instantaneous power failure. When *Pr. 162* = "0" or "2", automatic restart operation is performed at the first start after power supply-on, but the inverter starts at the starting frequency at the second time or later.

WWW.BSNEW.IR

(4) Restart coasting time *(Pr. 57)*


- Coasting time is the time from when the motor speed is detected until automatic restart control is started.
- Set *Pr. 57* to "0" to perform automatic restart operation. The coasting time is automatically set to the value below. Generally this setting will pose no problems.

200V class	00080 or less	00110 to 00330	00460 to 02150	02880 or more
400V class	00040 or less	00060 to 00170	00230 to 01100	01440 or more
Coasting time	0.5s	1s	3s	5s

- Operation may not be performed well depending on the magnitude of the moment (J) of inertia of the load or running frequency. Adjust the coasting time between 0.1s and 5s according to the load specifications.

(5) Restart cushion time *(Pr. 58)*

- Cushion time is the length of time taken to raise the voltage appropriate to the detected motor speed (output frequency prior to instantaneous power failure when *Pr. 162* = "1" or "11").
- Normally the initial value need not be changed for operation, but adjust it according to the magnitude of the moment (J) of inertia of the load or torque.
- *Pr. 58* is invalid during encoder feedback control (*Pr. 162* = "2, 12"), real sensorless vector control or vector control.



(6) Automatic restart operation adjustment *(Pr. 163 to Pr. 165, Pr. 611)*

- Using *Pr. 163* and *Pr. 164*, you can adjust the voltage rise time at a restart as shown on the left.
- Using *Pr. 165*, you can set the stall prevention operation level at a restart.
- Using *Pr. 611*, you can set the acceleration time until the set frequency is reached after automatic restart operation is performed besides the normal acceleration time.

REMARKS

- If the setting of *Pr. 21 Acceleration/deceleration time increments* is changed, the setting increments of *Pr. 611* does not change.

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.
- When automatic restart operation is selected, undervotage protection (E.UVT) and instantaneous power failure protection (E.IPF) among the alarm output signals will not be provided at occurrence of an instantaneous power failure.
- The SU and FU signals are not output during a restart. They are output after the restart cushion time has elapsed.
- Automatic restart operation will also be performed after a reset made by an inverter reset is canceled or when a retry is made by the retry function.
- Automatic restart after instantaneous power failure function is invalid when load torque high speed frequency control (*Pr. 270* = "2, 3") is set.

⚠ CAUTION

⚠ Provide mechanical interlocks for MC1 and MC2. The inverter will be damaged if the power supply is input to the inverter output section.

⚠ When automatic restart after instantaneous power failure has been selected, the motor and machine will start suddenly (after the reset time has elapsed) after occurrence of an instantaneous power failure. Stay away from the motor and machine. When you have selected automatic restart after instantaneous power failure function, apply in easily visible places the CAUTION stickers supplied to the installation guideline.

♦ Parameters referred to ♦

Pr. 7 Acceleration time, Pr. 21 Acceleration/deceleration time increments ☞ *Refer to page 173*
Pr. 13 Starting frequency ☞ *Refer to page 175*
Pr. 65, Pr. 67 to Pr. 69 Retry function ☞ *Refer to page 268*
Pr. 78 Reverse rotation prevention selection ☞ *Refer to page 306*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*


WWW.BSNEW.IR


4.17.2 Power failure-time deceleration-to-stop function (Pr. 261 to Pr. 266, Pr. 294)

When a power failure or undervoltage occurs, the inverter can be decelerated to a stop or can be decelerated and re-accelerated to the set frequency.

Parameter Number	Name	Initial Value	Setting Range	Description	
261	Power failure stop selection	0	0	Coasting to stop When undervoltage or power failure occurs, the inverter output is shut off.	
			1	Without under voltage avoidance	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop.
			11	With under voltage avoidance	
			2	Without under voltage avoidance	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop. If power is restored during a power failure, the inverter accelerates again.
			12	With under voltage avoidance	
262	Subtracted frequency at deceleration start	3Hz	0 to 20Hz	Normally operation can be performed with the initial value unchanged. But adjust the frequency according to the magnitude of the load specifications (moment of inertia, torque).	
263	Subtraction starting frequency	60Hz	0 to 120Hz	When output frequency ≥ *Pr. 263* Decelerate from the speed obtained from output frequency minus *Pr. 262*. When output frequency < *Pr. 263* Decelerate from output frequency	
			9999	Decelerate from the speed obtained from output frequency minus *Pr. 262*.	
264	Power-failure deceleration time 1	5s	0 to 3600/ 360s *	Set a deceleration slope down to the frequency set in *Pr. 266*.	
265	Power-failure deceleration time 2	9999	0 to 3600/ 360s *	Set a deceleration slope below the frequency set in *Pr. 266*.	
			9999	Same slope as in *Pr. 264*	
266	Power failure deceleration time switchover frequency	60Hz	0 to 400Hz	Set the frequency at which the deceleration slope is switched from the *Pr. 264* setting to the *Pr. 265* setting.	
294	UV avoidance voltage gain	100%	0 to 200%	Adjust the response level during undervoltage avoidance operation. A larger setting will improve responsiveness to the bus voltage change.	

* When the setting of *Pr. 21 Acceleration/deceleration time increments* is "0" (initial value), the setting range is "0 to 3600s" and the setting increments are "0.1s", and when the setting is "1", the setting range is "0 to 360s" and the setting increments are "0.01s"






(1) Connection and parameter setting

- Remove the jumpers across terminals R/L1-R1/L11 and across terminals S/L2-S1/L21, and connect terminals R1/L11 and P/+ and terminals S1/L21 and N/-.
- When *Pr. 261* is set to "1" or "2", the inverter decelerates to a stop if an undervoltage or power failure occurs.

(2) Operation outline of deceleration to stop at power failure

- If an undervoltage or power failure occurs, the output frequency is dropped by the frequency set in *Pr. 262* .
- Deceleration is made in the deceleration time set in *Pr. 264*. (The deceleration time setting is the time required from *Pr. 20 Acceleration/deceleration reference frequency* to a stop.)
- When the frequency is low and enough regeneration energy is not provided, for example, the deceleration time (slope) from *Pr. 265* to a stop can be changed.


WWW.BSNEW.IR



(3) Power failure stop mode (*Pr. 261* = "1, 11")

· If power is restored during power failure deceleration, deceleration to a stop is continued and the inverter remains stopped. To restart, turn off the start signal once, then turn it on again.


REMARKS




· When automatic restart after instantaneous power failure is selected (*Pr. 57* ≠ "9999"), deceleration to stop function is invalid and the restart after instantaneous power failure operation is performed.
· After a power failure stop, the inverter will not start if the power supply is switched on with the start signal (STF/STR) input. After switching on the power supply, turn off the start signal once and then on again to make a start.

(4) Original operation continuation at instantaneous power failure function (*Pr. 261* = "2, 12")

· When power is restored during deceleration after an instantaneous power failure, acceleration is made again up to the set frequency.
· When this function is used in combination with the automatic restart after instantaneous power failure operation, deceleration can be made at a power failure and acceleration can be made again after power restoration. When power is restored after a stop by deceleration at an instantaneous power failure, automatic restart operation is performed if automatic restart after instantaneous power failure has been selected (*Pr. 57* ≠ "9999")



* Acceleration time depends on *Pr. 7* (*Pr. 44*).



(5) Undervoltage avoidance function (*Pr. 261* = "11, 12", *Pr. 294*)

· When *Pr. 261* = "11, 12", the deceleration time is automatically adjusted (shortened) to prevent undervoltage from occuring during deceleration at an instantaneous power failure.
· Adjust the slope of frequency decrease and response level with *Pr. 294*. A larger setting will improve responsiveness to the bus voltage.

REMARKS

Undervoltage avoidance function is invalid during torque control by real sensorless vector control. When *Pr. 261* = "11 (12)", the inverter operates in the same manner as when "1 (2)" is set in *Pr. 261*.

WWW.BSNEW.IR

(6) Power failure deceleration signal (Y46 signal)

- After deceleration at an instantaneous power failure, inverter can not start even if the start command is given. In this case, check the power failure deceleration signal (Y46 signal). (at occurrence of input phase failure protection (E.ILF), etc.)
- The Y46 signal is on during deceleration at an instantaneous power failure or during a stop after deceleration at an instantaneous power failure.
- For the Y46 signal, set "46 (positive logic)" or "146 (negative logic)" in any of *Pr. 190 to Pr. 196 (output terminal function selection)* to assign the function.

REMARKS

When *Pr. 872* = "1" (input phase failure protection provided) and *Pr. 261* ≠ "0" (power failure stop function valid), input phase failure protection (E.ILF) is not provided but power-failure deceleration is made.

CAUTION

- When *Pr. 30 Regenerative function selection* = "2" (FR-HC, MT-HC, FR-CV is used), the power failure deceleration function is invalid.
- When the (output frequency - *Pr. 262*) at undervoltage or power failure occurrence is negative, the calculation result is regarded as 0Hz. (DC injection brake operation is performed without deceleration).
- During a stop or error, the power failure stop selection is not performed.
- Changing the terminal assignment using *Pr. 190 to Pr. 196 (output terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

⚠ CAUTION

⚠ If power-failure deceleration operation is set, some loads may cause the inverter to trip and the motor to coast. The motor will coast if enough regenerative energy is given from the motor.

♦ Parameters referred to ♦

Pr. 12 DC injection brake operation voltage ☞ *Refer to page 200*
Pr. 20 Acceleration/deceleration reference frequency, Pr. 21 Acceleration/deceleration time increments ☞ *Refer to page 173*
Pr. 30 Regenerative function selection ☞ *Refer to page 204*
Pr. 57 Restart coasting time ☞ *Refer to page 261*
Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*
Pr. 872 Input phase failure protection selection ☞ *Refer to page 271*

WWW.BSNEW.IR

4.18 Operation setting at alarm occurrence


Purpose	Parameter that must be Set		Refer to Page
Recover by retry operation at alarm occurrence	**Retry operatoin**	**Pr. 65, Pr. 67 to Pr. 69**	268
Output alarm code from terminal	**Alarm code output function**	**Pr. 76**	270
Do not output input/output phase failure alarm	**Input/output phase failure protection selection**	**Pr. 251, Pr. 872**	271
The motor is decelerated to stop at motor thermal activation	**Fault definition**	**Pr. 875**	272

4.18.1 Retry function (Pr. 65, Pr. 67 to Pr. 69)


If an alarm occurs, the inverter resets itself automatically to restart. You can also select the alarm description for a retry.
When automatic restart after instantaneous power failure is selected (*Pr. 57 Restart coasting time* ≠ "9999"), restart operation is performed at retry operation as at an instantaneous power failure. (Refer to *page 261* for the restart function.)

Parameter Number	Name	Initial Value	Setting Range	Description
65	**Retry selection**	0	0 to 5	An alarm for retry can be selected. *(Refer to the next page)*
67	**Number of retries at alarm occurrence**	0	0	No retry function
			1 to 10	Set the number of retries at alarm occurrence. An alarm output is not provided during retry operation.
			101 to 110	Set the number of retries at alarm occurrence. (The setting value of minus 100 is the number of retries.) An alarm output is provided during retry operation.
68	**Retry waiting time**	1s	0 to 10s	Set the waiting time from when an inverter alarm occurs until a retry is made.
69	**Retry count display erase**	0	0	Clear the number of restarts succeeded by retry.

Retry success example



Retry failure example



- Retry operation automatically resets an alarm and restarts the inverter at the starting frequency when the time set in *Pr. 68* elapses after the inverter stopped due to the alarm.
- Retry operation is performed by setting *Pr. 67* to any value other than "0". Set the number of retries at alarm occurrence in *Pr. 67*.
- When retries fail consecutively more than the number of times set in *Pr. 67* , a retry count excess alarm (E.RET) occurs, stopping the inverter output. (Refer to retry failure example)
- Use *Pr. 68* to set the waiting time from when an inverter alarm occurs until a retry is made in the range 0 to 10s. (When the setting value is "0s", the actual time is 0.1s.)
- Reading the *Pr. 69* value provides the cumulative number of successful restart times made by retry. The cumulative count in *Pr. 69* is increased by 1 when a retry is regarded as successful after normal operation continues without alarms occurring for more than four times longer than the time set in *Pr. 68* after a retry start.
- Writing "0" in *Pr. 69* clears the cumulative count.
- During a retry, the Y64 signal is on. For the Y64 signal, assign the function by setting "64 (positive logic)" or "164 (negative logic)" in any of *Pr. 190 to Pr. 196 (output terminal function selection)* .

CAUTION

When terminal assignment is changed using *Pr. 190 to Pr. 196*, the other functions may be affected. Please make setting after confirming the function of each terminal.

WWW.BSNEW.IR

· Using *Pr. 65* you can select the alarm that will cause a retry to be executed. No retry will be made for the alarm not indicated. (Refer to *page 400* for the alarm description.)
● indicates the errors selected for retry.

Alarm Display for Retry	*Pr. 65* Setting					
	0	1	2	3	4	5
E.OC1	●	●		●	●	●
E.OC2	●	●		●	●	
E.OC3	●	●		●	●	●
E.OV1	●		●	●	●	
E.OV2	●		●	●	●	
E.OV3	●		●	●	●	
E.THM	●					
E.THT	●					
E.IPF	●				●	
E.UVT	●				●	
E. BE	●				●	
E. GF	●				●	
E.OHT	●					
E.OLT	●				●	
E.OPT	●				●	
E.OP3	●				●	

Alarm Display for Retry	*Pr. 65* Setting					
	0	1	2	3	4	5
E. PE	●				●	
E.MB1	●				●	
E.MB2	●				●	
E.MB3	●				●	
E.MB4	●				●	
E.MB5	●				●	
E.MB6	●				●	
E.MB7	●				●	
E.OS	●				●	
E.OSD	●				●	
E.OD	●				●	
E.PTC	●					
E.CDO	●				●	
E.SER	●				●	
E.ILF	●				●	

CAUTION

· For a retry error, only the description of the first alarm is stored.
· When an inverter alarm is reset by the retry function at the retry time, the accumulated data of the electronic thermal relay function, regeneration converter duty etc. are not cleared. (Different from the power-on reset.)

⚠ CAUTION

⚠ When you have selected the retry function, stay away from the motor and machine unless required. They will start suddenly (after the reset time has elapsed) after occurrence of an alarm.
When you have selected the retry function, apply in easily visible places the CAUTION stickers supplied to the installation guideline.

♦ Parameters referred to ♦

Pr. 57 Restart coasting time ☞ *Refer to page 261*

WWW.BSNEW.IR

4.18.2 Alarm code output selection (Pr. 76)

At alarm occurrence, its description can be output as a 4-bit digital signal from the open collector output terminals.The alarm code can be read by a programmable controller, etc., and its corrective action can be shown on a display, etc.

Parameter Number	Name	Initial Value	Setting Range	Description
76	Alarm code output selection	0	0	Without alarm code output
			1	With alarm code output *(Refer to the following table)*
			2	Alarm code output at alarm occurrence only *(Refer to the following table)*

- By setting *Pr. 76* to "1" or "2", the alarm code can be output to the output terminals.
- When the setting is "2", an alarm code is output at only alarm occurrence, and during normal operation, the terminals output the signals assigned to *Pr. 190 to Pr. 196 (output terminal function selection)*.
- The following table indicates alarm codes to be output. (0: output transistor off, 1: output transistor on)

Operation Panel Indication (FR-DU07)	Output of Output Terminals				Alarm Code
	SU	IPF	OL	FU	
Normal *	0	0	0	0	0
E.OC1	0	0	0	1	1
E.OC2	0	0	1	0	2
E.OC3	0	0	1	1	3
E.OV1 to E.OV3	0	1	0	0	4
E.THM	0	1	0	1	5
E.THT	0	1	1	0	6
E.IPF	0	1	1	1	7
E.UVT	1	0	0	0	8
E.FIN	1	0	0	1	9
E. BE	1	0	1	0	A
E. GF	1	0	1	1	B
E.OHT	1	1	0	0	C
E.OLT	1	1	0	1	D
E.OPT	1	1	1	0	E
E.OP3	1	1	1	0	E
Other than the above	1	1	1	1	F

* When *Pr. 76* = "2", the output terminals output the signals assigned to *Pr. 190 to Pr. 196* .

CAUTION

- When a value other than "0" is set in *Pr. 76*
  When an alarm occurs, the output terminals SU, IPF, OL, FU output the signal in the above table, independently of the *Pr. 190 to Pr. 196 (output terminal function selection)* settings. Please be careful when inverter control setting has been made with the output signals of *Pr. 190 to Pr. 196*.

♦ Parameters referred to ♦

Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*

WWW.BSNEW.IR

4.18.3 Input/output phase failure protection selection (Pr. 251, Pr. 872)

You can disable the output phase failure protection function that stops the inverter output if one of the inverter output side (load side) three phases (U, V, W) opens.
The input phase failure protection function of the inverter input side (R/L1, S/L2, T/L3) can be made valid.

Parameter Number	Name	Initial Value	Setting Range	Description
251	Output phase failure protection selection	1	0	Without output phase failure protection
			1	With output phase failure protection
872	Input phase failure protection selection	0	0	Without input phase failure protection
			1	With input phase failure protection

(1) Output phase failure protection selection *(Pr. 251)*

· When *Pr. 251* is set to "0", output phase failure protection (E.LF) becomes invalid.

(2) Input phase failure protection selection *(Pr. 872)*

· When *Pr. 872* is set to "1", input phase failure protection (E.ILF) is provided if a phase failure of one phase among the three phases is detected for 1s continuously.

REMARKS

If an input phase failure has occurred when *Pr. 872* = "1" (input phase failure protected) and a value other than "0" (power failure stop function valid) is set in *Pr. 261*, input phase failure protection (E.ILF) is not provided but power-failure deceleration is made.

CAUTION


· When an input phase failure occurs in the R/L1 and S/L2 phases, input phase failure protection is not provided but the inverter output is shut off.
· If an input phase failure continues for a long time, the converter section and capacitor lives of the inverter will be shorter.

♦ **Parameters referred to** ♦

Pr. 261 Power failure stop selection ☞ *Refer to page 265*

4.18.4 Overspeed detection (Pr. 374)

Parameter Number	Name	Initial Value	Setting Range	Description
374	Overspeed detection level	140Hz	0 to 400Hz	When the motor speed reaches or exceeds the speed set in *Pr. 374* during encoder feedback control, real sensorless vector control, or vector control, over speed (E.OS) occurs and stops the inverter output.



* The output frequency and *Pr. 374* are compared during real sensorless vector control.

4.18.5 Encoder signal loss detection (Pr. 376) V/F Vector

When the encoder signal is lost during encoder feedback control, orientation control, or vector control, signal loss detection (E.ECT) is activated to stop the inverter output.

Parameter Number	Name	Initial Value	Setting Range	Description
376	Encoder signal loss detection enable/disable selection	0	0	Signal loss detection is invalid
			1	Signal loss detection is valid


* Setting can be made only when the FR-A7AP is mounted.

WWW.BSNEW.IR

4.18.6 Fault definition (Pr. 875)

When motor thermal protection is activated, an alarm can be output after the motor decelerates to a stop.

Parameter Number	Name	Initial Value	Setting Range	Description
875	Fault definition	0	0	Normal operation
			1	The motor decelerates to stop when motor thermal protection is activated.



(1) Output is immediately shutoff at occurrence of any alarm (setting value is "0", initial value)

· Output is immediately shutoff and an alarm output is provided at alarm occurrence.

(2) The motor decelerates to stop when motor thermal protection is activated (setting value is "1")

· When external thermal relay E.OHT (OHT), motor overload shutoff (electronic thermal relay function) E.THM (THM) or PTC thermistor E.PTC (PTC) is activated, turning on the minor fault output 2 signal (ER) starts the motor to decelerate and an alarm is provided after deceleration to a stop.
· When the ER signal turns on, decrease load, etc. to allow the inverter to decelerate.
· At occurrence of an alarm other than OHT, THM and PTC, output is immediately shut off and an alarm is output.
· Set "97 (positive logic) or 197 (negative logic)" in *Pr. 190 to Pr. 196 (output terminal function selection)* and assign the ER signal to the output terminal.
· This function is invalid during position control.

CAUTION

· The value "0" is recommended for the system in which the motor continues running without deceleration due to a large torque on the load side.
· Changing the terminal assignment using *Pr. 190 to Pr. 196 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*

WWW.BSNEW.IR

4.19 Energy saving operation and energy saving monitor

Purpose	Parameter that must be Set		Refer to Page
Energy saving operation	Energy saving operation	Pr. 60	273
How much energy can be saved	Energy saving monitor	Pr. 52, Pr. 54, Pr. 158, Pr. 891 to Pr. 899	274

4.19.1 Energy saving control (Pr. 60) V/F

Without a fine parameter setting, the inverter automatically performs energy saving control.
This inverter is optimum for fan and pump applications.

Parameter Number	Name	Initial Value	Setting Range	Description
60	Energy saving control selection*	0	0	Normal operation mode
			4	Energy saving operation mode

* When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.

Energy saving operation mode (setting "4")

- When "4" is set in *Pr. 60*, the inverter operates in the energy saving operation mode.
- In the energy saving operation mode, the inverter automatically controls the output voltage to minimize the inverter output voltage during a constant operation.

REMARKS

- For applications a large load torque is applied to or machines repeat frequent acceleration/deceleration, an energy saving effect is not expected.

CAUTION

- When the energy saving mode is selected, deceleration time may be longer than the setting value. Since overvoltage alarm tends to occur as compared to the constant torque load characteristics, set a longer deceleration time.
- The energy saving operation mode functions only under V/F control. When the advanced magnetic flux vector control, real sensorless vector control and vector control are selected, the energy saving mode is invalid.
- Since output voltage is controlled in energy saving operation mode, output current may slightly increase.

WWW.BSNEW.IR

4.19.2 Energy saving monitor (Pr. 891 to Pr. 899)

From the power consumption estimated value during commercial power supply operation, the energy saving effect by use of the inverter can be monitored/output.

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
52	**DU/PU main display data selection**	0 (output frequency)	0, 5 to 14, 17 to 20, 22 to 25, 32 to 35, 50 to 57, 100		50:Power saving monitor 51:Cumulative saving power monitor
54	**FM terminal function selection**	1 (output frequency)	1 to 3, 5 to 14, 17, 18, 21, 24, 32 to 34, 50, 52, 53, 70		50:Power saving monitor
158	**AM terminal function selection**				
891	**Cumulative power monitor digit shifted times**	9999	0 to 4		Set the number of times to shift the cumulative power monitor digit Clamp the monitoring value at maximum.
			9999		No shift Clear the monitor value when it exceeds the maximum value.
892	**Load factor**	100%	30 to 150%		Set the load factor for commercial power-supply operation. Multiplied by the power consumption rate *(page 277)* during commercial power supply operation.
893	**Energy saving monitor reference (motor capacity)**	Applied motor capacity	02150 (01100) or less	0.1 to 55kW	Set the motor capacity (pump capacity). Set when calculating power saving rate, power saving rate average value, commercial operation power.
			02880 (01440) or more	0 to 3600kW	
894	**Control selection during commercial power-supply operation**	0	0		Discharge damper control (fan)
			1		Inlet damper control (fan)
			2		Valve control (pump)
			3		Commercial power-supply drive (fixed value)
895	**Power saving rate reference value**	9999	0		Consider the value during commercial power-supply operation as 100%
			1		Consider the *Pr. 893* setting as 100%.
			9999		No function
896	**Power unit cost**	9999	0 to 500		Set the power unit cost. Display the power saving amount charge on the energy saving monitor.
			9999		No function
897	**Power saving monitor average time**	9999	0		Average for 30 minutes
			1 to 1000h		Average for the set time
			9999		No function
898	**Power saving cumulative monitor clear**	9999	0		Cumulative monitor value clear
			1		Cumulative monitor value hold
			10		Totalization continued (communication data upper limit 9999)
			9999		Totalization continued (communication data upper limit 65535)
899	**Operation time rate (estimated value)**	9999	0 to 100%		Use for calculation of annual power saving amount. Set the annual operation ratio (consider 365 days × 24hr as 100%).
			9999		No function

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

WWW.BSNEW.IR

(1) Energy saving monitor list

· The following provides the items that can be monitored by the power saving monitor (*Pr. 52, Pr. 54, Pr. 158* = "50"). (Only 1) power saving and 3) power saving average value can be output to *Pr. 54* (terminal FM) and *Pr. 158* (terminal AM))

	Energy Saving Monitor Item	Description and Formula	Incre-ments	Parameter Setting			
				Pr. 895	*Pr. 896*	*Pr. 897*	*Pr. 899*
1)	**Power saving**	Difference between the estimated value of power necessary for commercial power supply operation and the input power calculated by the inverter **Power during commercial power supply operation − input power monitor**	0.01kW/ 0.1kW *3	9999			
2)	**Power saving rate**	Ratio of power saving on the assumption that power during commercial power supply operation is 100% $\frac{\text{1) Power saving}}{\text{Power during commercial power supply operation}} \times 100$	0.1%	0	—	9999	
		Ratio of power saving on the assumption that *Pr. 893* is 100% $\frac{\text{1) Power saving}}{Pr.\ 893} \times 100$		1			
3)	**Power saving average value**	Average value of power saving amount per hour during predetermined time (*Pr. 897*) $\frac{\Sigma(\text{1) Power saving} \times \Delta t)}{Pr.\ 897}$	0.01kWh /0.1kWh *3	9999	9999	0 to 1000h	—
4)	**Power saving rate average value**	Ratio of power saving average value on the assumption that the value during commercial power supply operation is 100% $\frac{\Sigma(\text{2) Power saving rate} \times \Delta t)}{Pr.\ 897} \times 100$	0.1%	0			
		Ratio of power saving average value on the assumption that *Pr. 893* is 100% $\frac{\text{3) Power saving average value}}{Pr.\ 893} \times 100$		1			
5)	**Power saving amount average value**	Power saving average value represented in terms of charge **3) Power saving average value** × ***Pr. 896***	0.01/0.1 *3	—	0 to 500		

· The following shows the items which can be monitored by the cumulative saving power monitor (*Pr. 52* = "51"). (The monitor value of the cumulative monitor can be shifted to the right with *Pr. 891 Cumulative power monitor digit shifted times*.)

	Energy Saving Monitor Item	Description and Formula	Incre-ments	Parameter Setting			
				Pr. 895	*Pr. 896*	*Pr. 897*	*Pr. 899*
6)	**Power saving amount**	Power saving is added up per hour. $\Sigma(\text{1) Power saving} \times \Delta t)$	0.01kWh /0.1kWh *1*2*3	—	9999	—	9999
7)	**Power saving amount charge**	Power saving amount represented in terms of charge **6) Power saving amount** × ***Pr. 896***	0.01/0.1 *1*3	—	0 to 500		
8)	**Annual power saving amount**	Estimated value of annual power saving amount $\frac{\text{6) Power saving amount}}{\text{Operation time during accumulation of power saving amount}} \times 24 \times 365 \times \frac{Pr.\ 899}{100}$	0.01kWh /0.1kWh *1*2*3	—	9999		0 to 100%
9)	**Annual power saving amount charge**	Annual power saving amount represented in terms of charge **8) Annual power saving amount** × ***Pr. 896***	0.01/0.1 *1*3	—	0 to 500		

*1 For communication (RS-485 communication, communication option), the display increments are 1. For example, the communication data is "10" for "10.00kWh".

*2 When using the parameter unit (FR-PU04/FR-PU07), "kW" is displayed.

*3 The setting depends on capacities. (FR-A720-02150 (FR-A740-01100) or less/FR-A720-02880 (FR-A740-01440) or more)

REMARKS

· As the operation panel (FR-DU07) is 4-digit display, it displays in 0.1 increments since a carry occurs, e.g. "100.0", when a monitor value in 0.01 increments exceeds "99.99". The maximum display is "9999".

· As the operation panel (FR-PU04/FR-PU07) is 5-digit display, it displays in 0.1 increments since a carry occurs, e.g. "1000.0", when a monitor value in 0.01 increments exceeds "999.99". The maximum display is "99999".

· The upper limit of communication (RS-485 communication, communication option) is "65535" when *Pr. 898 Power saving cumulative monitor clear* = "9999". The upper limit of 0.01 increments monitor is "655.35" and that of 0.1 increments monitor is "6553.5".


WWW.BSNEW.IR

(2) Power saving instantaneous monitor (1) power savings, 2) power saving rate)

- On the power saving monitor (1)), an energy saving effect as compared to the power consumption during commercial power supply operation (estimated value) is calculated and displays on the main monitor.
- In the following case, the power saving monitor (1)) is "0".
  (a)Calculated values of the power saving monitor are negative values.
  (b)During the DC injection brake operation
  (c)Motor is not connected (output current monitor is 0A)
- On the power saving rate monitor (2)), setting "0" in *Pr. 895 Power saving rate reference value* displays the power saving rate on the assumption that power (estimated value) during commercial power supply operation is 100%. When *Pr. 895* = "1", the power saving rate on the assumption that the *Pr. 893 Energy saving monitor reference (motor capacity)* value is 100% is displayed.

(3) Power saving average value monitor (3) power saving average value, 4) average power saving rate average value, 5) power saving amount average value)

- Power saving average value monitor can be displayed when a value other than "9999" is set in *Pr. 897 Power saving monitor average time*.
- The power saving average value monitor (3)) displays the average value per unit time of the power saving amount at averaging.
- The average value is updated every time an average time has elapsed after the *Pr. 897* setting is changed, power is turned on or the inverter is reset, assuming as a starting point.The power savings average value update timing signal (Y92) is inverted every time the average value is updated.



- The power saving average value monitor (4)) displays the average value per unit time of power saving rate (2)) at every average time by setting "0" or "1" in *Pr. 895 Power saving rate reference value*.
- By setting the charge (power unit) per 1kWh of power amount in *Pr. 896 Power unit cost*, the power saving amount average value monitor (5)) displays the charge relative to the power saving average value (power saving average value (3)) × *Pr. 896*).

(4) Cumulative saving power monitor (6) power saving amount, 7) power saving amount charge, 8) annual power saving amount, 9) annual power saving amount charge)

- On the cumulative saving power monitor, the monitor data digit can be shifted to the right by the number of *Pr. 891 Cumulative power monitor digit shifted times* settings. For example, if the cumulative power value is 1278.56kWh when *Pr. 891* = "2", the PU/DU display is 12.78 (display in 100kWh increments) and the communication data is 12. If the maximum value is exceeded at *Pr. 891* = "0 to 4", the power is clamped at the maximum value, indicating that a digit shift is necessary. If the maximum value is exceeded at *Pr. 891* = "9999", the power returns to 0 and is recounted. The other monitors are clamped at the display maximum value.
- The cumulative saving power monitor (6)) can measure the power amount during a predetermined period. Measure according to the following steps
  1) Write "9999" or "10" in *Pr. 898 Power saving cumulative monitor clear*.
  2) Write "0" in *Pr. 898* at measurement start timing to clear the cumulative saving power monitor value and start totalization of power saving.
  3) Write "1" in *Pr. 898* at measurement end timing to hold the cumulative saving power monitor value.


REMARKS

- The cumulative saving power monitor value is stored every hour. Hence, when the power supply is switched on again within one hour after it was switched off, the previously stored monitor value is displayed and totalization starts. (The cumulative monitor value may decrease)

WWW.BSNEW.IR

(5) Power estimated value of commercial power supply operation *(Pr. 892, Pr. 893, Pr. 894)*

- Select the commercial power supply operation pattern from among the four patterns of discharge damper control (fan), inlet damper control (fan), valve control (pump) and commercial power supply drive, and set it to *Pr. 894 Control selection during commercial power-supply operation*.
- Set the motor capacity (pump capacity) in *Pr. 893 Energy saving monitor reference (motor capacity)*.
- The power consumption rate (%) during commercial power supply operation is estimated from the operation pattern and the ratio of speed to rating (current output frequency/*Pr. 3 Base frequency*) in the following chart.



- From the motor capacity set in *Pr. 893* and *Pr. 892 Load factor*, the power estimated value (kW) during commercial power supply operation is found by the following formula.

Power estimated value (kW) during commercial power supply operation

$$= Pr.\ 893\ (\text{kW}) \times \frac{\text{Power consumption (\%)}}{100} \times \frac{Pr.\ 892\ (\%)}{100}$$

REMARKS

- Since the speed does not increase above the power supply frequency in commercial power supply operation, it becomes constant when the output frequency rises to or above *Pr. 3 Base frequency*.

WWW.BSNEW.IR

(6) Annual power saving amount, power charge *(Pr. 899)*

- By setting the operation time rate [%] (ratio of time when the motor is actually driven by the inverter during a year) in *Pr. 899*, the annual energy saving effect can be predicted.
- When the operation pattern is predetermined to some degree, the estimated value of the annual power saving amount can be found by measurement of the power saving amount during a given measurement period.
- Refer to the following and set the operation time rate.
  1) Predict the average time [h/day] of operation in a day.
  2) Find the annual operation days [days/year]. (Monthly average operation days × 12 months)
  3) Calculate the annual operation time [h/year] from 1) and 2).

Annual operation time (h/year) = Average time (h/day) × Operation days (days/year)

  4) Calculate the operation time rate and set it to *Pr. 899*.

$$\text{Operation time rate (\%)} = \frac{\text{Annual operation time (h/year)}}{\text{24 (h/day)} \times \text{365 (days/year)}} \times 100(\%)$$

REMARKS

- Operation time rate setting example: When operation is performed for about 21 hours per day and the monthly average operation days are 16 days
  Annual operation time = 21 (h/day) × 16 (days/month) × 12 months = 4032 (h/year)
  Operation time rate (%) = $\frac{4032 \text{ (h/year)}}{24 \text{ (h/day)} \times 365 \text{ (days/year)}} \times 100(\%) = 46.03\%$
  Set 46.03% to *Pr. 899*.

- Calculate the annual power saving amount from *Pr. 899 Operation time rate (estimated value)* and power saving average value monitor

$$\text{Annual power saving amount (kWh/year)} = \text{Power saving average value (kW) during totalization when } Pr.\ 898 = 10 \text{ or } 9999 \times 24\text{h} \times 365 \text{ days} \times \frac{Pr.\ 899}{100}$$

- The annual power saving amount charge can be monitored by setting the power charge per hour in *Pr. 896 Power unit cost*.
  Calculate the annual power saving amount charge in the following method.

Annual power saving amount charge = Annual power saving amount (kWh/year) × *Pr. 896*

REMARKS

In the regeneration mode, make calculation on the assumption that "power saving = power during commercial power supply operation (input power = 0)".

♦ Parameters referred to ♦

Pr. 3 Base frequency ☞ *Refer to page 159*
Pr. 52 DU/PU main display data selection ☞ *Refer to page 250*
Pr. 54 FM terminal function selection ☞ *Refer to page 250*
Pr. 158 AM terminal function selection ☞ *Refer to page 250*

WWW.BSNEW.IR

4.20 Motor noise, noise reduction

4.20.1 PWM carrier frequency and Soft-PWM control (Pr. 72, Pr. 240, Pr. 260)

You can change the motor sound.

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
72 *1	PWM frequency selection	2	02150(01100) or less	0 to 15	PWM carrier frequency can be changed. The setting displayed is in [kHz]. Note that 0 indicates 0.7kHz, 15 indicates 14.5kHz and 25 indicates 2.5kHz.
			02880(01440) or more	0 to 6, 25	
240 *1	Soft-PWM operation selection	1	0		Soft-PWM is invalid
			1		When *Pr. 72* = "0 to 5" ("0 to 4" for FR-A720-02880 (FR-A740-01440) or more), soft-PWM is valid.
260 *2	PWM frequency automatic switchover	1	0		PWM carrier frequency is constant independently of load. When the carrier frequency is set to 3kHz or more (*Pr. 72* ≥ "3"), perform continuous operation at less than 85% of the rated inverter current.
			1		Decreases PWM carrier frequency automatically when load increases.

*1 The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

*2 Reading and writing are enabled when "0 (SLD) or 1 (LD)" is set in *Pr. 570*.

(1) PWM carrier frequency changing *(Pr. 72)*

- You can change the PWM carrier frequency of the inverter.
- Changing the PWM carrier frequency produces an effect on avoiding the resonance frequency of a mechanical system or motor or on reducing noise or leakage current generated from the inverter.
- Carrier frequencies under real sensorless vector control or vector control are as shown below.

Pr. 72 Setting 200V class (400V class)		Carrier Frequencies (kHz)
FR-A720-02150 (FR-A740-01100) or less	FR-A720-02880 (FR-A740-01440) or more	
0 to 5	0 to 5	2
6 to 9	6	6
10 to 13	—	10
14, 15	—	14

- When using an option sine wave filter (MT-BSL/BSC) for the FR-A720-02880 (FR-A740-01440) or more, set "25" in *Pr. 72* (2.5kHz).

REMARKS

When "25" (available with the FR-A720-02880 (FR-A740-01440) or more) is set in *Pr. 72*, V/F control is forcibly selected.

WWW.BSNEW.IR

(2) Soft-PWM control *(Pr. 240)*

· Soft-PWM control is a control method that changes the motor noise from a metallic tone into an unoffending complex tone.

(3) PWM carrier frequency automatic reduction function *(Pr. 260)*

For PWM carrier frequency automatic reduction function, the following should be noted.

Multiple rating (*Pr. 570*)		PWM carrier frequency automatic reduction
0	SLD	valid
1	LD	*Pr. 260* = "0" : invalid *Pr. 260* = "1" (initial setting) : valid
2 (initial setting)	ND	invalid
3	HD	invalid

· When continuous operation is performed at 85% or more of the inverter rated current (the parenthesized value of the rated output current on *page 432* or more) with the carrier frequency of the inverter set to 3kHz or more (*Pr. 72* ≥ "3"), the carrier frequency is automatically reduced to 2kHz to protect the output transistor of the inverter. (Motor noise increases, but it is not a failure)

· When *Pr. 260* is set to"0", the carrier frequency becomes constant (*Pr. 72* setting) independently of the load, making the motor sound uniform.
Note that continuous operation should be performed at less than 85% of the inverter rating.

CAUTION

· Decreasing the PWM carrier frequency reduces inverter-generated noise and leakage current, but increases motor noise.

· When PWM carrier frequency is set to 1kHz or less (*Pr. 72* ≤ 1), fast response current limit may function prior to stall prevention operation due to increase in harmonic currents depending on the motor, resulting in insufficient torque. In such case, set fast response current limit operation invalid using *Pr. 156 Stall prevention operation selection*.

♦ Parameters referred to ♦

Pr. 156 Stall prevention operation selection ☞ *Refer to page 150*
Pr. 570 Multiple rating setting ☞ *Refer to page 155*

WWW.BSNEW.IR

4.21 Frequency/torque setting by analog input (terminal 1, 2, 4)

Purpose	Parameter that must be Set		Refer to Page
Function assignment of analog input terminal	**Terminal 1 and terminal 4 function assignment**	**Pr. 858, Pr. 868**	281
Selection of voltage/current input (terminal 1, 2, 4) Perform forward/ reverse rotation by analog input	**Analog input selection**	**Pr. 73, Pr. 267**	282
Adjust the main speed by analog auxiliary input	**Analog auxliary input and compensation (added compensation and override function)**	**Pr. 73, Pr. 242, Pr. 243, Pr. 252, Pr. 253**	285
Noise elimination at the analog input	**Input filter**	**Pr. 74, Pr. 822, Pr. 826, Pr. 832, Pr. 836, Pr. 849**	287
Adjustment (calibration) of analog input frequency and voltage (current)	**Bias and gain of frequency setting voltage (current)**	**Pr. 125, Pr. 126, Pr. 241, C2 to C7 (Pr. 902 to Pr. 905) C12 to C15 (Pr. 917 to Pr. 918)**	289
Adjustment (calibration) of analog input torque and voltage (current)	**Bias and gain of torque setting voltage (current)**	**Pr. 241, C16 to C19 (Pr. 919 to Pr. 920), C38 to C41 (Pr. 932 to Pr. 933)**	295
Analog input (current) status check	**4mA input check**	**Pr. 573**	300

4.21.1 Function assignment of analog input terminal (Pr. 858, Pr. 868)

Function assignment of terminal 1 and terminal 4 of analog input can be selected and changed by parameter.

Parameter Number	Name	Initial Value	Setting Range	Description
858	**Terminal 4 function assignment**	0	0, 1, 4, 9999	Select the terminal 4 function. (Refer to the following list)
868	**Terminal 1 function assignment**	0	0 to 6, 9999	Select the terminal 1 function. (Refer to the following list)

· For the terminal 1 and terminal 4 used for analog input, frequency (speed) command, magnetic flux command, torque command, etc. can be selected.
Functions change according to the control mode as in the table below.

●Terminal 1 function according to control

Pr. 868 Setting	V/F Control, Advanced Magnetic Flux Vector Control	Real Sensorless Vector Control, Vector Control		Vector Control
		Speed control	Torque control	Position control
0 (Initial value)	Frequency setting auxiliary	Speed setting auxiliary	Speed limit auxiliary	—
1	—	Magnetic flux command	Magnetic flux command	Magnetic flux command
2	—	Regenerative torque limit (*Pr. 810* = 1)	—	Regenerative torque limit (*Pr. 810* = 1)
3	—	—	Torque command (*Pr. 804* = 0)	—
4	Stall prevention operation level input (*Pr. 810* = 1)	Torque limit (*Pr. 810* = 1)	Torque command (*Pr. 804* = 0)	Torque limit (*Pr. 810* = 1)
5	—	—	Forward/reverse rotation speed limit (*Pr. 807* = 2)	—
6	—	Torque bias input (*Pr. 840* = 1, 2, 3)	—	—
9999	—	—	—	—

●Terminal 4 function according to control

Pr. 858 Setting	V/F Control, Advanced Magnetic Flux Vector Control	Real Sensorless Vector Control, Vector Control		Vector Control
		Speed control	Torque control	Position control
0 (Initial value)	Frequency command (AU signal-ON)	Speed command (AU signal-ON)	Speed limit (AU signal-ON)	—
1	—	Magnetic flux command	Magnetic flux command	Magnetic flux command
4	Stall prevention operation level input (*Pr. 810* = 1)	Torque limit (*Pr. 810* = 1)	—	Torque limit (*Pr. 810* = 1)
9999	—	—	—	—

— :No function

WWW.BSNEW.IR

REMARKS

- When "1 or 4" is set in both *Pr. 868* and *Pr. 858*, terminal 1 is made valid and terminal 4 has no function.
- When "1" (magnetic flux), "4" (stall prevention/torque limit) is set in *Pr. 868*, functions of terminal 4 become valid independently of whether the AU terminal is on or off.

♦ Parameters referred to ♦

Advanced magnetic flux vector control ☞ *Refer to page 145*
Real sensorless vector control ☞ *Refer to page 92*
Pr. 804 Torque command source selection ☞ *Refer to page 122*
Pr. 807 Speed limit selection ☞ *Refer to page 124*
Pr. 810 Torque limit input method selection ☞ *Refer to page 99*


4.21.2 Analog input selection (Pr. 73, Pr. 267)

You can select the function that switches between forward rotation and reverse rotation according to the analog input terminal selection specifications, the override function and the input signal polarity.

Parameter Number	Name	Initial Value	Setting Range	Description: Voltage/current input switch	Description
73	Analog input selection	1	0 to 5, 10 to 15	Switch 2 - OFF (initial status)	You can select the input specifications of terminal 2 (0 to 5V, 0 to 10V, 0 to 20mA) and input specifications of terminal 1 (0 to ±5V, 0 to ±10V). Override and reversible operation can be selected.
			6, 7, 16, 17	Switch 2 - ON	
267	Terminal 4 input selection	0	0	Switch 1 - ON (initial status)	Terminal 4 input 0 to 20mA
			1	Switch 1 - OFF	Terminal 4 input 0 to 5V
			2		Terminal 4 input 0 to 10V

(1) Selection of analog input specifications

- For the terminals 2, 4 used for analog input, voltage input (0 to 5V, 0 to 10V) or current input (0 to 20mA) can be selected.
  Change parameters (*Pr. 73, Pr. 267*) and a voltage/current input switch (switch 1, 2) to change input specifications.



Switch 1:Terminal 4 input
ON: Current input (initial status)
OFF: Voltage input

Switch 2: Terminal 2 input
ON: Current input
OFF: Voltage input (initial status)

- Rated specifications of terminal 2 and 4 change according to the voltage/current input switch setting.
  Voltage input: Input resistance 10kΩ ± 1kΩ, Maximum permissible voltage 20VDC
  Current input: Input resistance 245Ω ± 5Ω, Maximum permissible current 30mA

CAUTION

- Set *Pr. 73*, *Pr. 267*, and a voltage/current input switch correctly, then input an analog signal in accordance with the setting. Incorrect setting as in the table below could cause component damage. Incorrect settings other than below can cause abnormal operation.

Setting Causing Component Damage		Operation
Switch setting	Terminal input	
ON (Current input)	Voltage input	This could cause component damage to the analog signal output circuit of signal output devices. (electrical load in the analog signal output circuit of signal output devices increases)
OFF (Voltage input)	Current input	This could cause component damage of the inverter signal input circuit . (output power in the analog signal output circuit of signal output devices increases)

WWW.BSNEW.IR

· Refer to the following table and set *Pr. 73* and *Pr. 267*. (indicates the main speed setting)

Pr. 73 Setting	Terminal 2 Input	Terminal 1 Input	Terminal 4 Input: AU signal	Terminal 4 Input	*Pr. 73* Setting	Compensation Input Terminal and Compensation Method	Polarity Reversible
0	0 to 10V	0 to ±10V	Off	—	0	Terminal 1 Added compensation	No (Indicates that a frequency command signal of negative polarity is not accepted.)
1 (initial value)	0 to to 5V	0 to ±10V			1 (initial value)		
2	0 to 10V	0 to ±5V			2		
3	0 to 5V	0 to ±5V			3		
4	0 to 10V	0 to ±10V			4	Terminal 2 Override	
5	0 to 5V	0 to ±5V			5		
6	0 to 20mA	0 to ±10V			6	Terminal 1 Added compensation	Yes
7	0 to 20mA	0 to ±5V			7		
10	0 to 10V	0 to ±10V			10		
11	0 to 5V	0 to ±10V			11		
12	0 to 10V	0 to ±5V			12		
13	0 to 5V	0 to ±5V			13		
14	0 to 10V	0 to ±10V			14	Terminal 2 Override	
15	0 to 5V	0 to ±5V			15		
16	0 to 20mA	0 to ±10V			16	Terminal 1 Added compensation	
17	0 to 20mA	0 to ±5V			17		
0	—	0 to ±10V	On	According to *Pr. 267* setting 0: 4 to 20mA (initial value) 1: 0 to 5V 2: 0 to 10V	0	Terminal 1 Added compensation	No (Indicates that a frequency command signal of negative polarity is not accepted.)
1 (initial value)		0 to ±10V			1 (initial value)		
2		0 to ±5V			2		
3		0 to ±5V			3		
4	0 to 10V	—			4	Terminal 2 Override	
5	0 to 5V				5		
6	—	0 to ±10V			6	Terminal 1 Added compensation	Yes
7		0 to ±5V			7		
10	—	0 to ±10V			10		
11		0 to ±10V			11		
12		0 to ±5V			12		
13		0 to ±5V			13		
14	0 to 10V	—			14	Terminal 2 Override	
15	0 to 5V				15		
16	—	0 to ±10V			16	Terminal 1 Added compensation	
17		0 to ±5V			17		

— : Invaild

· Set the voltage/current input switch referring to the table below.

Terminal 2 Input Specifications	*Pr. 73* Setting	Switch 2
Voltage input (0 to 10V)	0, 2, 4, 10, 12, 14	OFF
Voltage input (0 to 5V)	1 (initial value), 3, 5, 11, 13, 15	OFF
Current input (0 to 20mA)	6, 7, 16, 17	ON


Terminal 4 Input Specifications	*Pr. 267* Setting	Switch 1
Voltage input (0 to 10V)	2	OFF
Voltage input (0 to 5V)	1	OFF
Current input (4 to 20mA)	0 (initial value)	ON

indicates an initial value.


CAUTION

- Turn the AU signal on to make terminal 4 valid.
- Match the setting of parameter and switch. A different setting may cause a fault, failure or malfunction.
- The terminal 1 (frequency setting auxiliary input) signal is added to the main speed setting signal of the terminal 2 or 4.
- When an override is selected, the terminal 1 or 4 is used for the main speed setting and the terminal 2 for the override signal (50% to 150% at 0 to 5V or 0 to 10V). (When the main speed of the terminal 1 or terminal 4 is not input, compensation by the terminal 2 is made invalid.))
- Use *Pr. 125 (Pr. 126) (frequency setting gain)* to change the maximum output frequency at input of the maximum output frequency command voltage (current). At this time, the command voltage (current) need not be input.
  Also, the acceleration/deceleration time, which is a slope up/down to the acceleration/deceleration reference frequency, is not affected by the change in *Pr. 73* setting.
- When *Pr. 858 Terminal 4 function assignment, Pr. 868 Terminal 1 function assignment* = "4", the value of the terminal 1 or terminal 4 is as set to the stall prevention operation level. When terminal 1 and terminal 4 are used for frequency setting, set "0" (initial value) in *Pr. 858* and *Pr. 868*.

WWW.BSNEW.IR



Connection diagram using terminal 2 (0 to 5VDC)



Connection diagram using terminal 2 (0 to 10VDC)

(2) Perform operation by analog input voltage


- The frequency setting signal inputs 0 to 5VDC (or 0 to 10VDC) to across the terminals 2-5. The 5V (10V) input is the maximum output frequency. The maximum output frequency is reached when 5V (10V) is input.
- The power supply 5V (10V) can be input by either using the internal power supply or preparing an external power supply. The internal power supply outputs 5VDC across terminals 10-5, or 10V across terminals 10E-5.

Terminal	Inverter Built-in Power Supply Voltage	Frequency Setting Resolution	*Pr. 73* (terminal 2 input voltage)
10	5VDC	0.030Hz/60Hz	0 to 5VDC input
10E	10VDC	0.015Hz/60Hz	0 to 10VDC input

- When inputting 10VDC to the terminal 2, set any of "0, 2, 4, 10, 12, 14" in *Pr. 73*. (The initial value is 0 to 5V)
- Setting "1 (0 to 5VDC)" or "2 (0 to 10VDC)" in *Pr. 267* and a voltage/current input switch in the OFF position changes the terminal 4 to the voltage input specification. When the AU signal turns on, the terminal 4 input becomes valid.

REMARKS


The wiring length of the terminal 10, 2, 5 should be 30m (98.4 feet) maximum.



Connection diagram using terminal 4 (4 to 20mADC)

(3) Perform operation by analog input current

- When the pressure or temperature is controlled constant by a fan, pump, etc., automatic operation can be performed by inputting the output signal 0 to 20mADC of the adjuster to across the terminals 4-5.
- The AU signal must be turned on to use the terminal 4.
- Setting any of "6, 7, 16, 17" in *Pr. 73* and a voltage/current input switch in the ON position changes the terminal 2 to the current input specification. At this time, the AU signal need not be turned on.



Compensation input characteristic when STF is on

(4) Perform forward/reverse rotation by analog input (polarity reversible operation)

- Setting any of "10 to 17" in *Pr. 73* enables polarity reversible operation.
- Providing ± input (0 to ±5V or 0 to ±10V) to the terminal 1 enables forward/reverse rotation operation according to the polarity.

♦ Parameters referred to ♦

Pr. 22 Stall prevention operation level ☞ *Refer to page 150*
Pr. 125 Terminal 2 frequency setting gain frequency, Pr. 126 Terminal 4 frequency setting gain frequency ☞ *Refer to page 289*
Pr. 252, Pr. 253 Override bias/gain ☞ *Refer to page 285*
Pr. 858 Terminal 4 function assignment, Pr. 868 Terminal 1 function assignment ☞ *Refer to page 281*


WWW.BSNEW.IR

4.21.3 Analog input compensation (Pr. 73, Pr. 242, Pr. 243, Pr. 252, Pr. 253)

A fixed ratio of analog compensation (override) can be made by the added compensation or terminal 2 as an auxiliary input for multi-speed operation or the speed setting signal (main speed) of the terminal 2 or terminal 4.

Parameter Number	Name	Initial Value	Setting Range	Description
73	Analog input selection	1	0 to 3, 6, 7, 10 to 13, 16, 17	Added compensation
			4, 5, 14, 15	Override compensation
242	Terminal 1 added compensation amount (terminal 2)	100%	0 to 100%	Set the ratio of added compensation amount when terminal 2 is the main speed.
243	Terminal 1 added compensation amount (terminal 4)	75%	0 to 100%	Set the ratio of added compensation amount when terminal 4 is the main speed.
252	Override bias	50%	0 to 200%	Set the bias side compensation value of override function.
253	Override gain	150%	0 to 200%	Set the gain side compensation value of override function.

(1) Added compensation *(Pr. 242, Pr. 243)*



Added compensation connection example


- The compensation signal can be input for the main speed setting for synchronous/continuous speed control operation, etc.
- Setting any of "0 to 3, 6, 7, 10 to 13, 16, 17" in *Pr. 73* adds the voltage across terminals 1-5 to the voltage signal across terminals 2-5.
- If the result of addition is negative, it is regarded as 0 at the *Pr. 73* setting of any of "0 to 3, 6, 7", or reverse rotation operation (polarity reversible operation) is performed when the STF signal turns on at the *Pr. 73* setting of any of "10 to 13, 16, 17".
- The compensation input of the terminal 1 can also be added to the multi-speed setting or terminal 4 (initial value 4 to 20mA).
- The added compensation for terminal 2 can be adjusted by *Pr. 242*, and the compensation for terminal 4 by *Pr. 243*.

Analog command value using terminal 2

$$= \text{Terminal 2 input} + \text{Terminal 1 input} \times \frac{Pr.\ 242}{100(\%)}$$

Analog command value using terminal 4

$$= \text{Terminal 4 input} + \text{Terminal 1 input} \times \frac{Pr.\ 243}{100(\%)}$$



(a) When *Pr. 73* setting is 0 to 5 (b) When *Pr. 73* setting is 10 to 15


Auxiliary input characteristics

CAUTION

- When the *Pr. 73* setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (*Refer to page 282* for setting.)

WWW.BSNEW.IR

(2) Override function *(Pr. 252, Pr. 253)*




Override connection diagram


- Use the override function to change the main speed at a fixed ratio.
- Set any of "4, 5, 14, 15" in *Pr. 73* to select an override.
- When an override is selected, the terminal 1 or terminal 4 is used for the main speed setting and the terminal 2 for the override signal. (When the main speed of the terminal 1 or terminal 4 is not input, compensation made by the terminal 2 becomes invalid.)
- Using *Pr. 252* and *Pr. 253*, set the override range.
- How to find the set frequency for override

$$\text{Set frequency (Hz)} = \text{Main speed set frequency (Hz)} \times \frac{\text{Compensation amount (\%)}}{100(\%)}$$

Main speed set frequency (Hz): Terminal 1, 4 input, multi-speed setting
Compensation amount (%): Terminal 2 input



Example)When *Pr. 73* = "5"
The set frequency changes as shown below according to the terminal 1 (main speed) and terminal 2 (auxiliary) inputs.



CAUTION

- When the *Pr. 73* setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (*Refer to page 282* for setting.)

REMARKS

- The AU signal must be turned on to use the terminal 4.
- When inputting compensation to multi-speed operation or remote setting, set "1" (compensation made) in *Pr. 28 Multi-speed input compensation selection*. (Initial value is "0")

♦ Parameters referred to ♦

Pr. 28 Multi-speed input compensation selection ☞ *Refer to page 170*
Pr. 73 Analog input selection ☞ *Refer to page 282*


WWW.BSNEW.IR

4.21.4 Response level of analog input and noise elimination (Pr. 74, Pr. 822, Pr. 826, Pr. 832, Pr. 836, Pr. 849)

Response level and stability of frequency reference command and torque reference command by analog input (terminal 1, 2, 4) signal can be adjusted.

Parameter Number	Name	Initial Value	Setting Range	Description
74	**Input filter time constant**	1	0 to 8	The primary delay filter time constant for the analog input can be set. A larger setting results in slower response.
822	**Speed setting filter 1**	9999	0 to 5s	Set the time constant of the primary delay filter relative to the external speed command (analog input command).
			9999	*Pr. 74* used
826	**Torque setting filter 1**	9999	0 to 5s	Set the time constant of the primary delay filter relative to the external torque command (analog input command).
			9999	*Pr. 74* used
832	**Speed setting filter 2**	9999	0 to 5s, 9999	Second function of *Pr. 822* (valid when RT terminal is on)
836	**Torque setting filter 2**	9999	0 to 5s, 9999	Second function of *Pr. 826* (valid when RT terminal is on)
849	**Analog input offset adjustment**	100%	0 to 200%	This function provides speed command by analog input (terminal 2) with offset. Motor rotation due to noise, etc. by analog input can be avoided at zero speed command.

(1) Block diagram



WWW.BSNEW.IR

(2) Time constant of analog input *(Pr. 74)*


- Effective for eliminating noise in the frequency setting circuit.
- Increase the filter time constant if steady operation cannnot be performed due to noise.
  A larger setting results in slower response (The time constant can be set between approximately 10ms to 1s with the setting of 0 to 8).

(3) Time constant of analog speed command input *(Pr. 822, Pr. 832)*

- Set the time constant of the primary delay filter relative to the external torque command (analog input command) using *Pr. 822 Speed setting filter 1*.
  Set a large time constant when you want to delay the tracking of the speed command, when the analog input voltage fluctuates, etc.
- When you want to change time constant when switching two motors with one inverter, use the *Pr. 832 Speed setting filter 2*.
- *Pr. 832 Speed setting filter 2* is made valid when the RT signal turns on.

(4) Time constant of analog torque command input *(Pr. 826, Pr. 836)*

- Set the time constant of the primary delay filter relative to the external torque command (analog input command) using *Pr. 826 Torque setting filter 1*.
  Set a large time constant value when you want to delay the tracking of the torque command, when the analog input voltage fluctuates, etc.
- When you want to change time constant when switching two motors with one inverter, etc., use *Pr. 836 Torque setting filter 2*.
- *Pr. 836 Torque setting filter 2* is made valid when the RT signal turns on.



(5) Offset adjustment of analog speed command input *(Pr. 849)*

- When speed command by analog input is set, create the range where the motor remains stop to prevent malfunction at very low speed.
- On the assumption that the *Pr. 849* setting 100% as 0, the offset voltage is offset as follows:
  100% < *Pr. 849* .....positive side
  100% > *Pr. 849* .....negative side
  The offset voltage is found by the following formula.

$$\text{Offset voltage} = \begin{matrix}\text{Voltage at 100\%} \\ \text{(5V or 10V *)}\end{matrix} \times \frac{Pr.\ 849\ - 100}{100}\ [\text{V}]$$

* According to the *Pr. 73* setting

♦ Parameters referred to ♦

Pr. 73 Analog input selection ☞ *Refer to page 282*
Pr. 125, C2 to C4 (Bias and gain of the terminal 2 frequency setting) ☞ *Refer to page 289*

WWW.BSNEW.IR

4.21.5 Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2(Pr. 902) to C7(Pr. 905), C12(Pr. 917) to C15(Pr. 918))

You can set the magnitude (slope) of the output frequency as desired in relation to the frequency setting signal (0 to 5V, 0 to 10V or 0 to 20mADC).
Set *Pr. 73, Pr. 267* and voltage/current input switch to switch between 0 to 5VDC, 0 to 10VDC and 4 to 20mADC. *(Refer to page 282)*

● Frequency setting bias/gain parameter

Parameter Number	Name	Initial Value	Setting Range	Description	
125	**Terminal 2 frequency setting gain frequency**	60Hz	0 to 400Hz	Set the frequency of terminal 2 input gain (maximum).	
126	**Terminal 4 frequency setting gain frequency**	60Hz	0 to 400Hz	Set the frequency of terminal 4 input gain (maximum).	
241 *2	**Analog input display unit switchover**	0	0	Displayed in %	Select the unit of analog input display.
			1	Displayed in V/mA	
C2(902) *1	**Terminal 2 frequency setting bias frequency**	0Hz	0 to 400Hz	Set the frequency on the bias side of terminal 2 input.	
C3(902) *1	**Terminal 2 frequency setting bias**	0%	0 to 300%	Set the converted % of the bias side voltage (current) of terminal 2 input.	
C4(903) *1	**Terminal 2 frequency setting gain**	100%	0 to 300%	Set the converted % of the gain side voltage (current) of terminal 2 input.	
C5(904) *1	**Terminal 4 frequency setting bias frequency**	0Hz	0 to 400Hz	Set the frequency on the bias side of terminal 4 input.	
C6(904) *1	**Terminal 4 frequency setting bias**	20%	0 to 300%	Set the converted % of the bias side current (voltage) of terminal 4 input.	
C7(905) *1	**Terminal 4 frequency setting gain**	100%	0 to 300%	Set the converted % of the gain side current (voltage) of terminal 4 input.	

● Speed limit bias/gain parameter

Parameter Number	Name	Initial Value	Setting Range	Description
C12(917) *1	**Terminal 1 bias frequency (speed)**	0Hz	0 to 400Hz	Set the frequency (speed) on the bias side of terminal 1 input.
C13(917) *1	**Terminal 1 bias (speed)**	0%	0 to 300%	Set the converted % of the bias side voltage of terminal 1 input.
C14(918) *1	**Terminal 1 gain frequency (speed)**	60Hz	0 to 400Hz	Set the frequency (speed) of terminal 1 input gain (maximum).
C15(918) *1	**Terminal 1 gain (speed)**	100%	0 to 300%	Set the converted % of the gain side voltage of terminal 1 input.

*1 The parameter number in parentheses is the one for use with the parameter unit (FR-PU04/FR-PU07).
*2 The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

WWW.BSNEW.IR

(1) The relationship between analog input terminal and calibration parameter

●Terminal 1 functional calibration parameter

Pr. 868 Setting	Terminal Function	Calibration Parameters	
		Bias setting	Gain setting
0 (initial value)	Frequency (speed) setting auxiliary	*C2(Pr. 902) Terminal 2 frequency setting bias frequency* *C3(Pr. 902) Terminal 2 frequency setting bias* *C5(Pr. 904) Terminal 4 frequency setting bias frequency* *C6(Pr. 904) Terminal 4 frequency setting bias*	*Pr. 125 Terminal 2 frequency setting gain frequency* *C4(Pr. 903) Terminal 2 frequency setting gain* *Pr. 126 Terminal 4 frequency setting gain frequency* *C7(Pr. 905) Terminal 4 frequency setting gain*
1	Magnetic flux command	*C16(Pr.919) Terminal 1bias command (torque/magnetic flux)* *C17(Pr.919) Terminal 1bias (torque/magnetic flux)*	*C18(Pr. 920) Terminal 1 gain command (torque/magnetic flux)* *C19(Pr. 920) Terminal 1 gain (torque/magnetic flux)*
2	Regenerative torque limit	*C16(Pr. 919) Terminal 1 bias command (torque/magnetic flux)* *C17(Pr. 919) Terminal 1 bias (torque/magnetic flux)*	*C18(Pr. 920) Terminal 1 gain command (torque/magnetic flux)* *C19(Pr. 920) Terminal 1 gain (torque/magnetic flux)*
3	Torque command		
4	Stall prevention operation level */ torque limit/torque command		
5	Forward/reverse rotation speed limit	*C12(Pr. 917) Terminal 1 bias frequency (speed)* *C13(Pr. 917) Terminal 1 bias (speed)*	*C14(Pr. 918) Terminal 1 gain frequency (speed)* *C15(Pr. 918) Terminal 1 gain (speed)*
6	Torque bias input	*C16(Pr. 919) Terminal 1 bias command (torque/magnetic flux)* *C17(Pr. 919) Terminal 1 bias (torque/magnetic flux)*	*C18(Pr. 920) Terminal 1 gain command (torque/magnetic flux)* *C19(Pr. 920) Terminal 1 gain (torque/magnetic flux)*
9999	—	—	—


●Terminal 4 functional calibration parameter


Pr. 858 Setting	Terminal Function	Calibration Parameters	
		Bias setting	Gain setting
0 (initial value)	Frequency command/speed command	*C5(Pr. 904) Terminal 4 frequency setting bias frequency* *C6(Pr. 904) Terminal 4 frequency setting bias*	*Pr. 126 Terminal 4 frequency setting gain frequency* *C7(Pr. 905) Terminal 4 frequency setting gain*
1	Magnetic flux command	*C38(Pr.932) Terminal 4 bias command (torque/magnetic flux)* *C39(Pr.932) Terminal 4 bias (torque/magnetic flux)*	*C40(Pr.933) Terminal 4 gain command (torque/magnetic flux)* *C41(Pr.933) Terminal 4 gain (torque/magnetic flux)*
4	Stall prevention operation level */ torque limit	*C38(Pr. 932) Terminal 4 bias command (torque/magnetic flux)* *C39(Pr. 932) Terminal 4 bias (torque/magnetic flux)*	*C40(Pr. 933) Terminal 4 gain command (torque/magnetic flux)* *C41(Pr. 933) Terminal 4 gain (torque/magnetic flux)*
9999	—	—	—

— : No function

* Use *Pr. 148 Stall prevention level at 0V input* and *Pr. 149 Stall prevention level at 10V input* to adjust bias/gain of stall prevention operation level

WWW.BSNEW.IR





(2) Change the frequency at maximum analog input. *(Pr. 125, Pr. 126)*

· Set a value in *Pr. 125 (Pr. 126)* when changing only the frequency setting (gain) of the maximum analog input power (current). (*C2 (Pr. 902) to C7 (Pr. 905)* setting need not be changed)

(3) Analog input bias/gain calibration (*C2(Pr. 902) to C7(Pr. 905), C12(Pr. 917) to C15(Pr. 918)*)

· The "bias" and "gain" functions are used to adjust the relationship between the input signal entered from outside the inverter to set the output frequency, e.g. 0 to 5V, 0 to 10V or 4 to 20mADC, and the output frequency.
· Set the bias frequency of the terminal 2 input using *C2 (Pr. 902)*. (factory-set to the frequency at 0V)
· Using *Pr. 125*, set the output frequency relative to the frequency command voltage (current) set in *Pr. 73 Analog input selection*.
· Set the bias frequency of the terminal 1 input using *C12 (Pr. 917)*. (factory-set to the frequency at 0V)
· Set the gain frequency of the terminal 1 input using *C14 (Pr. 918)*. (factory-set to the frequency at 10V)
· Set the bias frequency of the terminal 4 input using *C5 (Pr. 904)*. (factory-set to the frequency at 4mA)
· Using *Pr. 126*, set the output frequency relative to 20mA of the frequency command current (4 to 20mA).
· There are three methods to adjust the frequency setting voltage (current) bias/gain.
  (a) Method to adjust any point by application of voltage (current) to across the terminals 2-5 (4-5). ☞ *page 292*
  (b) Method to adjust any point without application of a voltage (current) to across terminals 2-5(4-5). ☞ *page 293*
  (c) Adjusting only the frequency without adjusting the voltage (current). ☞ *page 294*

CAUTION

· When the terminal 2 is calibrated to change the inclination of the set frequency, the setting of the terminal 1 is also changed.
· When a voltage is input to the terminal 1 to make calibration, (terminal 2 (4) analog value + terminal 1 analog value) is the analog calibration value.
· When the voltage/current input specifications were changed using *Pr. 73, Pr. 267* and voltage/current input switch, be sure to make calibration.

(4) Analog input display unit changing *(Pr. 241)*

· You can change the analog input display unit (%/V/mA) for analog input bias/gain calibration.
· Depending on the terminal input specification set to *Pr. 73*, *Pr. 267* and voltage/current input switch, the display units of *C3 (Pr. 902), C4 (Pr. 903), C6 (Pr. 904) C7 (Pr. 905)* change as shown below.

Analog Command (terminal 2, 4) (according to *Pr. 73*, *Pr. 267*, voltage/current input switch)	*Pr. 241* = 0 (initial value)	*Pr. 241* = 1
0 to 5V input	0 to 5V → displayed in 0 to 100% (0.1%).	0 to 100% → displayed in 0 to 5V (0.01V).
0 to 10V input	0 to 10V → displayed in 0 to 100% (0.1%).	0 to 100% → displayed in 0 to 10V (0.01V).
0 to 20mA input	0 to 20mA → displayed in 0 to 100% (0.1%).	0 to 100% → displayed in 0 to 20mA (0.01mA).

REMARKS

· Analog input display is not displayed correctly if voltage is applied to terminal 1 when terminal 1 input specifications (0 to ±5V, 0 to ±10V) and main speed (terminal 2, terminal 4 input) specifications (0 to 5V, 0 to 10V, 0 to 20mA) differ. (For example, 5V (100%) is analog displayed when 0V and 10V are applied to terminal 2 and terminal 1 respectively in the initial status.
In this case, set "0" (initial value is 0% display) in *Pr. 241* to use.

WWW.BSNEW.IR

(5) Frequency setting voltage (current) bias/gain adjustment method

(a)Method to adjust any point by application of voltage (current) to across the terminals 2-5 (4-5).

Operation — **Display**

1. Confirmation of the RUN indication and operation mode indication
   - The inverter must be at a stop.
   - The inverter must be in the PU operation mode. (Using PU/EXT)



2. Press MODE to choose the parameter setting mode.



The parameter number read previously appears.

3. Turn the dial until C. . . appears.



4. Press SET to display C - - -.



C0 to *C41* setting is enabled.

5. Turn the dial until C. 4 (C. 7) appears. Set to *C4 Terminal 2 frequency setting gain*.



Terminal 2 input Terminal 4 input

6. Press SET to display the analog voltage (current) value (%).



Analog voltage (current) value (%) across terminals 2-5 (across terminals 4-5)

7. Apply a 5V (20mA) voltage (current). (Turn the external potentiometer connected across terminals 2-5 (across terminals 4-5) to maximum (any position).)



* The value is nearly 100 (%) in the maximum position of the potentiometer.

CAUTION

After performing the operation in step 6, do not touch the dial until completion of calibration.

8. Press SET to set.



* Terminal 2 input Terminal 4 input

Flicker...Parameter setting complete!!
(Adjustment completed)

* The value is nearly 100 (%) in the maximum position of the potentiometer.

- By turning the dial, you can read another parameter.
- Press SET to return to the C - - - indication (step 4).
- Press SET twice to show the next parameter (PrCL).

REMARKS

- If the frequency meter (indicator) connected to across terminals FM-SD does not indicate just 60Hz, set *calibration parameter C0 FM terminal calibration*. *(Refer to page 258)*

WWW.BSNEW.IR

(b) Method to adjust any point without application of a voltage (current) to across terminals 2-5(4-5).
(To change from 4V (80%) to 5V (100%))

Operation	Display
1. Confirmation of the RUN indication and operation mode indication ・The inverter must be at a stop. ・The inverter must be in the PU operation mode. (Using PU/EXT)	
2. Press MODE to choose the parameter setting mode.	MODE ⇨ P. 0 (The parameter number read previously appears.)
3. Turn dial until C. . . appears.	⇨ C. . .
4. Press SET to display C - - -.	SET ⇨ C - - - (*C0* to *C41* setting is enabled.)
5. Turn dial until C. 4 (C. 7) appears. Set to *C4 Terminal 2 frequency setting gain*.	⇨ C 4 (Terminal 2 input) C 7 (Terminal 4 input)
6. Press SET to display the analog voltage (current) value (%).	SET ⇨ 0.0 Analog voltage (current) value (%) across terminals 2-5 (across terminals 4-5)
7. Turn dial to set the gain voltage (%). "0V (0mA) equals to 0%, 5V (10V, 20mA) to 100%"	⇨ 100 The gain frequency is reached when the analog voltage (current) value across terminals 2-5 (across terminals 4-5) is 100%.
Remarks: The current setting at the instant of turning dial is displayed.	80
8. Press SET to set.	SET ⇨ 100 C 4 (Terminal 2 input) C 7 (Terminal 4 input)

Flicker...Parameter setting complete!!
(Adjustment completed)


- By turning dial, you can read another parameter.
- Press SET to return to the C - - - indication (step 4).
- Press SET twice to show the next parameter (PrCL).

REMARKS

By pressing dial after step 6, you can confirm the current frequency setting bias/gain setting.
It cannot be confirmed after execution of step 7.

WWW.BSNEW.IR

(c) Method to adjust only the frequency without adjustment of a gain voltage (current).
(When changing the gain frequency from 60Hz to 50Hz)

Operation	Display
1. Turn dial until P.125 (*Pr. 125*) or P.126 (*Pr. 126*) appears.	
2. Press SET to show the currently set value. (60.00Hz)	
3. Turn dial to change the set value to "50.00". (50.00Hz)	
4. Press SET to set.	 Flicker...Parameter setting complete!!
5. Mode/monitor check Press MODE twice to choose the monitor/frequency monitor.	
6. Apply a voltage across the inverter terminals 2-5 (across 4-5) and turn on the start command (STF, STR). Operation starts at 50Hz.	

REMARKS

- Changing *C4 (Pr. 903)* or *C7 (Pr. 905)* (gain adjustment) value will not change the *Pr. 20* value. The input of terminal 1 (frequency setting auxiliary input) is added to the frequency setting signal.
- For the operation procedure using the parameter unit (FR-PU04/FR-PU07), refer to the FR-PU04/FR-PU07 instruction manual.
- When setting the value to 120Hz or more, it is necessary to set *Pr. 18 High speed maximum frequency* to 120Hz or more. *(Refer to page 157)*
- Make the bias frequency setting using *calibration parameter C2 (Pr. 902) or C5 (Pr. 904). (Refer to page 291)*

⚠ CAUTION

⚠ Take care when setting any value other than "0" as the bias speed at 0V (0mA). Even if a frequency command is not given, merely turning on the start signal will start the motor at the preset frequency.

♦ Parameters referred to ♦

Pr. 20 Acceleration/deceleration reference frequency ☞ *Refer to page 173*
Pr. 73 Analog input selection, Pr. 267 Terminal 4 input selection ☞ *Refer to page 282*
Pr. 79 Operation mode selection ☞ *Refer to page 308*

WWW.BSNEW.IR

4.21.6 Bias and gain of torque (magnetic flux) setting voltage (current) (Pr. 241, C16(Pr. 919) to C19(Pr. 920), C38 (Pr. 932) to C41 (Pr. 933))

You can set the magnitude (slope) of the torque as desired in relation to the torque setting signal (0 to 5VDC, 0 to 10V or 4 to 20mA).
Use *Pr. 73 and Pr. 267* to switch from among 0 to 5V, 0 to 10V, 4 to 20mADC. *(Refer to page 282)*

Parameter Number	Name	Initial Value	Setting Range	Description	
241 *2	Analog input display unit switchover	0	0	Displayed in %	Select the unit of analog input display.
			1	Displayed in V/mA	
C16(919) *1	Terminal 1 bias command (torque/ magnetic flux)	0%	0 to 400%	Set the torque (magnetic flux) on the bias side of terminal 1 input.	
C17(919) *1	Terminal 1 bias (torque/magnetic flux)	0%	0 to 300%	Set the converted % of the bias side voltage (current) of terminal1 input.	
C18(920) *1	Terminal 1 gain command (torque/ magnetic flux)	150%	0 to 400%	Set the torque (magnetic flux) of the terminal 1 input gain (maximum).	
C19(920) *1	Terminal 1 gain (torque/magnetic flux)	100%	0 to 300%	Set the converted % of the gain side voltage of terminal1 input.	
C38(932) *1	Terminal 4 bias command (torque/ magnetic flux)	0%	0 to 400%	Set the torque (magnetic flux) on the bias side of terminal 4 input.	
C39(932) *1	Terminal 4 bias (torque/magnetic flux)	20%	0 to 300%	Set the converted % of the bias side current (voltage) of terminal 4 input.	
C40(933) *1	Terminal 4 gain command (torque/ magnetic flux)	150%	0 to 400%	Set the torque (magnetic flux) of the terminal 4 input gain (maximum).	
C41(933) *1	Terminal 4 gain (torque/magnetic flux)	100%	0 to 300%	Set the converted % of the gain side current (voltage) of terminal 4 input.	

*1 The parameter number in parentheses is the one for use with the parameter unit (FR-PU04/FR-PU07).
*2 The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection* .

(1) Change functions of analog input terminal

In the initial setting status, terminal 1 and terminal 4 used for analog input are respectively set to speed setting auxiliary (speed limit auxiliary) and speed command (speed limit). To use an analog input terminal as torque command, torque limit input or magnetic flux command input, set *Pr. 868 Terminal 1 function assignment* and *Pr. 858 Terminal 4 function assignment* to change functions. *(Refer to page 281)*

(2) The relationship between analog input terminal and calibration parameter

● Terminal 1 functional calibration parameter

Pr. 868 Setting	Terminal Function	Calibration Parameters	
		Bias setting	Gain setting
0 (initial value)	Frequency (speed) setting auxiliary	*C2(Pr. 902) Terminal 2 frequency setting bias frequency* *C3(Pr. 902) Terminal 2 frequency setting bias* *C5(Pr. 904) Terminal 4 frequency setting bias frequency* *C6(Pr. 904) Terminal 4 frequency setting bias*	*Pr. 125 Terminal 2 frequency setting gain frequency* *C4(Pr. 903) Terminal 2 frequency setting gain* *Pr. 126 Terminal 4 frequency setting gain frequency* *C7(Pr. 905) Terminal 4 frequency setting gain*
1	Magnetic flux command	*C16(Pr. 919) Terminal 1bias command (torque/magnetic flux)* *C17(Pr. 919) Terminal 1bias (torque/magnetic flux)*	*C18(Pr. 920) Terminal 1 gain command (torque/magnetic flux)* *C19(Pr. 920) Terminal 1 gain (torque/magnetic flux)*
2	Regenerative torque limit	*C16(Pr. 919) Terminal 1 bias command (torque/magnetic flux)* *C17(Pr. 919) Terminal 1 bias (torque/magnetic flux)*	*C18(Pr. 920) Terminal 1 gain command (torque/magnetic flux)* *C19(Pr. 920) Terminal 1 gain (torque/magnetic flux)*
3	Torque command		
4	Stall prevention operation level */ torque limit/torque command		
5	Forward/reverse rotation speed limit	*C12(Pr. 917) Terminal 1 bias frequency (speed)* *C13(Pr. 917) Terminal 1 bias (speed)*	*C14(Pr. 918) Terminal 1 gain frequency (speed)* *C15(Pr. 918) Terminal 1 gain (speed)*
6	Torque bias input	*C16(Pr. 919) Terminal 1 bias command (torque/magnetic flux)* *C17(Pr. 919) Terminal 1 bias (torque/magnetic flux)*	*C18(Pr. 920) Terminal 1 gain command (torque/magnetic flux)* *C19(Pr. 920) Terminal 1 gain (torque/magnetic flux)*
9999	—	—	—

* Use *Pr. 148 Stall prevention level at 0V input* and *Pr. 149 Stall prevention level at 10V input* to adjust bias/gain of stall prevention operation level.


WWW.BSNEW.IR

● Terminal 4 functional calibration parameter


Pr. 858 Setting	Terminal Function	Calibration Parameters	
		Bias setting	Gain setting
0 (initial value)	Frequency (speed) command/speed limit	*C5(Pr. 904) Terminal 4 frequency setting bias frequency* *C6(Pr. 904) Terminal 4 frequency setting bias*	*Pr. 126 Terminal 4 frequency setting gain frequency* *C7(Pr. 905) Terminal 4 frequency setting gain*
1	Magnetic flux command	*C38(Pr. 932) Terminal 4 bias command (torque/magnetic flux)* *C39(Pr. 932) Terminal 4 bias (torque/magnetic flux)*	*C40(Pr. 933) Terminal 4 gain command (torque/magnetic flux)* *C41(Pr. 933) Terminal 4 gain (torque/magnetic flux)*
4	Stall prevention operation level */ torque limit	*C38(Pr. 932) Terminal 4 bias command (torque/magnetic flux)* *C39(Pr. 932) Terminal 4 bias (torque/magnetic flux)*	*C40(Pr. 933) Terminal 4 gain command (torque/magnetic flux)* *C41(Pr. 933) Terminal 4 gain (torque/magnetic flux)*
9999	—	—	—

— : No function

* Use *Pr. 148 Stall prevention level at 0V input* and *Pr. 149 Stall prevention level at 10V input* to adjust bias/gain of stall prevention operation level.



Calibration example of terminal 1



Calibration example of terminal 4

(3) Change the torque at maximum analog input. *(C18(Pr. 920), C40(Pr. 933))*

· Set *C18(Pr. 920), C40(Pr. 933)* when changing only torque setting (gain) of the maximum analog input voltage (current).

(4) Calibration of analog input bias and gain *(C16(Pr. 919) to C19(Pr. 920), C38 (Pr. 932) to C41 (Pr. 933))*

· The "bias" and "gain" functions are used to adjust the relationship between the input signal entered from outside the inverter to set the torque command and torque limit, e.g. 0 to 5V, 0 to 10V or 4 to 20mADC, and the torque.
· Set the bias torque of terminal 1 input in *C16 (Pr. 919)* .
(It is factory-set to the torque at 0V)
· Set the torque in *C18 (Pr. 920)* for the torque command voltage set with *Pr. 73 Analog input selection*.
(initial value is 10V)
· Set the bias torque of terminal 4 input in *C38 (Pr. 932)* .
(It is factory-set to the torque at 4mA)
· Set the torque in *C40 (Pr. 933)* for 20mA of the torque command current (4 to 20mA).
· There are the following three methods to adjust the torque setting voltage (current) bias and gain.
a) Method to adjust any point without application of voltage (current) to across terminals 1-5(4-5)
☞ *page 297*
b) Method to adjust any point without application of voltage (current) to across terminals 1-5(4-5)
☞ *page 298*
c) Method to adjust torque only without adjustment of voltage (current) ☞ *page 299*

CAUTION

· When voltage/current input specifications were switched using *Pr. 73* and *Pr. 267* , perform calibration without fail.

(5) Analog input display unit changing *(Pr. 241)*

· You can change the analog input display unit (%/V/mA) for analog input bias/gain calibration.
· Display unit of *C17 (Pr. 919), C19 (Pr. 920), C39 (Pr. 932), C41 (Pr. 933)* changes as follows accrding to the terminal input specifications set in *Pr. 73* and *Pr. 267* .

Analog Command (terminal 1,4) (according to *Pr. 73, Pr. 267*)	*Pr. 241* = 0 (initial value)	*Pr. 241* = 1
0 to 5V input	0 to 5V → displayed in 0 to 100% (0.1%)	0 to 100% → displayed in 0 to 5V (0.01V)
0 to 10V input	0 to 10V → displayed in 0 to 100% (0.1%)	0 to 100% → displayed in 0 to 10V (0.01V)
0 to 20mA input	0 to 20mA → displayed in 0 to 100% (0.1%)	0 to 100% → displayed in 0 to 20mA (0.01mA)

WWW.BSNEW.IR

(6) Adjustment method of torque setting voltage (current) bias and gain


a) Method to adjust any point without application of a voltage (current) to across terminals 1-5(4-5)

Operation — **Display**

1. Confirmation of the RUN indication and operation mode indication
   - The inverter must be at a stop.
   - The inverter must be in the PU operation mode.(Using PU/EXT)



2. Press MODE to choose the parameter setting mode.



3. Turn dial until C. . . appears.



4. Press SET to display C - - -.




5. Turn dial until C. 19 (C. 41) appears.
   Set to *C19 Terminal 1 gain (torque)*.



6. Press SET to display the analog voltage (current) value (%).




7. Apply a 10V (20mA) voltage (current).
   (Turn the external potentiometer connected across terminals 1-5 (across terminals 4-5) to maximum (any position).)



CAUTION

After performing the operation in step 6, do not touch dial until completion of calibration.

8. Press SET to set.



- By turning dial, you can read another parameter.
- Press SET to return to the C - - - indication (step 4).
- Press SET twice to show the next parameter (PrCL).

REMARKS

- An error at writing (Er3) may appear if torque setting value of gain and bias are too close.

WWW.BSNEW.IR

b) Method to adjust any point without application of a voltage (current) to across terminals 1-5(4-5) (To change from 8V (80%) to 10V (100%))

Operation


1. Confirmation of the RUN indication and operation mode indication
   - The inverter must be at a stop.
   - The inverter must be in the PU operation mode. (Using PU/EXT)
2. Press MODE to choose the parameter setting mode.
3. Turn dial until C. . . appears.
4. Press SET to display C - - -.
5. Turn dial until C. 19 (C. 41) appears. Set to *C19 Terminal 1 gain (torque)*.
6. Press SET to display the analog voltage (current) value (%).
7. Turn dial to set the gain voltage (%). "0V (0mA) equals to 0%, 10V (5V, 20mA) to 100%"

   REMARKS

   The current setting at the instant of turning is displayed.
8. Press SET to set.

Display





- By turning dial, you can read another parameter.
- Press SET to return to the C - - - indication (step 4).
- Press SET twice to show the next parameter (Pr.CL).

REMARKS

You can check the current torque setting bias/gain setting by pressing dial after step 6.

You can not check after performing operation in step 7.


WWW.BSNEW.IR

c) Method to adjust torque only without adjustment of gain voltage (current) (when changing gain torque from 150% to 130%)

Operation

1. Turn ◯ until C. 18 (*Pr.920*) or C. 40 (*Pr.933*) appears.
2. Press (SET) to show the currently set value. (150%)
3. Turn ◯ to change the set value to "130.0" (130.0%)
4. Press (SET) to set.
5. Mode/monitor check
   Press (MODE) twice to choose the monitor/frequency monitor.
6. Apply a voltage across the inverter terminals 1-5 (across 4-5) and turn on the start command (STF, STR).
   Operation starts with 130% torque.

Display



REMARKS

- For operation from the parameter unit (FR-PU04/FR-PU07), refer to the instruction manual of the FR-PU04/FR-PU07.
- Set bias torque setting using *calibration parameter C16 (Pr. 919) or C38 (Pr. 932). (Refer to page 296)*

⚠ CAUTION

⚠ Take care when setting any value other than "0" as the bias torque at 0V (0mA). Torque is applied to the motor by merely tuning on the start signal without torque command.

♦ Parameters referred to ♦


Pr. 20 Acceleration/deceleration reference frequency ☞ *Refer to page 173*
Pr. 73 Analog input selection, Pr. 267 Terminal 4 input selection ☞ *Refer to page 282*
Pr. 79 Operation mode selection ☞ *Refer to page 308*
Pr. 858 Terminal 4 function assignment, Pr. 868 Terminal 1 function assignment ☞ *Refer to page 281*

WWW.BSNEW.IR

4.21.7 4mA input check of current input (Pr. 573)

When inputting 4 to 20mA current to terminal 2 or terminal 4, decrease in analog current input is detected to enable continuous operation even if input has decreased.

Parameter Number	Name	Initial Value	Setting Range	Description
573	**4mA input check selection**	9999	1	When the current input drops to or below 2mA, the LF signal is output and inverter continues operation at the frequency (average value) just before current reaches 2mA.
			9999	4mA input is not checked.




* When *Pr. 573* = "1", input decrease is detected (LF signal output) even if the analog input value to bias frequency of terminal 2 or terminal 4 is set to 2mA or less using *C2 (Pr. 902)* or *C5 (Pr. 904)* and the value is not as bias frequency settings.


(1) Operation at a current input decrease continues (*Pr. 573* = "1")

- When the input current of terminal 4 (terminal 2) falls 2mA or below, output minor fault signal (LF) is output.
- When the current falls below 2mA, the output frequency (average value) before detection is retained and operation at the retained frequency continues.
- When the current input increases above 3mA, the LF signal output is turned off and the inverter operates according to the current input.
- For the LF signal, set "98 (positive logic) or 198 (negative logic)" in *Pr. 190 to Pr. 196 (output terminal function selection)* and assign functions to the output terminal.
- Since turning off the start command clears the retained frequency, the inverter does not operate at the retained frequency even if restarted.

During external operation (*Pr. 573* = 1)



During PID control (reverse action) (*Pr. 573* = 1)



CAUTION

- When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions may be affected. Please make setting after confirming the function of each terminal.

WWW.BSNEW.IR

(2) Function related to 4mA input check

Function	Operation (*Pr. 573* = 1)	Refer to page
Minimum frequency	Even if the input current decreases, minimum frequency setting clamp is valid.	157
Multi-speed operation	Operation by multiple speed signal has precedence even if input current decreases. (Frequency is not retained when the input current decreases.) Operation stops when a multi-speed signal turns off.	166
Jog operation	The Jog signal has precedence. (Frequency is not retained when the input current decreases.) Operation stops when the jog signal is turned off during decrease in input current. PU/jog operation is enabled during PID control. At this time, PU/jog operation has precedence during decrease in input current.	168
MRS	Output is shut off by the MRS signal even if input current decreases. (The inverter stops when the MRS signal is turned off.)	231
Remote setting	The retained frequency will not change even if remote acceleration/deceleration and clear are performed during decrease in input current. Reflected at restoration.	170
Retry	When retry was successful at error occurrence during decrease in input current, retained frequency was not cleared and operation continues.	268
Added compensation, override function	Operation of added compensation (terminal 1) and override compensation (terminal 2) are invalid during decrease in input current.	285
Input filter time constant	The value before filtering is detected. When input current decreases, frequency after filtering (average value) is retained.	287
Forward/reverse rotation prevention	Motor rotation direction can be restricted independently of 4mA input check setting.	306
PID control	Although PID operation is stopped when input current decreases, the X14 signal remains on. (PID operation is valid.)	355
Power failure stop	Even if input current decreases when undervoltage or power failure occurs, the motor stops according to the setting of power-failure deceleration stop function	265
Switch-over	When the switchover function is operated, frequency is the same as that of the retained frequency. Note that if 4mA input is made invalid once in switchover mode, the frequency is not retained next time.	308

♦ Parameters referred to ♦

Pr. 73 Analog input selection ☞ *Refer to page 282*
Pr. 267 Terminal 4 input selection ☞ *Refer to page 282*

WWW.BSNEW.IR

4.22 Misoperation prevention and parameter setting restriction

Purpose	Parameter that must be Set		Refer to Page
Limit reset function Make alarm stop when PU is disconnected Stop from PU	**Reset selection/disconnected PU detection/PU stop selection**	**Pr. 75**	302
Prevention of parameter rewrite	**Parameter write disable selection**	**Pr. 77**	305
Prevention of reverse rotation of the motor	**Reverse rotation prevention selection**	**Pr. 78**	306
Display necessary parameters	**Display of applied parameters and user group function**	**Pr. 160, Pr. 172 to Pr. 174**	306
Control of parameter write by communication	**EEPROM write selection**	**Pr. 342**	328

4.22.1 Reset selection/disconnected PU detection/PU stop selection (Pr. 75)

You can select the reset input acceptance, disconnected PU (FR-DU07/FR-PU04/FR-PU07) connector detection function and PU stop function.

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
75	**Reset selection/disconnected PU detection/PU stop selection**	14	02150 (01100) or less	0 to 3, 14 to 17	For the initial value, reset always enabled, without disconnected PU detection, and with PU stop function are set.
			02880 (01440) or more	0 to 3, 14 to 17, 100 to 103, 114 to117	

·The *Pr. 75* value can be set any time. Also, if parameter (all) clear is executed, this setting will not return to the initial value.

Pr. 75 Setting	Reset Selection	Disconnected PU Detection	PU Stop Selection	Reset Limit
0	Reset input always enabled	If the PU is disconnected, operation will be continued.	Pressing STOP RESET decelerates the motor to a stop only in the PU operation mode.	Not function
1	Enabled only when the protective function is activated			
2	Reset input always enabled	When the PU is disconnected, the inverter output is shut off.		
3	Enabled only when the protective function is activated			
14 (initial value)	Reset input always enabled	If the PU is disconnected, operation will be continued.	Pressing STOP RESET decelerates the motor to a stop in any of the PU, external and communication operation modes.	
15	Enabled only when the protective function is activated			
16	Reset input always enabled	When the PU is disconnected, the inverter output is shut off.		
17	Enabled only when the protective function is activated			
100 *	Reset input always enabled	If the PU is disconnected, operation will be continued.	Pressing STOP RESET decelerates the motor to a stop only in the PU operation mode.	Function
101 *	Enabled only when the protective function is activated			
102 *	Reset input always enabled	When the PU is disconnected, the inverter output is shut off.		
103 *	Enabled only when the protective function is activated			
114 *	Reset input always enabled	If the PU is disconnected, operation will be continued.	Pressing STOP RESET decelerates the motor to a stop in any of the PU, external and communication operation modes.	
115 *	Enabled only when the protective function is activated			
116 *	Reset input always enabled	When the PU is disconnected, the inverter output is shut off.		
117 *	Enabled only when the protective function is activated			

* Available with the FR-A720-02880 (FR-A740-01440) or more.

WWW.BSNEW.IR

(1) Reset selection

- You can select the operation timing of reset function (RES signal, reset command through communication) input.
- When *Pr. 75* is set to any of "1, 3, 15, 17, 101, 103, 115, 117", a reset can be input only when the protective function is activated.

CAUTION

- When the reset signal (RES) is input during operation, the motor coasts since the inverter being reset shuts off the output. Also, the cumulative value of the electronic thermal relay function and regenerative brake duty is cleared.
- The reset key of the PU is valid only when the protective function is activated, independently of the *Pr. 75* setting.

(2) Disconnected PU detection

- This function detects that the PU (FR-DU07/FR-PU04/FR-PU07) has been disconnected from the inverter for longer than 1s and causes the inverter to provide an alarm output (E.PUE) and come to an alarm stop.
- When *Pr. 75* is set to any of "0, 1, 14, 15, 100, 101, 114, 115", operation is continued if the PU is disconnected.

CAUTION

- When the PU has been disconnected since before power-on, it is not judged as an alarm.
- To make a restart, confirm that the PU is connected and then reset the inverter.
- The motor decelerates to a stop when the PU is disconnected during PU jog operation with *Pr. 75* set to any of "0, 1, 14, 15" (operation is continued if the PU is disconnected).
- When RS-485 communication operation is performed through the PU connector, the reset selection/PU stop selection function is valid but the disconnected PU detection function is invalid.

(3) PU stop selection


- In any of the PU operation, external operation and network operation modes, the motor can be stopped by pressing STOP RESET of the PU.
- When the inverter is stopped by the PU stop function, "PS" is displayed but an alarm is not output. An alarm output is not provided.
- When *Pr. 75* is set to any of "0 to 3, 100 to 103", deceleration to a stop by STOP RESET is valid only in the PU operation mode.

REMARKS

The motor will also decelerate to a stop (PU stop) when STOP RESET is input during operation in the PU mode through RS-485 communication with *Pr. 551 PU mode operation command source selection* set to "1" (PU mode RS-485 terminals).

WWW.BSNEW.IR

(4) Restarting method when stop was made by pressing STOP RESET from the PU during external operation



Stop/restart example for external operation

(a) When operation panel (FR- DU07) is used

1)After the motor has decelerated to a stop, turn off the STF or STR signal.

2)Press PU EXT to display PU .••••••(PS canceled)

3)Press PU EXT to return to EXT.

4)Turn on the STF or STR signal.

(b) Connection of the parameter unit (FR-PU04/FR-PU07)

1)After the motor has decelerated to a stop, turn off the STF or STR signal.

2)Press EXT .••••••(PS canceled)

3)Turn on the STF or STR signal.

- The motor can be restarted by making a reset using a power supply reset or RES signal.

CAUTION

· If *Pr. 250 Stop selection* is set to other than "9999" to select coasting to a stop, the motor will not be coasted to a stop but decelerated to a stop by the PU stop function during external operation.
To restart after the inverter is stopped by PU with PLC function, reset using a power supply rest or RES signal. (sending stop signal from GX Developer, can also perform the reset.)

⚠ CAUTION

⚠ Do not reset the inverter with the start signal on. Doing so will cause the inverter to start immediately after a reset, leading to hazardous conditions.

(5) Reset limit

- Setting can be made for the FR-A720-02880 (FR-A740-01440) or more.
- You can set *Pr. 75* to disable reset operation until the thermal cumulative amount reaches 0 when a thermal trip (THM, THT) or an overcurrent trip (OC1 to OC3) occurs consecutively twice.
- When *Pr. 75* = "100 to 103, 114 to 117", reset limit is made valid.

REMARKS

When the power-on reset (no control power is supplied) is made, the thermal cumulative amount is cleared.

♦ Parameters referred to ♦

Pr. 250 Stop selection ☞ *Refer to page 210*

WWW.BSNEW.IR

4.22.2 Parameter write selection (Pr. 77)

You can select whether write to various parameters can be performed or not. Use this function to prevent parameter values from being rewritten by misoperation.

Parameter Number	Name	Initial Value	Setting Range	Description
77	Parameter write selection	0	0	Write is enabled only during a stop.
			1	Parameter write is not enabled.
			2	Parameter write is enabled in any operation mode regardless of operation status.

Pr. 77 can be always set independently of the operation mode and operation status.

(1) Write parameters only at a stop (setting "0", initial value)

- Parameters can be written only during a stop in the PU operation mode.
- The shaded parameters in the parameter list *(page 71)* can always be written, regardless of the operation mode and operation status. However, *Pr. 72 PWM frequency selection* and *Pr. 240 Soft-PWM operation selection* can be written during operation in the PU operation mode, but cannot be written in external operation mode.

(2) Disable parameter write (setting "1")

- Parameter write is not enabled. (Reading is enabled.)
- Parameter clear and all parameter clear cannot be performed, either.
- The parameters given on the right can be written even if *Pr. 77* = "1".

Parameter Number	Name
22	Stall prevention operation level
75	Reset selection/disconnected PU detection/PU stop selection
77	Parameter write selection
79	Operation mode selection
160	User group read selection

(3) Write parameters during operation (setting "2")

- Parameters can always be written.
- The following parameters cannot be written during operation if *Pr. 77* = "2". Stop operation when changing their parameter settings.

Parameter Number	Name
19	Base frequency voltage
23	Stall prevention operation level compensation factor at double speed
48	Second stall prevention operation current
49	Second stall prevention operation frequency
60	Energy saving control selection
61	Reference current
66	Stall prevention operation reduction starting frequency
71	Applied motor
79	Operation mode selection
80	Motor capacity
81	Number of motor poles
82	Motor excitation current
83	Motor rated voltage
84	Rated motor frequency
90 to 94	(Motor constants)
95	Online auto tuning selection
96	Auto tuning setting/status
100 to 109	(Adjustable 5 points V/F parameter)
135 to 139	(Parameter for electronic bypass sequence)
178 to 196	(I/O terminal function selection)
255	Life alarm status display
256	Inrush current limit circuit life display
257	Control circuit capacitor life display
258	Main circuit capacitor life display
291	Pulse train I/O selection
292	Automatic acceleration/deceleration

Parameter Number	Name
293	Acceleration/deceleration separate selection
329	Digital input unit selection (Parameter for the plug-in option FR-A7AX)
343	Communication error count
414	PLC function operation selection
415	Inverter operation lock mode setting
450	Second applied motor
451	Second motor control method selection
453	Second motor capacity
454	Number of second motor poles
455	Second motor excitation current
456	Rated second motor voltage
457	Rated second motor frequency
458 to 462	(Second motor constant)
463	Second motor auto tuning setting/status
541	Frequency command sign selection (CC-Link) (Parameter for the plug-in option FR-A7NC)
563	Energization time carrying-over times
564	Operating time carrying-over times
570	Multiple rating setting
574	Second motor online auto tuning
800	Control method selection
819	Easy gain tuning selection
858	Terminal 4 function assignment
859	Torque current
860	Second motor torque current
868	Terminal 1 function assignment

♦ **Parameters referred to** ♦

Pr. 79 Operation mode selection ☞ *Refer to page 308*

WWW.BSNEW.IR

4.22.3 Reverse rotation prevention selection (Pr. 78)

This function can prevent reverse rotation fault resulting from the incorrect input of the start signal.

Parameter Number	Name	Initial Value	Setting Range	Description
78	Reverse rotation prevention selection	0	0	Both forward and reverse rotations allowed
			1	Reverse rotation disabled
			2	Forward rotation disallowed

- Set this parameter when you want to limit the motor rotation to only one direction.
- This parameter is valid for all of the reverse rotation and forward rotation keys of the operation panel (FR-DU07), parameter unit (FR-PU04/FR-PU07), start signals (STF, STR signals) via external terminals, and the forward and reverse rotation commands through communication.

4.22.4 Display of applied parameters and user group function (Pr. 160, Pr. 172 to Pr. 174)

Parameter which can be read from the operation panel and parameter unit can be restricted.

Parameter Number	Name	Initial Value	Setting Range	Description
160	User group read selection	0	9999	Only the simple mode parameters can be displayed.
			0	The simple mode and extended parameters can be displayed
			1	Only parameters registered in the user group can be displayed.
172	User group registered display/ batch clear	0	(0 to 16)	Displays the number of cases registered as a user group. (Reading only)
			9999	Batch clear the user group registration
173 *1	User group registration	9999	0 to 999, 9999	Set the parameter numbers to be registered to the user group.
174 *1	User group clear	9999	0 to 999, 9999	Set the parameter numbers to be cleared from the user group.

*1 The values read from *Pr. 173* and *Pr. 174* are always "9999".

(1) Display of simple mode parameters and extended parameters (*Pr. 160*)

- When *Pr. 160* = "9999", only the simple mode parameters can be displayed on the operation panel (FR-DU07) and parameter unit (FR-PU04/FR-PU07). (Refer to the parameter list, *pages 71 to 84*, for the simple mode parameters.)
- In the initial setting (*Pr. 160* = "0") status, simple mode parameters and extended parameters can be displayed.

REMARKS

- When a plug-in option is fitted to the inverter, the option parameters can also be read.
- When reading the parameters using the communication option, all parameters (simple mode, extended mode, parameters for options) can be read regardless of the *Pr. 160* setting.
- When reading the parameters using the RS-485 terminals, all parameters can be read reagrdless of the *Pr. 160* setting by setting *Pr.550 NET mode operation command source selection* and *Pr. 551 PU mode operation command source selection*.

Pr. 551	*Pr. 550*	*Pr. 160* Valid/Invalid
1 (RS-485)	—	Valid
2 (PU) (initial value) 3 (USB)	0 (OP)	Valid
	1 (RS-485)	Invalid (all readable)
	9999 (auto-detect) (initial value)	With OP: valid
		Without OP: invalid (all readable)

* OP indicates a communication option

- *Pr. 15 Jog frequency*, *Pr. 16 Jog acceleration/deceleration time Pr. 991 PU contrast adjustment* are displayed as simple mode parameters when the parameter unit (FR-PU04/FR-PU07) is mounted.

WWW.BSNEW.IR

(2) User group function (*Pr. 160, Pr. 172 to Pr. 174*)

- The user group function is designed to display only the parameters necessary for setting.
- From among all parameters, a maximum of 16 parameters can be registered to a user group. When *Pr. 160* is set to "1", only the parameters registered to the user group can be accessed. (Reading of parameters other than the user group registration is disabled.)
- To register a parameter to the user group, set its parameter number to *Pr. 173*.
- To delete a parameter from the user group, set its parameter number to *Pr. 174*. To batch-delete the registered parameters, set *Pr. 172* to "9999".

(3) Registration of parameter to user group (*Pr. 173*)

When registering *Pr. 3* to user group

Operation		Indication	
1. Confirm the operation display and operation mode display. • The inverter must be at a stop. • The inverter must be in the PU operation mode. (Press PU/EXT in the external operation mode.)			
2. Press MODE to choose the parameter setting mode.	MODE		Parameter setting mode
3. Turn dial until P.173 appears.	dial		*Pr. 173* User group registration is displayed.
4. Press SET to display. "9999"	SET		When *Pr. 173* is read, "9999" is displayed.
5. Turn dial until *Pr. 3* appears.	dial		Select the parameter number to be registered.
6. Press SET to set. "P.173" and "3" are displayed alternately. To continue parameter registration, repeat steps 3 to 6.	SET		**Flicker ··· Registration of *Pr. 3* to user group completed!!**

(4) Deletion of parameter from user group (*Pr. 174*)

When deleting *Pr. 3* from user group

Operation		Indication	
1. Confirm the operation display and operation mode display. • The inverter must be at a stop. • The inverter must be in the PU operation mode. (Press PU/EXT in the external operation mode.)			
2. Press MODE to choose the parameter setting mode.	MODE		Parameter setting mode
3. Turn dial until P.174 appears.	dial		*Pr. 174* User group clear is displayed.
4. Press SET to display. "9999"	SET		When *Pr. 174* is read, "9999" is displayed.
5. Turn dial until *Pr. 3* appears.	dial		Select the parameter number to be deleted.
6. Press SET to clear. "P.174" and "3" are displayed alternately. To continue parameter registration, repeat steps 3 to 6.	SET		**Flicker ··· Deletion of *Pr. 3* from user group completed!!**

REMARKS

- *Pr. 77, Pr. 160* and *Pr. 991* can always be read, independently of the user group setting.
- *Pr. 77, Pr. 160* and *Pr. 172 to Pr. 174* cannot be registered to the user group.
- When *Pr. 174* or *Pr. 175* is read, "9999" is always displayed. Although "9999" can be written, no function is available.
- When any value other than "9999" is set to *Pr. 172*, no function is available.

♦ Parameters referred to ♦

Pr. 550 NET mode operation command source selection ☞ *Refer to page 317*
Pr. 551 PU mode operation command source selection ☞ *Refer to page 317*


WWW.BSNEW.IR

4.23 Selection of operation mode and operation location

Purpose	Parameter that must be Set		Refer to Page
Operation mode selection	**Operation mode selection**	**Pr. 79**	308
Started in network operation mode	**Operation mode at power on**	**Pr. 79, Pr. 340**	316
Selection of control location	**Sslection of control source, speed command source and control location during communication operation**	**Pr. 338, Pr. 339, Pr. 550, Pr. 551**	317

4.23.1 Operation mode selection (Pr. 79)


Used to select the operation mode of the inverter.
Mode can be changed as desired between operation using external signals (external operation), operation from the PU (FR-DU07/FR-PU07/FR-PU04), combined operation of PU operation and external operation (external/PU combined operation, and network operation (when RS-485 terminals or a communication option is used).

Parameter Number	Name	Initial Value	Setting Range	Description	LED Indication ▭: Off ▭: On
79	**Operation mode selection**	0	0	Use external/PU switchover mode ((PU/EXT)) to switch between the PU and external operation mode. At power on, the inverter is placed in the external operation mode.	External operation mode  PU operation mode 
			1	Fixed to PU operation mode	
			2	Fixed to external operation mode Operation can be performed by switching between the external and Net operation mode.	External operation mode  NET operation mode 
			3	External/PU combined operation mode 1 **Running frequency**: PU (FR-DU07/FR-PU04/FR-PU07) setting or external signal input (multi-speed setting, across terminals 4-5 (valid when AU signal turns on)). **Start signal**: External signal input (terminal STF, STR)	
			4	External/PU combined operation mode 2 **Running frequency**: External signal input (Terminal 2, 4, 1, JOG, multi-speed selection, etc.) **Start signal**: Input from the PU (FR-DU07/FR-PU04/FR-PU07) ((FWD), (REV))	
			6	Switch-over mode Switch among PU operation, external operation, and NET operation while keeping the same operation status.	PU operation mode  External operation mode  NET operation mode 
			7	External operation mode (PU operation interlock) X12 signal ON Operation mode can be switched to the PU operation mode. (output stop during external operation) X12 signal OFF Operation mode can not be switched to the PU operation mode.	PU operation mode  External operation mode 

The above parameters can be changed during a stop in any operation mode.

WWW.BSNEW.IR

(1) Operation mode basics




- The operation mode is to specify the source of inputting the start command and set frequency of the inverter.
- Select the "external operation mode" when performing operation by basically using the control circuit terminals and providing potentiometers, switches, etc. externally, select the "PU operation mode" when inputting the start command and frequency setting through communication from the operation panel (FR-DU07), parameter unit (FR-PU04/FR-PU07), PU connector, or select the "network operation mode (NET operation mode)" when using the RS-485 terminals or communication option.
- The operation mode can be selected from the operation panel or with the communication instruction code.

REMARKS


- Either "3" or "4" may be set to select the PU/external combined operation, and these settings differ in starting method.
- In the initial setting, the stop function by STOP RESET of the PU (FR-DU07/FR-PU07) (PU stop selection) is valid also in other than the PU operation mode. *(Pr. 75 Reset selection/disconnected PU detection/PU stop selection. Refer to page 302.)*

(2) Operation mode switching method

When "0, 1, or 2" is set in *Pr. 340*



When "10 or 12" is set in *Pr. 340*



REMARKS


- For switching of operation by external terminals, refer to the following:

PU operation external interlock signal (X12 signal) ☞ *page 313*
PU-external operation switch-over signal (X16) ☞ *page 314*
PU-NET operation switchover signal (X65), External-NET operation switchover signal (X66) ☞ *page 315*
Pr. 340 Communication startup mode selection ☞ *page 316*

WWW.BSNEW.IR


(3) Operation mode selection flow

In the following flowchart, select the basic parameter setting and terminal connection related to the operation mode.




WWW.BSNEW.IR

(4) External operation mode (setting "0" (initial value), "2")



- Select the external operation mode when performing operation by providing a frequency setting potentiometer, start switch, etc. externally and connecting them to the control circuit terminals of the inverter.
- Basically, parameter changing is disabled in external operation mode. (Some parameters can be changed. Refer to *page 71* for the parameter list.)
- When "0" or "2" is selected for *Pr. 79*, the inverter enters the external operation mode at power on. (When using the network operation mode, refer to *page 316*)
- When parameter changing is seldom necessary, setting "2" fixes the operation mode to external operation mode. When frequent parameter changing is necessary, setting "0" (initial value) allows the operation mode to be changed easily to PU operation mode by pressing (PU/EXT) of the operation panel. When you switched to PU operation mode, always return to external operation mode.
- The STF and STR signal are used as a start command, and the terminal 2, 4, multi-speed setting, JOG signal, etc. are used as frequency setting.


(5) PU operation mode (setting "1")



- Select the PU operation mode when performing operation by only the key operation of the operation panel (FR-DU07) or parameter unit (FR-PU04/FR-PU07). Also select the PU operation mode when making communication using the PU connector.
- When "1" is selected for *Pr. 79*, the inverter enters the PU operation mode at power on. You cannot change to the other operation mode.
- The setting dial of the operation panel can be used for setting like a potentiometer. *(Pr. 161 Frequency setting/key lock operation selection, refer to page 387.)*
- When PU operation mode is selected, the PU operation mode signal (PU) can be output.
  For the terminal used for the PU signal output, assign the function by setting "10 (positive logic) or 110 (negative logic)" in any of *Pr. 190 to Pr. 196 (output terminal function selection)*.


WWW.BSNEW.IR


(6) PU/external combined operation mode 1 (setting "3")



- Select the PU/external combined operation mode 1 when making frequency setting from the operation panel (FR-DU07) or parameter unit (FR-PU04/FR-PU07) and inputting the start command with the external start switch.
- Select "3" for *Pr. 79*. You cannot change to the other operation mode.
- When a frequency is input from the external signal by multi-speed setting, it has a higher priority than the frequency setting of the PU. When AU is on, the terminal 4 is used.

(7) PU/external combined operation mode 2 (setting "4")





- Select the PU/external combined operation mode 2 when making frequency setting from the external potentiometer, multi-speed or JOG signal and inputting the start command by key operation of the operation panel (FR-DU07) or parameter unit (FR-PU04/FR-PU07).
- Select "4" for *Pr. 79*. You cannot change to the other operation mode.

WWW.BSNEW.IR

(8) Switch-over mode (setting "6")

· While continuing operation, you can switch between the PU operation, external operation and network operation (when RS-485 terminals or communication option is used).

Operation Mode Switching	Switching Operation/Operating Status
External operation → PU operation	Select the PU operation mode with the operation panel or parameter unit. · Rotation direction is the same as that of external operation. · The frequency set with the volume (frequency setting potentiometer), etc. is used unchanged. (Note that the setting will disappear when power is switched off or the inverter is reset.)
External operation → NET operation	Send the mode change command to network operation mode through communication. · Rotation direction is the same as that of external operation. · The value set with the setting volume (frequency setting potentiometer) or like is used unchanged. (Note that the setting will disappear when power is switched off or the inverter is reset.)
PU operation → external operation	Press the external operation key of the operation panel, parameter unit. · The rotation direction is determined by the input signal of the external operation. · The set frequency is determined by the external frequency setting signal.
PU operation → NET operation	Send the mode change command to network operation mode through communication. · Rotation direction and set frequency are the same as those of PU operation.
NET operation → external operation	Command to change to external mode is transmitted by communication. · Rotation direction is determined by the external operation input signal. · The set frequency is determined by the external frequency setting signal.
NET operation → PU operation	Select the PU operation mode with the operation panel or parameter unit. · The rotation direction and set frequency signal in network operation mode are used unchanged.

(9) PU operation interlock (setting "7")

· The PU operation interlock function is designed to forcibly change the operation mode to external operation mode when the PU operation interlock signal (X12) input turns off. This function prevents the inverter from being inoperative by the external command if the mode is accidentally left unswitched from PU operation mode.

· Set "7" (PU operation interlock) in *Pr. 79*.

· For the terminal used for X12 signal (PU operation interlock signal) input, set "12" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function. (Refer to *page 228* for *Pr. 178 to Pr. 189*.)

· When the X12 signal has not been assigned, the function of the MRS signal switches from MRS (output stop) to the PU operation interlock signal.

X12 (MRS) Signal	Function/Operation	
	Operation mode	Parameter write
ON	Operation mode (external, PU, NET) switching enabled Output stop during external operation	Parameter write enabled (*Pr. 77 Parameter write selection*, depending on the corresponding parameter write condition (Refer to *page 71* for the parameter list))
OFF	Forcibly switched to external operation mode External operation allowed Switching to PU or NET operation mode disabled	Parameter write disabled with exception of *Pr. 79*

<Function/operation changed by switching on-off the X12 (MRS) signal>

Operating Condition		X12 (MRS) Signal	Operation Mode	Operating Status	Switching to PU, NET Operation Mode
Operation mode	Status				
PU/NET	During stop	ON→OFF *1	External *2	If external operation frequency setting and start signal are entered, operation is performed in that status.	Disallowed
	Running	ON→OFF *1			Disallowed
External	During stop	OFF→ON	External *2	During stop	Allowed
		ON→OFF			Disallowed
	Running	OFF→ON		During operation → output stop	Disallowed
		ON→OFF		Output stop → operation	Disallowed

*1 The operation mode switches to external operation mode independently of whether the start signal (STF, STR) is on or off. Therefore, the motor is run in external operation mode when the X12 (MRS) signal is turned off with either of STF and STR on.

*2 At alarm occurrence, pressing STOP RESET of the operation panel resets the inverter.

CAUTION

· If the X12 (MRS) signal is on, the operation mode cannot be switched to PU operation mode when the start signal (STF, STR) is on.

· When the MRS signal is used as the PU interlock signal, the MRS signal serves as the normal MRS function (output stop) by turning on the MRS signal and then changing the *Pr. 79* value to other than "7" in the PU operation mode. Also as soon as "7" is set in *Pr. 79*, the signal acts as the PU interlock signal.

· When the MRS signal is used as the PU operation interlock signal, the logic of the signal is as set in *Pr. 17*. When *Pr. 17* = "2", read ON as OFF and OFF as ON in the above explanation.

· Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

WWW.BSNEW.IR

(10) Switching of operation mode by external terminal (X16 signal)

- When external operation and operation from the operation panel are used together, use of the PU-external operation switching signal (X16) allows switching between the PU operation mode and external operation mode during a stop (during a motor stop, start command off).
- When *Pr. 79* = any of "0, 6, 7", the operation mode can be switched between the PU operation mode and external operation mode. (*Pr. 79* = "6" switch-over mode can be changed during operation)
- For the terminal used for X16 signal input, set "16" in any of *Pr. 178 to Pr. 189 (input terminal function selection)* to assign the function.

Pr. 79 Setting		X16 Signal State Operation Mode		Remarks
		ON (external)	OFF (PU)	
0 (initial value)		External operation mode	PU operation mode	Can be switched to external, PU or NET operation mode
1		PU operation mode		Fixed to PU operation mode
2		External operation mode		Fixed to external operation mode (Can be switched to NET operation mode)
3, 4		External/PU combined operation mode		External/PU combined mode fixed
6		External operation mode	PU operation mode	Can be switched to external, PU or NET operation mode with operation continued
7	X12 (MRS) ON	External operation mode	PU operation mode	Can be switched to external, PU or NET operation mode (Output stop in external operation mode)
	X12 (MRS) OFF	External operation mode		Fixed to external operation mode (Forcibly switched to external operation mode)

REMARKS

- The operation mode status changes depending on the setting of *Pr. 340 Communication startup mode selection* and the ON/OFF status of the X65 and X66 signals. (For details, refer to *page 315*.)
- The priorities of *Pr. 79*, *Pr. 340* and signals are *Pr. 79* > X12 > X66 > X65 > X16 > *Pr. 340*.

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

WWW.BSNEW.IR

(11) Switching of operation mode by external terminal (X65, X66 signal)

· When *Pr. 79* = any of "0, 2, 6, 7", the operation mode switching signals (X65, X66) can be used to change the PU or external operation mode to network operation mode during a stop (during a motor stop or start command off). (*Pr. 79* = "6" switch-over mode can be changed during operation)

· When switching between the network operation mode and PU operation mode

1) Set *Pr. 79* to "0" (initial value), "6" or "7". (At the *Pr. 79* setting of "7", the operation mode can be switched when the X12 (MRS) signal turns on.)
2) Set "10 or 12" in *Pr. 340 Communication startup mode selection*.
3) Set "65" in any of *Pr. 178 to Pr. 189* to assign the NET-PU operation switchover signal (X65) to the external terminal.
4) The operation mode changes to PU operation mode when the X65 signal turns on, or to network operation mode when the X65 signal turns off.

Pr. 340 Setting	*Pr. 79* Setting		X65 Signal State		Remarks
			ON (PU)	OFF (NET)	
10, 12	0 (initial value)		PU operation mode *1	NET operation mode *2	Cannot be switched to external operation mode
	1		PU operation mode		Fixed to PU operation mode
	2		NET operation mode		Fixed to NET operation mode
	3, 4		External/PU combined operation mode		External/PU combined mode fixed
	6		PU operation mode *1	NET operation mode *2	Operation mode can be switched with operation continued Cannot be switched to external operation mode
	7	X12(MRS) ON	PU operation mode *1	NET operation mode *2, 3	Output stop in external operation mode
		X12(MRS) OFF	External operation mode		Forcibly switched to external operation mode

*1 NET operation mode when the X66 signal is on.

*2 PU operation mode when the X16 signal is off. PU operation mode also when *Pr. 550 NET mode operation command source selection* = "1" (communication option control source) and the communication option is not fitted.

*3 External operation mode when the X16 signal is on.

· When switching between the network operation mode and external operation mode

1)Set *Pr. 79* to "0" (initial value), "2", "6" or "7". (At the *Pr. 79* setting of "7", the operation mode can be switched when the X12 (MRS) signal turns on.)
2)Set "0 (initial value), 1 or 2" in *Pr. 340 Communication startup mode selection*.
3)Set "66" in any of *Pr. 178 to Pr. 189* to assign the NET-external operation switchover signal (X66) to the external terminal.
4)The operation mode changes to network operation mode when the X66 signal turns on, or to external operation mode when the X66 signal turns off.

Pr. 340 Setting	*Pr. 79* Setting		X66 Signal State		Remarks
			ON (NET)	OFF(external)	
0 (initial value), 1, 2	0 (initial value)		NET operation mode *1	External operation mode *2	
	1		PU operation mode		Fixed to PU operation mode
	2		NET operation mode *1	External operation mode	Cannot be switched to PU operation mode
	3, 4		External/PU combined operation mode		External/PU combined mode fixed
	6		NET operation mode *1	External operation mode *2	Operation mode can be switched with operation continued
	7	X12(MRS) ON	NET operation mode *1	External operation mode *2	Output stop in external operation mode
		X12(MRS) OFF	External operation mode		Forcibly switched to external operation mode

*1 PU operation mode is selected when *Pr. 550 NET mode operation command source selection* = "1" (communication option control source) and the communication option is not fitted.

*2 PU operation is selected when the X16 signal is off. When the X65 signal has been assigned, the operation mode changes with the ON/OFF state of the X65 signal.

REMARKS

· The priorities of *Pr. 79*, *Pr. 340* and signals are *Pr. 79* > X12 > X66 > X65 > X16 > *Pr. 340*.

CAUTION

· Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 15 Jog frequency ☞ *Refer to page 168*
Pr. 4 to 6, Pr. 24 to 27, Pr. 232 to Pr. 239 Multi-speed operation ☞ *Refer to page 166*
Pr. 75 Reset selection/disconnected PU detection/PU stop selection ☞ *Refer to page 302*
Pr. 161 Frequency setting/key lock operation selection ☞ *Refer to page 387*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*
Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*
Pr. 340 Communication startup mode selection ☞ *Refer to page 316*
Pr. 550 NET mode operation command source selection ☞ *Refer to page 317*

WWW.BSNEW.IR

4.23.2 Operation mode at power on (Pr. 79, Pr. 340)

When power is switched on or when power comes back on after instantaneous power failure, the inverter can be started up in network operation mode.
After the inverter has started up in the network operation mode, parameter write and operation can be performed from a program.
Set this mode for communication operation using the RS-485 terminals or communication option.

Parameter Number	Name	Initial Value	Setting Range	Description
79	**Operation mode selection**	0	0 to 4, 6, 7	Select the operation mode. *(Refer to page 310.)*
340 *	**Communication startup mode selection**	0	0	As set in *Pr. 79*.
			1, 2	Started in network operation mode. When the setting is "2", it will resume the pre-instantaneous power failure operation mode after an instantaneous power failure occurs.
			10, 12	Started in network operation mode. Operation mode can be changed between the PU operation mode and network operation mode from the operation panel. When the setting is "12", it will resume the pre-instantaneous power failure operation mode after an instantaneous power failure occurs.

The above parameters can be changed during a stop in any operation mode.
* The parameters can be set whenever the communication option is connected. *(Refer to page 306.)*.

(1) Specify operation mode at power on *(Pr. 340)*

· Depending on the *Pr. 79* and *Pr. 340* settings, the operation mode at power on (reset) changes as described below.

Pr. 340 Setting	*Pr. 79* Setting	Operation Mode at Power on, Power Restoration, Reset	Operation Mode Switching
0 (initial value)	0 (initial value)	External operation mode	Switching among the external, PU, and NET operation mode is enabled *2
	1	PU operation mode	Fixed to PU operation mode
	2	External operation mode	Switching between the external and Net operation mode is enabled Switching to PU operation mode is disabled
	3, 4	External/PU combined operation mode	Operation mode switching is disabled
	6	External operation mode	Switching among the external, PU, and NET operation mode is enabled while running
	7	X12 (MRS) signal ON ....External operation mode	Switching among the external, PU, and NET operation mode is enabled *2
		X12 (MRS) signal OFF ..External operation mode	Fixed to external operation mode (forcibly switched to external operation mode.)
1, 2 *1	0	NET operation mode	Same as when *Pr. 340* = "0"
	1	PU operation mode	
	2	NET operation mode	
	3, 4	External/PU combined operation mode	
	6	NET operation mode	
	7	X12 (MRS) signal ON NET operation mode X12 (MRS) signal OFF	
10, 12 *1	0	NET operation mode	Switching between the PU and NET operation mode is enabled *3
	1	PU operation mode	Same as when *Pr. 340* = "0"
	2	NET operation mode	Fixed to NET operation mode
	3, 4	External/PU combined operation mode	Same as when *Pr. 340* = "0"
	6	NET operation mode	Switching among the external, PU, and NET operation mode is enabled while running *3
	7	External operation mode	Same as when *Pr. 340* = "0"

*1 The *Pr. 340* setting "2" or "12" is mainly used for communication operation using the inverter RS-485 terminals. When a value other than "9999" (selection of automatic restart after instantaneous power failure) is set in *Pr. 57 Restart coasting time*, the inverter will resume the same operation state which was in before after power has been restored from an instantaneous power failure.
When *Pr. 340* = "1, 10", a start command turns off if power failure has occurred and then restored during a start command is on.
*2 The operation mode cannot be switched directly between the PU operation mode and network operation mode.
*3 Operation mode can be changed between the PU operation mode and network operation mode with PU/EXT key of the operation panel (FR-DU07) and X65 signal.

♦ Parameters referred to ♦

Pr. 57 Restart coasting time ☞ *Refer to page 261.*
Pr. 79 Operation mode selection ☞ *Refer to page 308.*

WWW.BSNEW.IR

4.23.3 Operation command source and speed command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551)

When the RS-485 terminals or communication option is used, the external operation command and speed command can be made valid. Also, the control command source in the PU operation mode can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
338	Communication operation command source	0	0	Operation command source communication
			1	Operation command source external
339	Communication speed command source	0	0	Speed command source communication
			1	Speed command source external (Frequency setting from communication is invalid, terminal 2 and 1 setting from external is valid)
			2	Speed command source external (Frequency setting from communication is valid, terminal 2 and 1 setting from external is invalid)
550 *	NET mode operation command source selection	9999	0	Communication option valid
			1	RS-485 terminals valid
			9999	Automatic recognition of the communication option Normally, the RS-485 terminals are valid. When the communication option is fitted, the communication option is valid.
551 *	PU mode operation command source selection	2	1	Select the RS-485 terminals as the PU operation mode control source.
			2	Select the PU connector as the PU operation mode control source.
			3	Select the USB connector as the PU operation mode control source.

The above parameters can be set whenever the communication option is connected. *(Refer to page 306.)*

* *Pr. 550* and *Pr. 551* are always write-enabled.

(1) Select the control source of the network operation mode *(Pr. 550)*

- Either the RS-485 terminals or communication option can be specified as the source of control in network operation mode.
- For example, set *Pr. 550* to "1" when executing parameter write, start command or frequency setting from the inverter RS-485 terminals in the network operation mode independently of whether the communication option is connected or not.

CAUTION

- Since *Pr. 550* = "9999" (automatic recognition of the communication option) in the initial setting, parameter write, start command and frequency setting cannot be executed by communication using the inverter RS-485 terminals when the communication option is fitted. (Monitor and parameter read can be performed.)

(2) Select the control source of the PU operation mode *(Pr. 551)*

- Any of the PU connector, RS-485 terminals, or USB connector can be specified as the source of control in the PU operation mode.
- In the PU operation mode, set *Pr. 551* to "1" when executing parameter write, start command or frequency setting through communication from the unit RS-485 terminals. Set *Pr. 551* to "3" for communication from the USB connector.

CAUTION

- The PU operation mode has a higher priority when *Pr. 550* = "1" (NET mode RS-485 terminals) and *Pr. 551* = "1" (PU mode RS-485 terminals). When the communication option is not fitted, therefore, the operation mode cannot be switched to network operation mode.
- Changed setting value is made valid when powering on or resetting the inverter.

Pr. 550 Setting	*Pr. 551* Setting	Operation Mode of Control Source				Remarks
		PU connector	USB connector	RS-485 terminals	Communication option	
0	1	×	×	PU operation mode *1	NET operation mode *2	
	2 (initial value)	PU operation mode	×	×	NET operation mode *2	
	3	×	PU operation mode	×	NET operation mode *2	
1	1	×	×	PU operation mode *1	×	Switching to NET operation mode disabled
	2 (initial value)	PU operation mode	×	NET operation mode	×	
	3	×	PU operation mode	NET operation mode	×	
9999 (initial value)	1	×	×	PU operation mode *1	NET operation mode *2	
	2 (initial value)	PU operation mode	×	×	NET operation mode *2	Communication option fitted
				NET operation mode	×	Communication option not fitted
	3	×	PU operation mode	×	NET operation mode *2	Communication option fitted
				NET operation mode	×	Communication option not fitted

*1 The Modbus-RTU protocol cannot be used in the PU operation mode. When using the Modbus-RTU protocol, set *Pr. 551* to "2".
*2 When the communication option is not fitted, the operation mode cannot be switched to network operation mode.

WWW.BSNEW.IR

(3) Controllability through communcation

Operation Location	Condition (*Pr. 551* Setting)	Operation Mode / Item	PU Operation	External Operation	External/PU Combined Operation Mode 1 (*Pr. 79* = 3)	External/PU Combined Operation Mode 2 (*Pr. 79* = 4)	NET Operation (when RS-485 terminals are used) *6	NET Operation (when communication option is used) *7
Control by RS-485 communication from PU connector	2 (PU connector)	Run command (start)	○	×	×	○	×	
		Run command (stop)	○	★ *3	★ *3	○	★ *3	
		Running frequency setting	○	×	○	×	×	
		Monitor	○	○	○	○	○	
		Parameter write	○ *4	× *5	○ *4	○ *4	× *5	
		Parameter read	○	○	○	○	○	
		Inverter reset	○	○	○	○	○	
	Except for 2	Run command (start)	×	×	×	×	×	
		Run command (stop)	★ *3	★ *3	★ *3	★ *3	★ *3	
		Running frequency setting	×	×	×	×	×	
		Monitor	○	○	○	○	○	
		Parameter write	× *5	× *5	× *5	× *5	× *5	
		Parameter read	○	○	○	○	○	
		Inverter reset	○	○	○	○	○	
Control by communication from RS-485 terminals	1 (RS-485 terminals)	Run command (start, stop)	○	×	×	○	×	
		Running frequency setting	○	×	○	×	×	
		Monitor	○	○	○	○	○	
		Parameter write	○ *4	× *5	○ *4	○ *4	× *5	
		Parameter read	○	○	○	○	○	
		Inverter reset	○	○	○	○	○	
	Except for 1	Run command (start, stop)	×	×	×	×	○ *1	×
		Running frequency setting	×	×	×	×	○ *1	×
		Monitor	○	○	○	○	○	○
		Parameter write	× *5	× *5	× *5	× *5	○ *4	× *5
		Parameter read	○	○	○	○	○	○
		Inverter reset	×	×	×	×	○ *2	×
Operation from the USB connector	3 (USB connector)	Run command (start, stop)	○	×	×	○	×	
		Running frequency setting	○	×	○	×	×	
		Monitor	○	○	○	○	○	
		Parameter write	○ *4	× *5	× *5	× *5	× *5	
		Parameter read	○	○	○	○	○	
		Inverter reset	○	○	○	○	○	
	Except for 3	Run command (start, stop)	×	×	×	×	×	
		Running frequency setting	×	×	×	×	×	
		Monitor	○	○	○	○	○	
		Parameter write	× *5	× *5	× *5	× *5	× *5	
		Parameter read	○	○	○	○	○	
		Inverter reset	○	○	○	○	○	
Control by communication from communication option	—	Run command (start, stop)	×	×	×	×	×	○ *1
		Running frequency setting	×	×	×	×	×	○ *1
		Monitor	○	○	○	○	○	○
		Parameter write	× *5	× *5	× *5	× *5	× *5	○ *4
		Parameter read	○	○	○	○	○	○
		Inverter reset	×	×	×	×	×	○ *2

○: Enabled, ×: Disabled, ★ : Some are enabled

WWW.BSNEW.IR

Operation Location	Condition (*Pr. 551* Setting)	Operation Mode / Item	PU Operation	External Operation	External/PU Combined Operation Mode 1 (*Pr. 79* = 3)	External/PU Combined Operation Mode 2 (*Pr. 79* = 4)	NET Operation (when RS-485 terminals are used) *6	NET Operation (when communication option is used) *7
Control circuit external terminals	—	Inverter reset	○	○	○	○	○	
		Run command (start, stop)	×	○	○	×	× *1	
		Frequency setting	×	○	×	○	× *1	

○: Enabled, ×: Disabled, ★ : Some are enabled

*1 As set in *Pr. 338 Communication operation command source* and *Pr. 339 Communication speed command source*. *(Refer to page 317)*
*2 At occurrence of RS-485 communication error, the inverter cannot be reset from the computer.
*3 Enabled only when stopped by the PU. At a PU stop, PS is displayed on the operation panel. As set in *Pr. 75 Reset selection/disconnected PU detection/PU stop selection*. *(Refer to page 302)*
*4 Some parameters may be write-disabled according to the *Pr. 77 Parameter write selection* setting and operating status. *(Refer to page 305)*
*5 Some parameters are write-enabled independently of the operation mode and command source presence/absence. When *Pr. 77* = 2, write is enabled. (Refer to *page 71* for the parameter list)Parameter clear is disabled.
*6 When *Pr. 550 NET mode operation command source selection* = 1 (RS-485 terminals valid) or *Pr. 550 NET mode operation command source selection* = 9999 and the communication option is not fitted.
*7 When *Pr. 550 NET mode operation command source selection* = 0 (communication option valid) or *Pr. 550 NET mode operation command source selection* = 9999 and the communication option is fitted.

(4) Operation at alarm occurrence

Alarm Definition	Operation Mode / Condition (*Pr. 551* setting)	PU Operation	External Operation	External/PU Combined Operation Mode 1 (*Pr. 79* = 3)	External/PU Combined Operation Mode 2 (*Pr. 79* = 4)	NET Operation (when RS-485 terminals are used) *5	NET Operation (when communication option is used) *6
Inverter fault	—	Stop					
PU disconnection of the PU connector	2 (PU connector)	Stop/continued *1, 4					
	Except for 2	Stop/continued *1					
Communication alarm of PU connector	2 (PU connector)	Stop/ continued *2	Continued		Stop/continued *2	Continued	
	Except for 2	Continued					
Communication alarm of RS-485 terminals	1 (RS-485 terminals)	Stop/ continued *2	Continued		Stop/continued *2	Continued	
	Except for 1	Continued				Stop/continued *2	Continued
Communication alarm of USB connector	3 (USB connector)	Stop/ continued *2	Continued				
	Except for 3	Continued					
Communication alarm of communication option	—	Continued				Stop/continued *3	Continued

*1 Can be selected using *Pr. 75 Reset selection/disconnected PU detection/PU stop selection*
*2 Can be selected using *Pr. 122 PU communication check time interval*, *Pr. 336 RS-485 communication check time interval or Pr. 548 USB communication check time interval.*
*3 As controlled by the communication option.
*4 In the PU jog operation mode, operation is always stopped when the PU is disconnected. Whether error (E.PEU) occurrence is allowed or not is as set in *Pr. 75 Reset selection/disconnected PU detection/PU stop selection*.
*5 When *Pr. 550 NET mode operation command source selection* = 1 (RS-485 terminals valid) or *Pr. 550 NET mode operation command source selection* = 9999 and the communication option is not fitted
*6 When *Pr. 550 NET mode operation command source selection* = 0 (communication option valid) or *Pr. 550 NET mode operation command source selection* = 9999 and the communication option is fitted

WWW.BSNEW.IR

(5) Selection of control source in network operation mode *(Pr. 338, Pr. 339)*

- As control sources, there are the operation command sources that control the signals related to the inverter start command and function selection and the speed command source that controls the signals related to frequency setting.
- In network operation mode, the commands from the external terminals and communication (RS-485 terminals or communication option) are as listed below.

Operation Location Selection			*Pr. 338 Communication operation command source*		0: NET			1: External			Remarks
			Pr. 339 Communication speed command source		0: NET	1:External	2:External	0: NET	1:External	2:External	
Fixed function (Terminal-equivalent function)			Running frequency from communication		NET	—	NET	NET	—	NET	
			Terminal 2		—	External	—	—	External	—	
			Terminal 4		—	External		—	External		
			Terminal 1		Compensation						
Selective function	*Pr. 178 to Pr. 189* setting	0	RL	Low speed operation command/remote setting clear stop-on-contact selection 0	NET	External		NET	External		*Pr. 59* = "0" (multi-speeds) *Pr. 59* = "1 , 2" (remote) *Pr. 270* = "1 , 3" (stop-on-contact)
		1	RM	Middle-speed operation command/remote setting deceleration	NET	External		NET	External		
		2	RH	High speed operation command/remote setting acceleration	NET	External		NET	External		
		3	RT	Second function selection/ Stop-on contact selection 1	NET			External			*Pr. 270* = "1 , 3" (stop-on-contact)
		4	AU	Current input selection	—	Combined		—	Combined		
		5	JOG	Jog operation selection	—			External			
		6	CS	Selection of automatic restart after instantaneous power failure	External						
		7	OH	External thermal relay input	External						
		8	REX	Fifteen speed selection	NET	External		NET	External		*Pr. 59* = "0" (multi-speeds)
		9	X9	Third function selection	NET			External			
		10	X10	Inverter operation enable signal	External						
		11	X11	FR-HC connection, instantaneous power failure detection	External						
		12	X12	PU operation external interlock	External						
		13	X13	External DC injection brake operation start	NET			External			
		14	X14	PID control valid terminal	NET	External		NET	External		
		15	BRI	Brake opening completion signal	NET			External			
		16	X16	PU-external operation switchover	External						
		17	X17	Load pattern selection forward rotation reverse rotation boost	NET			External			
		18	X18	V/F switching	NET			External			
		19	X19	Load torque high-speed frequency	NET			External			
		20	X20	S-pattern acceleration/deceleration C switchover	NET			External			
		22	X22	Orientation command	NET			External			
		23	LX	Pre-excitation	NET			External			
		24	MRS	Output stop	Combined			External			*Pr. 79* ≠ "7"
				PU operation interlock	External						*Pr. 79* = "7" When X12 signal is not assigned
		25	STOP	Start self-holding selection	—			External			
		26	MC	Control mode swichover	NET			External			
		27	TL	Torque limit selection	NET			External			
		28	X28	Start-time tuning start external input	NET			External			

WWW.BSNEW.IR

Operation Location Selection					Pr. 338 Communication operation command source / Pr. 339 Communication speed command source	0: NET			1: External			Remarks
						0: NET	1:External	2:External	0: NET	1:External	2:External	
Selective function	Pr. 178 to Pr. 189 setting	42	X42	Torque bias selection 1	NET			External				
		43	X43	Torque bias selection 2	NET			External				
		44	X44	P/PI control switchover	NET			External				
		50	SQ	Sequence start	NET			External				
		60	STF	Forward rotation command	NET			External				
		61	STR	Reverse rotation command	NET			External				
		62	RES	Reset	External							
		63	PTC	PID forward action switchover	External							
		64	X64	PID forward action switchover	NET	External		NET	External			
		65	X65	PU-NET operation switchover	External							
		66	X66	External-NET operation switchover	External							
		67	X67	Command source switchover	External							
		68	NP	Conditional position pulse train sign	External							
		69	CLR	Conditional position droop pulse clear	External							
		70	X70	DC feeding operation permission	NET			External				
		71	X71	DC feeding cancel	NET			External				
		74	X74	Magnetic flux decay output shutoff	NET			External				

[Explanation of table]

External : Control is valid only from external terminal signal.
NET : Control only from communication is valid
Combined : Control is valid from either of external terminal and communication.
— : Control is invalid from either of external terminal and communication.
Compensation : Control by signal from external terminal is only valid when *Pr. 28 Multi-speed input compensation selection* = "1"

REMARKS

- The control source of communication is as set in *Pr. 550* and *Pr. 551*.

(6) Switching of command source by external terminal (X67)

- In network operation mode, the command source switching signal (X67) can be used to switch the operation command source and speed command source. This signal can be utilized to control the signal input from both the external terminal and communication.
- Set "67" in any of *Pr. 178 to Pr. 189* (input terminal function selection) to assign the X67 signal to the external terminal.
- When the X67 signal is off, the operation command source and speed command source are external.

X67 Signal State	Operation Command Source	Speed Command Source
No signal assignment	According to *Pr. 338*	According to *Pr. 339*
ON		
OFF	Operation is valid only from external terminal signal.	

REMARKS

- The ON/OFF state of the X67 signal is reflected only during a stop. It is reflected after a stop when the terminal is switched during operation.
- When the X67 signal is off, a reset via communication is disabled.

CAUTION

- Changing the terminal assignment using *Pr. 178 to Pr. 189 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 28 Multi-speed input compensation selection ☞ *Refer to page 170.*
Pr. 59 Remote function selection ☞ *Refer to page 170.*
Pr. 79 Operation mode selection ☞ *Refer to page 308.*

WWW.BSNEW.IR


4.24 Communication operation and setting

Purpose	Parameter that must be Set		Refer to Page
Communication operation from PU connector	**Initial setting of computer link communication (PU connector)**	**Pr. 117 to Pr. 124**	327
Communication operation from RS-485 terminals	**Initial setting of computer link communication (RS-485 terminals)**	**Pr. 331 to Pr. 337, Pr. 341**	
	Modbus-RTU communication specifications	**Pr. 331, Pr. 332, Pr. 334, Pr. 343, Pr. 549**	340
Restrictions on parameter write through communication	**Communication EEPROM write selection**	**Pr. 342**	328
Operation by PLC function	**PLC function**	**Pr. 414 to Pr. 417, Pr. 498, Pr. 506 to Pr. 515**	353
Communication using USB (FR-Configurator)	**USB communication**	**Pr. 547, Pr. 548**	354

4.24.1 Wiring and configuration of PU connector

Using the PU connector, you can perform communication operation from a personal computer etc.
When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

(1) PU connector pin-outs



Pin Number	Name	Description
1)	SG	Earth (Ground) (connected to terminal 5)
2)	—	Operation panel power supply
3)	RDA	Inverter receive+
4)	SDB	Inverter send-
5)	SDA	Inverter send+
6)	RDB	Inverter receive-
7)	SG	Earth (Ground) (connected to terminal 5)
8)	—	Operation panel power supply


CAUTION

- Pins No. 2 and 8 provide power to the operation panel or parameter unit. Do not use these pins for RS-485 communication.
- Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector. The product could be damaged due to differences in electrical specifications.


WWW.BSNEW.IR

(2) PU connector communication system configuration and wiring

● System configuration



● Connection with RS-485 computer



* Make connections in accordance with the manual of the computer used. Fully check the terminal numbers of the computer since they change with the model.

REMARKS

· Computer-inverter connection cable
Refer to the following for the cable (RS-232C ⇔ RS-485 converter) for connection of the computer having the RS-232C interface with the inverter. Commercially available product examples (as of September, 2006)

Type	Maker
FA-T-RS40□ *	Mitsubishi Electric Engineering Co., Ltd.

* The converter cable cannot connect two or more inverters (the computer and inverter are connected on a 1:1 basis). Since the product is packed with the RS-232C cable and RS-485 cable (10BASE-T + RJ-45 connector), the cable and connector need not be prepared separately. Contact a maker for details of the product.

· Refer to the following when fabricating the cable on the user side.
Commercially available product examples (as of September, 2006)

	Product	Type	Maker
1)	10BASE-T cable	SGLPEV-T 0.5mm × 4P *	Mitsubishi Cable Industries, Ltd.

* Do not use pins No. 2, 8 of the 10- BASE-T cable.


CAUTION

When performing RS-485 communication with multiple inverters, use the RS-485 terminals. *(Refer to page 325)*

WWW.BSNEW.IR

4.24.2 Wiring and arrangement of RS-485 terminals

(1) RS-485 terminal layout



Name	Description
RDA1 (RXD1+)	Inverter receive+
RDB1 (RXD1-)	Inverter receive-
RDA2 (RXD2+)	Inverter receive+ (for branch)
RDB2 (RXD2-)	Inverter receive- (for branch)
SDA1 (TXD1+)	Inverter send+
SDB1 (TXD1-)	Inverter send-
SDA2 (TXD2+)	Inverter send+ (for branch)
SDB2 (TXD2-)	Inverter send- (for branch)
P5S (VCC)	5V Permissible load current 100mA
SG (GND)	Earth (Ground) (connected to terminal SD)


(2) Connection of RS-485 terminals and wires

Loosen the terminal screw and insert the cable into the terminal.

Screw size	M2
Tightening torque	0.22N•m to 0.25N•m
Cable size	0.3mm^2 to 0.75mm^2
Screwdriver	Small ⊖ flat-blade screwdriver (Tip thickness: 0.4mm /tip width: 2.5mm)

Wire the stripped cable after twisting it to prevent it from becoming loose. In addition, do not solder it.

Cable stripping size



Use a bar terminal as necessary.

CAUTION

Undertightening can cause signal loss or malfunction. Overtightening can cause a short circuit or malfunction due to damage to the screw or unit.

REMARKS

Information on bar terminals

Introduced products (as of September, 2006): Phoenix Contact Co.,Ltd.

Terminal Screw Size	Bar Terminal Model (with insulation sleeve)	Bar Terminal Model (without insulation sleeve)	Wire Size (mm^2)
M2	AI 0.5-6WH	A 0.5-6	0.3 to 0.5

☞Bar terminal crimping tool: CRIMPFOX ZA3 (Phoenix Contact Co., (Ltd.))

Use shielded or twisted cables for connection to the control circuit terminals and run them away from the main and power circuits (including the 200V relay sequence circuit).


When using the bar terminal (without insulation sleeve), use care so that the twisted wires do not come out.



WWW.BSNEW.IR


(3) RS-485 terminal system configuration

- **Connection of a computer to the inverter (1:1 connection)**



*Set the terminating resistor switch to the "100Ω" position.


- **Combination of computer and multiple inverters (1:n connection)**




WWW.BSNEW.IR

(4) RS-485 terminal wiring method

● **Wiring of one RS-485 computer and one inverter**



● **Wiring of one RS-485 computer and "n" inverters (several inverters)**




*1 Make connections in accordance with the manual of the computer used.
Fully check the terminal numbers of the computer since they change with the model.

*2 For the inverter farthest from the computer, set the terminating resistor switch to ON (100Ω side).


REMARKS

For branching, connect the wires as shown below.



(5) 2-wire type connection

If the computer is 2-wire type, pass wires across receiving terminals and transmission terminals of the RS-485 terminals to enable 2-wire type connection with the inverter.



REMARKS

· A program should be created so that transmission is disabled (receiving state) when the computer is not sending and reception is disabled (sending state) during sending to prevent the computer from receiving its own data.

WWW.BSNEW.IR

4.24.3 Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 124, Pr. 331 to Pr. 337, Pr. 341, Pr. 549)

Used to perform required settings for communication between the inverter and personal computer.

- There are two different communications: communication using the PU connector of the inverter and communication using the RS-485 terminals.
- You can perform parameter setting, monitor, etc. from the PU connector or RS-485 terminals of the inverter using the Mitsubishi inverter protocol (computer link communication).
- To make communication between the personal computer and inverter, initialization of the communication specifications must be made to the inverter.
  Data communication cannot be made if the initial settings are not made or there is any setting error.

[PU connector communication related parameter]

Parameter Number	Name	Initial Value	Setting Range	Description	
117	**PU communication station number**	0	0 to 31	Specify the inverter station number. Set the inverter station numbers when two or more inverters are connected to one personal computer.	
118	**PU communication speed**	192	48, 96, 192, 384	Set the communication speed. The setting value × 100 equals the communication speed. For example, the communication speed is 19200bps when the setting value is "192".	
119	**PU communication stop bit length**	1		Stop bit length	Data length
			0	1bit	8bit
			1	2bit	
			10	1bit	7bit
			11	2bit	
120	**PU communication parity check**	2	0	Without parity check	
			1	With odd parity check	
			2	With even parity check	
121	**Number of PU communication retries**	1	0 to 10	Set the permissible number of retries at occurrence of a data receive error. If the number of consecutive errors exceeds the permissible value, the inverter will come to an alarm stop.	
			9999	If a communication error occurs, the inverter will not come to an alarm stop.	
122	**PU communication check time interval**	9999	0	No PU connector communication	
			0.1 to 999.8s	Set the interval of communication check (signal loss detection) time. If a no-communication state persists for longer than the permissible time, the inverter will come to an alarm stop.	
			9999	No communication check (signal loss detection)	
123	**PU communication waiting time setting**	9999	0 to 150ms	Set the waiting time between data transmission to the inverter and response.	
			9999	Set with communication data.	
124	**PU communication CR/LF selection**	1	0	Without CR/LF	
			1	With CR	
			2	With CR/LF	

WWW.BSNEW.IR

[RS-485 terminal communication related parameter]

Parameter Number	Name	Initial Value	Setting Range	Description
331	RS-485 communication station number	0	0 to 31 (0 to 247) *1	Set the inverter station number. (same specifications as *Pr. 117*)
332	RS-485 communication speed	96	3, 6, 12, 24, 48, 96, 192, 384	Used to select the communication speed. (same specifications as *Pr. 118*)
333 *2	RS-485 communication stop bit length	1	0, 1, 10, 11	Select stop bit length and data length. (same specifications as *Pr. 119*)
334	RS-485 communication parity check selection	2	0, 1, 2	Select the parity check specifications. (same specifications as *Pr. 120*)
335 *3	RS-485 communication retry count	1	0 to 10, 9999	Set the permissible number of retries at occurrence of a data receive error. (same specifications as *Pr. 121*)
336 *3	RS-485 communication check time interval	0s	0	RS-485 communication can be made, but the inverter will come to an alarm stop in the NET operation mode.
			0.1 to 999.8s	Set the interval of communication check (signal loss detection) time. (same specifications as *Pr. 122*)
			9999	No communication check (signal loss detection)
337 *3	RS-485 communication waiting time setting	9999	0 to 150ms, 9999	Set the waiting time between data transmission to the inverter and response. (same specifications as *Pr. 123*)
341 *3	RS-485 communication CR/LF selection	1	0, 1, 2	Select presence/absence of CR/LF. (same specifications as *Pr. 124*)
549	Protocol selection	1	0	Mitsubishi inverter (computer link) protocol
			1	Modbus-RTU protocol *4

*1 When "1" (Modbus-RTU protocol) is set in *Pr. 549*, the setting range within parenthesis is applied.
*2 For the Modbus-RTU protocol, the data length is fixed to 8 bits and the stop bit depends on the *Pr. 334* setting. *(Refer to page 340)*
*3 The Modbus-RTU protocol becomes invalid.
*4 The Modbus-RTU protocol is valid for only communication from the RS-485 terminals.

CAUTION

- If communication is made without *Pr. 336 RS-485 communication check time interval* being changed from "0" (initial value), monitor, parameter read, etc. can be performed, but the inverter results in an alarm as soon as it is switched to the NET operation mode. If the operation mode at power on is the network operation mode, a communication alarm (E.SER) occurs after first communication.
  When performing operation or parameter write through communication, set "9999" or a greater value to *Pr. 336*. (The setting depends on the computer side program.) *(Refer to page 333)*
- Always reset the inverter after making the initial settings of the parameters. After you have changed the communication-related parameters, communication cannot be made until the inverter is reset.

4.24.4 Communication EEPROM write selection (Pr. 342)

Parameters written via the inverter's PU connector, RS-485 terminals, USB communication or from the communication option can be written to the RAM. Set this parameter when frequent parameter changes are required.

Parameter Number	Name	Initial Value	Setting Range	Description
342	Communication EEPROM write selection	0	0	Parameter values written by communication are written to the EEPROM and RAM.
			1	Parameter values written by communication are written to the RAM.

The above parameters can be set any time when the communication option is connected. *(Refer to page 306)*

- When changing the parameter values frequently, set "1" in *Pr. 342* to write them to the RAM. The life of the EEPROM will be shorter if parameter write is performed frequently with the setting unchanged from "0 (initial value)" (EEPROM write).

REMARKS

- When *Pr. 342* is set to "1" (only RAM write), the new values of the parameters will be cleared at power supply-off of the inverter. Therefore, the parameter values available when power is switched on again are the values stored in EEPROM previously.

WWW.BSNEW.IR

4.24.5 Mitsubishi inverter protocol (computer link communication)


You can perform parameter setting, monitor, etc. from the PU connector or RS-485 terminals of the inverter using the Mitsubishi inverter protocol (computer link communication).

(1) Communication specifications

· The communication specifications are given below.

Item		Description	Related Parameters
Communication protocol		Mitsubishi protocol (computer link)	Pr. 551
Conforming standard		EIA-485 (RS-485)	—
Number of inverters connected		1:N (maximum 32 units), setting is 0 to 31 stations	Pr. 117 Pr. 331
Communication speed	**PU connector**	Selected from among 4800/9600/19200 and 38400bps	Pr. 118
	RS-485 terminal	Can be selected from 300, 600, 1200, 2400, 4800, 9600, 19200 and 38400bps	Pr. 332
Control protocol		Asynchronous system	—
Communication method		Half-duplex system	—
Communication specifications	**Character system**	ASCII (7 bits or 8 bits can be selected)	Pr. 119 Pr. 333
	Start bit	1bit	—
	Stop bit length	1 bit or 2 bits can be selected	Pr. 119 Pr. 333
	Parity check	Check (even, odd) or no check can be selected	Pr. 120 Pr. 334
	Error check	Sum code check	—
	Terminator	CR/LF (presence or absence can be selected)	Pr. 124 Pr. 341
Waiting time setting		Selectable between presence and absence	Pr. 123 Pr. 337

(2) Communication procedure



· Data communication between the computer and inverter is made in the following procedure.

1) Request data is sent from the computer to the inverter. (The inverter will not send data unless requested.)
2) After waiting for the waiting time
3) The inverter sends return data to the computer in response to the computer request.
4) After having waited for the time taken for inverter processing
5) Answer from computer in response to reply data 3) is sent. (Even if 5) is not sent, subsequent communication is made properly.)

*1 If a data error is detected and a retry must be made, execute retry operation with the user program. The inverter comes to an alarm stop if the number of consecutive retries exceeds the parameter setting.

*2 On receipt of a data error occurrence, the inverter returns "reply data 3)" to the computer again. The inverter comes to an alarm stop if the number of consecutive data errors reaches or exceeds the parameter setting.

WWW.BSNEW.IR

(3) Communication operation presence/absence and data format types

· Data communication between the computer and inverter is made in ASCII code (hexadecimal code).
· Communication operation presence/absence and data format types are as follows:

Symbol	Operation		Run Command	Running Frequency	Parameter Write	Inverter Reset	Monitor	Parameter Read
1)	Communication request is sent to the inverter in accordance with the user program in the computer.		A A'	A	A	A	B	B
2)	Inverter data processing time		Present	Present	Present	Absent	Present	Present
3)	Reply data from the inverter (Data 1) is checked for error)	No error *1 (Request accepted)	C	C	C	C *2	E E'	E
		With error. (Request rejected)	D	D	D	D *2	D	D
4)	Computer processing delay time		Absent	Absent	Absent	Absent	Absent	Absent
5)	Answer from computer in response to reply data 3) (Data 3) is checked for error)	No error *1 (No inverter processing)	Absent	Absent	Absent	Absent	Absent (C)	Absent (C)
		With error (Inverter re-outputs 3))	Absent	Absent	Absent	Absent	F	F

*1 In the communication request data from the computer to the inverter, 10ms or more is also required after "no data error (ACK)". *(Refer to page 331)*
*2 The inverter response to the inverter reset request can be selected. *(Refer to page 335)*

1)Communication request data from the computer to the inverter

Format	Number of Characters												
	1	2	3	4	5	6	7	8	9	10	11	12	13
A (Data write)	ENQ *1	Inverter station number *2		Instruction code		Waiting time *3	Data				Sum check		*4
A' (Data write)	ENQ *1	Inverter station number *2		Instruction code		Waiting time *3	Data		Sum check		*4		
B (Data read)	ENQ *1	Inverter station number *2		Instruction code		Waiting time *3	Sum check		*4				

3)Reply data from the inverter to the computer

· When data is written

Format	Number of Characters				
	1	2	3	4	5
C (No data error detected)	ACK *1	Inverter station number *2		*4	
D (Data error detected)	NAK *1	Inverter station number *2		Error Code	*4

· When data is read

Format	Number of Characters										
	1	2	3	4	5	6	7	8	9	10	11
E (No data error detected)	STX *1	Inverter station number *2		Read data				ETX *1	Sum check		*4
E' (No data error detected)	STX *1	Inverter station number *2		Read data		ETX *1	Sum check		*4		
D (Data error detected)	NAK *1	Inverter station number *2		Error Code	*4						

5)Send data from the computer to the inverter during data read

Format	Number of Characters			
	1	2	3	4
C (No data error detected)	ACK *1	Inverter station number *2		*4
F (Data error detected)	NAK *1	Inverter station number *2		*4

*1 Indicate a control code
*2 Specify the inverter station numbers between H00 and H1F (stations 0 to 31) in hexadecimal.
*3 When *Pr. 123, Pr. 337 (waiting time setting)* ≠ "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
*4 CR, LF code
When data is transmitted from the computer to the inverter, CR (carriage return) and LF (line feed) codes are automatically set at the end of a data group on some computers. In this case, setting must also be made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using *Pr. 124 or Pr. 341 (CR, LF presence/absence selection)*.

WWW.BSNEW.IR

(4) Data definitions

1) Control codes


Signal Name	ASCII Code	Description
STX	H02	Start Of Text (start of data)
ETX	H03	End Of Text (end of data)
ENQ	H05	Enquiry (communication request)
ACK	H06	Acknowledge (no data error detected)
LF	H0A	Line Feed
CR	H0D	Carriage Return
NAK	H15	Negative Acknowledge (data error detected)

2) Inverter station number
Specify the station number of the inverter which communicates with the computer.

3) Instruction code
Specify the processing request, e.g. operation or monitoring, given by the computer to the inverter. Hence, the inverter can be run and monitored in various ways by specifying the instruction code as appropriate. *(Refer to page 454)*

4) Data
Indicates the data such as frequency and parameters transferred to and from the inverter. The definitions and ranges of set data are determined in accordance with the instruction codes. *(Refer to page 454)*


5) Waiting time
Specify the waiting time between the receipt of data at the inverter from the computer and the transmission of reply data. Set the waiting time in accordance with the response time of the computer between 0 and 150ms in 10ms increments (e.g. 1 = 10ms, 2 = 20ms).




REMARKS

- When *Pr. 123, Pr. 337 (waiting time setting)* ≠ "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- The data check time changes depending on the instruction code. *(Refer to page 332)*

6) Sum check code
The sum check code is 2-digit ASCII (hexadecimal) representing the lower 1 byte (8 bits) of the sum (binary) derived from the checked ASCII data



* When the *Pr. 123 Waiting time setting* ≠ "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)




WWW.BSNEW.IR

7) Error Code

If any error is found in the data received by the inverter, its definition is sent back to the computer together with the NAK code.

Error Code	Error Item	Error Description	Inverter Operation
H0	Computer NAK error	The number of errors consecutively detected in communication request data from the computer is greater than allowed number of retries.	Brought to an alarm stop if error occurs continuously more than the allowable number of retries. (E.PUE/E.SER)
H1	Parity error	The parity check result does not match the specified parity.	
H2	Sum check error	The sum check code in the computer does not match that of the data received by the inverter.	
H3	Protocol error	The data received by the inverter has a grammatical mistake. Alternatively, data receive is not completed within the predetermined time. CR or LF is not as set in the parameter.	
H4	Framing error	The stop bit length differs from the initial setting.	
H5	Overrun error	New data has been sent by the computer before the inverter completes receiving the preceding data.	
H6	—	—	—
H7	Character error	The character received is invalid (other than 0 to 9, A to F, control code).	Does not accept received data but is not brought to alarm stop.
H8	—	—	—
H9	—	—	—
HA	Mode error	Parameter write was attempted in other than the computer link operation mode, when operation command source is not selected or during inverter operation.	Does not accept received data but is not brought to alarm stop.
HB	Instruction code error	The specified command does not exist.	
HC	Data range error	Invalid data has been specified for parameter write, frequency setting, etc.	
HD	—	—	—
HE	—	—	—
HF	—	—	—

(5) Response time



[Formula for data sending time]

$$\frac{1}{\text{Communication speed (bps)}} \times \text{Number of data characters} \times \text{Communication specifications (total number of bits)} = \text{Data send time (s)}$$

(Refer to page 330) (See below.)

●Communication specifications

Name		Number of Bits
Stop bit length		1 bit 2 bits
Data length		7 bits 8 bits
Parity check	Yes	1 bit
	No	0

In addition to the above, 1 start bit is necessary.
Minimum number of total bits..... 9 bits
Maximum number of total bits..... 12 bits

●Data check time


Item	Check Time
Various monitors, run command, frequency setting (RAM)	< 12ms
Parameter read/write, frequency setting (EEPROM)	< 30ms
Parameter clear/all clear	< 5s
Reset command	No answer

WWW.BSNEW.IR


(6) Retry count setting (*Pr. 121, Pr. 335*)

- Set the permissible number of retries at occurrence of a data receive error. (Refer to *page 332* for data receive error for retry)
- When data receive errors occur consecutively and exceed the permissible number of retries set, an inverter alarm (E.PUE) is provided and the output is shut off.
- When "9999" is set, an inverter alarm is not provided even if data receive error occurs but a minor fault output signal (LF) is output.
  For the terminal used for the LF signal output, assign the function by setting "98 (positive logic) or 198 (negative logic)" in any of *Pr. 190 to Pr. 196 (output terminal function selection)*.

Example: PU connector communication, *Pr. 121* = "1" (initial value)




Example: PU connector communication, *Pr. 121* = "9999"



(7) Signal loss detection *(Pr. 122, Pr. 336 RS-485 communication check time interval)*

- If a signal loss (communication stop) is detected between the inverter and computer as a result of a signal loss detection, a communication error (PU connector communication: E.PUE, RS-485 terminal communication: E.SER) occurs and the inverter output is shut off.
- When the setting is "9999", communication check (signal loss detection) is not made.
- When the setting is "0", communication from the PU connector cannot be performed. For communication via the RS-485 terminals, monitor, parameter read, etc. can be peformed, but a communication error (E.SER) occurs as soon as the inverter is switched to network operation mode.
- A signal loss detection is made when the setting is any of "0.1s" to "999.8s". To make a signal loss detection, it is necessary to send data (control code *refer to page 331*) from the computer within the communication check time interval. (The send data has nothing to do with the station number)
- Communication check is started at the first communication in the operation mode having the operation source (PU operation mode for PU connector communication in the initial setting or network operation mode for RS-485 terminal communication).

Example: PU connector communication, *Pr. 122* = "0.1 to 999.8s"




WWW.BSNEW.IR

(8) Instructions for the program

1) When data from the computer has any error, the inverter does not accept that error. Hence, in the user program, always insert a retry program for data error.
2) All data communication, e.g. run command or monitoring, are started when the computer gives a communication request. The inverter does not return any data without the computer's request. Hence, design the program so that the computer gives a data read request for monitoring, etc. as required.
3) Program example
   To change the operation mode to computer link operation

```
                                                  Initial setting of I/O file
 10 OPEN"COM1:9600,E,8,2,HD"AS #1          : Communication file open
 20 COMST1,1,1:COMST1,2,1                  : Circuit control signal (RS, ER) ON/OFF setting
 30 ON COM(1)GOSUB*REC                     : Interrupt definition at data receive
 40 COM(1)ON                               : Interrupt enable
 50 D$="01FB10002"                         Send data setting
 60 S=0
 70 FOR I=1 TO LEN(D$)
 80 A$=MID$(D$,I,1)
 90 A=ASC(A$)
100 S=S+A                                  Sum code calculation
110 NEXTI
120 D$=CHR$(&H5)+D$+RIGHT$(HEX$(S),2) : Addition of control code and sum code
130 PRINT#1,D$                             Data transmission
140 GOTO 50
1000 *REC                                  Interrupt data receive
1010 IF LOC(1)=0 THEN RETURN              : Interrupt occurrence at data receive
1020 PRINT"RECEIVE DATA"
1030 PRINT INPUT$(LOC(1),#1)
1040 RETURN
```

General flow



⚠ CAUTION

⚠ Always set the communication check time interval before starting operation to prevent hazardous conditions.


⚠ Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal loss etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter will come to an alarm stop (E.PUE, E.SER). The inverter can be coasted to a stop by switching on its RES signal or by switching power off.

⚠ If communication is broken due to signal loss, computer fault etc., the inverter does not detect such a fault. This should be fully noted.

WWW.BSNEW.IR

(9) Setting items and set data

After completion of parameter setting, set the instruction codes and data then start communication from the computer to allow various types of operation control and monitoring.

No.	Item		Read/ Write	Instruction Code	Data Description	Number of Data Digits (format)
1	Operation mode		Read	H7B	H0000: Network operation H0001: External operation H0002: PU operation (RS-485 communication operation via PU connector)	4 digits (B.E/D)
			Write	HFB		4 digits (A,C/D)
2	Monitor	Output frequency/ speed	Read	H6F	H0000 to HFFFF: Output frequency in 0.01Hz increments Speed in 1r/min increments (when *Pr. 37* = 1 to 9998 or *Pr. 144* = 2 to 10, 102 to 110)	4 digits (B.E/D)
		Output current	Read	H70	H0000 to HFFFF: Output current (hexadecimal) in 0.01A increments (FR-A720-02150(FR-A740-01100) or less) / 0.1A increments (FR-A720-02880(FR-A740-01440) or more)	4 digits (B.E/D)
		Output voltage	Read	H71	H0000 to HFFFF: Output voltage (hexadecimal) in 0.1V increments	4 digits (B.E/D)
		Special monitor	Read	H72	H0000 to HFFFF: Monitor data selected in instruction code HF3	4 digits (B.E/D)
		Special monitor selection No.	Read	H73	H01 to H3C: Monitor selection data Refer to the special monitor No. table *(page 337)*	2digits (B.E'/D)
			Write	HF3		2digits (A',C/D)
		Alarm definition	Read	H74 to H77	H0000 to HFFFF: Two most recent alarm definitions  Refer to the alarm data table *(page 338)*	4 digits (B.E/D)
3	Run command (extended)		Write	HF9	You can set the control input commands such as the forward rotation signal (STF) and reverse rotation signal (STR). (*Refer to page 338* for details)	4 digits (A,C/D)
	Run command		Write	HFA		2digits (A',C/D)
4	Inverter status monitor (extended)		Read	H79	You can monitor the status of the output signals such as forward rotation, reverse rotation and inverter running (RUN). (*Refer to page 339* for details)	4 digits (B.E/D)
	Inverter status monitor		Read	H7A		2digits (B.E'/D)
5	Set frequency (RAM)		Read	H6D	Read the set frequency/speed from the RAM or EEPROM. H0000 to HFFFF: Set frequency in 0.01Hz increments Speed in 1r/min increments (When *Pr. 37* = 1 to 9998 or *Pr. 144* = 2 to 10, 102 to 110)	4 digits (B.E/D)
	Set frequency (EEPROM)			H6E		
	Set frequency (RAM)		Write	HED	Write the set frequency/speed into the RAM or EEPROM. H0000 to H9C40 (0 to 400.00Hz) : frequency in 0.01Hz increments H0000 to H270E (0 to 9998) : speed in r/min increments (when *Pr. 37* = 1 to 9998 or *Pr. 144* = 2 to 10, 102 to 110) · To change the running frequency consecutively, write data to the inverter RAM. (Instruction code: HED)	4 digits (A,C/D)
	Set frequency (RAM, EEPROM)			HEE		
6	Inverter reset		Write	HFD	H9696: Resets the inverter. · As the inverter is reset at start of communication by the computer, the inverter cannot send reply data back to the computer.	4 digits (A,C/D)
					H9966: Resets the inverter. · When data is sent normally, ACK is returned to the computer and then the inverter is reset.	4 digits (A,D)
7	Alarm definition all clear		Write	HF4	H9696: Alarm history batch clear	4 digits (A,C/D)

Refer to *page 330* for data formats (A, A', B, B', C, D)

WWW.BSNEW.IR

<table>
<tr><th>No.</th><th>Item</th><th>Read/ Write</th><th>Instruction Code</th><th>Data Description</th><th>Number of Data Digits (format)</th></tr>
<tr><td>8</td><td>All parameter clear</td><td>Write</td><td>HFC</td><td>All parameters return to the initial values.
Any of four different all clear operations are performed according to the data.
<table>
<tr><th>Pr. / Data</th><th>Communi-cation Pr. *1</th><th>Calibration Pr. *2</th><th>Other Pr. *3</th><th>HEC HF3 HFF</th></tr>
<tr><td>H9696</td><td>○</td><td>×</td><td>○</td><td>○</td></tr>
<tr><td>H9966</td><td>○</td><td>○</td><td>○</td><td>○</td></tr>
<tr><td>H5A5A</td><td>×</td><td>×</td><td>○</td><td>○</td></tr>
<tr><td>H55AA</td><td>×</td><td>○</td><td>○</td><td>○</td></tr>
</table>
When all parameter clear is executed for H9696 or H9966, communication-related parameter settings also return to the initial values. When resuming operation, set the parameters again.
*1 Refer to page 327, 328.
*2 Refer to the list of calibration parameters on the next page for calibration parameters.
*3 Pr. 75 is not cleared</td><td>4 digits (A,C/D)</td></tr>
<tr><td>9</td><td rowspan="2">Parameters</td><td>Read</td><td>H00 to H63</td><td rowspan="2">Refer to the instruction code (page 454) and write and/or read the values as required.
When setting Pr. 100 and later, link parameter extended setting must be set.</td><td>4 digits (B.E/D)</td></tr>
<tr><td>10</td><td>Write</td><td>H80 to HE3</td><td>4 digits (A,C/D)</td></tr>
<tr><td rowspan="2">11</td><td rowspan="2">Link parameter extended setting</td><td>Read</td><td>H7F</td><td rowspan="2">Parameter description is changed according to the H00 to H09 setting.
For details of the setting, refer to the instruction code (page 454).</td><td>2digits (B.E'/D)</td></tr>
<tr><td>Write</td><td>HFF</td><td>2digits (A',C/D)</td></tr>
<tr><td rowspan="2">12</td><td rowspan="2">Second parameter changing (instruction code HFF=1, 9)</td><td>Read</td><td>H6C</td><td rowspan="2">When setting the calibration parameters *1
H00:Frequency *2
H01: Parameter-set analog value
H02: Analog value input from terminal
*1 Refer to the list of calibration parameters on the next page for calibration parameters.
*2 The gain frequency can also be written using Pr. 125 (instruction code H99) or Pr. 126 (instruction code H9A).</td><td>2digits (B.E'/D)</td></tr>
<tr><td>Write</td><td>HEC</td><td>2digits (A',C/D)</td></tr>
</table>

Refer to *page 330* for data formats (A, A', B, B', C, D)

REMARKS

- Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999".
- For the instruction codes HFF, HEC and HF3, their values are held once written but cleared to zero when an inverter reset or all clear is performed.

Example) When reading the *C3 (Pr. 902) and C6 (Pr. 904)* settings from the inverter of station 0

	Computer Send Data	Inverter Send Data	Description
1)	ENQ 00 FF 0 01 82	ACK 00	Set "H01" in the extended link parameter.
2)	ENQ 00 EC 0 01 7E	ACK 00	Set "H01" in second parameter changing.
3)	ENQ 00 5E 0 0F	STX 00 0000 ETX 25	*C3 (Pr. 902)* is read. 0% is read.
4)	ENQ 00 60 0 FB	STX 00 0000 ETX 25	*C6 (Pr. 904)* is read. 0% is read.

To read/write *C3 (Pr. 902)* and *C6 (Pr. 904)* after inverter reset or parameter clear, execute from 1) again.

WWW.BSNEW.IR

●List of calibration parameters

Para meter	Name	Instruction code		
		Read	Write	Extended
C2 (902)	Terminal 2 frequency setting bias frequency	5E	DE	1
C3 (902)	Terminal 2 frequency setting bias	5E	DE	1
125 (903)	Terminal 2 frequency setting gain frquency	5F	DF	1
C4 (903)	Terminal 2 frequency setting gain	5F	DF	1
C5 (904)	Terminal 4 frequency setting bias frequency	60	E0	1
C6 (904)	Terminal 4 frequency setting bias	60	E0	1
126 (905)	Terminal 4 frequency setting gain frequency	61	E1	1
C7 (905)	Terminal 4 frequency setting gain	61	E1	1
C12 (917)	Terminal 1 bias frequency (speed)	11	91	9

Para meter	Name	Instruction code		
		Read	Write	Extended
C13 (917)	Terminal 1 bias frequency (speed)	11	91	9
C14 (918)	Terminal 1 gain frequency (speed)	12	92	9
C15 (918)	Terminal 1 gain (speed)	12	92	9
C16 (919)	Terminal 1 bias command (torque/ magnetic flux)	13	93	9
C17 (919)	Terminal 1 bias (torque/magnetic flux)	13	93	9
C18 (920)	Terminal 1 gain command (torque/ magnetic flux)	14	94	9
C19 (920)	Terminal 1 gain (torque/magnetic flux)	14	94	9
C38 (932)	Terminal 4 bias command (torque/ magnetic flux)	20	A0	9

Para meter	Name	Instruction code		
		Read	Write	Extended
C39 (932)	Terminal 4 bias (torque/magnetic flux)	20	A0	9
C40 (933)	Terminal 4 gain command (torque/ magnetic flux)	21	A1	9
C41 (933)	Terminal 4 gain (torque/magnetic flux)	21	A1	9

[Special monitor selection No.]

Refer to *page 250* for details of the monitor description.

Data	Description	Increments
H01	Output frequency	0.01Hz
H02	Output current	0.01A/ 0.1A *1
H03	Output voltage	0.1V
H05	Frequency setting	0.01Hz
H06	Running speed	1r/min
H07	Motor torque	0.1%
H08	Converter output voltage	0.1V
H09	Regenerative brake duty	0.1%
H0A	Electronic thermal relay function load factor	0.1%
H0B	Output current peak value	0.01A/ 0.1A *1
H0C	Converter output voltage peak value	0.1V

Data	Description	Increments
H0D	Input power	0.01kW/ 0.1kW *1
H0E	Output power	0.01kW/ 0.1kW *1
H0F	Input terminal status *2	—
H10	Output terminal status *3	—
H11	Load meter	0.1%
H12	Motor excitation current	0.01A/ 0.1A *1
H13	Position pulse	—
H14	Cumulative energization time	1h
H16	Orientation status	—
H17	Actual operation time	1h
H18	Motor load factor	0.1%
H19	Cumulative power	1kWh

Data	Description	Increments
H20	Torque command	0.1%
H21	Torque current command	0.1%
H22	Motor output	0.01kW/ 0.1kW *1
H23	Feedback pulse	—
H32	Power saving effect	Variable
H33	Cumulative saving power	Variable
H34	PID set point	0.1%
H35	PID measured value	0.1%
H36	PID deviation value	0.1%
H3A	Option input terminal status1 *4	—
H3B	Option input terminal status2 *5	—
H3C	Option output terminal status *6	—

*1 The setting depends on capacities. (FR-A720-02150 (FR-A740-01100) or less / FR-A740-02880(FR-A740-01440) or more)

*2 Input terminal monitor details

b15															b0
—	—	—	—	CS	RES	STOP	MRS	JOG	RH	RM	RL	RT	AU	STR	STF

*3 Output terminal monitor details

b15															b0
—	—	—	—	—	—	—	—	—	ABC2	ABC1	FU	OL	IPF	SU	RUN

*4 Details of option input terminal monitor 1 (input terminal status of FR-A7AX)-all terminals are off when an option is not fitted

b15															b0
X15	X14	X13	X12	X11	X10	X9	X8	X7	X6	X5	X4	X3	X2	X1	X0

*5 Details of option input terminal monitor 2 (input terminal status of FR-A7AX)-all terminals are off when an option is not fitted

b15															b0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	DY

*6 Details of option output terminal monitor (output terminal status of FR-A7AY/A7AR)-all terminals are off when an option is not fitted

b15															b0
—	—	—	—	—	—	RA3	RA2	RA1	Y6	Y5	Y4	Y3	Y2	Y1	Y0

WWW.BSNEW.IR

[Alarm data]


Refer to *page 399* for details of alarm description.

Data	Description
H00	No alarm
H10	E.OC1
H11	E.OC2
H12	E.OC3
H20	E.OV1
H21	E.OV2
H22	E.OV3
H30	E.THT
H31	E.THM
H40	E.FIN
H50	E.IPF
H51	E.UVT
H52	E.ILF
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT

Data	Description
H91	E.PTC
HA0	E.OPT
HA3	E.OP3
HB0	E.PE
HB1	E.PUE
HB2	E.RET
HB3	E.PE2
HC0	E.CPU
HC1	E.CTE
HC2	E.P24
HC4	E.CDO
HC5	E.IOH
HC6	E.SER
HC7	E.AIE
HC8	E.USB
HD0	E.OS
HD1	E.OSD
HD2	E.ECT

Data	Description
HD3	E.OD
HD5	E.MB1
HD6	E.MB2
HD7	E.MB3
HD8	E.MB4
HD9	E.MB5
HDA	E.MB6
HDB	E.MB7
HDC	E.EP
HF1	E.1
HF2	E.2
HF3	E.3
HF6	E.6
HF7	E.7
HFB	E.11
HFD	E.13

Alarm description display example (instruction code H74)



[Run command]

Item	Instruction Code	Bit Length	Description	Example
Run command	HFA	8bit	b0: AU (current input selection) *1 b1: Forward rotation command b2: Reverse rotation command b3: RL (low speed operation command) *1 b4: RM (middle speed operation command) *1 b5: RH (high speed operation command) *1 b6: RT (second function selection) *1 b7: MRS (output stop) *1	[Example 1] H02 Forward rotation b7 b0 0 0 0 0 0 0 1 0 [Example 2] H00 Stop b7 b0 0 0 0 0 0 0 0 0
Run command (extended)	HF9	16bit	b0:AU (current input selection) *1 b1:Forward rotation command b2:Reverse rotation command b3:RL (low speed operation command) *1 b4:RM (middle speed operation command) *1 b5: RH (high speed operation command) *1 b6:RT (second function selection) *1 b7:MRS (output stop) *1 b8:JOG (Jog operation) *2 b9:CS (selection of automatic restart after instantaneous power failure) *2 b10: STOP (start self-holding) *2 b11:RES (reset) *2 b12:— b13:— b14:— b15:—	[Example 1] H0002 Forward rotation b15 b0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0 [Example 2] H0800 low speed operation (When *Pr. 189 RES terminal function selection* is set to "0") b15 b0 0 0 0 0 1 0 0 0 0 0 0 0 0 0 0 0

*1 The signal within parentheses is the initial setting. The description changes depending on the setting of *Pr. 180 to Pr. 184, Pr. 187 (input terminal function selection) (page 228)*.

*2 The signal within parentheses is the initial setting. Since jog operation/selection of automatic restart after instantaneous power failure/start self-holding/reset cannot be controlled by the network, bit 8 to bit 11 are invalid in the initial status. When using bit 8 to bit 11, change the signals with *Pr. 185, Pr. 186, Pr. 188, Pr. 189 (input terminal function selection) (page228)*. (Reset can be executed with the instruction code HFD.)

WWW.BSNEW.IR

[Inverter status monitor]

Item	Instruction Code	Bit Length	Description	Example
Inverter status monitor	H7A	8bit	b0:RUN (inverter running)* b1:Forward rotation b2:Reverse rotation b3:SU (up to frequency) * b4:OL (overload) * b5:IPF (instantaneous power failure) * b6:FU (frequency detection)* b7:ABC1 (alarm) *	[Example 1] H02 ··· During forward rotation b7 b0 0 0 0 0 0 0 1 0 [Example 2] H80 ··· Stop at alarm occurrence b7 b0 0 0 0 0 0 0 1 0
Inverter status monitor (extended)	H79	16bit	b0:RUN (inverter running) * b1:Forward rotation b2:Reverse rotation b3:SU (up to frequency) * b4:OL (overload) * b5:IPF (instantaneous power failure) * b6:FU (frequency detection) * b7:ABC1 (alarm) * b8:ABC2 (—)* b9:— b10:— b11:— b12:— b13:— b14:— b15: Alarm occurrence	[Example 1] H0002 ···During forward rotation b15 b0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0 [Example 2] H8080 ···Stop at alarm occurrence b15 b0 1 0 0 0 0 0 0 0 1 0 0 0 0 0 0 0

* The signal within parentheses is the initial setting. The description changes depending on the setting of *Pr. 190 to Pr. 196 (output terminal function selection)*.

WWW.BSNEW.IR

4.24.6 Modbus-RTU communication specifications (Pr. 331, Pr. 332, Pr. 334, Pr. 343, Pr. 539, Pr. 549)

Using the Modbus-RTU communication protocol, communication operation or parameter setting can be performed from the RS-485 terminals of the inverter.

Parameter Number	Name	Initial Value	Setting Range	Description
331	RS-485 communication station number	0	0	Broadcast communication is selected.
			1 to 247	Specify the inverter station number. Set the inverter station numbers when two or more inverters are connected to one personal computer.
332	RS-485 communication speed	96	3, 6, 12, 24, 48, 96, 192, 384	Set the communication speed. The setting value × 100 equals the communication speed. For example, the communication speed is 9600bps when the setting value is "96".
334	RS-485 communication parity check selection	2	0	Without parity check Stop bit length 2bits
			1	With odd parity check Stop bit length 1bit
			2	With even parity check Stop bit length 1bit
343	Communication error count	0	—	Display the number of communication errors during Modbus-RTU communication. Reading only
539	Modbus-RTU communication check time interval	9999	0	Modbus-RTU communication can be made, but the inverter will come to an alarm stop in the NET operation mode.
			0.1 to 999.8s	Set the interval of communication check time. (same specifications as *Pr. 122*)
			9999	No communication check (signal loss detection)
549	Protocol selection	1	0	Mitsubishi inverter (computer link) protocol
			1	Modbus-RTU protocol

CAUTION

When Modbus-RTU communication is performed from the master with address 0 (station 0) set, broadcast communication is selected and the inverter does not send a response message to the master.
When response from the inverter is necessary, set a value other than "0" in *Pr. 331* (initial value 0).
Some functions are invalid for broadcast communication. *(Refer to page 342)*

REMARKS

- When using the Modbus-RTU protocol, set *Pr. 549 Protocol selection* to "1".
- When the communication option is fitted with *Pr. 550 NET mode operation command source selection* set to "9999" (initial value), the command source (e.g. run command) from the RS-485 terminals is invalid. *(Refer to page 317)*

(1) Communication specifications

- The communication specifications are given below.

Item		Description	Related Parameters
Communication protocol		Modbus-RTU protocol	Pr. 549
Conforming standard		EIA-485 (RS-485)	—
Number of inverters connected		1: N (maximum 32 units), setting is 0 to 247 stations	Pr. 331
Communication speed		Can be selected from 300, 600, 1200, 2400, 4800, 9600, 19200 and 38400bps	Pr. 332
Control protocol		Asynchronous system	—
Communication method		Half-duplex system	—
Communication specifications	Character system	Binary(fixed to 8 bits)	—
	Start bit	1bit	—
	Stop bit length	Select from the following three types · No parity, stop bit length 2 bits · Odd parity, stop bit length 1 bit · Even parity, stop bit length 1 bit	Pr. 334
	Parity check		
	Error check	CRC code check	—
	Terminator	Not used	—
Waiting time setting		Not used	—

WWW.BSNEW.IR


(2) Outline

The Modbus protocol is the communication protocol developed by Modicon for PLC.
The Modbus protocol performs serial communication between the master and slave using the dedicated message frame. The dedicated message frame has the functions that can perform data read and write. Using the functions, you can read and write the parameter values from the inverter, write the input command of the inverter, and check the operating status. In this product, the inverter data are classified in the holding register area (register addresses 40001 to 49999). By accessing the assigned holding register address, the master can communicate with the inverter which is a slave.

REMARKS

There are two different serial transmission modes: ASCII (American Standard Code for Information Interchange) mode and RTU (Remote Terminal Unit) mode. This product supports only the RTU mode in which 1-byte (8-bit) data is transmitted as-is.
Only the communication protocol is defined by the Modbus protocol, and the physical layer is not stipulated.

(3) Message format



●Data check time

Item	Check Time
Various monitors, operation command, frequency setting (RAM)	< 12ms
Parameter read/write, frequency setting (EEPROM)	< 30ms
Parameter clear/all clear	< 5s
Reset command	No answer

1) Query
The master sends a message to the slave (= inverter) at the specified address.
2) Normal Response
After receiving the query from the master, the slave executes the requested function and returns the corresponding normal response to the master.
3) Error Response
If an invalid function code, address or data is received, the slave returns it to the master.
When a response description is returned, the error code indicating that the request from the master cannot be executed is added.
No response is returned for the hardware-detected error, frame error and CRC check error.
4) Broadcast
By specifying address 0, the master can send a message to all slaves. All slaves that received the message from the master execute the requested function. In this communication, the slaves do not return a response to the master.

REMARKS


The slave executes the function independently of the inverter station number setting (*Pr. 331*) during broadcast communication.

WWW.BSNEW.IR

(4) Message frame (protocol)

- Communication method

  Basically, the master sends a query message (question) and the slave returns a response message (response). When communication is normal, Device Address and Function Code are copied as they are, and when communication is abnormal (function code or data code is illegal), bit 7 (= 80h) of Function Code is turned on and the error code is set to Data Bytes.



  The message frame consists of the four message fields as shown above.
  By adding the no-data time (T1: Start, End) of 3.5 characters to the beginning and end of the message data, the slave recognizes it as one message.

- Protocol details

  The four message fields will be explained below.

Start	1) ADDRESS	2) FUNCTION	3) DATA	4) CRC CHECK		End
T1	8bit	8bit	n × 8bit	L 8bit	H 8bit	T1

Message Field	Description
1) ADDRESS field	The address is 1 byte long (8 bits) and any of 0 to 247 can be set. Set 0 to send a broadcast message (all-address instruction) or any of 1 to 247 to send a message to each slave. When the slave responds, it returns the address set from the master. The value set to *Pr. 331 RS-485 communication station number* is the slave address.
2) FUNCTION field	The function code is 1 byte long (8 bits) and any of 1 to 255 can be set. The master sets the function that it wants to request from the slave, and the slave performs the requested operation. The following table gives the supported function codes. An error response is returned if the set function code is other than those in the following table. When the slave returns a normal response, it returns the function code set by the master. When the slave returns an error response, it returns H80 + function code.
3) DATA field	The format changes depending on the function code *(refer to page 343)*. Data includes the byte count, number of bytes, description of access to the holding register, etc.
4) CRC CHECK field	The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side recalculates CRC during message receiving, and compares the result of that calculation and the actual value received in the CRC CHECK field. If these two values do not match, the result is defined as error.

Code	Function Name	Outline	Broadcast Communication
H03	Read Holding Register	Reads the holding register data.	Disallowed
H06	Preset Single Register	Writes data to the holding register.	Allowed
H08	Diagnostics	Makes a function diagnosis. (communication check only)	Disallowed
H10	Preset Multiple Registers	Writes data to multiple consecutive holding registers.	Allowed
H46	Read Holding Register Access Log	Reads the number of registers that succeeded in communication last time.	Disallowed

Table 1: Function code list

WWW.BSNEW.IR

(5) Message format types

The message formats corresponding to the function codes in Table 1 on *page 342* will be explained.

- **Read holding register data (H03 or 03)**

  Can read the description of 1) system environment variables, 2) real-time monitor, 3) alarm history, and 4) inverter parameters assigned to the holding register area (refer to the register list *(page 348)*).

Query Message

1) Slave Address	2) Function	3) Starting Address		4) No. of Points		CRC Check	
(8bit)	H03 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	L (8bit)	H (8bit)

Normal response (Response message)

1) Slave Address	2) Function	5) Byte Count	6) Data			CRC Check	
(8bit)	H03 (8bit)	(8bit)	H (8bit)	L (8bit)	... (n × 16bit)	L (8bit)	H (8bit)

· **Query message setting**

Message	Setting Description
1)Slave Address	Set the address to which the message will be sent. Broadcast communication cannot be made (0 is invalid).
2)Function	Set H03.
3)Starting Address	Set the address at which holding register data read will be started. Starting address = starting register address (decimal) – 40001 For example, setting of the starting address 0001 reads the data of the holding register 40002.
4)No. of Points	Set the number of holding registers from which data will be read. The number of registers from which data can be read is a maximum of 125.

· **Description of normal response**

Message	Setting Description
5)Byte Count	The setting range is H02 to H14 (2 to 20). Twice greater than the No. of Points specified at 4) is set.
6)Data	The number of data specified at 4) is set. Data are read in order of Hi byte and Lo byte, and set in order of starting address data, starting address + 1 data, starting address + 2 data, ...

Example) To read the register values of 41004 *(Pr. 4)* to 41006 *(Pr. 6)* from the slave address 17 (H11)

Query message

Slave Address	Function	Starting Address		No. of Points		CRC Check	
H11 (8bit)	H03 (8bit)	H03 (8bit)	HEB (8bit)	H00 (8bit)	H03 (8bit)	H77 (8bit)	H2B (8bit)

Normal response (Response message)

Slave Address	Function	Byte Count	Data						CRC Check	
H11 (8bit)	H03 (8bit)	H06 (8bit)	H17 (8bit)	H70 (8bit)	H0B (8bit)	HB8 (8bit)	H03 (8bit)	HE8 (8bit)	H2C (8bit)	HE6 (8bit)

Read value
Register 41004 *(Pr. 4)*: H1770 (60.00Hz)
Register 41005 *(Pr. 5)*: H0BB8 (30.00Hz)
Register 41006 *(Pr. 6)*: H03E8 (10.00Hz)

WWW.BSNEW.IR

- **Write multiple holding register data (H06 or 06)**

You can write the description of 1) system environment variables and 4) inverter parameters assigned to the holding register area (refer to the register list *(page 348)*).

Query message

1) Slave Address	2) Function	3) Register Address		4) Preset Data		CRC Check	
(8bit)	H06 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	L (8bit)	H (8bit)

Normal response (Response message)

1) Slave Address	2) Function	3) Register Address		4) Preset Data		CRC Check	
(8bit)	H06 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	L (8bit)	H (8bit)

· **Query message setting**

Message	Setting Description
1) Slave Address	Set the address to which the message will be sent. Setting of address 0 enables broadcast communication
2) Function	Set H06.
3) RegisterAddress	Set the address of the holding register to which data will be written. Register address = holding register address (decimal) – 40001 For example, setting of register address 0001 writes data to the holding register address 40002.
4) Prese Data	Set the data that will be written to the holding register. The written data is fixed to 2 bytes.

· **Description of normal response**

1) to 4) (including CRC check) of the normal response are the same as those of the query message.
No response is made for broadcast communication.

Example) To write 60Hz (H1770) to 40014 (running frequency RAM) at slave address 5 (H05).

Query message

Slave Address	Function	Register Address		Preset Data		CRC Check	
H05 (8bit)	H06 (8bit)	H00 (8bit)	H0D (8bit)	H17 (8bit)	H70 (8bit)	H17 (8bit)	H99 (8bit)

Normal Response (Response message)
Same data as the query message

CAUTION

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.

WWW.BSNEW.IR

- **Function diagnosis (H08 or 08)**

A communication check can be made since the query message sent is returned unchanged as a response message (function of subfunction code H00).
Subfunction code H00 (Return Query Data)
Query Message

1) Slave Address	2) Function	3) Subfunction		4) Date		CRC Check	
(8bit)	H08 (8bit)	H00 (8bit)	H00 (8bit)	H (8bit)	L (8bit)	L (8bit)	H (8bit)

Normal Response (Response message)

1) Slave Address	2) Function	3) Subfunction		4) Date		CRC Check	
(8bit)	H08 (8bit)	H00 (8bit)	H00 (8bit)	H (8bit)	L (8bit)	L (8bit)	H (8bit)

· **Query message setting**

Message	Setting Description
1) Slave Address	Set the address to which the message will be sent. Broadcast communication cannot be made (0 is invalid).
2) Function	Set H08.
3) Subfunction	Set H0000.
4) Data	Any data can be set if it is 2 bytes long. The setting range is H0000 to HFFFF.

· **Description of normal response**

1) to 4) (including CRC check) of the normal response are the same as those of the query message.

CAUTION

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.

- **Write multiple holding register data (H10 or 16)**

You can write data to multiple holding registers.

Query message

1) Slave Address	2) Function	3) Starting Address		4) No. of Registers		5) ByteCount	6) Data			CRC Check	
(8bit)	H10 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	(8bit)	H (8bit)	L (8bit)	... (n × 2 × 8bit)	L (8bit)	H (8bit)

Normal Response (Response message)

1) Slave Address	2) Function	3) Starting Address		4) No. of Registers		CRC Check	
(8bit)	H10 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	L (8bit)	H (8bit)

· **Query message setting**

Message	Setting Description
1) Slave Address	Set the address to which the message will be sent. Setting of address 0 enables broadcast communication.
2) Function	Set H10.
3) Starting Address	Set the address where holding register data write will be started. Starting address = starting register address (decimal) − 40001 For example, setting of the starting address 0001 reads the data of the holding register 40002.
4) No. of Points	Set the number of holding registers where data will be written. The number of registers where data can be written is a maximum of 125.
5) Byte Count	The setting range is H02 to HFA (0 to 250). Set a value twice greater than the value specified at 4).
6) Data	Set the data specified by the number specified at 4). The written data are set in order of Hi byte and Lo byte, and arranged in order of the starting address data, starting address + 1 data, starting address + 2 data ...

WWW.BSNEW.IR

· **Description of normal response**

1) to 4) (including CRC check) of the normal response are the same as those of the query message.

Example) To write 0.5s (H05) to 41007 *(Pr. 7)* at the slave address 25 (H19) and 1s (H0A) to 41008 *(Pr. 8)*.

Query Message

Slave Address	Function	Starting Address		No. of Points		Byte Count	Data				CRC Check	
H19 (8bit)	H10 (8bit)	H03 (8bit)	HEE (8bit)	H00 8bit)	H02 (8bit)	H04 (8bit)	H00 (8bit)	H05 (8bit)	H00 (8bit)	H0A (8bit)	H86 (8bit)	H3D (8bit)

Response message (Response message)

Slave Address	Function	Starting Address		No. of Points		CRC Check	
H19 (8bit)	H10 (8bit)	H03 (8bit)	HEE (8bit)	H00 (8bit)	H02 (8bit)	H22 (8bit)	H61 (8bit)

- **Read holding register access log (H46 or 70)**

A response can be made to a query made by the function code H03 or H10.
The starting address of the holding registers that succeeded in access during previous communication and the number of successful registers are returned.
In response to the query for other than the above function code, 0 is returned for the address and number of registers.

Query Message

1) Slave Address	2) Function	CRC Check	
(8bit)	H46 (8bit)	L (8bit)	H (8bit)

Normal Response (Response message)

1) Slave Address	2) Function	3) Starting Address		4) No. of Points		CRC Check	
(8bit)	H46 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	L (8bit)	H (8bit)

· **Query message setting**

Message	Setting Description
1) Slave Address	Set the address to which the message will be sent. Broadcast communication cannot be made (0 is invalid)
2) Function	Set H46.

· **Description of normal response**

Message	Setting Description
3) Starting Address	The starting address of the holding registers that succeeded in access is returned. Starting address = starting register address (decimal) − 40001 For example, when the starting address 0001 is returned, the address of the holding register that succeeded in access is 40002.
4) No. of Points	The number of holding registers that succeeded in access is returned.

Example) To read the successful register starting address and successful count from the slave address 25 (H19).

Query Message

Slave Address	Function	CRC Check	
H19 (8bit)	H46 (8bit)	H8B (8bit)	HD2 (8bit)

Normal Response (Response message)

Slave Address	Function	Starting Address		No. of Points		CRC Check	
H19 (8bit)	H10 (8bit)	H03 (8bit)	HEE (8bit)	H00 (8bit)	H02 (8bit)	H22 (8bit)	H61 (8bit)

Success of two registers at starting address 41007 *(Pr. 7)* is returned.

WWW.BSNEW.IR

● **Error response**

An error response is returned if the query message received from the master has an illegal function, address or data. No response is returned for a parity, CRC, overrun, framing or busy error.

CAUTION

No response message is sent in the case of broadcast communication also.

Error response (Response message)

1) Slave Address	2) Function	3) Exception Code	CRC Check	
(8bit)	H80 + Function (8bit)	(8bit)	L (8bit)	H (8bit)

Message	Setting Description
1) Slave address	Set the address received from the master.
2) Function	The master-requested function code + H80 is set.
3) Exception code	The code in the following table is set.

Error code list

Code	Error Item	Error Definition
01	ILLEGAL FUNCTION (Function code illegal)	The set function code in the query message from the master cannot be handled by the slave.
02	ILLEGAL DATA ADDRESS *1 (Address illegal)	The set register address in the query message from the master cannot be handled by the inverter. (No parameter, parameter read disabled, parameter write disabled)
03	ILLEGAL DATA VALUE (Data illegal)	The set data in the query message from the master cannot be handled by the inverter. (Out of parameter write range, mode specified, other error)

*1 An error will not occur in the following cases.
1) Function code H03 (Read Holding Register Data)
When the No. of Points is 1 or more and there is one or more holding registers from which data can be read
2) Function code H10 (Write Multiple Holding Register Data)
When the No. of Points is 1 or more and there is 1 or more holding registers to which data can be written
Namely, when the function code H03 or H10 is used to access multiple holding registers, an error will not occur if a non-existing holding register or read disabled or write disabled holding register is accessed.

REMARKS

An error will occur if all accessed holding registers do not exist.
Data read from a non-existing holding register is 0, and data written there is invalid.

· **Message data mistake detection**

To detect the mistakes of message data from the master, they are checked for the following errors. If an error is detected, an alarm stop will not occur.

Error check item

Error Item	Error Definition	Inverter Side Operation
Parity error	The data received by the inverter differs from the specified parity (*Pr. 334* setting).	1) *Pr. 343* is increased by 1 at error occurrence. 2) The terminal LF is output at error occurrence.
Framing error	The data received by the inverter differs from the specified stop bit length (*Pr. 333*).	
Overrun error	The following data was sent from the master before the inverter completes data receiving.	
Message frame error	The message frame data length is checked, and the received data length of less than 4 bytes is regarded as an error.	
CRC check error	A mismatch found by CRC check between the message frame data and calculation result is regarded as an error.	

WWW.BSNEW.IR

(6) Modbus registers

- System environment variable

Register	Definition	Read/Write	Remarks
40002	Inverter reset	Write	Any value can be written
40003	Parameter clear	Write	Set H965A as a written value.
40004	All parameter clear	Write	Set H99AA as a written value.
40006	Parameter clear *1	Write	Set H5A96 as a written value.
40007	All parameter clear *1	Write	Set HAA99 as a written value.
40009	Inverter status/control input instruction *2	Read/write	See below.
40010	Operation mode/inverter setting *3	Read/write	See below.
40014	Running frequency (RAM value)	Read/write	According to the *Pr. 37* and *Pr. 144* settings, the frequency and selectable speed are in 1r/min increments.
40015	Running frequency (EEPROM value)	Write	

*1 The communication parameter values are not cleared.

*2 For write, set the data as a control input instruction. For read, data is read as an inverter operating status.

*3 For write, set data as the operation mode setting. For read, data is read as the operation mode status.

<Inverter status/control input instruction>

Bit	Definition	
	Control input instruction	Inverter status
0	Stop command	RUN (inverter running) *2
1	Forward rotation command	Forward rotation
2	Reverse rotation command	Reverse rotation
3	RH (high speed operation command) *1	SU (up to frequency) *2
4	RM (middle speed operation command) *1	OL (overload) *2
5	RL (low speed operation command) *1	IPF (instantaneous power failure) *2
6	JOG (Jog operation) *1	FU (frequency detection) *2
7	RT (second function selection) *1	ABC1 (alarm) *2
8	AU (current input selection) *1	ABC2 (—) *2
9	CS (selection of automatic restart after instantaneous power failure) *1	0
10	MRS (output stop) *1	0
11	STOP (start self-holding) *1	0
12	RES (reset) *1	0
13	0	0
14	0	0
15	0	Alarm occurrence

<Operation mode/inverter setting>

Mode	Read Value	Written Value
EXT	H0000	H0010
PU	H0001	—
EXT JOG	H0002	—
PU JOG	H0003	—
NET	H0004	H0014
PU+ EXT	H0005	—

The restrictions depending on the operation mode changes according to the computer link specifications.

*1 The signal within parentheses is the initial setting. The description changes depending on the setting of *Pr. 180 to Pr. 189 (input terminal function selection) (page 228)*.
Each assigned signal is valid or invalid depending on NET. *(Refer to page 317)*

*2 The signal within parentheses is the initial setting. The description changes depending on the setting of *Pr. 190 to Pr. 196 (output terminal function selection) (page 236)*.

WWW.BSNEW.IR

- Real-time monitor
  Refer to *page 250* for details of the monitor description.

Register	Definition	Increments
40201	Output frequency	0.01Hz
40202	Output current	0.01A/ 0.1A *6
40203	Output voltage	0.1V
40205	Frequency setting	0.01Hz
40206	Running speed	1r/min
40207	Motor torque	0.1%
40208	Converter output voltage	0.1V
40209	Regenerative brake duty	0.1%
40210	Electronic thermal relay function load factor	0.1%
40211	Output current peak value	0.01A/ 0.1A *6
40212	Converter output voltage peak value	0.1V

Register	Definition	Increments
40213	Input power	0.01kW/ 0.1kW *6
40214	Output power	0.01kW/ 0.1kW *6
40215	Input terminal status *1	—
40216	Output terminal status *2	—
40217	Load meter	0.1%
40218	Motor excitation current	0.01A/ 0.1A *6
40219	Position pulse	—
40220	Cumulative energization time	1h
40222	Orientation status	—
40223	Actual operation time	1h
40224	Motor load factor	0.1%
40225	Cumulative power	1kWh

Register	Definition	Increments
40226	Torque command	0.1%
40227	Torque current command	0.1%
40228	Motor output	0.01/ 0.1kW *6
40229	Feedback pulse	—
40250	Power saving effect	Variable
40251	Cumulative saving power	Variable
40252	PID set point	0.1%
40253	PID measured value	0.1%
40254	PID deviation value	0.1%
40258	Option input terminal status1 *3	—
40259	Option input terminal status2 *4	—
40260	Option output terminal status *5	—

*1 Input terminal monitor details

b15															b0
—	—	—	—	CS	RES	STOP	MRS	JOG	RH	RM	RL	RT	AU	STR	STF

*2 Output terminal monitor details

b15															b0
—	—	—	—	—	—	—	—	—	ABC2	ABC1	FU	OL	IPF	SU	RUN

*3 Details of option input terminal monitor 1 (input terminal status of FR-A7AX)-all terminals are off when an option is not fitted

b15															b0
X15	X14	X13	X12	X11	X10	X9	X8	X7	X6	X5	X4	X3	X2	X1	X0

*4 Details of option input terminal monitor 2 (input terminal status of FR-A7AX)-all terminals are off when an option is not fitted

b15															b0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	DY

*5 Details of option input terminal monitor (output terminal status of FR-A7AY/A7AR)-all terminals are off when an option is not fitted

b15															b0
—	—	—	—	—	—	RA3	RA2	RA1	Y6	Y5	Y4	Y3	Y2	Y1	Y0

*6 The setting depends on capacities. (FR-A720-02150 (FR-A740-01100) or less / FR-A720-02880 (FR-A740-01440) or more)

WWW.BSNEW.IR

- Parameter

Parameters	Register	Parameter Name	Read/Write	Remarks
0 to 999	**41000 to 41999**	Refer to the parameter list *(page 71)* for the parameter names.	Read/write	The parameter number + 41000 is the register number.
C2(902)	**41902**	Terminal 2 frequency setting bias (frequency)	Read/write	
C3(902)	**42092**	Terminal 2 frequency setting bias (analog value)	Read/write	The analog value (%) set to *C3 (902)* is read.
	43902	Terminal 2 frequency setting bias (terminal analog value)	Read	The analog value (%) of the voltage (current) applied to the terminal 2 is read.
125(903)	**41903**	Terminal 2 frequency setting gain (frequency)	Read/write	
C4(903)	**42093**	Terminal 2 frequency setting gain (analog value)	Read/write	The analog value (%) set to *C4 (903)* is read.
	43903	Terminal 2 frequency setting gain (terminal analog value)	Read	The analog value (%) of the voltage (current) applied to the terminal 2 is read.
C5(904)	**41904**	Terminal 4 frequency setting bias (frequency)	Read/write	
C6(904)	**42094**	Terminal 4 frequency setting bias (analog value)	Read/write	The analog value (%) set to *C6 (904)* is read.
	43904	Terminal 4 frequency setting bias (terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.
126(905)	**41905**	Terminal 4 frequency setting gain (frequency)	Read/write	
C7(905)	**42095**	Terminal 4 frequency setting gain (analog value)	Read/write	The analog value (%) set to *C7 (905)* is read.
	43905	Terminal 4 frequency setting gain (terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.
C12(917)	**41917**	Terminal 1 bias frequency (speed)	Read/write	
C13(917)	**42107**	Terminal 1 bias (speed)	Read/write	Analog value (%) set in *C13 (917)* is read.
	43917	Terminal 1 bias (speed) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 1 is read.
C14(918)	**41918**	Terminal 1 gain frequency (speed)	Read/write	
C15(918)	**42108**	Terminal 1 gain (speed)	Read/write	Analog value (%) set in *C15 (918)* is read.
	43918	Terminal 1 gain (speed) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 1 is read.
C16(919)	**41919**	Terminal 1 bias command (torque/ magnetic flux)	Read/write	
C17(919)	**42109**	Terminal 1 bias (torque/magnetic flux)	Read/write	Analog value (%) set in *C17 (919)* is read.
	43919	Terminal 1 bias (torque/magnetic flux) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 1 is read.
C18(920)	**41920**	Terminal 1 gain command (torque/ magnetic flux)	Read/write	
C19(920)	**42110**	Terminal 1 gain (torque/magnetic flux)	Read/write	Analog value (%) set in *C19 (920)* is read.
	43920	Terminal 1 gain (torque/magnetic flux) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 1 is read.
C38(932)	**41932**	Terminal 4 bias command (torque/ magnetic flux)	Read/write	
C39(932)	**42122**	Terminal 4 bias (torque/magnetic flux)	Read/write	Analog value (%) set in *C39 (932)* is read.
	43932	Terminal 4 bias (torque/magnetic flux) (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to terminal 4 is read.
C40(933)	**41933**	Terminal 4 gain command (torque/ magnetic flux)	Read/write	
C41(933)	**42123**	Terminal 4 gain (torque/magnetic flux)	Read/write	Analog value (%) set in *C41 (933)* is read.
	43933	Terminal 4 gain (torque/magnetic flux) (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to terminal 4 is read.

WWW.BSNEW.IR

- Alarm history

Register	Definition	Read/Write	Remarks
40501	Alarm history 1	Read/write	Being 2 bytes in length, the data is stored as "H00○○". The error code can be referrred to in the low-order 1 byte. Performing write using the register 40501 batch-clears the alarm history. Set any value as data.
40502	Alarm history 2	Read	
40503	Alarm history 3	Read	
40504	Alarm history 4	Read	
40505	Alarm history 5	Read	
40506	Alarm history 6	Read	
40507	Alarm history 7	Read	
40508	Alarm history 8	Read	

Alarm code list

Data	Description	Data	Description	Data	Description	Data	Description
H00	No alarm	H70	E.BE	HC4	E.CDO	HDA	E.MB6
H10	E.OC1	H80	E.GF	HC5	E.IOH	HDB	E.MB7
H11	E.OC2	H81	E.LF	HC6	E.SER	HDC	E.EP
H12	E.OC3	H90	E.OHT	HC7	E.AIE	HF1	E.1
H20	E.OV1	H91	E.PTC	HC8	E.USB	HF2	E.2
H21	E.OV2	HA0	E.OPT	HD0	E.OS	HF3	E.3
H22	E.OV3	HA3	E.OP3	HD1	E.OSD	HF6	E.6
H30	E.THT	HB0	E.PE	HD2	E.ECT	HF7	E.7
H31	E.THM	HB1	E.PUE	HD3	E.OD	HFB	E.11
H40	E.FIN	HB2	E.RET	HD5	E.MB1	HFD	E.13
H50	E.IPF	HB3	E.PE2	HD6	E.MB2		
H51	E.UVT	HC0	E.CPU	HD7	E.MB3		
H52	E.ILF	HC1	E.CTE	HD8	E.MB4		
H60	E.OLT	HC2	E.P24	HD9	E.MB5		

* Refer to *page 399* for details of alarm definition.

(7) *Pr. 343 Communication error count*

You can check the cumulative number of communication errors.


Parameters	Setting Range	Minimum Setting Range	Initial Value
343	(Read only)	1	0

CAUTION

The number of communication errors is temporarily stored into the RAM. As it is not stored into the EEPROM, performing a power supply reset or inverter reset clears the value to 0.

(8) Output signal LF "minor failure output (communication error warnings)"

During a communication error, the minor failure output (LF signal) is output by open collector output. Assign the used terminal using any of *Pr. 190 to Pr. 196 (output terminal function selection)*.



CAUTION

The LF signal can be assigned to the output terminal using any of *Pr. 190 to Pr. 196*. When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.

WWW.BSNEW.IR

(9) Signal loss detection (*Pr. 539 Modbus-RTU communication check time interval*)

If a signal loss (communication stop) is detected between the inverter and master as a result of a signal loss detection, a communication error (E.SER) occurs and the inverter output is shut off.

· When the setting is "9999", communication check (signal loss detection) is not made.


· When the setting value is "0", monitor, parameter read, etc. can be performed. However, a communication error (E.SER) occurs as soon as the inverter is switched to the network operation mode.

· A signal loss detection is made when the setting is any of "0.1s to 999.8s". To make a signal loss detection, it is necessary to send data from the master within the communication check time interval. (The inverter makes communication check (clearing of communication check counter) regardless of the station number setting of the data sent from the master.)

· Communication check is started from the first communication after switching to the network operation mode (use *Pr. 551 PU mode operation command source selection* to change).

· Communication check time of query communication includes data absence time (3.5 byte).
Since this data absence time differs according to the communication speed, make setting considering this absence time.

Example: RS-485 terminal communication, *Pr. 539* = "0.1 to 999.8s"



WWW.BSNEW.IR

4.24.7 Operation by PLC function (Pr. 414 to Pr. 417, Pr. 498, Pr. 506 to Pr. 515)

I/O data read, write, etc. can be performed by accessing the inverter in the predetermined method using special relays, special registers, etc.
Operation, parameter read/write, etc. can be performed in accordance with the created sequence programs (built in the inverter) using input data from the control input terminals.
With the output signals, output data can be output to outside the inverter from the control output terminals as not only the inverter's status signals but also pilot lamp on/off, interlock and other control signals set freely by the user.

Parameter Number	Name	Initial Value	Setting Range	Description
414	PLC function operation selection	0	0	PLC function is invalid
			1	PLC function is valid (Inverter reset is necessary to make this setting valid.)
415	Inverter operation lock mode setting	0	0	The inverter start signal is made valid regardless of the sequence program execution key.
			1	The inverter start signal is made valid only when the sequence program execution key is set to RUN. When the sequence program execution key is in the STOP position, the inverter does not start if the inverter start signal STF or STR is turned on. (If the key is switched from RUN to STOP during inverter operation, the inverter is decelerated to a stop.)
416	Pre-scale function selection	0	0 to 5	Pre-scale function selection (increments scaling factor) 0: No function 1: × 1 2: × 0.1 3: × 0.01 4: × 0.001 5: × 0.0001
417	Pre-scale setting value	1	0 to 32767	Set the pre-scale value to calcute the number of sampling pulse when inputting the pulse train.
498	PLC function flash memory clear	0	0 to 9999	9696: Flash memory clear
				Other than 9696: Flash memory is not cleared
506	Parameter 1 for user	0	0 to 65535	Inverter parameters *Pr. 506 to Pr. 515* can be used as user parameters. Since this parameter area and the devices used with the PLC function, D110 to D119, are accessible to each other, the values set in *Pr. 506 to Pr. 515* can be used in a sequence program. The result of operation performed in the sequence program can also be monitored using *Pr. 506 to Pr. 515*.
507	Parameter 2 for user			
508	Parameter 3 for user			
509	Parameter 4 for user			
510	Parameter 5 for user			
511	Parameter 6 for user			
512	Parameter 7 for user			
513	Parameter 8 for user			
514	Parameter 9 for user			
515	Parameter 10 for user			

Refer to the FR-A700 PLC function programming manual for details of the PLC function.

WWW.BSNEW.IR

4.24.8 USB communication (Pr. 547, Pr. 548)


Inverter setup can be easily performed using the FR-Configurator by connecting the inverter and personal computer with a USB cable.

- A personal computer and inverter can be easily connected with one USB cable.

Parameter Number	Name	Initial Value	Setting Range	Description
547	**USB communication station number**	0	0 to 31	Specify the inverter station number.
548	**USB communication check time interval**	9999	0	USB communication is enabled. However, the inverter will come to an alarm stop (E. USB) if operation is changed to PU operation mode.
			0.1 to 999.8s	Set the interval of communication check time. If a no-communication state persists for longer than the permissible time, the inverter will come to an alarm stop (E.USB).
			9999	No communication check

●USB communication specifications

Interfase	Conforms to USB1.1
Transmission speed:	12Mbps
Connector	USB B connector (B receptacle)
Cable	Twisted pair shield cable 5m (16.4feet) maximum
Power supply	Self-power supply



Removal of cover
Place a flat-blade screwdriver, etc. in a slot and push up the cover to open.

- When using USB communication, set "3" in *Pr. 551 PU mode operation command source selection*.
- You can perform parameter setting and monitoring with the FR Configurator. Refer to the instruction manual of the FR-Configurator for details.

♦ Parameters referred to ♦

Pr. 551 PU mode operation command source selection ☞ *Refer to page 317*

WWW.BSNEW.IR

4.25 Special operation and frequency control

Purpose	Parameter that must be Set		Refer to Page
Perform process control such as pump and air volume.	**PID control**	**Pr. 127 to Pr. 134, Pr. 575 to Pr. 577**	355
Switch between the inverter operation and commercial power-supply operation to operate.	**Commercial power supply-inverter switchover function**	**Pr. 135 to Pr. 139, Pr. 159**	363
Increase speed when the load is light.	**Load torque high speed frequency control**	**Pr. 4, Pr. 5, Pr. 270 to Pr. 274**	368
Frequency control appropriate for the load torque	**Droop control**	**Pr. 286 to Pr. 288**	370
Frequency setting by pulse train input	**Pulse train input**	**Pr. 291, Pr. 384 to Pr. 386**	372
Make the motor speed constant by encoder	**Encoder feedback control**	**Pr. 144, Pr. 285, Pr. 359, Pr. 367 to Pr. 369**	375
Avoid overvoltage alarm due to regeneration by automatic adjustment of output frequency	**Regeneration avoidance function**	**Pr. 882 to Pr. 886**	377

4.25.1 PID control (Pr. 127 to Pr. 134, Pr. 575 to Pr. 577)

The inverter can be used to exercise process control, e.g. flow rate, air volume or pressure.
The terminal 2 input signal or parameter setting is used as a set point and the terminal 4 input signal used as a feedback value to constitute a feedback system for PID control.

Parameter Number	Name	Initial Value	Setting Range	Description	
127	**PID control automatic switchover frequency**	9999	0 to 400Hz	Set the frequency at which the control is automatically changed to PID control.	
			9999	Without PID automatic switchover function	
128	**PID action selection**	10	10	PID reverse action	Deviation value signal input (terminal 1)
			11	PID forward action	
			20	PID reverse action	Measured value (terminal 4) Set point (terminal 2 or *Pr. 133*)
			21	PID forward action	
			50	PID reverse action	Deviation value signal input (LONWORKS , CC-Link communication)
			51	PID forward action	
			60	PID reverse action	Measured value, set point input (LONWORKS , CC-Link communication)
			61	PID forward action	
			70 *2	PID reverse action	Deviation value signal input (PLC function)
			71 *2	PID forward action	
			80 *2	PID reverse action	Measured value, set point input (PLC function)
			81 *2	PID forward action	
			90 *2	PID reverse action	Deviation value signal input (PLC function) (Not reflected to the inverter frequency)
			91 *2	PID forward action	
			100 *2	PID reverse action	Measured value, set point input (PLC function) (Not reflected to the inverter frequency)
			101 *2	PID forward action	
129 *1	**PID proportional band**	100%	0.1 to 1000%	If the proportional band is narrow (parameter setting is small), the manipulated variable varies greatly with a slight change of the measured value. Hence, as the proportional band narrows, the response sensitivity (gain) improves but the stability deteriorates, e.g. hunting occurs. Gain Kp = 1/proportional band	
			9999	No proportional control	
130 *1	**PID integral time**	1s	0.1 to 3600s	For deviation step input, time (Ti) required for only the integral (I) action to provide the same manipulated variable as that for the proportional (P) action. As the integral time decreases, the set point is reached earlier but hunting occurs more easily.	
			9999	No integral control	
131	**PID upper limit**	9999	0 to 100%	Set the maximum value. If the feedback value exceeds the setting, the FUP signal is output. The maximum input (20mA/ 5V/10V) of the measured value (terminal 4) is equivalent to 100%.	
			9999	No function	


WWW.BSNEW.IR

Parameter Number	Name	Initial Value	Setting Range	Description
132	**PID lower limit**	9999	0 to 100%	Set the minimum value. If the measured value falls below the setting range, the FDN signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4) is equivalent to 100%.
			9999	No function
133 *1	**PID action set point**	9999	0 to 100%	Used to set the set point for PID control.
			9999	Terminal 2 input is the set point.
134 *1	**PID differential time**	9999	0.01 to 10.00s	For deviation lamp input, time (Td) required for providing only the manipulated variable for the proportional (P) action. As the differential time increases, greater response is made to a deviation change.
			9999	No differential control
575	**Output interruption detection time**	1s	0 to 3600s	The inverter stops operation if the output frequency after PID operation remains at less than the *Pr. 576* setting for longer than the time set in *Pr. 575*.
			9999	Without output interruption function
576	**Output interruption detection level**	0Hz	0 to 400Hz	Set the frequency at which the output interruption processing is performed.
577	**Output interruption cancel level**	1000%	900 to 1100%	Set the level (*Pr. 577* minus 1000%) at which the PID output interruption function is canceled.

*1 *Pr. 129, Pr. 130, Pr. 133* and *Pr. 134* can be set during operation. They can also be set independently of the operation mode.
*2 For details, refer to *the FR-A700 PLC FUNCTION PROGRAM MANUAL*.


(1) PID control basic configuration

·*Pr. 128* = "10, 11" (Deviation value signal input)



Kp: Proportionality constant Ti: Integral time S: Operator Td: Differential time

·*Pr. 128* = "20, 21" (Measured value input)



Kp: Proportionality constant Ti: Integral time S: Operator Td: Differential time

WWW.BSNEW.IR


(2) PID action overview

1) PI action

A combination of P action (P) and I action (I) for providing a manipulated variable in response to deviation and changes with time.

[Operation example for stepped changes of measured value]

(Note) PI action is the sum of P and I actions.




2) PD action

A combination of P action (P) and differential control action (D) for providing a manipulated variable in response to deviation speed to improve the transient characteristic.

[Operation example for proportional changes of measured value]


(Note) PD action is the sum of P and D actions.



3) PID action

The PI action and PD action are combined to utilize the advantages of both actions for control.


(Note) PID action is the sum of P, I and D actions.



WWW.BSNEW.IR


4)Reverse action

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is positive, and decreases the manipulated variable if deviation is negative.



5)Forward action

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is negative, and decreases the manipulated variable if deviation is positive.




Relationships between deviation and manipulated variable (output frequency)

	Deviation	
	Positive	Negative
Reverse action	↗	↘
Forward action	↘	↗

(3) Connection diagram

· Sink logic
· *Pr. 128* = 20
· *Pr. 183* = 14
· *Pr. 191* = 47
· *Pr. 192* = 16
· *Pr. 193* = 14
· *Pr. 194* = 15



*1 The power supply must be selected in accordance with the power specifications of the detector used.
*2 The used output signal terminal changes depending on the *Pr. 190 to Pr. 196 (output terminal selection)* setting.
*3 The used input signal terminal changes depending on the *Pr. 178 to Pr. 189 (input terminal selection)* setting.

WWW.BSNEW.IR

(4) I/O signals and parameter setting

- Turn on the X14 signal to perform PID control. When this signal is off, PID action is not performed and normal inverter operation is performed. (Note that it is not necessary to turn on X14 signal when performing PID control with using LONWORKS or CC-Link communication.)
- Enter the set point across inverter terminals 2-5 or into *Pr. 133* and enter the measured value signal across inverter terminals 4-5. At this time, set "20" or "21" in *Pr. 128*.
- When entering the externally calculated deviation signal, enter it across terminals 1-5. At this time, set "10" or "11" in *Pr. 128*.

Signal		Terminal Used	Function	Description	Parameter Setting
Input	X14	Depending on *Pr. 178 to Pr. 189*	PID control selection	Turn on X14 to perform PID control.	Set 14 in any of *Pr. 178 to Pr. 189*.
	X64		PID forward/ reverse action switchover	By turning on X64, forward action can be selected for PID reverse action (*Pr. 128* = 10, 20), and reverse action for forward action (*Pr. 128* = 11, 21).	Set 64 in any of *Pr. 178 to Pr. 189*.
	2	2	Set point input	Enter the set point for PID control.	*Pr. 128* = 20, 21, *Pr. 133* = 9999
				0 to 5V.....0 to 100%	*Pr. 73* = 1 *1, 3, 5, 11, 13, 15
				0 to 10V.....0 to 100%	*Pr. 73* = 0, 2, 4, 10, 12, 14
				0 to 20mA.....0 to 100%	*Pr. 73* = 6, 7, 16, 17
	PU	—	Set point input	Set the set value *(Pr. 133)* from the operation panel or parameter unit.	*Pr. 128* = 20, 21, *Pr. 133* = 0 to 100%
	1	1	Deviation signal input	Input the deviation signal calculated externally.	*Pr. 128* = 10 *1, 11
				-5V to +5V .....-100% to +100%	*Pr. 73* = 2, 3, 5, 7, 12, 13, 15, 17
				-10V to +10V .....-100% to +100%	*Pr. 73* = 0, 1 *1, 4, 6, 10, 11, 14, 16
	4	4	Measured value input	Input the signal from the detector (measured value signal).	*Pr. 128* = 20, 21
				4 to 20mA. 0 to 100%	*Pr. 267* = 0 *1
				0 to 5V ..... 0 to 100%	*Pr. 267* = 1
				0 to 10V ... 0 to 100%	*Pr. 267* = 2
	Communi-cation *2	—	Deviation value input	Input the deviation value from LONWORKS, CC-Link communication.	*Pr. 128* = 50, 51
			Set value, measured value input	Input the set value and measured value from LONWORKS , CC-Link communication.	*Pr. 128* = 60, 61
	PLC	—	Deviation value input	Input the deviation value from PLC function.	*Pr. 128* = 70, 71, 90, 91
			Set value, measured value input	Input the set value and measured value from PLC function.	*Pr. 128* = 80, 81, 100, 101
Output	FUP	Depending on *Pr. 190 to Pr. 196*	Upper limit output	Output to indicate that the measured value signal exceeded the maximum value *(Pr. 131)*.	*Pr. 128* = 20, 21, 60, 61 *Pr. 131* ≠ 9999 Set 15 or 115 in any of *Pr. 190 to Pr. 196*. *3
	FDN		Lower limit output	Output when the measured value signal falls below the minimum value *(Pr. 132)*.	*Pr. 128* = 20, 21, 60, 61 *Pr. 132* ≠ 9999 Set 14 or 114 in any of *Pr. 190 to Pr. 196*. *3
	RL		Forward (reverse) rotation direction output	"Hi" is output to indicate that the output indication of the parameter unit is forward rotation (FWD) or "Low" to indicate that it is reverse rotation (REV) or stop (STOP).	Set 16 or 116 in any of *Pr. 190 to Pr. 196*. *3
	PID		During PID control activated	Turns on during PID control.	Set 47 or 147 in any of *Pr. 190 to Pr. 196*. *3
	SLEEP		PID output interruption	Turns on when the PID output interruption function is performed.	*Pr. 575* ≠ 9999 Set 70 or 170 in any of *Pr. 190 to Pr. 196*. *3
	SE	SE	Output terminal common	Common terminal for terminals FUP, FDN, RL, PID and SLEEP	

*1 The shaded area indicates the parameter initial value.

*2 For the setting method via LONWORKS communication, refer to the LONWORKS communication option (FR-A7NL) instruction manual.
For the setting method via CC-Link communication, refer to the CC-Link communication option (FR-A7NC) instruction manual.

*3 When 100 or larger value is set in any of *Pr. 190 to Pr. 196 (output terminal function selection)*, the terminal output has negative logic. *(Refer to page 236 for details)*


CAUTION

- Changing the terminal function using any of *Pr. 178 to Pr. 189, 190 to Pr. 196* may affect the other functions. Please make setting after confirming the function of each terminal.
- When the *Pr. 73* and *Pr. 267* settings were changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (*Refer to page 282* for setting.)

WWW.BSNEW.IR


(5) PID control automatic switchover control *(Pr. 127)*

- For a fast system startup at an operation start, the system can be started up in normal operation mode only at a start.
- When the frequency is set to *Pr. 127 PID control automatic switchover frequency* within the range 0 to 400Hz, the system starts up in normal operation mode from a start until *Pr. 127* is reached, and then it shifts to PID control operation mode. Once the system has entered PID control operation, it continues PID control if the output frequency falls to or below *Pr. 127*.



(6) PID output suspension function (SLEEP function) (SLEEP signal, *Pr. 575 to Pr. 577*)

- The inverter stops operation if the output frequency after PID operation remains at less than the *Pr. 576 Output interruption detection level* setting for longer than the time set in *Pr. 575 Output interruption detection time*. This function can reduce energy consumption in the low-efficiency, low-speed range.
- When the deviation (= set value - measured value) reaches the PID output shutoff cancel level (*Pr. 577* setting - 1000%) while the PID output interruption function is on, the PID output interruption function is canceled and PID control operation is resumed automatically.
- While the PID output interruption function is on, the PID output interruption signal (SLEEP) is output. At this time, the inverter running signal (RUN) is off and the PID control operating signal (PID) is on.




(7) PID monitor function

- The PID control set value, measured value and deviation value can be output to the operation panel monitor display and terminal FM, AM.
- The deviation monitor can display a negative value on the assumption that 1000 is 0%. (The deviation monitor cannot be output from the terminal FM, AM.)
- For the monitors, set the following values in *Pr. 52 DU/PU main display data selection*, *Pr. 54 FM terminal function selection*, and *Pr. 158 AM terminal function selection*.

Setting	Monitor Description	Minimum Increments	Terminal FM, AM Full Scale	Remarks
52	**PID set point**	0.1%	100%	For deviation input (*Pr. 128* = 10, 11), the monitor value is always displayed as 0.
53	**PID measurement value**	0.1%	100%	
54	**PID deviation value**	0.1%	—	Value cannot be set to *Pr. 54* or *Pr. 158*. The PID deviation value of 0% is displayed as 1000.

WWW.BSNEW.IR

(8) Adjustment procedure




Adjust the PID control parameters, *Pr. 127 to Pr. 134 and Pr. 575 to Pr. 577*.

Set the I/O terminals for PID control. *(Pr. 178 to Pr. 189 (input terminal function selection), Pr. 190 to Pr. 196 (output terminal function selection))*

(9) Calibration example

(A detector of 4mA at 0°C (32°F) and 20mA at 50°C (122°F) is used to adjust the room temperature to 25°C (77°F) under PID control.
The set point is given to across inverter terminals 2-5 (0 to 5V).)



*When calibration is required → Using calibration *Pr. 902* and *Pr. 903* (terminal 2) or *Pr. 904* and *Pr. 905* (terminal 4), calibrate the detector output and target setting input.
Make calibration in the PU mode during an inverter stop.

WWW.BSNEW.IR

<Set point input calibration>

1. Apply the input voltage of 0% set point setting (e.g. 0V) across terminals 2-5.
2. Enter in *C2 (Pr. 902)* the frequency which should be output by the inverter at the deviation of 0% (e.g. 0Hz).
3. In *C3 (Pr. 902)*, set the voltage value at 0%.
4. Apply the voltage of 100% set point (e.g. 5V) to across terminals 2-5.
5. Enter in *Pr. 125* the frequency which should be output by the inverter at the deviation of 100% (e.g. 60Hz).
6. In *C4 (Pr. 903)*, set the voltage value at 100%.


<Detector output calibration>

1. Apply the output current of 0% detector setting (e.g. 4mA) across terminals 4-5.
2. Make calibration using *C6 (Pr. 904)*.
3. Apply the output current of 100% detector setting (e.g. 20mA) across terminals 4-5.
4. Make calibration using *C7 (Pr. 905)*.

REMARKS


- The frequency set in *C5 (Pr. 904)* and *Pr. 126* should be the same as set in *C2 (Pr. 902)* and *Pr. 125*.

The results of the above calibration are as shown below:



CAUTION

- If the multi-speed (RH, RM, RL signal) or jog operation (jog signal) is entered with the X14 signal on, PID control is stopped and multi-speed or jog operation is started.
- If the setting is as follows, PID control becomes invalid.
  Pr. 79 Operation mode selection = "6" (switchover mode)
  Pr. 858 Terminal 4 function assignment, Pr. 868 Terminal 1 function assignment = "4" (torque command)
- When the *Pr. 128* setting is "20" or "21", note that the input across inverter terminals 1-5 is added to the set value across terminals 2-5.
- When using terminal 4 (measured value input) and terminal 1 (deviation input) under PID control, set "0" (initial value) in *Pr. 858 Terminal 4 function assignment* and "0" (initial value) in *Pr. 868 Terminal 1 function assignment*.
- Changing the terminal function using any of *Pr. 178 to Pr. 189, Pr. 190 to Pr. 196* may affect the other functions. Please make setting after confirming the function of each terminal.
- When PID control is selected, the minimum frequency is the frequency set in *Pr. 902* and the maximum frequency is the frequency set in *Pr. 903*. (*Pr. 1 Maximum frequency* and *Pr. 2 Minimum frequency* settings are also valid.)
- The remote operation function is invalid during PID operation.
- When the control is switched to PID control during normal operation, the frequency command value calculated by PID operation using 0Hz as standard is used without the frequency during the operation.



Operation when control is switched to PID control during normal operation

♦ Parameters referred to ♦

Pr. 59 Remote function selection ☞ *Refer to page 170*
Pr. 73 Analog input selection ☞ *Refer to page 282*
Pr. 79 Operation mode selection ☞ *Refer to page 308*
Pr. 178 to Pr. 189 (input terminal function selection) ☞ *Refer to page 228*
Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*
C2 (Pr. 902) to C7 (Pr. 905) Frequency setting voltage (current) bias/gain ☞ *Refer to page 289*

WWW.BSNEW.IR

4.25.2 Bypass-inverter switchover function (Pr. 57, Pr. 58, Pr. 135 to Pr. 139, Pr. 159)

The complicated sequence circuit for bypass operation is built in the inverter. Hence, merely inputting the start, stop or automatic switchover selection signal facilitates the interlock operation of the switchover magnetic contactor.

Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
57	Restart coasting time	9999	0		· FR-A720-00080 (FR-A740-00040) or less..... 0.5s, · FR-A720-00110 to 00330 (FR-A740-00060 to 00170) ..... 1s, · FR-A720-00460 to 02150 (FR-A740-00230 to 01100) ..... 3.0s, · FR-A720-02880 (FR-A740-01440) or more..... 5.0s, The above times are coasting time.
			02150 (01100) or less	0.1 to 5s	Set the waiting time for inverter-triggered restart after an instantaneous power failure.
			02880 (01440) or more	0.1 to 30s	
			9999		No restart
58	Restart cushion time	1s	0 to 60s		Set a voltage starting time at restart.
135	Electronic bypass sequence selection	0	0		Without electronic bypass sequence
			1		With electronic bypass sequence
136	MC switchover interlock time	1s	0 to 100s		Set the operation interlock time of MC2 and MC3.
137	Start waiting time	0.5s	0 to 100s		Set the time slightly longer (0.3 to 0.5s or so) than the time from when the ON signal enters MC3 until it actually turns on.
138	Bypass selection at an alarm	0	0		Inverter output is stopped (motor coast) at inverter fault.
			1		Operation is automatically switched to bypass operation at inverter fault (Not switched when an external thermal error occurs)
139	Automatic switchover frequency from inverter to bypass operation	9999	0 to 60Hz		Set the frequency to switch inverter operation to bypass operation. Inverter operation is performed from a start until *Pr. 139* is reached, and when the output frequency is at or above *Pr. 139*, inverter operation is automatically switched to bypass operation.
			9999		Without automatic switchover
159	Automatic switchover frequency range from bypass to inverter operation	9999	0 to 10Hz		Valid during automatic switchover operation (*Pr. 139* ≠ 9999) When the frequency command decreases below (*Pr. 139* minus *Pr. 159*) after operation is switched from inverter operation to bypass operation, the inverter automatically switches operation to inverter operation and operates at the frequency of frequency command. When the inverter start command (STF/STR) is turned off, operation is switched to inverter operation also.
			9999		Valid during automatic switchover operation (*Pr. 139* ≠ 9999) When the inverter start command (STF/STR) is turned off after operation is switched from inverter operation to bypass operation, operation is switched to inverter operation and the motor decelerates to stop.

· When the motor is operated at 60Hz (or 50Hz), more efficient operation can be performed by the commercial power supply than by the inverter. When the motor cannot be stopped for a long time for the maintenance/inspection of the inverter, it is recommended to provide the commercial power supply circuit.

· To switch between inverter operation and bypass operation, an interlock must be provided to stop the motor once and then start it by the inverter in order to prevent the inverter from resulting in an overcurrent alarm. Using the electronic bypass sequence function that outputs the timing signal for operation of the magnetic contactor, a complicated commercial power supply switchover interlock can be provided by the inverter.


CAUTION

Commercial operation can not be performed with the Mitsubishi vector motor (SF-V5RU).

WWW.BSNEW.IR

(1) Connection diagram

· The following shows the connection diagram of a typical electronic bypass sequence. Sink logic, *Pr. 185* = "7", *Pr. 192* = "17", *Pr. 193* = "18", *Pr. 194* = "19"



Electronic bypass sequence connection diagram

*1 Take caution for the capacity of the sequence output terminal. The used terminal changes depending on the setting of *Pr. 190 to Pr. 196 (output terminal function selection)*.

Output Terminal Capacity	Output Terminal Permissble Load
Inverter open collector output (RUN, SU, IPF, OL, FU)	24VDC 0.1A
Inverter relay output (A1-C1, B1-C1, A2-B2, B2-C2) Relay output option (FR-A7AR)	230VAC 0.3A 30VDC 0.3A

*2 When connecting a DC power supply, insert a protective diode. When connecting an AC power supply, connect a relay output option (FR-A7AR) and use a contact output.

*3 The used terminal changes depending on the setting of *Pr. 180 to Pr. 189 (input terminal function selection)*.

CAUTION

· Use the bypass operation function in external operation mode. Be sure to connect the other power supply since the function is not performed normally unless the connection terminals R1/L11, S1/L21 are not connected to the other power supply (power supply that does not pass MC1).

· Be sure to provide mechanical interlocks for MC2 and MC3.

· Operations of magnetic contactors (MC1, MC2, MC3)

Magnetic Contactor	Installation Place	Operation (○: Shorted, ×: Open)		
		Bypass operation	During inverter operation	At an inverter alarm occurrence
MC1	Between power supply and inverter input	○	○	× (Shorted by reset)
MC2	Between power supply and motor	○	×	× (Can be selected using *Pr. 138*, always open when external thermal relay is on)
MC3	Between inverter output and motor	×	○	×

WWW.BSNEW.IR

· The input signals are as indicated below.

Signal	Terminal Used	Function	Operation	MC Operation *6		
				MC1 *5	MC2	MC3
MRS	MRS	Operation enable/disable selection *1	ON ..... Bypass-inverter operation enabled	○	—	—
			OFF ... Bypass-inverter operation disabled	○	×	No change
CS	CS	Inverter/bypass *2	ON ..... Inverter operation	○	×	○
			OFF ... Bypass operation	○	○	×
STF (STR)	STF(STR)	Inverter operation command (Invalid for bypass) *3	ON ..... Forward rotation (reverse rotation)	○	×	○
			OFF ... Stop	○	×	○
OH	Set "7" in any of *Pr. 180 to Pr. 189*.	External thermal relay input	ON ..... Motor normal	○	—	—
			OFF .... Motor abnormal	×	×	×
RES	RES	Operating status initialization *4	ON ..... Initialization	No change	×	No change
			OFF ... Normal operation	○	—	—

*1 Unless the MRS signal is turned on, neither bypass operation nor inverter operation can be performed.
*2 The CS signal functions only when the MRS signal is on.
*3 STF (STR) functions only when both the MRS signal and CS signal are on.
*4 The RES signal enables reset input acceptance selection using *Pr. 75 Reset selection/disconnected PU detection/PU stop selection*.
*5 MC1 turns off when an inverter alarm occurs.
*6 MC operation
○ : MC-ON
× : MC-OFF
— : Inverter operation .....MC2 is off and MC3 is on
Bypass operation .....MC2 is on and MC3 is off
No change : The status before the signal turns on or off is held.


· The output signals are as indicated below.

Signal	Terminal Used (*Pr. 190 to Pr. 196* setting)	Description
MC1	17	Control signal output of inverter input side magnetic contactor MC1
MC2	18	Control signal output of bypass operation magnetic contactor MC2
MC3	19	Control signal output of inverter output side magnetic contactor MC3


WWW.BSNEW.IR

(2) Electronic bypass operation sequence

· Operation sequence example when there is no automatic switchover sequence (*Pr. 139* = "9999")




· Operation sequence example when there is automatic switchover sequence (*Pr. 139* ≠ "9999", *Pr. 159* = "9999")



A : *Pr. 136* MC switchover interlock time B : *Pr. 137* Start waiting time
C : *Pr. 57* Restart coasting time D : *Pr. 58* Restart cushion time

· Operation sequence example when there is automatic switchover sequence (*Pr. 139* ≠ "9999", *Pr. 159* ≠ "9999")




A : *Pr. 136* MC switchover interlock time B : *Pr. 137* Start waiting time
C : *Pr. 57* Restart coasting time D : *Pr. 58* Restart cushion time

WWW.BSNEW.IR

(3) Operation procedure

1)Procedure for operation

Operation pattern



- *Pr. 135* = "1" (open collector output terminal of inverter)
- *Pr. 136* = "2.0s"
- *Pr. 137* = "1.0s" (Set the time longer than the time from when MC3 actually turns on until the inverter and motor are connected. If the time is short, a restart may not function properly.)
- *Pr. 57* = "0.5s"
- *Pr. 58* = "0.5s" (Be sure to set this parameter when bypass operation is switched to inverter operation.)

2)Signal ON/OFF after parameter setting

	MRS	CS	STF	MC1	MC2	MC3	Remarks
Power supply ON	OFF (OFF)	OFF (OFF)	OFF (OFF)	OFF → ON (OFF → ON)	OFF (OFF)	OFF → ON (OFF → ON)	External operation mode (PU operation mode)
At start (inverter)	OFF → ON	OFF → ON	OFF → ON	ON	OFF	ON	
At constant speed (commercial power supply)	ON	ON → OFF	ON	ON	OFF → ON	ON → OFF	MC2 turns on after MC3 turns off (coasting status during this period) Waiting time 2s
Switched to inverter for deceleration (inverter)	ON	OFF → ON	ON	ON	ON → OFF	OFF → ON	MC3 turns on after MC2 turns off (coasting status during this period) Waiting time 4s
Stop	ON	ON	ON → OFF	ON	OFF	ON	

CAUTION

- Connect the control power supply (R1/L11, S1/L21) in front of input side MC1. If the control power supply is connected behind input side MC1, the electronic bypass sequence function is not executed.
- The electronic bypass sequence function is valid only when *Pr. 135* = "1" in the external operation or combined operation mode (PU speed command, external operation command *Pr. 79* = "3"). When *Pr. 135* = "1" in the operation mode other than the above, MC1 and MC3 turn on.
- When the MRS and CS signals are on and the STF (STR) signal is off, MC3 is on, but when the motor was coasted to a stop from bypass operation last time, a start is made after the time set in *Pr. 137* has elapsed.
- Inverter operation can be performed when the MRS, STF (STR) and CS signals turn on. In any other case (MRS signal - ON), bypass operation is performed.
- When the CS signal is turned off, the motor switches to bypass operation. However, when the STF (STR) signal is turned off, the motor is decelerated to a stop in the inverter operation mode.
- When both MC2 and MC3 are off and either MC2 or MC3 is then turned on, there is a waiting time set in *Pr. 136*.
- If electronic bypass sequence is made valid (*Pr. 135* = "1"), the *Pr. 136 and Pr. 137* settings are ignored in the PU operation mode. The input terminals (STF, CS, MRS, OH) of the inverter return to their normal functions.
- When the electronic bypass sequence function (*Pr. 135* = "1") and PU operation interlock function (*Pr. 79* = "7") are used simultaneously, the MRS signal is shared by the PU operation external interlock signal unless the X12 signal is assigned. (When the MRS and CS signals turn on, inverter operation is enabled)
- Changing the terminal function using any of *Pr. 178 to Pr. 189, 190 to Pr. 196* may affect the other functions. Please make setting after confirming the function of each terminal.


♦ Parameters referred to ♦

Pr. 11 DC injection brake operation time ☞ *Refer to page 200*
Pr. 57 Restart coasting time ☞ *Refer to page 261*
Pr. 58 Restart cushion time ☞ *Refer to page 261*
Pr. 79 Operation mode selection ☞ *Refer to page 308*
Pr. 178 to Pr. 189 (Input terminal function selection) ☞ *Refer to page 228*
Pr. 190 to Pr. 196 (Output terminal function selection) ☞ *Refer to page 236*

WWW.BSNEW.IR

4.25.3 Load torque high speed frequency control (Pr. 4, Pr. 5, Pr. 270 to Pr. 274)

Load torque high speed frequency control is a function which automatically sets the operational maximum frequency according to the load.
More specifically, the magnitude of the load is judged according to the average current at a certain time after starting to perform operation at higher than the preset frequency under light load.
This function is designed to increase speed automatically under light load, for example to minimize the incoming/outgoing time in a multi-story parking lot.




Parameter Number	Name	Initial Value	Setting Range	Description
4	**Multi-speed setting (high speed)**	60Hz	0 to 400Hz	Set the higher-speed frequency.
5	**Multi-speed setting (middle speed)**	30Hz	0 to 400Hz	Set the lower-speed frequency.
270	**Stop-on contact/load torque high-speed frequency control selection**	0	0	Normal operation
			1	Stop-on-control *(refer to page 211)*
			2	Load torque high speed frequency control
			3	Stop-on-contact *(refer to page 211)* + load torque high speed frequency control
271	**High-speed setting maximum current**	50%	0 to 220% *	Set the upper and lower limits of the current at high and middle speeds.
272	**Middle-speed setting minimum current**	100%	0 to 220% *	
273	**Current averaging range**	9999	0 to 400Hz	Average current during acceleration from (*Pr. 273* × 1/2) Hz to (*Pr. 273*) Hz can be achieved.
			9999	Average current during acceleration from (*Pr. 5* × 1/2) Hz to (*Pr. 5*) Hz is achieved.
274	**Current averaging filter time constant**	16	1 to 4000	Set the time constant of the primary delay filter relative to the output current. The time constant [ms] is 0.75 × *Pr. 274* and the initial value is 12ms. A larger setting provides higher stability but poorer response.

* When *Pr. 570 Multiple rating setting* ≠ "2", performing inverter reset and all parameter clear changes the setting range. *(Refer to page 155)*

<Connection diagram>

- Sink logic
- *Pr. 186* = 19




* The used terminal changes according to the *Pr. 180 to Pr. 189 (input terminal function selection)* settings.

WWW.BSNEW.IR

(1) Load torque high speed frequency control setting

- Set "2 or 3" in *Pr. 270 Stop-on contact/load torque high-speed frequency control selection*.
- When operating with the load torque high speed frequency function selection signal (X19) on, the inverter automatically changes the maximum frequency within the setting range of *Pr. 4 Multi-speed setting (high speed)* and *Pr. 5* according to the magnitude of the average current during the time to accelerate from 1/2 of the frequency set in *Pr. 5 Multi-speed setting (middle speed)* to the frequency set in *Pr. 5* .
- Set "19" in *Pr. 178 to Pr. 189 (input terminal function selection)* and assign the X19 signal function to the input terminal.
- Made valid only in the external operation mode.
- This control can be activated at every start.



Value in parenthesis is initial value.

(2) Operation of load torque high speed frequency control setting

- When the average current of the current averaging range (above chart A) during operation with the X19 signal on is less than the "rated inverter current × *Pr. 271* setting (%)", the maximum frequency automatically becomes the *Pr. 4 Multi-speed setting (high speed)* setting value.
- When the average current of the current averaging range (above chart B) during operation with the X19 signal on is more than the "rated inverter current × *Pr. 272* setting (%)", the maximum frequency automatically becomes the *Pr. 5 Multi-speed setting (middle speed)* setting value.
- The current averaging range can be set between 1/2 frequency of the *Pr. 273* setting value and *Pr. 273* set frequency.

CAUTION

- When the current averaging range includes the constant power range, the output current may become large in the constant power range.
- When the average current value in the current averaging range is small, deceleration time becomes longer as the running frequency increases.
- The maximum output frequency is 120Hz. The output frequency is 120Hz even when the setting is above 120Hz.
- The fast response current limit function is made invalid.
- Changing the terminal function using any of *Pr. 178 to Pr. 189* may affect the other functions. Please make setting after confirming the function of each terminal.
- The load torque high speed frequency function is made invalid in the following operation conditions.
  PU operation *(Pr. 79)* , PU+external operation *(Pr. 79)* , JOG operation *(JOG signal)* , PID control function operation *(X14 signal)*, remote setting function operation *(Pr. 59)*, orientation control function operation, multi-speed setting (*RH, RM, RL signal*), 16 bit digital input option (FR-A7AX)
- When the average current during acceleration is too small, it may be judged as regeneration and the maximum frequency becomes the setting of *Pr. 5*.

⚠ CAUTION

⚠ When the load is light, the motor may suddenly accelerate to 120Hz maximum, causing hazard.
Securely provide mechanical interlock on the machine side to perform.

♦ Parameters referred to ♦


Pr. 4 to Pr. 6, Pr. 24 to Pr. 27 (multi-speed setting) ☞*Refer to page 166*
Pr. 59 Remote function selection ☞*Refer to page 170*
Pr. 79 Operation mode selection ☞*Refer to page 308*
Pr. 128 PID action selection ☞*Refer to page 355*
Pr. 178 to Pr. 189 (input terminal function selection) ☞*Refer to page 228*

WWW.BSNEW.IR

4.25.4 Droop control (Pr. 286 to Pr. 288)

This function is designed to balance the load in proportion to the load torque to provide the speed drooping characteristic under advanced magnetic flux vector control, real sensorless vector control and vector control.
This function is effective for balancing the load when using multiple inverters

Parameter Number	Name	Initial Value	Setting Range	Description
286	Droop gain	0%	0	Normal operation
			0.1% to 100%	Droop control is valid Set the drooping amount at the rated torque as a percentage with respect to the rated motor frequency.
287	Droop filter time constant	0.3s	0 to 1s	Set the time constant of the filter applied on the torque amount current.
288	Droop function activation selection	0	0	Droop control is not exercised during acceleration/ deceleration.
			1	Droop control is always exercised during operation. (with 0 limit)
			2	Droop control is always exercised during operation. (without 0 limit)
			10	Droop control is not exercised during acceleration/ deceleration. (Motor speed is referenced)
			11	Droop control is always exercised during operation. (Motor speed is referenced)



(1) Droop control

- The output frequency is changed according to the magnitude of torque amount current under advanced magnetic flux vector control, real sensorless vector control and vector control.
  The drooping amount at the rated torque is set by the droop gain as a percentage using the rated frequency (Motor speed when *Pr. 288* = "10, 11") as a reference.
- The maximum droop compensation frequency is 120Hz.

When *Pr. 288* = "0 to 2", or under advanced magnetic flux vector control

$$\text{Droop compensation frequency} = \frac{\text{Amount of torque current after filtering}}{\text{Rated value of torque current}} \times \frac{\text{Rated motor frequency} \times \text{Droop gain}}{100}$$

When *Pr. 288* = "10, 11"

$$\text{Droop compensation frequency} = \frac{\text{Amount of torque current after filtering}}{\text{Rated value of torque current}} \times \frac{\text{Motor speed} \times \text{Droop gain}}{100}$$

REMARKS

Set the droop gain to about the rated slip of the motor.

$$\text{Rated slip} = \frac{\text{Synchronous speed at base frequency - Rated speed}}{\text{Synchronous speed at base frequency}} \times 100[\%]$$

WWW.BSNEW.IR

(2) Limit the frequency after droop compensation (0 limit)

· Setting *Pr. 288* under real sensorless vector control or vector control can limit the frequency command when the frequency after droop compensation is negative.

Pr. 288 Setting	Description	
	Under advanced magnetic flux vector control	Under real sensorless vector control or vector control
0 (initial value), 10	Droop control is not exercised during acceleration/ deceleration. Note that the frequency command after droop control is limited at 0.5Hz when the frequency command after droop control is negative. Droop compensation amount is determined using the rated motor frequency as reference.	Droop control is not exercised during acceleration/ deceleration. Note that the frequency command is limited at 0Hz when the frequency command after droop control is negative. When *Pr. 288* = "10", droop compensation amount is determined using the motor speed as reference.
1, 11		Droop control is always exercised during operation. Note that the frequency command is limited at 0Hz when the frequency command after droop control is negative. When *Pr. 288* = "11", droop compensation amount is determined using the motor speed as reference.
2		Droop control is always exercised during operation. Note that under vector control, the frequency command is not limited at 0Hz even when the frequency command after droop control is negative. (The frequency command is limited at 0Hz under real sesorless vector control.)

REMARKS

The maximum value of frequency after droop compensation is either 120Hz or *Pr. 1 Maximum frequency* , whichever is smaller.

♦ Parameters referred to ♦

Pr. 1 Maximum frequency ☞ *Refer to page 157*

WWW.BSNEW.IR

4.25.5 Frequency setting by pulse train input (Pr. 291, Pr. 384 to Pr. 386)


The inverter speed can be set by inputting pulse train from terminal JOG.
In addition, synchronous speed operation of inverters can be performed by combining pulse train I/O.

Parameter Number	Name	Initial Value	Setting Range	Description	
291	Pulse train I/O selection	0		Pulse train input	Pulse train output
			0	Terminal JOG	FM output
			1	Pulse train input	FM output
			10	Terminal JOG	High speed pulse train output (50%Duty)
			11	Pulse train input	High speed pulse train output (50%Duty)
			20	Terminal JOG	High speed pulse train output (ON width is always same)
			21	Pulse train input	High speed pulse train output (ON width is always same)
			100	Pulse train input	High speed pulse train output (ON width is always same) The inverter outputs the signal input as pulse train as it
384	Input pulse division scaling factor	0	0	Pulse train input invalid	
			1 to 250	Indicates division scaling factor to the input pulse and the frequency resolution to the input pulse changes according to the value.	
385	Frequency for zero input pulse	0Hz	0 to 400Hz	Set the frequency when the input pulse is 0 (bias).	
386	Frequency for maximum input pulse	60Hz	0 to 400Hz	Set the frequency when the input pulse is maximum (gain).	


(1) Pulse train input selection *(Pr. 291)*

- Setting any of "1, 11, 21, 100" in *Pr. 291 Pulse train I/O selection* and a value other than "0" in *Pr. 384 Input pulse division scaling factor* switches terminal JOG to pulse train input terminal and frequency setting of the inverter can be performed. (The initial value is JOG signal)
  Pulse train input of maximum of 100k pulse/s is enabled.
- Output specifications (high speed pulse train output or FM output) of terminal FM can be selected using *Pr. 291*.


●Connection with an open collector output system pulse generator




●Connection with a complimentary output system pulse generator



●Connection with an open collector output system pulse generator



●Connection with a complimentary output system pulse generator



WWW.BSNEW.IR

* When the wiring length of the open collector output connection is long, input pulse can not be recognized because of a pulse shape deformation due to the stray capacitances of the wiring.
When wiring length is long (10m (32.8feet) or more of 0.75mm^2 twisted cable is recommended), connect an open collector output signal and power supply using a pull up resistance. The reference of resistance value to the wiring length is as in the table below,

Wiring Length	Less than 10m	10 to 50m	50 to 100m
Pull up/down resistance	Not necessary	1kΩ	470Ω
Load current (for reference)	10mA	35mA	65mA

Stray capacitances of the wiring greately differ according to the cable type and cable laying, the above cable length is not a guaranteed value.
When using a pull up/down resistance, check the permissible power of the resistor and permissible load current of output transistor and use them within a permissible range.

REMARKS

- When pulse train input is selected, a function assigned to terminal JOG using *Pr. 185 JOG terminal function selection* is made invalid.
- When *Pr. 419 Position command source selection* = "2" (conditional position pulse train command by inverter pulse train input), JOG terminal serves as conditional position pulse train terminal regardless of the *Pr. 291*.


CAUTION

- Since *Pr. 291* is a selection parameter for pulse train output/FM output, check the specifications of a device connected to terminal FM when changing the setting value. (Refer to *page 255* for pulse train output.)
- Output specifications (high speed pulse train output or FM output) of terminal FM can be selected using *Pr. 291*. Change the setting value using care not to change output specifications of terminal FM. (Refer to *page 255* for pulse train output.)

●Pulse train input specifications

Item		Specifications
Available pulse method		Open collector output Complimentary output (power supply voltage 24V)
H input level		20V or more (voltage between JOG-SD)
L input level		5V or less (voltage between JOG-SD)
Maximum input pulse rate		100kpps
Minimum input pulse width		2.5us
Input resistance/load current		2kΩ (typ) / 10mA (typ)
Maximum wiring length (reference value)	Open collector output system	10m (32.8feet) (0.75mm^2/ twisted pair)
	Complemenraty output system	100m (output resistance 50Ω) *
Detection resolution		1/3750

* The wiring length of complementary output depends on the output wiring specifications of complementary output device.
Stray capacitances of the wiring greatly differ according to the cable type and cable laying, the maximum cable length is not a guaranteed value.



(2) Adjustment of pulse train input and frequency *(Pr. 385, Pr. 386)*

- Frequency for zero input pulse can be set using *Pr. 385 Frequency for zero input pulse* and frequency at maximum input pulse can be set using *Pr. 386 Frequency for maximum input pulse*.

* Limit value can be calculated from the following formula.
(*Pr. 386* - *Pr. 385*) × 1.1 + *Pr. 385*

(3) Calculation method of division scaling factor of input pulse (*Pr. 384*)

- Maximum input pulse can be calcualted from the following formula using *Pr. 384 Input pulse division scaling factor*.
Maximum of input pulse (pulse/s) = *Pr. 384* × 400 (maximum of 100kpulse/s)
Detectable pulse = 11.45 pulse/s


- For example, when you want to operate at 0Hz when pulse train input is zero and operate at 30Hz when pulse train is 4000 pulse/s, set parameters as below.
Pr. 384 = 10 (maximum input pulse 4000 pulse/s)
Pr. 385 = 0Hz, *Pr. 386* = 30Hz (pulse train limit value is 33Hz)

REMARKS

The priorities of the frequency commands by the external signals are "jog operation > multi-speed operation > teminal 4 analog input > pulse train input".
When pulse train input is made valid (when *Pr. 291* = "1, 11, 21, or 100" and *Pr. 384* ≠ "0"), terminal 2 analog input is made invalid.

WWW.BSNEW.IR

(4) Synchronous speed operation by pulse I/O



* When the wiring length between FM and JOG is long, a pulse shape is deformed due to the stray capacitances of the wiring and input pulse can not be recognized.
When wiring length is long (10m (32.8feet) or more of 0.75mm^2 twisted cable is recommended), connect terminal JOG and terminal PC using an external pull up resistance. The reference of resistance value to the wiring length is as in the table below.
Stray capacitances of the wiring greately differ according to the cable type and cable laying, the above cable length is not a guaranteed value.
When using a pull up resistance, check the permissible power and permissible load current (terminal PC : 100mA, high speed pulse train output : 85mA) of the resistor and use them within a permissible range.

- By setting "100" in *Pr. 291*, pulse train input can be output at pulse train output (terminal FM) as it is. Synchronous speed operation of multiple inverters can be enabled by daisy chain connection.
- Since maximum pulse train output is maximum of 50k pulse/s, set "125" in *Pr. 384* of the inverter receiving pulse train.
- When operating two or more inverters synchronously, perform wiring according to the following steps. (so that 24V contact input will not be applied to terminal FM)
  1) Set pulse train output (a value other than "0, 1") in *Pr. 291* of the master side inverter.
  2) Turn off the inverter power
  3) Perform wiring of the master side terminal FM-SD and slave side terminal JOG-SD
  4) Turn on the inverter power

CAUTION

- After changing a setting value of *Pr. 291* , connect JOG terminal between termial FM and SD. Take note that a voltage should not be applied to terminal FM specially when FM output (voltage output) pulse train is selected.
- For the slave side inverter, use sink logic (factory setting). The inverter will not function properly if source logic is selected.

●Specifications of synchronous speed operation

Item	Specifications
Output pulse type	Pulse width is fixed (10μs)
Pulse rate	0 to 50kpps
Pulse transmission delay	1 to 2μs per inverter *

* When a pulse transmission delay in a slave is approximately 1 to 2μs and wiring length is long, the delay further increases.

♦ Parameters referred to ♦



Pr. 291 (pulse train output) ☞*Refer to page 255*

WWW.BSNEW.IR

4.25.6 Encoder feedback control (Pr. 144, Pr. 285, Pr. 359, Pr. 367 to Pr. 369)

V/F

This controls the inverter output frequency so that the motor speed is constant to the load variation by detecting the motor speed with the speed detector (encoder) to feed it back to the inverter.
Option FR-A7AP is necessary.

Parameter Numbers	Name	Initial Value	Setting Range	Description
144	**Speed setting switchover**	4	0, 2, 4, 6, 8, 10, 102, 104, 106, 108, 110	Set the number of motor poles when performing encoder feedback control under V/F control.
285	**Overspeed detection frequency (Speed deviation excess detection frequency)** *1	9999	0 to 30Hz	If (detected frequency) - (output frequency) > *Pr. 285* during encoder feedback control, the inverter alarm (E.MB1) is provided.
			9999	Overspeed is not detected.
359 *2	**Encoder rotation direction**	1	0	 Clockwise direction as viewed from A is forward rotation
			1	 Counter clockwise direction as viewed from A is forward rotation
367 *2	**Speed feedback range**	9999	0 to 400Hz	Set the region of speed feedback control.
			9999	Encoder feedback control is invalid
368 *2	**Feedback gain**	1	0 to 100	Set when the rotation is unstable or response is slow.
369 *2	**Number of encoder pulses**	1024	0 to 4096	Set the number of pulses of the encoder. Set the number of pulses before multiplied by four.

*1 When exercising vector control with the FR-A7AP, this parameter changes to excessive speed deviation detection frequency. (For details, refer to *page 116*)
*2 The above parameters can be set when the FR-A7AP (option) is mounted.

(1) Setting before the operation (*Pr. 144, Pr. 359, Pr. 369*)

- When performing encoder feedback control under V/F control, set the number of motor poles in *Pr. 144 Speed setting switchover* according to the motor used. Because the number of motor poles is set in *Pr. 81 Number of motor poles* under advanced magnetic flux vector control, it is unnecessary to change *Pr. 144*.
- Set the rotation direction and the number of encoder pulses of the encoder using *Pr. 359 Encoder rotation direction* and *Pr. 369 Number of encoder pulses*.

REMARKS


- When "0, 10, 110" is set in *Pr. 144* and run the inverter, error E.1 to E.3 occurs.
- When "102, 104, 106, 108" is set in *Pr. 144*, the value subtracting 100 is set as the number of motor poles.
- Setting *Pr. 81 Number of motor poles* changes the *Pr. 144* setting automatically. However, changing the *Pr. 144* setting will not change the *Pr. 81* setting automatically.

CAUTION

- If the number of motor poles is wrong, control at correct speed can not be performed. Always check before operation.
- Encoder feedback control can not be performed when the setting of encoder rotation direction is wrong. (Inverter operation is enabled.)
  Encoder rotation direction can be checked with the rotation direction display of the parameter unit.

WWW.BSNEW.IR

(2) Selection of encoder feedback control (*Pr. 367*)



· When a value other than "9999" is set in *Pr. 367 Speed feedback range*, encoder feedback control is valid.
Using the set point (frequency at which stable speed operation is performed) as reference, set the higher and lower setting range. Normally, set the frequency converted from the slip amount (r/min) of the rated motor speed (rated load). If the setting is too large, response becomes slow.

Example: Rated speed of a 4-pole motor is 1740r/min (60Hz)

Slip Nsp = Synchronous speed - Rated speed
= 1800 - 1740 = 60(r/min)

Frequency equivalent to slip (fsp)

$$fsp = \frac{Nsp \times \text{Number of poles}}{120} = \frac{60 \times 4}{120} = 2\ (Hz)$$

(3) Feedback gain (*Pr. 368*)

· Set *Pr. 368 Feedback gain* when the rotation is unstable or response is slow.
· If the acceleration/deceleration time is long, feedback response becomes slower. In this case, increase the *Pr. 368* setting.

Pr. 368 Setting	Description
***Pr. 368* > 1**	Although the response becomes faster, overcurrent or unstable rotation is liable to occur.
1 < *Pr. 368*	Although the response becomes slower, the motor rotation becomes stable.

(4) Overspeed detection (*Pr. 285*)

· If (detection frequency) - (output frequency) > *Pr. 285* under encoder feedback control, E.MB1 occurs and the inverter output is stopped to prevent malfunction when the accurate pulse signal from the encoder can not be detected. Overspeed is not detected when *Pr. 285* = "9999".

CAUTION

· The encoder should be coupled on the same axis with the motor shaft with a speed ratio of 1 to 1 without any mechanical looseness.
· During acceleration/deceleration, encoder feedback control is not performed to prevent unstable phenomenon such as hunting.
· Encoder feedback control is performed once output frequency has reached within [set speed] ± [speed feedback range].
· If the following conditions occur during encoder feedback control, the inverter operates at the frequency within [set speed] ± [speed feedback range] without coming to an alarm stop nor tracking the motor speed.
  · The pulse signals are not received from the encoder due to a signal loss, etc.
  · The accurate pulse signal from the encoder can not be detected due to induction noise, etc.
  · The motor has been forcibly accelerated (regeneration) or decelerated (motor lock or the like) by large external force.
· For the motor with brake, use the RUN signal (inverter running) to open the brake. (The brake may not be opened if the FU (output frequency detection) signal is used.)
· Do not turn off the external power supply of the encoder during encoder feedback control. Encoder feedback control functions abnormally.

♦ Parameters referred to ♦

Pr. 81 Number of motor poles ☞ *Refer to page 145*

WWW.BSNEW.IR

4.25.7 Regeneration avoidance function (Pr. 665, Pr. 882 to Pr. 886)


This function detects a regenerative status and increases the frequency to avoid the regenerative status.


- Possible to avoid regeneration by automatically increasing the frequency and continue operation if the fan happens to rotate faster than the set speed due to the effect of another fan in the same duct.


Parameter Number	Name	Initial Value	Setting Range	Description
882	Regeneration avoidance operation selection	0	0	Regeneration avoidance function invalid
			1	Regeneration avoidance function is always valid
			2	Regeneration avoidance function is valid only during a constant speed operation
883	Regeneration avoidance operation level	380VDC/ 760VDC *	300 to 800V	Set the bus voltage level at which regeneration avoidance operates. When the bus voltage level is set to low, overvoltage error will be less apt to occur. However, the actual deceleration time increases. The set value must be higher than the power supply voltage × 2. * The initial value differs according to the voltage level. (200V / 400V)
884	Regeneration avoidance at deceleration detection sensitivity	0	0	Regeneration avoidance by bus voltage change ratio is invalid
			1 to 5	Set sensitivity to detect the bus voltage change ratio Setting 1 → 5 Detection sensitivity low → high
885	Regeneration avoidance compensation frequency limit value	6Hz	0 to 10Hz	Set the limit value of frequency which rises at activation of regeneration avoidance function.
			9999	Frequency limit invalid
886	Regeneration avoidance voltage gain	100%	0 to 200%	Adjust responsiveness at activation of regeneration avoidance. A larger setting will improve responsiveness to the bus voltage change. However, the output frequency could become unstable. When vibration is not suppressed by decreasing the *Pr. 886* setting, set a smaller value in *Pr. 665*.
665	Regeneration avoidance frequency gain	100%	0 to 200%	

(1) What is regeneration avoidance function? *(Pr. 882, Pr. 883)*

- When the regenerative status is serious, the DC bus voltage rises and an overvoltage alarm (E. OV□) may occur. When this bus voltage rise is detected and the bus voltage level reaches or exceeds *Pr. 883*, increasing the frequency avoids the regenerative status.
- For regeneration avoidance operation, you can select whether it is always activated or activated only at a constant speed.







- Setting *Pr. 882* to "1, 2" validates the regeneration avoidance function.

REMARKS

- The inclination of the frequency increased or decreased by the regeneration avoidance function changes depending on the regenerative status.
- The DC bus voltage of the inverter is normally about $\sqrt{2}$ times greater than the input voltage.
  When the input voltage is 220VAC (440VAC), the bus voltage is about 311VDC (622VDC).
  However, it varies with the input power supply waveform.
- The *Pr. 883* setting should be kept higher than the DC bus voltage level. Otherwise, the regeneration avoidance function is always on.
- While overvoltage stall (oL) is activated only during deceleration and stops the decrease in output frequency, the regeneration avoidance function is always on (*Pr. 882* = 1) or activated only during a constant speed (*Pr. 882* = 2) and increases the frequency according to the regeneration amount.

WWW.BSNEW.IR


(2) To detect the regenerative status during deceleration faster *(Pr. 884)*

· As the regeneration avoidance function cannot respond to an abrupt voltage change by detection of the bus voltage level, the ratio of bus voltage change is detected to stop deceleration if the bus voltage is less than *Pr. 883 Regeneration avoidance operation level*.
Set that detectable bus voltage change ratio to *Pr. 884* as detection sensitivity.
Increasing the setting raises the detection sensitivity.

CAUTION

Too small setting (low detection sensitivity) will disable detection, and too large setting will turn on the regeneration avoidance function if the bus voltage is varied by an input power change, etc.

(3) Limit regeneration avoidance operation frequency *(Pr. 885)*



You can limit the output frequency compensated for (increased) by the regeneration avoidance function.

· The frequency is limited to the output frequency (frequency prior to regeneration avoidance operation) + *Pr. 885 Regeneration avoidance compensation frequency limit value* during acceleration or constant speed. If the regeneration avoidance frequency exceeds the limit value during deceleration, the limit value is held until the output frequency falls to 1/2 of *Pr. 885*.
· When the regeneration avoidance frequency has reached *Pr. 1 Maximum frequency*, it is limited to the maximum frequency.
· *Pr. 885* is set to "9999", the frequency setting is invalid.

(4) Regeneration avoidance function adjustment *(Pr. 665, Pr. 886)*

· If the frequency becomes unstable during regeneration avoidance operation, decrease the setting of *Pr. 886 Regeneration avoidance voltage gain*. Reversely, if sudden regeneration causes an overvoltage alarm, increase the setting.
· When vibration is not suppressed by decreasing the *Pr. 886 Regeneration avoidance voltage gain* setting, set a smaller value in *Pr. 665 Regeneration avoidance frequency gain*.

CAUTION

· When regeneration avoidance operation is performed, oL (overvoltage stall) is displayed and the OL signal is output.
· When regeneration avoidance operation is performed, stall prevention is also activated at the same time.
· The regeneration avoidance function cannot shorten the actual deceleration time taken to stop the motor. The actual deceleration time depends on the regeneration capability. When shortening the deceleration time, consider using the regeneration unit (FR-BU2, BU, FR-BU, MT-BU5, FR-CV, FR-HC, MT-HC) or the brake resistor (FR-ABR, etc.).
· When using the regeneration unit (FR-BU2, BU, FR-BU, MT-BU5, FR-CV, FR-HC, MT-HC) or the brake resistor (FR-ABR, etc.), set *Pr. 882* to "0 (initial value)" (regeneration avoidance function invalid).
· When regeneration avoidance operation is performed, the OL signal output item of *Pr. 156* also becomes the target of oL (overvoltage stall). *Pr. 157 OL signal output timer* also becomes the target of oL (overvoltage stall).
· Under vector control, unusual noise may be generated from the motor during deceleration when using regeneration avoidance function. To prevent this, make gain adjustment, e.g. by performing easy gain tuning. *(Refer to page 104)*

♦ Parameters referred to ♦

Pr. 1 Maximum frequency ☞ *Refer to page 157*
Pr. 8 Deceleration time ☞ *Refer to page 173*
Pr. 22 Stall prevention operation level ☞ *Refer to page 150*

WWW.BSNEW.IR

4.26 Useful functions

Purpose	Parameter that must be Set		Refer to Page
Increase cooling fan life	Cooling fan operation selection	Pr. 244	379
To determine the maintenance time of parts.	Inverter part life display	Pr. 255 to Pr. 259	380
	Maintenance output function	Pr. 503, Pr. 504	383
	Current average value monitor signal	Pr. 555 to Pr. 557	384
Freely available parameter	Free parameter	Pr. 888, Pr. 889	386

4.26.1 Cooling fan operation selection (Pr. 244)

You can control the operation of the cooling fan (FR-A720-00080 or more, FR-A740-00060 or more) built in the inverter.

Parameter Number	Name	Initial Value	Setting Range	Description
244	Cooling fan operation selection	1	0	A cooling fan operates at power on Cooling fan on/off control invalid (The cooling fan is always on at power on)
			1	Cooling fan on/off control valid The fan is always on while the inverter is running. During a stop, the inverter status is monitored and the fan switches on-off according to the temperature.

- In either of the following cases, fan operation is regarded as faulty, [FN] is shown on the operation panel, and the fan fault (FAN) and minor fault (LF) signals are output.
  - *Pr. 244* = "0"
    When the fan comes to a stop with power on
  - *Pr. 244* = "1"
    When the fan stops during the fan ON command while the inverter is running
- For the terminal used for FAN signal output, set "25" (positive logic) or "125" (negative logic) in any of *Pr. 190 to Pr. 196 (output terminal function selection)*, and for the LF signal, set "98" (positive logic) or "198" (negative logic).

CAUTION

- When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions may be affected. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 190 to Pr. 196 (output terminal function selection) ☞ *Refer to page 236*

WWW.BSNEW.IR

4.26.2 Display of the life of the inverter parts (Pr. 255 to Pr. 259)


Degrees of deterioration of main circuit capacitor, control circuit capacitor, cooling fan and inrush current limit circuit can be diagnosed by monitor.
When any part has approached the end of its life, an alarm can be output by self diagnosis to prevent a fault.
(Use the life check of this function as a guideline since the life except the main circuit capacitor is calculated theoretically.)
For the life check of the main circuit capacitor, the alarm signal (Y90) will not be output if a measuring method of (4) is not performed.

Parameter Number	Name	Initial Value	Setting Range	Description
255	**Life alarm status display**	0	(0 to 15)	Display whether the control circuit capacitor, main circuit capacitor, cooling fan, and each parts of the inrush current limit circuit has reached the life alarm output level or not. Reading only
256	**Inrush current limit circuit life display**	100%	(0 to 100%)	Display the deterioration degree of the inrush current limit circuit. Reading only
257	**Control circuit capacitor life display**	100%	(0 to 100%)	Display the deterioration degree of the control circuit capacitor. Reading only
258	**Main circuit capacitor life display**	100%	(0 to 100%)	Display the deterioration degree of the main circuit capacitor. Reading only The value measured by *Pr. 259* is displayed.
259	**Main circuit capacitor life measuring**	0	0, 1 (2, 3, 8, 9)	Setting "1" and switching the power supply off starts the measurement of the main circuit capacitor life. When the *Pr. 259* value is "3" after powering on again, the measuring is completed. Read the deterioration degree in *Pr. 258*.

WWW.BSNEW.IR

(1) Life alarm display and signal output (Y90 signal, *Pr. 255*)

· Whether any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit has reached the life alarm output level or not can be checked by *Pr. 255 Life alarm status display* and life alarm signal (Y90).



Pr. 255 (decimal)	Bit (binary)	Inrush Current Limit Circuit Life	Cooling Fan Life	Main Circuit Capacitor Life	Control Circuit Capacitor Life
15	1111	○	○	○	○
14	1110	○	○	○	×
13	1101	○	○	×	○
12	1100	○	○	×	×
11	1011	○	×	○	○
10	1010	○	×	○	×
9	1001	○	×	×	○
8	1000	○	×	×	×
7	0111	×	○	○	○
6	0110	×	○	○	×
5	0101	×	○	×	○
4	0100	×	○	×	×
3	0011	×	×	○	○
2	0010	×	×	○	×
1	0001	×	×	×	○
0	0000	×	×	×	×

○: With warnings, ×: Without warnings

· The life alarm signal (Y90) turns on when any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit reaches the life alarm output level.
· For the terminal used for the Y90 signal, set "90" (positive logic) or "190" (negative logic) to any of *Pr. 190 to Pr. 196 (output terminal function selection)*.

REMARKS

· The digital output option (FR-A7AY, FR-A7AR, FR-A7NC) allows the control circuit capacitor life signal (Y86), main circuit capacitor life signal (Y87), cooling fan life signal (Y88) and inrush current limit circuit life signal (Y89) to be output individually.

CAUTION

· When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions may be affected. Please make setting after confirming the function of each terminal.

(2) Life display of the inrush current limit circuit *(Pr. 256)*

· The life of the inrush current limit circuit (relay, contactor and inrush resistor) is displayed in *Pr. 256*.
· The number of contact (relay, contactor, thyristor) ON times is counted, and it is counted down from 100% (1 million times) every 1%/10,000 times. As soon as 10% (900,000 times) is reached, *Pr. 255* bit 3 is turned on and also an alarm is output to the Y90 signal.

(3) Control circuit capacitor life display *(Pr. 257)*

· The deterioration degree of the control circuit capacitor is displayed in *Pr. 257* as a life.
· In the operating status, the control circuit capacitor life is calculated from the energization time and temperature, and is counted down from 100%. As soon as the control circuit capacitor life falls below 10%, *Pr. 255* bit 0 is turned on and also an alarm is output to the Y90 signal.

WWW.BSNEW.IR

(4) Main circuit capacitor life display *(Pr. 258, Pr. 259)*

- The deterioration degree of the main circuit capacitor is displayed in *Pr. 258* as a life.
- On the assumption that the main circuit capacitor capacitance at factory shipment is 100%, the capacitor life is displayed in *Pr. 258* every time measurement is made. When the measured value falls to or below 85%, *Pr. 255* bit 1 is turned on and also an alarm is output to the Y90 signal.
- Measure the capacitor capacity according to the following procedure and check the deterioration level of the capacitor capacity.
  1) Check that the motor is connected and at a stop.
  2) Set "1" (measuring start) in *Pr. 259*
  3) Switch power off. The inverter applies DC voltage to the motor to measure the capacitor capacity while the inverter is off.
  4) After making sure that the power lamp is off, switch on the power supply again.
  5) Check that "3" (measuring completion) is set in *Pr. 259*, read *Pr. 258*, and check the deterioration degree of the main circuit capacitor.

Pr. 259	Description	Remarks
0	No measurement	Initial value
1	Measurement start	Measurement starts when the power supply is switched off.
2	During measurement	Only displayed and cannot be set
3	Measurement complete	
8	Forced end	
9	Measurement error	

REMARKS

- When the main circuit capacitor life is measured under the following conditions, "forced end" (*Pr. 259* = "8") or "measuring error" (*Pr. 259* = "9") occurs or it remains in "measuring start" (*Pr. 259* = "1").
  When measuring, avoid the following conditions to perform.
  (a) The FR-HC, MT-HC, FR-CV, FR-BU2, FR-BU, MT-BU5 or BU is connected
  (b) Terminals R1/L11, S1/L21 or DC power supply is connected to the terminal P/+ and N/-.
  (c) Switch power on during measuring.
  (d) The motor is not connected to the inverter.
  (e) The motor is running. (The motor is coasting.)
  (f) The motor capacity is two rank smaller as compared to the inverter capacity.
  (g) The inverter is at an alarm stop or an alarm occurred while power is off.
  (h) The inverter output is shut off with the MRS signal.
  (i) The start command is given while measuring.
- Operating environment: Ambient Temperature (annual average 40°C (104°F) (free from corrosive gas, flammable gas, oil mist, dust and dirt))
  Output current (equivalent to rating current of the Mitsubishi standard motor (4 poles))

POINT

For the accurate life measuring of the main circuit capacitor, perform after more than 3h passed since the turn off of the power as it is affected by the capacitor temperature.

⚠ WARNING

⚠ When measuring the main circuit capacitor capacity (*Pr. 259 Main circuit capacitor life measuring* = "1"), the DC voltage is applied to the motor for 1s at powering off. Never touch the motor terminal, etc. right after powering off to prevent an electric shock.

(5) Cooling fan life display

- The cooling fan speed of 50% or less is detected and "FN" is displayed on the operation panel (FR-DU07) and parameter unit (FR-PU04/FR-PU07). As an alarm display, *Pr. 255* bit 2 is turned on and also an alarm is output to the Y90 signal.

REMARKS

- When the inverter is mounted with two or more cooling fans, the life of even one cooling fan is diagnosed.

CAUTION


- For replacement of each part, contact the nearest Mitsubishi FA center.

WWW.BSNEW.IR

4.26.3 Maintenance timer alarm (Pr. 503, Pr. 504)

When the cumulative energization time of the inverter reaches the parameter set time, the maintenance timer output signal (Y95) is output. MT (MT) is displayed on the operation panel (FR-DU07).
This can be used as a guideline for the maintenance time of peripheral devices.

Parameter Number	Name	Initial Value	Setting Range	Description
503	**Maintenance timer**	0	0 (1 to 9998)	Display the cumulative energization time of the inverter in 100h increments. Reading only Writing the setting of "0" clears the cumulative energization time.
504	**Maintenance timer alarm output set time**	9999	0 to 9998	Set the time taken until when the maintenance timer alarm output signal (Y95) is output.
			9999	No function



- The cumulative energization time of the inverter is stored into the EEPROM every hour and indicated in *Pr. 503 Maintenance timer* in 100h increments. *Pr. 503* is clamped at 9998 (999800h).
- When the *Pr. 503* value reaches the time set in *Pr. 504 Maintenance timer alarm output set time* (100h increments), the maintenance timer alarm output signal (Y95) is output.
- For the terminal used for the Y95 signal output, assign the function by setting "95" (positive logic) or "195" (negative logic) to any of *Pr. 190 to Pr. 196 (output terminal function selection)*.

CAUTION

- The cumulative energization time is counted every hour. The energization time of less than 1h is not counted.
- When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions may be affected. Please make setting after confirming the function of each terminal.


♦ Parameters referred to ♦

Pr. 190 to Pr. 196(output terminal function selection) ☞ *Refer to page 236*

WWW.BSNEW.IR


4.26.4 Current average value monitor signal (Pr. 555 to Pr. 557)

The average value of the output current during constant speed operation and the maintenance timer value are output as a pulse to the current average value monitor signal (Y93).
The pulse width output to the I/O module of the PLC etc. can be used as a guideline due to abrasion of machines and elongation of belt and for aged deterioration of devices to know the maintenance time.
The current average value monitor signal (Y93) is output as pulse for 20s as 1 cycle and repeatedly output during constant speed operation.



Parameter Number	Name	Initial Value	Setting Range 200V class (400V class)		Description
555	**Current average time**	1s	0.1 to 1.0s		Set the time taken to average the current during start pulse output (1s).
556	**Data output mask time**	0s	0.0 to 20.0s		Set the time for not obtaining (mask) transient state data.
557	**Current average value monitor signal output reference current**	Rated inverter current	02150(01100) or less	0 to 500A	Set the reference (100%) for outputting the signal of the current average value.
			02880(01440) or more	0 to 3600A	

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.



- The pulse output of the current average value monitor signal (Y93) is shown above.
- For the terminal used for the Y93 signal output, assign the function by setting "93" (positive logic) or "193" (negative logic) to any of *Pr. 190 to Pr. 194 (output terminal function selection)*. (The function can not be assigned to *Pr. 195 ABC1 terminal function selection* and *Pr. 196 ABC2 terminal function selection*.)

(1) Setting of *Pr. 556 Data output mask time*
The output current is unstable (transient state) right after the operation is changed from the acceleration/deceleration state to the constant speed operation. Set the time for not obtaining (mask) transient state data in *Pr. 556*.

(2) Setting of the *Pr. 555 Current average time*
The average output current is calculated during Hi output of start bit (1s). Set the time taken to average the current during start bit output in *Pr. 555*.

WWW.BSNEW.IR

(3) Setting of *Pr. 557 Current average value monitor signal output reference current*


Set the reference (100%) for outputting the signal of the current average value. Obtain the time to output the signal from the following formula.

$$\frac{\text{Output current average value}}{Pr.\ 557\ \text{setting}} \times 5\text{s}$$ **(output current average value 100%/5s)**

Note that the output time range is 0.5 to 9s, and it is 0.5s when the output current average value is less than 10% of the setting value of *Pr. 557* and 9s when exceeds 180%.

Example)When *Pr. 557* = 10A and the average value of output current is 15A

As 15A/10A × 5s = 7.5, the current average value monitor signal is output as low pulse shape for 7.5s.




(4) Output of *Pr. 503 Maintenance timer*

After the output current average value is output as low pulse shape, the maintenance timer value is output as high pulse shape. The output time of the maintenance timer value is obtained from the following formula.


$$\frac{Pr.\ 503 \times 100}{40000\text{h}} \times 5\text{s}$$ **(maintenance timer value 100%/5s)**

Note that the output time range is 2 to 9s, and it is 2s when *Pr. 503* is less than 16000h and 9s when exceeds 72000h.



REMARKS

- Mask of data output and sampling of output current are not performed during acceleration/deceleration.
- When the speed is changed to acceleration/deceleration from constant speed during start pulse output, the data is judged as invalid, the start pulse is output as high pulse shape for 3.5s, and the end signal is output as low pulse shape for 16.5s.
  The signal is output for at least 1 cycle even when acceleration/deceleration state continues after the start pulse output is completed.



- When the output current value (inverter output current monitor) is 0A on completion of the 1 cycle signal output, the signal is not output until the speed becomes constant next time
- The current average value monitor signal (Y93) is output as low pulse shape for 20s (without data output) under the following condition.
  (a)When the motor is in the acceleration/deceleration state on completion of the 1 cycle signal output
  (b)When 1-cycle signal output was ended during restart operation with the setting of automatic restart after instantaneous power failure (*Pr. 57* ≠ "9999")
  (c)When automatic restart operation was being performed with automatic restart after instantaneous power failure selected (*Pr. 57* ≠ "9999") on completion of the data output mask

CAUTION

- When terminal assignment is changed using *Pr. 190 to Pr. 196 (output terminal function selection)*, the other functions may be affected. Please make setting after confirming the function of each terminal.

♦ Parameters referred to ♦

Pr. 190 to Pr. 196(output terminal function selection) ☞ *Refer to page 236*
Pr. 503 Maintenance timer ☞ *Refer to page 383*
Pr. 57 Restart coasting time ☞ *Refer to page 261*

WWW.BSNEW.IR

4.26.5 Free parameter (Pr. 888, Pr. 889)

You can input any number within the setting range 0 to 9999.
For example, the number can be used:
- As a unit number when multiple units are used.
- As a pattern number for each operation application when multiple units are used.
- As the year and month of introduction or inspection.

Parameter Number	Name	Initial Value	Setting Range	Description
888	**Free parameter 1**	9999	0 to 9999	Desired values can be input. Data is held even if the inverter power is turned off.
889	**Free parameter 2**	9999	0 to 9999	

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

REMARKS

- The set value is stored in EEPROM as same as other parameter, the setting value is saved even after power off.
- *Pr. 888* and *Pr. 889* do not influence the inverter operation.

WWW.BSNEW.IR

4.27 Setting of the parameter unit and operation panel

Purpose	Parameter that must be Set		Refer to Page
Switch the display language of the parameter unit	**PU display language selection**	**Pr. 145**	387
Use the setting dial of the operation panel like a volume for frequency setting. Key lock of operation panel	**Operation panel operation selection**	**Pr. 161**	387
Control of the parameter unit, operation panel buzzer	**PU buzzer control**	**Pr. 990**	389
Adjust the LCD contrast of the parameter unit	**PU contrast adjustment**	**Pr. 991**	389

4.27.1 PU display language selection (Pr. 145)

You can switch the display language of the parameter unit (FR-PU04/FR-PU07) to another.

Parameter Number	Name	Initial Value	Setting Range	Description
145	**PU display language selection**	1	0	Japanese
			1	English
			2	Germany
			3	French
			4	Spanish
			5	Italian
			6	Swedish
			7	Finnish

4.27.2 Operation panel frequency setting/key lock operation selection (Pr. 161)


The setting dial of the operation panel (FR-DU07) can be used like a volume to perform operation.
The key operation of the operation panel can be disabled.

Parameter Number	Name	Initial Value	Setting Range	Description	
161	**Frequency setting/key lock operation selection**	0	0	Setting dial frequency setting mode	Key lock mode invalid
			1	Setting dial volume mode	
			10	Setting dial frequency setting mode	Key lock mode valid
			11	Setting dial volume mode	

WWW.BSNEW.IR

(1) Using the setting dial like a volume to set the frequency.

Operation example Changing the frequency from 0Hz to 60Hz during operation

Operation	Display
1. Screen at powering on The monitor display appears.	
2. Press (PU/EXT) to choose the PU operation mode.	PU indication is lit. 
3. Press (MODE) to choose the parameter setting mode.	 (The parameter number previously read appears.)
4. Turn dial until P.161 (*Pr. 161*) appears.	
5. Press (SET) to read the currently set value. "0" (initial value) appears.	
6. Turn dial to change it to the setting value "1".	
7. Press (SET) to set.	 **Flicker ··· Parameter setting complete!!**
8. Mode/monitor check Press (MODE) twice to choose monitor/frequency monitor.	
9. Press (FWD) (or (REV)) to start the inverter.	
10. Turn dial until "60.00" appears. The flickering frequency is the set frequency. You need not press (SET).	 The frequency flickers for about 5s.

REMARKS

- If the display changes from flickering "60.00" to "0.00", the setting of *Pr. 161 Frequency setting/key lock operation selection* may not be "1".
- Independently of whether the inverter is running or at a stop, the frequency can be set by merely turning the dial.
- When the frequency is changed, it will be stored in EEPROM as the set frequency after 10s.

WWW.BSNEW.IR

(2) Disable the setting dial and key operation of the operation panel (Press [MODE] long (2s))

- Operation using the setting dial and key of the operation panel can be made invalid to prevent parameter change and unexpected start and stop.
- Set "10 or 11" in *Pr. 161*, then press (MODE) for 2s to make the setting dial and key operation invalid.
- When the setting dial and key operation is made invalid, HOLd appears on the operation panel. When the setting dial and key operation is invalid, HOLd appears if the setting dial or key operation is performed. (When the setting dial or key operation is not performed for 2s, the monitor display appears.)
- To make the setting dial and key operation valid again, press (MODE) for 2s.

REMARKS

- Even if the setting dial and key operation are disabled, the monitor display (STOP RESET) is valid.

CAUTION

- Release the operation lock to release the PU stop by key operation.

4.27.3 Buzzer control (Pr. 990)

You can make the buzzer "beep" when you press key of the operation panel (FR-DU07) and parameter unit (FR-PU04/FR-PU07).

Parameter Number	Name	Initial Value	Setting Range	Description
990	PU buzzer control	1	0	Without buzzer
			1	With buzzer

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

4.27.4 PU contrast adjustment (Pr. 991)

Contrast adjustment of the LCD of the parameter unit (FR-PU04/FR-PU07) can be performed.
Decreasing the setting value makes contrast light.

Parameter Number	Name	Initial Value	Setting Range	Description
991	PU contrast adjustment	58	0 to 63	0 : Light ↓ 63: Dark

The above parameters are displayed as simple mode parameters only when the parameter unit (FR-PU04/FR-PU07) is connected.

WWW.BSNEW.IR

4.28 Parameter clear

POINT

· Set "1" in *Pr. CL parameter clear* to initialize all parameters. (Parameters are not cleared when "1" is set in *Pr. 77 Parameter write selection*. In addition, calibration parameters are not cleared.)

Operation	Display
1. Screen at powering on The monitor display appears.	
2. Press PU/EXT to choose the PU operation mode.	PU/EXT ⇨  PU indication is lit.
3. Press MODE to choose the parameter setting mode.	MODE ⇨ P. 0 (The parameter number read previously appears.)
4. Turn the dial until " PrCL " appears.	⇨ PrCL
5. Press SET to read the currently set value. " 0 "(initial value) appears.	SET ⇨ 0
6. Turn the dial to change it to the setting value " 1 ".	⇨ 1
7. Press SET to set.	SET ⇨ 1 PrCL (Flicker)

Flicker ··· Parameter setting complete!!

· Turn the dial to read another parameter.

· Press SET to show the setting again.

· Press SET twice to show the next parameter.

Setting	Description
0	Not executed.
1	Returns all parameters except *calibration parameters C0 (Pr. 900) to C7 (Pr. 905), C12 (Pr. 917) to C19 (Pr. 920), C38 (Pr. 932) to C41 (Pr. 933)* to the initial values.

REMARKS

Refer to the list of parameters on *page 454* for availability of parameter clear.

? 1 and Er4 are displayed alternately ... Why?

☞ The inverter is not in the PU operation mode.

1. Press PU/EXT.

   PU is lit and the monitor (4 digit LED) displays "0" (*Pr. 79* = "0" (initial value)).

2. Carry out operation from step 6 again.

WWW.BSNEW.IR

4.29 All parameter clear

POINT

· Set "1" in *ALLC parameter clear* to initialize all parameters. (Parameters are not cleared when "1" is set in *Pr. 77 Parameter write selection*. In addition, calibration parameters are not cleared.)

Operation

1. Screen at powering on
   The monitor display appears.
2. Press (PU/EXT) to choose the PU operation mode.
3. Press (MODE) to choose the parameter setting mode.
4. Turn the dial until "ALLC" (all parameter clear) appears.
5. Press (SET) to read the currently set value.
   "0"(initial value) appears.
6. Turn the dial to change it to the setting value "1".
7. Press (SET) to set.

Display



PU indication is lit.






The parameter number read previously appears.









Flicker ··· Parameter setting complete!!

· Press the dial to read another parameter.
· Press (SET) to show the setting again.
· Press (SET) twice to show the next parameter.

Setting	Description
0	Not executed.
1	All parameters return to the initial values.

REMARKS

Refer to the list of parameters on *page 454* for availability of all parameter clear.

? "1" and "Er4" are displayed alternately ... Why?

☞ The inverter is not in the PU operation mode.

1. Press (PU/EXT).
   PU is lit and the monitor (4 digit LED) displays "0" (*Pr. 79* = "0" (initial value)).
2. Carry out operation from step 6 again.

WWW.BSNEW.IR

4.30 Parameter copy and parameter verification

PCPY Setting	Description
0	Cancel
1	Copy the source parameters to the operation panel.
2	Write the parameters copied to the operation panel into the destination inverter.
3	Verify parameters in the inverter and operation panel. *(Refer to page 47.)*

REMARKS

- When the copy destination inverter is not the FR-A700 series or parameter copy write is performed after parameter copy read is stopped, "model error (rE4)" is displayed.
- Refer to the parameter list on *page 454* and later for availability of parameter copy.
- When the power is turned off or an operation panel is disconnected, etc. during parameter copy write, perform write again or check the values by parameter verification.

4.30.1 Parameter copy

Parameter settings can be copied to multiple inverters.


Operation

1. Connect the operation panel to the copy source inverter.
   - **Connect it during a stop.**
2. Press (MODE) to choose the parameter setting mode.
3. Turn dial until PCPY (parameter copy) appears.
4. Press (SET) to read the currently set value. "0"(initial value) appears.
5. Turn dial to change it to the setting value "1".
6. Press (SET) to copy the source parameters to the operation panel.
7. Connect the operation panel to the copy source inverter.
8. After performing steps 2 to 5, turn dial to change it to "2".
9. Press (SET) to write the parameters copied to the operation panel to the destination inverter.
10. When copy is completed, "2" and "PCPY" flicker.
11. After writing the parameter values to the copy destination inverter, always reset the inverter, e.g. switch power off once, before starting operation.


Display



(MODE) ⇨ P. 0 (The parameter number previously read appears.)

 ⇨ PCPY


(SET) ⇨ 0


 ⇨ 1

(SET) ⇨ 1 Flickers for about 30s

About 30s later ⇨ 1 PCPY

Flicker ··· Parameter copy complete!!



 ⇨ 2

(SET) ⇨ 2 The frequency flickers for about 30s

⇨ 2 PCPY

Flicker ··· Parameter copy complete!!

WWW.BSNEW.IR

? rE1 appears...Why? ☞ Parameter read error. Perform operation from step 3 again.

? rE2 appears...Why? ☞ Parameter write error. Perform operation from step 8 again.

? CP and 0.00 flicker alternately

☞ Appears when parameters are copied between the inverter of FR-A720-02150 (FR-A740-01100) or less and FR-A720-02880 (FR-A740-01440) or more.


1. Set "0" (initial value) in *Pr. 160 User group read selection*.
2. Set the following setting (initial value) in *Pr. 989 Parameter copy alarm release*.

	FR-A720-02150 (FR-A740-01100) **or less**	FR-A720-02880 (FR-A740-01440) **or more**
Pr. 989 Setting	10	100

3. Reset *Pr. 9, Pr. 30, Pr. 51, Pr. 52, Pr. 54, Pr. 56, Pr. 57, Pr. 61, Pr. 70, Pr. 72, Pr. 80, Pr. 82, Pr. 90 to Pr. 94 , Pr. 158, Pr. 455, Pr. 458 to Pr. 462, Pr. 557, Pr. 859, Pr. 860, Pr. 893*.

4.30.2 Parameter verification

Whether same parameter values are set in other inverters or not can be checked.



REMARKS

When the copy destination inverter is not the FR-A700 series, "model error (rE4)" is displayed.


? rE3 flickers ... Why?

☞ Set frequencies, etc. may be different. Check set frequencies.

WWW.BSNEW.IR

4.31 Check and clear of the alarm history

(1) Check for the alarm (major fault) history




WWW.BSNEW.IR

(2) Clearing procedure

POINT

· The alarm history can be cleared by setting "1" in *Er.CL Alarm history clear*.



· Press to read another parameter.

· Press SET to show the setting again.

· Press SET twice to show the next parameter.

WWW.BSNEW.IR

MEMO

WWW.BSNEW.IR

5 PROTECTIVE FUNCTIONS

This chapter describes the basic "PROTECTIVE FUNCTION" for use of this product.
Always read the instructions before using the equipment

5.1 Reset method of protective function 398
5.2 List of alarm display 399
5.3 Causes and corrective actions 400
5.4 Correspondences between digital and actual characters 413
5.5 Check first when you have troubles 414

WWW.BSNEW.IR

When an alarm (major failures) occurs in the inverter, the protective function is activated bringing the inverter to an alarm stop and the PU display automatically changes to any of the following error (alarm) indications.
If your fault does not correspond to any of the following errors or if you have any other problem, please contact your sales representative.

- Retention of alarm output signal..... When the magnetic contactor (MC) provided on the input side of the inverter is opened at the activation of the protective function, the inverter's control power will be lost and the alarm output will not be held.
- Alarm display ..... When the protective function is activated, the operation panel display automatically switches to the above indication.
- Resetting method ..... When the protective function is activated, the inverter output is kept stopped. Unless reset, therefore, the inverter cannot restart. *(Refer to page 398.)*
- When the protective function is activated, take the corresponding corrective action, then reset the inverter, and resume operation.
  Not doing so may lead to the inverter fault and damage.

Inverter alarm displays are roughly divided as below.

(1) Error Message
A message regarding operational fault and setting fault by the operation panel (FR-DU07) and parameter unit (FRPU04 /FR-PU07) is displayed.
The inverter does not shut off output.

(2) Warnings
The inverter does not shut off output even when a warning is displayed. However, failure to take appropriate measures will lead to a major fault.


(3) Minor fault
The inverter does not shut off output.You can also output a minor fault signal by making parameter setting.

(4) Major fault
When the protective function is activated, the inverter output is shut off and an alarm is output.


5.1 Reset method of protective function

(1) Resetting the inverter
The inverter can be reset by performing any of the following operations. Note that the internal thermal integrated value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the inverter.
Recover about 1s after reset is cancelled.


Operation 1: ..... (STOP RESET) ... Using the operation panel, press (Enabled only when the inverter protective function is activated (major fault) (Refer to *page 404* for major fault.))



Operation 2: ..... Switch power off once, then switch it on again.



Operation 3: ..... Turn on the reset signal (RES) for more than 0.1s. (If the RES signal is kept on, "Err." appears (flickers) to indicate that the inverter is in a reset status.)



REMARKS

For the FR-A720-02880 (FR-A740-01440) or more, you can set *Pr. 75* to disable reset operation until the thermal cumulative amount reaches 0 when a thermal trip (THM, THT) or an overcurrent trip (OC1 to OC3) occurs consecutively twice. *(Refer to page 302.)*

WWW.BSNEW.IR

5.2 List of alarm display

Operation Panel Indication			Name	Refer to
Error message	E - - -	E - - -	Alarm history	394
	HOLd	HOLD	Operation panel lock	400
	Er 1 to Er4	Er1 to 4	Parameter write error	400
	rE 1 to rE4	rE1 to 4	Copy operation error	401
	Err.	Err.	Error	401
Warnings	OL	OL	Stall prevention (overcurrent)	402
	oL	oL	Stall prevention (overvoltage)	402
	rb	RB	Regenerative brake prealarm	403
	TH	TH	Electronic thermal relay function prealarm	403
	PS	PS	PU stop	402
	MT	MT	Maintenance signal output	403
	CP	CP	Parameter copy	403
	SL	SL	Speed limit indication (Output during speed limit)	403
Minor fault	Fn	FN	Fan fault	403
Major fault	E.OC1	E.OC1	Overcurrent shut-off during acceleration	404
	E.OC2	E.OC2	Overcurrent shut-off during constant speed	404
	E.OC3	E.OC3	Overcurrent shut-off during deceleration or stop	404
	E.Ov1	E.OV1	Regenerative overvoltage shut-off during acceleration	405
	E.Ov2	E.OV2	Regenerative overvoltage shut-off during constant speed	405
	E.Ov3	E.OV3	Regenerative overvoltage shut-off during deceleration or stop	405
	E.THT	E.THT	Inverter overload shut-off (electronic thermal relay function)	405
	E.THM	E.THM	Motor overload shut-off (electronic thermal relay function)	405
	E.FIN	E.FIN	Fin overheat	406
	E.IPF	E.IPF	Instantaneous power failure	406
	E. bE	E.BE	Brake transistor alarm detection	406
	E.UVT	E.UVT	Undervoltage	406
	E.ILF	E.ILF*	Input phase failure	406
	E.OLT	E.OLT	Stall prevention	407

Operation Panel Indication			Name	Refer to
Major fault	E. GF	E.GF	Output side earth (ground) fault overcurrent	407
	E. LF	E.LF	Output phase failure	407
	E.OHT	E.OHT	External thermal relay operation *2	407
	E.PTC	E.PTC*	PTC thermistor operation	407
	E.OPT	E.OPT	Option alarm	408
	E.OP3	E.OP3	Communication option alarm	408
	E. 1 to E. 3	E. 1 to E. 3	Option alarm	408
	E. PE	E.PE	Parameter storage device alarm	408
	E.PUE	E.PUE	PU disconnection	409
	E.rET	E.RET	Retry count excess	409
	E.PE2	E.PE2*	Parameter storage device alarm	409
	E. 6/ E. 7/ E.CPU	E. 6 / E. 7 / E.CPU	CPU error	409
	E.CTE	E.CTE	Operation panel power supply short circuit, RS-485 terminal power supply short circuit	409
	E.P24	E.P24	24VDC power output short circuit	411
	E.CDO	E.CDO*	Output current detection value exceeded	411
	E.IOH	E.IOH*	Inrush current limit circuit alarm	411
	E.SER	E.SER*	Communication error (inverter)	411
	E.AIE	E.AIE*	Analog input error	411
	E. OS	E.OS	Overspeed occurence	410
	E.OSD	E.OSD	Speed deviation excess detection	410
	E.ECT	E.ECT	Signal loss detection	410
	E. Od	E.OD	Excessive position error	410
	E.MB1 to E.MB7	E.MB1 to E.MB7	Brake sequence error	409
	E.EP	E.EP	Encoder phase error	410
	E.USB	E.USB*	USB communication error	411
	E. 11	E.11	Opposite rotation deceleration error	412
	E. 13	E.13	Internal circuit error	412

* If an error occurs when using the FR-PU04, "Fault 14" is displayed on the FR-PU04.

WWW.BSNEW.IR

5.3 Causes and corrective actions

(1) Error message

A message regarding operational troubles is displayed. Output is not shut off.

Operation Panel Indication	HOLD	HOLd
Name	Operation panel lock	
Description	Operation lock mode is set. Operation other than STOP RESET is made invalid. *(Refer to page 389.)*	
Check point	—	
Corrective action	Press MODE for 2s to release lock.	

Operation Panel Indication	Er1	Er 1
Name	Write disable error	
Description	1. You attempted to make parameter setting when *Pr. 77 Parameter write selection* has been set to disable parameter write. 2. Frequency jump setting range overlapped. 3. Adjustable 5 points V/F settings overlapped 4. The PU and inverter cannot make normal communication	
Check point	1. Check the setting of *Pr. 77 Parameter write selection (Refer to page 305.)* 2. Check the settings of *Pr. 31 to 36 (frequency jump). (Refer to page 158.)* 3. Check the settings of *Pr. 100 to Pr. 109 (adjustable 5 points V/F). (Refer to page 165.)* 4. Check the connection of the PU and inverter.	

Operation Panel Indication	Er2	Er2
Name	Write error during operation	
Description	When parameter write was performed during operation with a value other than "2" (writing is enabled independently of operation status in any operation mode) is set in *Pr. 77* and the STF (STR) is on.	
Check point	1. Check the *Pr. 77* setting. *(Refer to page 305.)* 2. Check that the inverter is not operating.	
Corrective action	1. Set "2" in *Pr. 77*. 2. After stopping operation, make parameter setting.	

Operation Panel Indication	Er3	Er3
Name	Calibration error	
Description	Analog input bias and gain calibration values are too close.	
Check point	Check the settings of C3, C4, C6 and C7 (calibration functions). *(Refer to page 289.)*	

Operation Panel Indication	Er4	Er4
Name	Mode designation error	
Description	You attempted to make parameter setting in the NET operation mode when *Pr. 77* is not "2".	
Check point	1. Check that operation mode is "PU operation mode". 2. Check the *Pr. 77* setting. *(Refer to page 305.)*	
Corrective action	1. After setting the operation mode to the "PU operation mode", make parameter setting. *(Refer to page 305.)* 2. After setting "2" in *Pr. 77*, make parameter setting.	

WWW.BSNEW.IR

Operation Panel Indication	rE1	rE1
Name	Parameter read error	
Description	An error occurred in the EEPROM on the operation panel side during parameter copy reading.	
Check point	—	
Corrective action	· Make parameter copy again. *(Refer to page 392.)* · Check for an operation panel (FR-DU07) failure. Please contact your sales representative.	

Operation Panel Indication	rE2	rE2
Name	Parameter write error	
Description	1. You attempted to perform parameter copy write during operation. 2. An error occurred in the EEPROM on the operation panel side during parameter copy writing.	
Check point	Is the FWD or REV LED of the operation panel (FR-DU07) lit or flickering?	
Corrective action	1. After stopping operation, make parameter copy again. *(Refer to page 392.)* 2. Check for an operation panel (FR-DU07) failure. Please contact your sales representative.	

Operation Panel Indication	rE3	rE3
Name	Parameter verification error	
Description	1. Data on the operation panel side and inverter side are different. 2. An error occurred in the EEPROM on the operation panel side during parameter verification.	
Check point	Check for the parameter setting of the source inverter and inverter to be verified.	
Corrective action	1. Press (SET) to continue verification. Make parameter verification again. *(Refer to page 47.)* 2. Check for an operation panel (FR-DU07) failure. Please contact your sales representative.	

Operation Panel Indication	rE4	rE4
Name	Model error	
Description	1. A different model was used for parameter write and verification during parameter copy. 2. When parameter copy write is stopped after parameter copy read is stopped	
Check point	1. Check that the verified inverter is the same model. 2. Check that the power is not turned off or an operation panel is not disconnected, etc. during parameter copy read.	
Corrective action	1. Use the same model (FR-A700 series) for parameter copy and verification. 2. Perform parameter copy read again.	

Operation Panel Indication	Err.	Err.
Description	1. The RES signal is on 2. The PU and inverter cannot make normal communication (contact fault of the connector) 3. When the control circuit power (R1/L11, S1/L21) and the main circuit power (R/L1, S/L2, T/L3) are connected to a separate power, it may appear at turning on of the main circuit. It is not a fault.	
Corrective action	1. Turn off the RES signal. 2. Check the connection of the PU and inverter.	

WWW.BSNEW.IR

(2) Warnings

When the protective function is activated, the output is not shut off.

Operation Panel Indication	OL		FR-PU04 FR-PU07	OL
Name	Stall prevention (overcurrent)			
Description	During acceleration	When the output current (output torque during real sensorless vector control or vector control) of the inverter exceeds the stall prevention operation level (*Pr. 22 Stall prevention operation level*, etc.), this function stops the increase in frequency until the overload current decreases to prevent the inverter from resulting in overcurrent shut-off. When the overload current has decreased below stall prevention operation level, this function increases the frequency again.		
	During constant-speed operation	When the output current (output torque during real sensorless vector control or vector control) of the inverter exceeds the stall prevention operation level (*Pr. 22 Stall prevention operation level*, etc.), this function reduces frequency until the overload current decreases to prevent the inverter from resulting in overcurrent shut-off. When the overload current has decreased below stall prevention operation level, this function increases the frequency up to the set value.		
	During deceleration	When the output current (output torque during real sensorless vector control or vector control) of the inverter exceeds the stall prevention operation level (*Pr. 22 Stall prevention operation level*, etc.), this function stops the decrease in frequency until the overload current decreases to prevent the inverter from resulting in overcurrent shut-off. When the overload current has decreased below stall prevention operation level, this function decreases the frequency again.		
Check point	1. Check that the *Pr. 0 Torque boost* setting is not too large. 2. Check that the *Pr. 7 Acceleration time* and *Pr. 8 Deceleration time* settings are not too small. 3. Check that the load is not too heavy. 4. Are there any failure in peripheral devices? 5. Check that the *Pr. 13 Starting frequency* is not too large. · Check the motor for use under overload.			
Corrective action	1. Increase or decrease the *Pr. 0 Torque boost* value 1% by 1% and check the motor status. *(Refer to page 143.)* 2. Set a larger value in *Pr. 7 Acceleration time* and *Pr. 8 Deceleration time*. *(Refer to page 173.)* 3. Reduce the load weight. 4. Try advanced magnetic flux vector control, real sensorless vector control or vector control. 5. Change the *Pr. 14 Load pattern selection* setting. 6. Set stall prevention operation current in *Pr. 22 Stall prevention operation level*. (The initial value is 150%.) The acceleration/deceleration time may change. Increase the stall prevention operation level with *Pr. 22 Stall prevention operation level*, or disable stall prevention with *Pr. 156 Stall prevention operation selection*. (Use *Pr. 156* to set either operation continued or not at OL operation.)			

Operation Panel Indication	oL		FR-PU04 FR-PU07	oL
Name	Stall prevention (overvoltage)			
Description	During deceleration	· If the regenerative energy of the motor becomes excessive and exceeds the regenerative energy consumption capability, this function stops the decrease in frequency to prevent overvoltage shut-off. As soon as the regenerative energy has decreased, deceleration resumes. · If the regenerative energy of the motor becomes excessive when regeneration avoidance function is selected (*Pr. 882* = 1), this function increases the speed to prevent overvoltage shut-off. *(Refer to page 377.)*		
Check point	· Check for sudden speed reduction. · Regeneration avoidance function *(Pr. 882 to Pr. 886)* is being used? *(Refer to page 377.)*			
Corrective action	The deceleration time may change. Increase the deceleration time using *Pr. 8 Deceleration time*.			

Operation Panel Indication	PS		FR-PU04 FR-PU07	PS
Name	PU stop			
Description	Stop with STOP RESET of the PU is set in *Pr. 75 Reset selection/disconnected PU detection/PU stop selection*. (For *Pr. 75*, refer to *page 302*.)			
Check point	Check for a stop made by pressing STOP RESET of the operation panel.			
Corrective action	Turn the start signal off and release with PU EXT.			

WWW.BSNEW.IR

Operation Panel Indication	RB	rb	FR-PU04 / FR-PU07	RB
Name	Regenerative brake prealarm			
Description	Appears if the regenerative brake duty reaches or exceeds 85% of the *Pr. 70 Special regenerative brake duty* value. If the regenerative brake duty reaches 100%, a regenerative overvoltage (E. OV_) occurs. The RBP signal can be simultaneously output with the [RB] display. For the terminal used for the RBP signal output, assign the function by setting "7" (positive logic) or "107" (negative logic) in any of *Pr. 190 to Pr. 196 (output terminal function selection)*. *(Refer to page 236)*			
Check point	• Check that the brake resistor duty is not high. • Check that the *Pr. 30 Regenerative function selection* and *Pr. 70 Special regenerative brake duty* values are correct.			
Corrective action	• Increase the deceleration time. • Check the *Pr. 30 Regenerative function selection* and *Pr. 70 Special regenerative brake duty* values.			

Operation Panel Indication	TH	TH	FR-PU04 / FR-PU07	TH
Name	Electronic thermal relay function prealarm			
Description	Appears if the cumulative value of the *Pr. 9 Electronic thermal O/L relay* reaches or exceeds 85% of the preset level. If it reaches 100% of the *Pr. 9 Electronic thermal O/L relay* setting, a motor overload shut-off (E. THM) occurs. The THP signal can be simultaneously output with the [TH] display. For the terminal used for the THP signal output, assign the function by setting "8" (positive logic) or "108" (negative logic) in any of *Pr. 190 to Pr. 196 (output terminal function selection)*. *(Refer to page 236)*			
Check point	1. Check for large load or sudden acceleration. 2. Is the *Pr. 9 Electronic thermal O/L relay* setting is appropriate? *(Refer to page 181.)*			
Corrective action	1. Reduce the load weight or the number of operation times. 2. Set an appropriate value in *Pr. 9 Electronic thermal O/L relay*. *(Refer to page 181.)*			

Operation Panel Indication	MT	mt	FR-PU04	———
			FR-PU07	MT
Name	Maintenance signal output			
Description	Indicates that the cumulative energization time of the inverter has reached a given time.			
Check point	The *Pr. 503 Maintenance timer* setting is larger than the *Pr. 504 Maintenance timer alarm output set time* setting. *(Refer to page 383.)*			
Corrective action	Setting "0" in *Pr. 503 Maintenance timer* erraces the signal.			

Operation Panel Indication	CP	CP	FR-PU04	———
			FR-PU07	CP
Name	Parameter copy			
Description	Appears when parameters are copied between models with capacities of FR-A720-02150(FR-A740-01100) or less and FR-A720-02880(FR-A740-01440) or more.			
Check point	Resetting of *Pr. 9, Pr. 30, Pr. 51, Pr. 52, Pr. 54, Pr. 56, Pr. 57, Pr. 61, Pr. 70, Pr. 72, Pr. 80, Pr. 82, Pr. 90 to Pr. 94, Pr. 158, Pr. 455, Pr. 458 to Pr. 462, Pr. 557, Pr. 859, Pr. 860* and *Pr. 893* is necessary.			
Corrective action	Set the initial value in *Pr. 989 Parameter copy alarm release*.			

Operation Panel Indication	SL	SL	FR-PU04	———
			FR-PU07	SL
Name	Speed limit indication (output during speed limit)			
Description	Output if the speed limit level is exceeded during torque control.			
Check point	• Check that the torque command is not larger than required. • Check that the speed limit level is not low.			
Corrective action	• Decrease the torque command. • Increase the speed limit level.			

(3) Minor fault

When the protective function is activated, the output is not shut off. You can also output a minor fault signal by making parameter setting. (Set "98" in any of *Pr. 190 to Pr. 196 (output terminal function selection)*. *(Refer to page 236.)*)

Operation Panel Indication	FN	Fn	FR-PU04 / FR-PU07	FN
Name	Fan fault			
Description	For the inverter that contains a cooling fan, Fn appears on the operation panel when the cooling fan stops due to a fault or different operation from the setting of *Pr. 244 Cooling fan operation selection*.			
Check point	Check the cooling fan for a fault.			
Corrective action	Check for fan fault. Please contact your sales representative.			

WWW.BSNEW.IR

(4) Major fault

When the protective function is activated, the inverter output is shut off and an alarm is output.

Operation Panel Indication	E.OC1	E.OC 1	FR-PU04 FR-PU07	OC During Accs
Name	Overcurrent shut-off during acceleration			
Description	When the inverter output current reaches or exceeds approximately 220% of the rated current during acceleration, the protective circuit is activated to stop the inverter output.			
Check point	1. Check for sudden acceleration. 2. Check that the downward acceleration time is not long in vertical lift application. 3. Check for output short circuit. 4. Check that the *Pr. 3 Base frequency* setting is not 60Hz when the motor rated frequency is 50Hz. 5. Check that stall prevention operation is correct. 6. Check that the regeneration is not performed frequently. (Check that the output voltage becomes larger than the V/F reference voltage at regeneration and overcurrent due to increase in motor current occurs.) 7. Check that the power supply for RS-485 terminal is not shorted. (under vector control) 8. Check that the rotation direction is not switched from forward to reverse rotation (or from reverse to forward) during torque control under real sensorless vector control.			
Corrective action	1. Increase the acceleration time. (Shorten the downward acceleration time in vertical lift application.) 2. When "E.OC1" is always lit at starting, disconnect the motor once and start the inverter. If "E.OC1" is still lit, contact your sales representative. 3. Check the wiring to make sure that output short circuit does not occur. 4. Set the *Pr. 3 Base frequency* to 50Hz. *(Refer to page 159.)* 5. Perform a correct stall prevention operation. *(Refer to page 150.)* 6. Set base voltage (rated voltage of the motor, etc.) in *Pr. 19 Base frequency voltage*. *(Refer to page 159.)* 7. Check RS-485 terminal connection. (under vector control) 8. Prevent the motor from switching the rotation direction from forward to reverse (or from reverse to forward) during torque control under real sensorless vector control.			

Operation Panel Indication	E.OC2	E.OC2	FR-PU04 FR-PU07	Stedy Spd OC
Name	Overcurrent shut-off during constant speed			
Description	When the inverter output current reaches or exceeds approximately 220% of the rated current during constant speed operation, the protective circuit is activated to stop the inverter output.			
Check point	1. Check for sudden load change. 2. Check for output short circuit. 3. Check that stall prevention operation is correct 4. Check that the power supply for RS-485 terminal is not shorted. (under vector control) 5. Check that the rotation direction is not switched from forward to reverse rotation (or from reverse to forward) during torque control under real sensorless vector control.			
Corrective action	1. Keep load stable. 2. Check the wiring to make sure that output short circuit does not occur. 3. Check that stall prevention operation setting is correct. *(Refer to page 150.)* 4. Check RS-485 terminal connection. (under vector control) 5. Prevent the motor from switching the rotation direction from forward to reverse (or from reverse to forward) during torque control under real sensorless vector control.			

Operation Panel Indication	E.OC3	E.OC3	FR-PU04 FR-PU07	OC During Dec
Name	Overcurrent shut-off during deceleration or stop			
Description	When the inverter output current reaches or exceeds approximately 220% of the rated inverter current during deceleration (other than acceleration or constant speed), the protective circuit is activated to stop the inverter output.			
Check point	1. Check for sudden speed reduction. 2. Check for output short circuit. 3. Check for too fast operation of the motor's mechanical brake. 4. Check that stall prevention operation setting is correct. 5. Check that the power supply for RS-485 terminal is not shorted. (under vector control) 6. Check that the rotation direction is not switched from forward to reverse rotation (or from reverse to forward) during torque control under real sensorless vector control.			
Corrective action	1. Increase the deceleration time. 2. Check the wiring to make sure that output short circuit does not occur. 3. Check the mechanical brake operation. 4. Check that stall prevention operation setting is correct.*(Refer to page 150.)* 5. Check RS-485 terminal connection. (under vector control) 6. Prevent the motor from switching the rotation direction from forward to reverse (or from reverse to forward) during torque control under real sensorless vector control.			

WWW.BSNEW.IR

Operation Panel Indication	E.OV1	E.0u 1	FR-PU04 FR-PU07	OV During Acc
Name	Regenerative overvoltage shut-off during acceleration			
Description	If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.			
Check point	Check for too slow acceleration. (e.g. during descending acceleration in vertical lift load)			
Corrective action	· Decrease the acceleration time. · Use regeneration avoidance function *(Pr. 882 to Pr. 886)*. *(Refer to page 377.)*			

Operation Panel Indication	E.OV2	E.0u2	FR-PU04 FR-PU07	Stedy Spd OV
Name	Regenerative overvoltage shut-off during constant speed			
Description	If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.			
Check point	Check for sudden load change.			
Corrective action	· Keep load stable. · Use regeneration avoidance function *(Pr. 882 to Pr. 886)*. *(Refer to page 377.)* · Use the brake unit or power regeneration common converter (FR-CV) as required.			

Operation Panel Indication	E.OV3	E.0u3	FR-PU04 FR-PU07	OV During Dec
Name	Regenerative overvoltage shut-off during deceleration or stop			
Description	If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.			
Check point	Check for sudden speed reduction.			
Corrective action	· Increase the deceleration time. (Set the deceleration time which matches the inertia of moment of the load) · Decrease the braking duty. · Use regeneration avoidance function *(Pr. 882 to Pr. 886)*. *(Refer to page 377.)* · Use the brake unit or power regeneration common converter (FR-CV) as required.			

Operation Panel Indication	E.THT	E.IHT	FR-PU04 FR-PU07	Inv. Overload
Name	Inverter overload shut-off (electronic thermal relay function) *2			
Description	If a current not less than 150% of the rated output current flows and overcurrent shut-off does not occur (220% or less), inverse-time characteristics cause the electronic thermal relay to be activated to stop the inverter output in order to protect the output transistors. (overload immunity 150%*1 60s)			
Check point	Check the motor for use under overload.			
Corrective action	Reduce the load weight.			

*1 When ND is selected. *(Refer to page 432.)*

Operation Panel Indication	E.THM	E.IHn	FR-PU04 FR-PU07	Motor Overload
Name	Motor overload shut-off (electronic thermal relay function) *2			
Description	The electronic thermal relay function in the inverter detects motor overheat due to overload or reduced cooling capability during constant-speed operation and pre-alarm (TH display) is output when the temperature reaches 85% of the *Pr. 9 Electronic thermal O/L relay* setting and the protection circuit is activated to stop the inverter output when the temperature reaches the specified value. When running a special motor such as a multi-pole motor or multiple motors, provide a thermal relay on the inverter output side since such motor(s) cannot be protected by the electronic thermal relay function.			
Check point	1. Check the motor for use under overload. 2. Check that the setting of *Pr. 71 Applied motor* for motor selection is correct. *(Refer to page 185.)* 3. Check that stall prevention operation setting is correct.			
Corrective action	1. Reduce the load weight. 2. For a constant-torque motor, set the constant-torque motor in *Pr. 71 Applied motor*. 3. Check that stall prevention operation setting is correct. *(Refer to page 150.)*			

*2 Resetting the inverter initializes the internal thermal integrated data of the electronic thermal relay function.

WWW.BSNEW.IR

Operation Panel Indication	E.FIN	E.FIn	FR-PU04 FR-PU07	H/Sink O/Temp
Name	Fin overheat			
Description	If the heatsink overheats, the temperature sensor is actuated to stop the inverter output. The FIN signal can be output when the temperature becomes approximately 85% of the heatsink overheat protection operation temperature. For the terminal used for the FIN signal output, assign the function by setting "26" (positive logic) or "126" (negative logic) in any of *Pr. 190 to Pr. 196 (output terminal function selection)*. *(Refer to page 236)*			
Check point	1. Check for too high ambient temperature. 2. Check for heatsink clogging. 3. Check that the cooling fan is stopped. (Check that Fn is displayed on the operation panel.)			
Corrective action	1. Set the ambient temperature to within the specifications. 2. Clean the heatsink. 3. Replace the cooling fan.			

Operation Panel Indication	E.IPF	E.IPF	FR-PU04 FR-PU07	Inst. Pwr. Loss
Name	Instantaneous power failure			
Description	If a power failure occurs for longer than 15ms (this also applies to inverter input shut-off), the instantaneous power failure protective function is activated to stop the inverter output in order to prevent the control circuit from malfunctioning. If a power failure persists for longer than 100ms, the alarm warning output is not provided, and the inverter restarts if the start signal is on upon power restoration. (The inverter continues operating if an instantaneous power failure is within 15ms.) In some operating status (load magnitude, acceleration/deceleration time setting, etc.), overcurrent or other protection may be activated upon power restoration. When instantaneous power failure protection is activated, the IPF signal is output. *(Refer to page 261)*			
Check point	Find the cause of instantaneous power failure occurrence.			
Corrective action	· Remedy the instantaneous power failure. · Prepare a backup power supply for instantaneous power failure. · Set the function of automatic restart after instantaneous power failure (*Pr. 57*). *(Refer to page 261.)*			

Operation Panel Indication	E.BE	E. bE	FR-PU04 FR-PU07	Br. Cct. Fault
Name	Brake transistor alarm detection			
Description	This function stops the inverter output if an alarm occurs in the brake circuit, e.g. damaged brake transistors. In this case, the inverter must be powered off immediately.			
Check point	· Reduce the load inertia. · Check that the frequency of using the brake is proper.			
Corrective action	Replace the inverter.			

Operation Panel Indication	E.UVT	E.UVT	FR-PU04 FR-PU07	Under Voltage
Name	Undervoltage			
Description	If the power supply voltage of the inverter decreases, the control circuit will not perform normal functions. In addition, the motor torque will be insufficient and/or heat generation will increase. To prevent this, if the power supply voltage decreases below about 150VAC (300VAC for the 400V class), this function stops the inverter output. When a jumper is not connected across P/+-P1, the undervoltage protective function is activated. When undervoltage protection is activated, the IPF signal is output. *(Refer to page 261)*			
Check point	1. Check for start of large-capacity motor. 2. Check that a jumper or DC reactor is connected across terminals P/+-P1.			
Corrective action	1. Check the power supply system equipment such as the power supply. 2. Connect a jumper or DC reactor across terminals P/+-P1. If the problem still persists after taking the above measure, please contact your sales representative.			

Operation Panel Indication	E.ILF	E.ILF	FR-PU04	Fault 14
			FR-PU07	Input phase loss
Name	Input phase failure			
Description	This alarm is output when function valid setting (= 1) is set in *Pr. 872 Input phase failure protection selection* and one phase of the three phase power input opens. *(Refer to page 271.)*			
Check point	Check for a break in the cable for the three-phase power supply input.			
Corrective action	· Wire the cables properly. · Repair a brake portion in the cable. · Check the *Pr. 872 Input phase failure protection selection* setting.			

WWW.BSNEW.IR

Operation Panel Indication	E.OLT	E.OLT	FR-PU04 FR-PU07	Stll Prev STP (OL shown during stall prevention operation)
Name	Stall prevention			
Description	If the frequency has fallen to 0.5Hz by stall prevention operation and remains for 3s, an alarm (E.OLT) appears to shutoff the inverter output. OL appears while stall prevention is being activated. When speed control is performed by real sensorless vector control or vector control, an alarm (E.OLT) is displayed and the inverter output is stopped if frequency drops to the *Pr. 865 Low speed detection* (initial value is 1.5Hz) setting by torque limit operation and the output torque exceeds *Pr. 874 OLT level setting* (initial value is 150%) setting and remains for more than 3s.			
Check point	· Check the motor for use under overload. *(Refer to page 150.)* · Check that the *Pr. 865 Low speed detection* and *Pr. 874 OLT level setting* values are correct. (Check the *Pr. 22 Stall prevention operation level* setting if V/F control is exercised.)			
Corrective action	· Reduce the load weight. · Change the *Pr. 22 Stall prevention operation level*, *Pr. 865 Low speed detection* and *Pr. 874 OLT level setting* values. (Check the *Pr. 22 Stall prevention operation level* setting if V/F control is exercised.)			

Operation Panel Indication	E.GF	E. GF	FR-PU04 FR-PU07	Ground Fault
Name	Output side earth (ground) fault overcurrent			
Description	This function stops the inverter output if an earth (ground) fault overcurrent flows due to an earth (ground) fault that occurred on the inverter's output (load) side.			
Check point	Check for an earth (ground) fault in the motor and connection cable.			
Corrective action	Remedy the earth (ground) fault portion.			

Operation Panel Indication	E.LF	E. LF	FR-PU04 FR-PU07	——
Name	Output phase failure			
Description	This function stops the inverter output if one of the three phases (U, V, W) on the inverter's output side (load side) opens.			
Check point	· Check the wiring (Check that the motor is normal.) · Check that the capacity of the motor used is not smaller than that of the inverter.			
Corrective action	· Wire the cables properly. · Check the *Pr. 251 Output phase failure protection selection* setting.			

Operation Panel Indication	E.OHT	E.OHT	FR-PU04 FR-PU07	OH Fault
Name	External thermal relay operation *3			
Description	If the external thermal relay provided for motor overheat protection, or the internally mounted temperature relay in the motor, etc. switches on (contacts open), the inverter output is stopped.			
Check point	· Check for motor overheating. · Check that the value of 7 (OH signal) is set correctly in any of *Pr. 178 to Pr. 189 (input terminal function selection)*.			
Corrective action	· Reduce the load and operating duty. · Even if the relay contacts are reset automatically, the inverter will not restart unless it is reset.			

*3 Functions only when any of *Pr. 178 to Pr. 189 (input terminal function selection)* is set to OH.

Operation Panel Indication	E.PTC	E.PTC	FR-PU04	Fault 14
			FR-PU07	PTC activated
Name	PTC thermistor operation			
Description	Appears when the motor overheat status is detected for 10s or more by the external PTC thermistor input connected to the terminal AU.			
Check point	· Check the connection between the PTC thermistor switch and thermal protector. · Check the motor for operation under overload. · Is valid setting (= 63) selected in *Pr. 184 AU terminal function selection* ? *(Refer to page 184, 228.)*			
Corrective action	Reduce the load weight.			

WWW.BSNEW.IR

Operation Panel Indication	E.OPT	E.OPT	FR-PU04 FR-PU07	Option Fault
Name	Option alarm			
Description	Appears when the AC power supply is connected to the terminal R/L1, S/L2, T/L3 accidentally when a high power factor converter is connected. Appears when torque command by the plug-in option is selected using *Pr. 804 Torque command source selection* and no plug-in option is mounted. Appears when the switch for the manufacturer setting of the plug-in option is changed.			
Check point	· Check that the AC power supply is not connected to the terminal R/L1, S/L2, T/L3 when a high power factor converter (FR-HC, MT-HC) or power regeneration common converter (FR-CV) is connected. · Check that the plug-in option for torque command setting is connected.			
Corrective action	· Check the parameter (*Pr. 30*) setting and wiring. · The inverter may be damaged if the AC power supply is connected to the terminal R/L1, S/L2, T/L3 when a high power factor converter is connected. Please contact your sales representative. · Check for connection of the plug-in option. Check the *Pr. 804 Torque command source selection* setting. · Return the switch for the manufacturer setting of the plug-in option to the initial status. *(Refer to instruction manual of each option)*			

Operation Panel Indication	E.OP3	E.OP3	FR-PU04 FR-PU07	Option slot alarm 3
Name	Communication option alarm			
Description	Stops the inverter output when a communication line error occurs in the communication option.			
Check point	· Check for a wrong option function setting and operation. · Check that the plug-in option is plugged into the connector securely. · Check for a brake in the communication cable. · Check that the terminating resistor is fitted properly.			
Corrective action	· Check the option function setting, etc. · Connect the plug-in option securely. · Check the connection of communication cable.			

Operation Panel Indication	E. 1 to E. 3	E. 1 to E. 3	FR-PU04 FR-PU07	Fault 1 to Fault 3
Name	Option alarm			
Description	Stops the inverter output if a contact faullt, etc. of the connector between the inverter and plug-in option occurs or if a communication option is fitted to the connector 1 or 2. Appears when the switch for the manufacturer setting of the plug-in option is changed.			
Check point	1. Check that the plug-in option is plugged into the connector securely. (1 to 3 indicate the option connector numbers.) 2. Check for excess electrical noises around the inverter. 3. Check that the communication option is not fitted to the connector 1 or 2.			
Corrective action	1. Connect the plug-in option securely. 2. Take measures against noises if there are devices producing excess electrical noises around the inverter. If the problem still persists after taking the above measure, please contact your sales representative or distributor. 3. Fit the communication option to the connector 3. 4. Return the switch for the manufacturer setting of the plug-in option to the initial status. *(Refer to instruction manual of each option)*			

Operation Panel Indication	E.PE	E. PE	FR-PU04 FR-PU07	Corrupt Memry
Name	Parameter storage device alarm (control circuit board)			
Description	A fault occurred in parameters stored (EEPROM failure)			
Check point	Check for too many number of parameter write times.			
Corrective action	Please contact your sales representative. When performing parameter write frequently for communication purposes, set "1" in *Pr. 342* to enable RAM write. Note that powering off returns the inverter to the status before RAM write.			

WWW.BSNEW.IR

Operation Panel Indication	E.PE2	EPE2	FR-PU04	Fault 14
			FR-PU07	PR storage alarm
Name	Parameter storage device alarm (main circuit board)			
Description	A fault occurred in parameters stored (EEPROM failure)			
Check point	————————			
Corrective action	Please contact your sales representative.			

Operation Panel Indication	E.PUE	EPUE	FR-PU04 FR-PU07	PU Leave Out
Name	PU disconnection			
Description	This function stops the inverter output if communication between the inverter and PU is suspended, e.g. the operation panel and parameter unit is disconnected, when "2", "3", "16" or "17" was set in *Pr. 75 Reset selection/ disconnected PU detection/PU stop selection*. This function stops the inverter output when communication errors occurred consecutively for more than permissible number of retries when a value other than "9999" is set in *Pr. 121 Number of PU communication retries* during the RS-485 communication with the PU connector. This function also stops the inverter output if communication is broken for the period of time set in *Pr. 122 PU communication check time interval*.			
Check point	· Check that the FR-DU07 or parameter unit (FR-PU04/FR-PU07) is fitted tightly. · Check the *Pr. 75* setting.			
Corrective action	Fit the FR-DU07 or parameter unit (FR-PU04/FR-PU07) securely.			

Operation Panel Indication	E.RET	E.rET	FR-PU04 FR-PU07	Retry No Over
Name	Retry count excess			
Description	If operation cannot be resumed properly within the number of retries set, this function stops the inverter output.			
Check point	Find the cause of alarm occurrence.			
Corrective action	Eliminate the cause of the error preceding this error indication.			

Operation Panel Indication	E. 6	E. 6	FR-PU04 FR-PU07	Fault 6
	E. 7	E. 7		Fault 7
	E.CPU	E.CPU		CPU Fault
Name	CPU error			
Description	Stops the inverter output if the communication error of the built-in CPU occurs.			
Check point	Check for devices producing excess electrical noises around the inverter.			
Corrective action	· Take measures against noises if there are devices producing excess electrical noises around the inverter. · Please contact your sales representative.			

Operation Panel Indication	E.CTE	E.CTE	FR-PU04	——
			FR-PU07	E.CTE
Name	Operation panel power supply short circuit, RS-485 terminal power supply short circuit			
Description	When the operation panel power supply (PU connector) is shorted, this function shuts off the power output. At this time, the operation panel (parameter unit) cannot be used and RS-485 communication from the PU connector cannot be made. When the power supply for the RS-485 terminals are shorted, this function shuts off the power output. At this time, communication from the RS-485 terminals cannot be made. To reset, enter the RES signal or switch power off, then on again.			
Check point	1. Check for a short circuit in the PU connector cable. 2. Check that the RS-485 terminals are connected correctly.			
Corrective action	1. Check the PU and cable. 2. Check the connection of the RS-485 terminals			

Operation Panel Indication	E.MB1 to 7	E.MB1 to E.MB7	FR-PU04	——
			FR-PU07	E.MB1 Fault to E.MB7 Fault
Name	Brake sequence error			
Description	The inverter output is stopped when a sequence error occurs during use of the brake sequence function (*Pr. 278* to *Pr. 285*). *(Refer to page 214)*			
Check point	Find the cause of alarm occurrence.			
Corrective action	Check the set parameters and perform wiring properly.			

WWW.BSNEW.IR

Operation Panel Indication	E.OS	E. 05	FR-PU04 FR-PU07	Overspeed occurrence
Name	Overspeed occurence			
Description	Appears when the motor speed reaches and exceeds the overspeed setting level under encoder feedback control, real sensorless vector control or vector control.			
Check point	· Check that the *Pr. 374 Overspeed detection level* value is correct. · Check that the number of encoder pulses does not differ from the actual number of encoder pulses.			
Corrective action	· Set the *Pr. 374 Overspeed detection level* value correctly. · Set the correct number of encoder pulses in *Pr. 369 Number of encoder pulses*.			

Operation Panel Indication	E.OSD	E.05d	FR-PU04 FR-PU07	Excessive speed deflection
Name	Speed deviation excess detection			
Description	Stops the inverter output if the motor speed is increased or decreased under the influence of the load etc. during vector control and cannot be controlled in accordance with the speed command value.			
Check point	· Check that the values of *Pr. 285 Excessive speed deviation detection frequency* and *Pr. 853 Speed deviation time* are correct. · Check for sudden load change. · Check that the number of encoder pulses does not differ from the actual number of encoder pulses.			
Corrective action	· Set *Pr. 285 Excessive speed deviation detection frequency* and *Pr. 853 Speed deviation time* correctly. · Keep load stable. · Set the correct number of encoder pulses in *Pr. 369 Number of encoder pulses*.			

Operation Panel Indication	E.ECT	E.ECT	FR-PU04 FR-PU07	No encoder signal
Name	Signal loss detection			
Description	Stops the inverter output when the encoder signal is shut off under orientation control, encoder feedback control or vector control.			
Check point	· Check for the encoder signal loss. · Check that the encoder specifications are correct. · Check for a loose connector. · Check that the switch setting of the FR-A7AP is correct. · Check that the power is supplied to the encoder. Or, check that the power is not supplied to the encoder later than the inverter.			
Corrective action	· Remedy the signal loss. · Use an encoder that meets the specifications. · Make connection securely. · Make a switch setting of the FR-A7AP correctly. *(Refer to page 37)* · Supply the power to the encoder. Or supply the power to the encoder at the same time when the power is supplied to the inverter. If the power is supplied to the encoder after the inverter, check that the encoder signal is securely sent and set "0" in *Pr. 376*.			

Operation Panel Indication	E.OD	E. 0d	FR-PU04 FR-PU07	Fault 14 Excessive position error
Name	Excessive position error			
Description	Indicates that the difference between the position command and position feedback exceeded the reference under position control.			
Check point	· Check that the position detecting encoder mounting orientation matches the parameter. · Check that the load is not large. · Check that the *Pr. 427 Excessive level error* and *Pr. 369 Number of encoder pulses* are correct.			
Corrective action	· Check the parameters. · Reduce the load weight. · Set the *Pr. 427 Excessive level error* and *Pr. 369 Number of encoder pulses* correctly.			

Operation Panel Indication	E.EP	E.EP	FR-PU04 FR-PU07	Fault 14 E.EP
Name	Encoder phase error			
Description	The rotation command of the inverter differs from the actual motor rotation direction detected from the encoder during offline auto tuning.			
Check point	· Check for mis-wiring of the encoder cable. · Check for wrong setting of *Pr. 359 Encoder rotation direction*.			
Corrective action	· Perform connection and wiring securely. · Change the *Pr. 359 Encoder rotation direction* value.			

WWW.BSNEW.IR

Operation Panel Indication	E.P24	E.P24	FR-PU04 FR-PU07	E.P24
Name	24VDC power output short circuit			
Description	When the 24VDC power output from the PC terminal is shorted, this function shuts off the power output. At this time, all external contact inputs switch off. The inverter cannot be reset by entering the RES signal. To reset it, use the operation panel or switch power off, then on again.			
Check point	· Check for a short circuit in the PC terminal output.			
Corrective action	· Remedy the earth (ground) fault portion.			

Operation Panel Indication	E.CDO	E.CdO	FR-PU04	Fault 14
			FR-PU07	OC detect level
Name	Output current detection value exceeded			
Description	This function is activated when the output current exceeds the *Pr. 150 Output current detection level* setting.			
Check point	Check the settings of *Pr. 150 Output current detection level*, *Pr. 151 Output current detection signal delay time*, *Pr. 166 Output current detection signal retention time*, *Pr. 167 Output current detection operation selection*. *(Refer to page 245.)*			

Operation Panel Indication	E.IOH	E.IOH	FR-PU04	Fault 14
			FR-PU07	Inrush overheat
Name	Inrush current limit circuit alarm			
Description	This function is activated when the resistor of the inrush current limit circuit overheats. The inrush current limit circuit failure			
Check point	· Check that frequent power ON/OFF is not repeated. · Check that the primary side fuse (5A) in the power supply circuit of the inrush current limit circuit contactor (FR-A740-02160 or more) is not fused. · Check that the power supply circuit of inrush current limit circuit contactor is not damaged.			
Corrective action	Configure a circuit where frequent power ON/OFF is not repeated. If the problem still persists after taking the above measure, please contact your sales representative.			

Operation Panel Indication	E.SER	E.SEr	FR-PU04	Fault 14
			FR-PU07	VFD Comm error
Name	Communication error (inverter)			
Description	This function stops the inverter output when communication error occurs consecutively for more than permissible retry count when a value other than "9999" is set in *Pr. 335 RS-485 communication retry count* during RS-485 communication from the RS-485 terminals. This function also stops the inverter output if communication is broken for the period of time set in *Pr. 336 RS-485 communication check time interval*.			
Check point	Check the RS-485 terminal wiring.			
Corrective action	Perform wiring of the RS-485 terminals properly.			

Operation Panel Indication	E.AIE	E.AIE	FR-PU04	Fault 14
			FR-PU07	Analog in error
Name	Analog input error			
Description	Appears when 30mA or more is input or a voltage (7.5V or more) is input with the terminal 2/4 set to current input.			
Check point	Check the setting of *Pr. 73 Analog input selection*, *Pr. 267 Terminal 4 input selection* and voltage/current input switch. *(Refer to page 282.)*			
Corrective action	Either give a frequency command by current input or set *Pr. 73 Analog input selection*, *Pr. 267 Terminal 4 input selection*, and voltage/current input switch to voltage input.			

Operation Panel Indication	E.USB	E.USb	FR-PU04	Fault 14
			FR-PU07	USB comm error
Name	USB communication error			
Description	When the time set in *Pr. 548 USB communication check time interval* has broken, this function stops the inverter output.			
Check point	Check the USB communication cable.			
Corrective action	· Check the *Pr. 548 USB communication check time interval* setting. · Check the USB communication cable. · Increase the *Pr. 548 USB communication check time interval* setting. Or, change the setting to 9999. *(Refer to page 354)*			

WWW.BSNEW.IR

Operation Panel Indication	E.11	E. 11	FR-PU04 FR-PU07	Fault 11
Name	Opposite rotation deceleration error			
Description	The speed may not decelerate during low speed operation if the rotation direction of the speed command and the estimated speed differ when the rotation is changing from forward to reverse or from reverse to forward during torque control under real sensorless vector control. At this time, the inverter output is stopped if the rotation direction will not change, causing overload.			
Check point	Check that the rotation direction is not switched from forward to reverse rotation (or from reverse to forward) during torque control under real sensorless vector control.			
Corrective action	· Prevent the motor from switching the rotation direction from forward to reverse (or from reverse to forward) during torque control under real sensorless vector control. · Please contact your sales representative.			

Operation Panel Indication	E.13	E. 13	FR-PU04 FR-PU07	Fault 13
Name	Internal circuit error			
Description	Appears when an internal circuit error occurred.			
Corrective action	Please contact your sales representative.			

CAUTION

- If protective functions of E.ILF, E.PTC, E.PE2, E.EP, E.OD, E.CDO, E.IOH, E.SER, E.AIE, E.USB are activated when using the FR-PU04, "Fault 14" appears.
  Also when the alarm history is checked on the FR-PU04, the display is "E.14".
- If alarms other than the above appear, contact your sales representative.

WWW.BSNEW.IR

5.4 Correspondences between digital and actual characters

There are the following correspondences between the actual alphanumeric characters and the digital characters displayed on the operation panel.

Actual	Digital
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Actual	Digital
A	A
B	b
C	C
D	d
E	E
F	F
G	G
H	H
I	I
J	J
L	L

Actual	Digital
M	M
N	n
O	O
o	o
P	P
S	S
T	T
U	U
V	V
r	r
-	-

WWW.BSNEW.IR

5.5 Check first when you have troubles

When performing real sensorless vector control or vector control, refer to trouble shooting on *page 109* (speed control), *page 128* (torque control) and *page 140* (position control) in addition to the following check points.

POINT

If the cause is still unknown after every check, it is recommended to initialize the parameters (initial value) then reset the required parameter values and check again.

5.5.1 Motor will not start

- 1) Check the *Pr.0 Torque boost* setting if V/F control is exercised. *(Refer to page 143)*
- 2) Check the main circuit
  - Check that a proper power supply voltage is applied (operation panel display is provided).
  - Check that the motor is connected properly.
  - Check that the jumper across P/+-P1 is connected.
- 3) Check the input signals
  - Check that start signal is input.
  - Check that both the forward and reverse rotation start signals are not input simultaneously.
  - Check that the frequency setting signal is not zero. (When the frequency command is 0Hz and the start command is entered, FWD or REV LED on the operation panel flickers.)
  - Check that the AU signal is on when terminal 4 is used for frequency setting.
  - Check that the output stop signal (MRS) or reset signal (RES) is not on.
  - Check that the CS signal is not OFF with automatic restart after instantaneous power failure function is selected (*Pr. 57* ≠ "9999").
  - Check that the sink or source jumper connector is fitted securely. *(Refer to page 31)*
  - Check that the encoder wiring is correct. (during encoder feedback control or vector control)
  - Check that the voltage/current input switch is correctly set for analog input signal (0 to 5V/0 to 10V, 4 to 20mA).
- 4) Check the parameter settings
  - Check that *Pr. 78 Reverse rotation prevention selection* is not selected.
  - Check that the *Pr. 79 Operation mode selection* setting is correct.
  - Check that the bias and gain *(calibration parameter C2 to C7)* settings are correct.
  - Check that the *Pr. 13 Starting frequency* setting is not greater than the running frequency.
  - Check that frequency settings of each running frequency (such as multi-speed operation) are not zero. Check that especially the *Pr. 1 Maximum frequency* setting is not zero.
  - Check that the *Pr. 15 Jog frequency* setting is not lower than the *Pr. 13 Starting frequency* setting.
  - Check that the *Pr. 359 Encoder rotation direction* setting under encoder feed back control or vector control is correct.
    Set "1" in *Pr. 359* if "REV" on the operation panel is on when the forward command is given.
- 5) Inspection of load
  - Check that the load is not too heavy.
  - Check that the shaft is not locked.

5.5.2 Motor generates abnormal noise

- No carrier frequency noises (metallic noises) are generated.
  - Soft-PWM control to change the motor tone into an unoffending complex tone is factory-set to valid by *Pr. 72 PWM frequency selection*.
    Adjust *Pr. 72 PWM frequency selection* to change the motor tone.
- Check that the gain value under real sensorless vector control or vector control is not too high. Check the setting of *Pr. 820 (Pr. 830) Speed control P gain* when speed control is exercised and *Pr. 824 (Pr. 834) Torque control P gain* when torque control is exercised.
- Check for any mechanical looseness.
- Contact the motor manufacturer.

WWW.BSNEW.IR

5.5.3 Motor generates heat abnormally

- Is the fan for the motor is running? (Check for accumulated dust.)
- Check that the load is not too heavy. Lighten the load.
- Check that the inverter output voltages (U, V, W) balanced.
- Check that the *Pr. 0 Torque boost* setting is correct.
- Was the motor type set? Check the setting of *Pr. 71 Applied motor*.
- When using any other manufacturer's motor, perform offline auto tuning. *(Refer to page 187.)*

5.5.4 Motor rotates in opposite direction

- Check that the phase sequence of output terminals U, V and W is correct.
- Check that the start signals (forward rotation, reverse rotation) are connected properly. *(Refer to page 28)*

5.5.5 Speed greatly differs from the setting

- Check that the frequency setting signal is correct. (Measure the input signal level.)
- Check that the *Pr. 1, Pr. 2, Pr. 19, Calibration parameter C2 to C7* settings are correct.
- Check that the input signal lines are not affected by external noise.
  (Use shielded cables)
- Check that the load is not too heavy.
- Check that the *Pr. 31* to *Pr. 36* (frequency jump) settings are correct.

5.5.6 Acceleration/deceleration is not smooth

- Check that the acceleration and deceleration time settings are not too short.
- Check that the load is not too heavy.
- Check that the torque boost (*Pr. 0, Pr. 46, Pr. 112*) setting is not too large and the stall prevention function is not activated under V/F control.

5.5.7 Motor current is large

- Check that the load is not too heavy.
- Check that the *Pr. 0 Torque boost* setting is appropriate.
- Check that the *Pr. 3 Base frequency* setting is appropriate.
- Check that the *Pr. 14 Load pattern selection* setting is appropriate.
- Check that the *Pr. 19 Base frequency voltage* setting is appropriate.

5.5.8 Speed does not increase

- Check that the maximum frequency *(Pr. 1)* setting is correct. (If you want to run the motor at 120Hz or more, set *Pr. 18 High speed maximum frequency*. *(Refer to page 157.)*)
- Check that the load is not too heavy.
  (In agitators, etc., load may become heavier in winter.)
- Check that the torque boost *(Pr. 0, Pr. 46, Pr. 112)* setting is not too large and the stall prevention function is not activated under V/F control.
- Check that the brake resistor is not connected to terminals P/+-P1 accidentally.

WWW.BSNEW.IR

5.5.9 Speed varies during operation

When advanced magnetic flux vector control, real sensorless vector control, vector control or encoder feedback control is exercised, the output frequency varies with load fluctuation between 0 and 2Hz. This is a normal operation and is not a fault.

1) Inspection of load
- Check that the load is not varying.

2) Check the input signals
- Check that the frequency setting signal is not varying.
- Check that the frequency setting signal is not affected by noise. Input filter to the analog input terminal using *Pr. 74 Input filter time constant* and *Pr. 822 Speed setting filter 1*.
- Check for a malfunction due to undesirable currents when the transistor output unit is connected. *(Refer to page 32)*

3) Others
- Check that the settings of *Pr. 80 Motor capacity* and *Pr. 81 Number of motor poles* are correct to the inverter capacity and motor capacity under advanced magnetic flux vector control, real sensorless vector control or vector control.
- Check that the wiring length is not exceeding 30m when advanced magnetic flux vector control, real sensorless vector control or vector control is exercised. Perform offline auto tuning. *(Refer to pege 187)*
- Check that the wiring length is not too long for V/F control.
- Change the *Pr. 19 Base frequency voltage* setting (about 3%) under V/F control.

5.5.10 Operation mode is not changed properly

If the operation mode does not change correctly, check the following:

1) Inspection of load
- Check that the STF or STR signal is off.
  When it is on, the operation mode cannot be changed.

2) Parameter setting
- Check the *Pr. 79* setting.
  When the *Pr. 79 Operation mode selection* setting is "0" (initial value), the inverter is placed in the external operation mode at input power-on. At this time, press (PU/EXT) on the operation panel (press PU when the parameter unit (FR-PU04/FR-PU07) is used) to switch to the PU operation mode.

5.5.11 Operation panel (FR-DU07) display is not operating

- Check that the operation panel is connected to the inverter securely.

5.5.12 POWER lamp is not lit

- Check that wiring is securely performed and installation is correct.

5.5.13 Parameter write cannot be performed

- Make sure that operation is not being performed (signal STF or STR is not ON).
- Make sure that you are not attempting to set the parameter in the external operation mode.
- Check *Pr. 77 Parameter write selection.*
- Check *Pr. 161 Frequency setting/key lock operation selection.*

WWW.BSNEW.IR

6 PRECAUTIONS FOR MAINTENANCE AND INSPECTION

This chapter provides the "PRECAUTIONS FOR MAINTENANCE AND INSPECTION" of this product.
Always read the instructions before using the equipment

6.1 Inspection item 418
6.2 Measurement of main circuit voltages, currents and powers 426

WWW.BSNEW.IR

The inverter is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

• Precautions for maintenance and inspection

For some short time after the power is switched off, a high voltage remains in the smoothing capacitor. When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched off, and then make sure that the voltage across the main circuit terminals P/+-N/– of the inverter is not more than 30VDC using a tester, etc.

6.1 Inspection item

6.1.1 Daily inspection

Basically, check for the following faults during operation.
(1) Motor operation fault
(2) Improper installation environment
(3) Cooling system fault
(4) Unusual vibration and noise
(5) Unusual overheat and discoloration
During operation, check the inverter input voltages using a tester.

6.1.2 Periodic inspection

Check the areas inaccessible during operation and requiring periodic inspection. Consult us for periodic inspection.
1) Check for cooling system fault.....Clean the air filter, etc.
2) Tightening check and retightening.....The screws and bolts may become loose due to vibration, temperature changes, etc.
Tighten them according to the specified tightening torque. *(Refer to page 22, 23)*
3) Check the conductors and insulating materials for corrosion and damage.
4) Measure insulation resistance.
5) Check and change the cooling fan and relay.

WWW.BSNEW.IR

6.1.3 Daily and periodic inspection

Area of Inspection	Inspection Item	Description	Interval		Corrective Action at Alarm Occurrence	Customer's Check
			Daily	Periodic *2		
General	Surrounding environment	Check the ambient temperature, humidity, dirt, corrosive gas, oil mist , etc.	○		Improve emvironment	
	Overall unit	Check for unusual vibration and noise.	○		Check alarm location and retighten	
	Power supply voltage	Check that the main circuit voltages and control voltages are normal.*1	○		Inspect the power supply	
Main circuit	General	(1) Check with megger (across main circuit terminals and earth (ground) terminal).		○	Contact the manufacturer	
		(2) Check for loose screws and bolts.		○	Retighten	
		(3) Check for overheat traces on the parts.		○	Contact the manufacturer	
		(4) Check for stain.		○	Clean	
	Conductors, cables	(1) Check conductors for distortion.		○	Contact the manufacturer	
		(2) Check cable sheaths for breakage and deterioration (crack, discoloration, etc.).		○	Contact the manufacturer	
	Transformer/reactor	Check for unusual odor and abnormal increase in whining sound.	○		Stop the device and contact the manufacturer.	
	Terminal block	Check for damage.		○	Stop the device and contact the manufacturer.	
	Smoothing aluminum electrolytic capacitor	(1) Check for liquid leakage.		○	Contact the manufacturer	
		(2) Check for safety valve projection and bulge.		○	Contact the manufacturer	
		(3) Visual check and judge by the life check of the main circuit capacitor. *(Refer to page 420)*		○		
	Relay/contactor	Check that the operation is normal and no chatter is heard.		○	Contact the manufacturer	
	Resistor	(1) Check for crack in resistor insulation.		○	Contact the manufacturer	
		(2) Check for a break in the cable.		○	Contact the manufacturer	
Control circuit protective circuit	Operation check	(1) Check that the output voltages across phases with the inverter operated alone is balanced.		○	Contact the manufacturer	
		(2) Check that no fault is found in protective and display circuits in a sequence protective operation test.		○	Contact the manufacturer	
	Parts check: Overall	(1) Check for unusual odor and discoloration.		○	Stop the device and contact the manufacturer.	
		(2) Check for serious rust development.		○	Contact the manufacturer	
	Parts check: Aluminum electrolytic capacitor	(1) Check for liquid leakage in a capacitor and deformation trance.		○	Contact the manufacturer	
		(2) Visual check and judge by the life check of the control circuit capacitor. *(Refer to page 380.)*		○		
Cooling system	Cooling fan	(1) Check for unusual vibration and noise.	○		Replace the fan	
		(2) Check for loose screws and bolts.		○	Retighten	
		(3) Check for stain.		○	Clean	
	Heatsink	(1) Check for clogging.		○	Clean	
		(2) Check for stain.		○	Clean	
	Air filter, etc.	(1) Check for clogging.		○	Clean or replace	
		(2) Check for stain.		○	Clean or replace	
Display	Indication	(1) Check that display is normal.	○		Contact the manufacturer	
		(2) Check for stain.		○	Clean	
	Meter	Check that reading is normal.	○		Stop the device and contact the manufacturer.	
Load motor	Operation check	Check for vibration and abnormal increase in operation noise.	○		Stop the device and contact the manufacturer.	

*1 It is recommended to install a device to monitor voltage for checking the power supply voltage to the inverter.

*2 One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. Consult us for periodic inspection.

WWW.BSNEW.IR

6.1.4 Display of the life of the inverter parts

The self-diagnostic alarm is output when the life span of the control circuit capacitor, cooling fan, each parts of the inrush current limit circuit is near to give an indication of replacement time .

The life alarm output can be used as a guideline for life judgement.

Parts	Judgement Level
Main circuit capacitor	85% of the initial capacity
Control circuit capacitor	Estimated 10% life remaining
Inrush current limit circuit	Estimated 10% life remaining (Power on: 100,000 times left)
Cooling fan	Less than 50% of the predetermined speed

Refer to page 380 to perform the life check of the inverter parts.

6.1.5 Checking the inverter and converter modules

<Preparation>

(1) Disconnect the external power supply cables (R/L1, S/L2, T/L3) and motor cables (U, V, W).
(2) Prepare a tester. (Use 100Ω range.)

<Checking method>


Change the polarity of the tester alternately at the inverter terminals R/L1, S/L2, T/L3, U, V, W, P/+ and N/–, and check for continuity.

CAUTION

1. Before measurement, check that the smoothing capacitor is discharged.
2. At the time of discontinuity, due to the smothing capacitor, the tester may not indicate ∞. At the time of continuity, the measured value is several to several ten's-of ohms depending on the module type, circuit tester type, etc. If all measured values are almost the same, the modules are without fault.

<Module device numbers and terminals to be checked>

		Tester Polarity ⊕	Tester Polarity ⊖	Measured Value		Tester Polarity ⊕	Tester Polarity ⊖	Measured Value
Converter module	D1	R/L1	P/+	Discontinuity	D4	R/L1	N/–	Continuity
		P/+	R/L1	Continuity		N/–	R/L1	Discontinuity
	D2	S/L2	P/+	Discontinuity	D5	S/L2	N/–	Continuity
		P/+	S/L2	Continuity		N/–	S/L2	Discontinuity
	D3	T/L3	P/+	Discontinuity	D6	T/L3	N/–	Continuity
		P/+	T/L3	Continuity		N/–	T/L3	Discontinuity
Inverter module	TR1	U	P/+	Discontinuity	TR4	U	N/–	Continuity
		P/+	U	Continuity		N/–	U	Discontinuity
	TR3	V	P/+	Discontinuity	TR6	V	N/–	Continuity
		P/+	V	Continuity		N/–	V	Discontinuity
	TR5	W	P/+	Discontinuity	TR2	W	N/–	Continuity
		P/+	W	Continuity		N/–	W	Discontinuity



(Assumes the use of an analog meter.)

WWW.BSNEW.IR

6.1.6 Cleaning

Always run the inverter in a clean status.
When cleaning the inverter, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.

CAUTION

Do not use solvent, such as acetone, benzene, toluene and alcohol, as they will cause the inverter surface paint to peel off.
The display, etc. of the operation panel (FR-DU07) and parameter unit (FR-PU04/FR-PU07) are vulnerable to detergent and alcohol. Therefore, avoid using them for cleaning.

6.1.7 Replacement of parts

The inverter consists of many electronic parts such as semiconductor devices.
The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the inverter. For preventive maintenance, the parts must be replaced periodically.
Use the life check function as a guidance of parts replacement.

Part Name	Standard Replacement Interval *1	Description
Cooling fan	10 years	Replace (as required)
Main circuit smoothing capacitor	10 years *2	Replace (as required)
On-board smoothing capacitor	10 years	Replace the board (as required)
Relays	–	as required
Fuse (FR-A740-03250 or more)	10 years	Replace the fuse (as required)

*1 Replacement years for when the yearly average ambient temperature is 40°C (104°F) (without corrosive gas, flammable gas, oil mist, dust and dirt etc)
*2 Output current : equivalent to rating current of the Mitsubishi standard motor (4 poles)

CAUTION

For parts replacement, consult the nearest Mitsubishi FA Center.

WWW.BSNEW.IR

(1) Cooling fan

The replacement interval of the cooling fan used for cooling the parts generating heat such as the main circuit semiconductor is greatly affected by the ambient temperature. When unusual noise and/or vibration is noticed during inspection, the cooling fan must be replaced immediately.

CAUTION


For parts replacement, consult the nearest Mitsubishi FA Center.

Inverter Type		Fan Type	Units
A720	00080 to 00175	MMF-06F24ES-RP1 BKO-CA1638H01	1
	00240 to 00460	MMF-08D24ES-RP1 BKO-CA1639H01	2
	00610, 00760	MMF-12D24DS-RP1 BKO-CA1619H01	1
	00900	MMF-06F24ES-RP1 BKO-CA1638H01	1
		MMF-12D24DS-RP1 BKO-CA1619H01	1
	01150 to 02150	MMF-12D24DS-RP1 BKO-CA1619H01	2
	02880, 03460	MMF-12D24DS-RP1 BKO-CA1619H01	3
A740	00060, 00090	MMF-06F24ES-RP1 BKO-CA1638H01	1
	00120 to 00310	MMF-08D24ES-RP1 BKO-CA1639H01	2
	00380, 00440	MMF-12D24DS-RP1 BKO-CA1619H01	1
	00570	MMF-09D24TS-RP1 BKO-CA1640H01	2
	00710 to 01100	MMF-12D24DS-RP1 BKO-CA1619H01	2
	01440 to 02600		3
	03250, 03610	9LB1424H5H03	3
	04320 to 05470		4
	06100, 06830		5
	07700 to 09620	9LB1424S5H04	6


The FR-A720-00030, 00050, FR-A740-00015 to 00040 are not provided with a cooling fan.

• Removal (FR-A720-00080 to 03460, FR-A740-00060 to 02600)


1) Push the hooks from above and remove the fan cover.



FR-A720-00080 to 00175
FR-A740-00060, 00090




FR-A720-00240 to 00900
FR-A740-00120 to 00440




FR-A720-01150 or more
FR-A740-00570 to 02600

2) Disconnect the fan connectors.


3) Remove the fan.



FR-A720-00080 to 00175
FR-A740-00060, 00090



FR-A720-00240 to 00900
FR-A740-00120 to 00440




FR-A720-01150 or more
FR-A740-00570 to 02600

* The number of cooling fans differs according to the inverter capacity. (Refer to the table above)

WWW.BSNEW.IR


• Reinstallation (FR-A720-00080 to 03460, FR-A740-00060 to 02600)

1)After confirming the orientation of the fan, reinstall the fan so that the arrow on the left of "AIR FLOW" faces up.




<Fan side face>


2)Reconnect the fan connectors.




FR-A720-00080 to 00175
FR-A740-00060, 00090




FR-A720-00240 to 00460
FR-A740-00120 to 00310



FR-A720-00610, 00760
FR-A740-00380, 00440




FR-A720-00900




FR-A720-01150 or more
FR-A740-00570 to 02600


3) Reinstall the fan cover.



FR-A720-00080 to 00175
FR-A740-00060, 00090



FR-A720-00240 to 00900
FR-A740-00120 to 00440




FR-A720-01150 or more
FR-A740-00570 to 02600

CAUTION

- Installing the fan in the opposite air flow direction can cause the inverter life to be shorter.
- Prevent the cable from being caught when installing a fan.
- Switch the power off before replacing fans. Since the inverter circuits are charged with voltage even after power off, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.


WWW.BSNEW.IR

- Removal (FR-A740-03250 or more)
  1) Remove a fan cover.
  2) After removing a fan connector, remove a fan block.
  3) Remove the fan.



* The number of cooling fans differs according to the inverter capacity. (*refer to page 422*.)

- Reinstallation (FR-A740-03250 or more)
  1) After confirming the orientation of the fan, reinstall the fan so that the arrow on the left of "AIR FLOW" faces up.



<Fan side face>


  2) Install fans referring to the above figure.

CAUTION

- Installing the fan in the opposite air flow direction can cause the inverter life to be shorter.
- Prevent the cable from being caught when installing a fan.
- Switch the power off before replacing fans. Since the inverter circuits are charged with voltage even after power off, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.

(2) Replacement procedure of the cooling fan when using a heatsink protrusion attachment (FR-A7CN)

When replacing a cooling fan, remove a top cover of the heatsink protrusion attachment and perform replacement. After replacing the cooling fan, replace the top cover in the original position.



WWW.BSNEW.IR

(3) Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing in the main circuit DC section, and an aluminum electrolytic capacitor is used for stabilizing the control power in the control circuit. Their characteristics are deteriorated by the adverse effects of ripple currents, etc.
The replacement intervals greatly vary with the ambient temperature and operating conditions. When the inverter is operated in air-conditioned, normal environment conditions, replace the capacitors about every 10 years.
The appearance criteria for inspection are as follows:
1) Case: Check the side and bottom faces for expansion
2) Sealing plate: Check for remarkable warp and extreme crack.
3) Check for external crack, discoloration, fluid leakage, etc. Judge that the capacitor has reached its life when the measured capacitance of the capacitor reduced below 80% of the rating.


Refer to page 380 to perform the life check of the main circuit capacitor.

(4) Relays


To prevent a contact fault, etc., relays must be replaced according to the cumulative number of switching times (switching life).

6.1.8 Inverter replacement

The inverter can be replaced with the control circuit wiring kept connected. Before replacement, remove the wiring cover of the inverter.
1) Loosen the two installation screws in both ends of the control circuit terminal block. (These screws cannot be removed.) Pull down the terminal block from behind the control circuit terminals.



2) Using care not to bend the pins of the inverter's control circuit connector, reinstall the control circuit terminal block and fix it with the mounting screws.



CAUTION


Before starting inverter replacement, switch power off, wait for at least 10 minutes, and then check the voltage with a tester and such to ensure safety.

WWW.BSNEW.IR

6.2 Measurement of main circuit voltages, currents and powers

Since the voltages and currents on the inverter power supply and output sides include harmonics, measurement data depends on the instruments used and circuits measured.
When instruments for commercial frequency are used for measurement, measure the following circuits with the instruments given on the next page.


- When installing meters etc. on the inverter output side
  When the inverter-to-motor wiring length is large, especially in the 400V class, small-capacity models, the meters and CTs may generate heat due to line-to-line leakage current. Therefore, choose the equipment which has enough allowance for the current rating.
  When measuring and indicating the output voltage and output current of the inverter, it is recommended to utilize the AM-5 and FM-SD terminal output function of the inverter.



Examples of Measuring Points and Instruments

WWW.BSNEW.IR

Measuring points and instruments

Item	Measuring Point	Measuring Instrument	Remarks (Reference Measured Value)
Power supply voltage V_1	Across R/L1-S/L2, S/L2-T/L3, T/L3-R/L1	Moving-iron type AC voltmeter	Commercial power supply Within permissible AC voltage fluctuation (Refer to *page 432*)
Power supply side current I_1	R/L1, S/L2, and T/L3 line currents	Moving-iron type AC ammeter	
Power supply side power P_1	R/L1, S/L2, T/L3 and R/L1-S/L2, S/L2-T/L3, T/L3-R/L1	Electrodynamic type single-phase wattmeter	P1=W11+W12+W13 (3-wattmeter method)
Power supply side power factor Pf_1	Calculate after measuring power supply voltage, power supply side current and power supply side power. $Pf_1 = \frac{P_1}{\sqrt{3}\, V_1 \times I_1} \times 100\%$		
Output side voltage V_2	Across U-V, V-W and W-U	Rectifier type AC voltage meter *1 (Moving-iron type cannot measure)	Difference between the phases is within ±1% of the maximum output voltage.
Output side current I_2	U, V and W line currents	Moving-iron type AC ammeter *2	Difference between the phases is 10% or lower of the rated inverter current.
Output side power P_2	U, V, W and U-V, V-W	Electrodynamic type single-phase wattmeter	$P_2 = W_{21} + W_{22}$ 2-wattmeter method (or 3-wattmeter method)
Output side power factor Pf_2	Calculate in similar manner to power supply side power factor. $Pf_2 = \frac{P_2}{\sqrt{3}\, V_2 \times I_2} \times 100\%$		
Converter output	Across P/+-N/−	Moving-coil type (such as tester)	Inverter LED display is lit. 1.35 × V1
Frequency setting signal	Across 2, 4(+)-5	Moving-coil type (Tester and such may be used) (Internal resistance: 50kΩ or larger)	0 to 10VDC, 4 to 20mA — "5" is common
	Across 1(+)-5		0 to ±5VDC, 0 to ±10VDC — "5" is common
Frequency setting power supply	Across 10 (+) -5		5.2VDC — "5" is common
	Across 10E(+)-5		10VDC — "5" is common
Frequency meter signal	Across AM(+)-5		Approximately 10VDC at maximum frequency (without frequency meter) — "5" is common
	Across FM(+)-SD		Approximately 5VDC at maximum frequency (without frequency meter)  Pulse width T1: Adjusted by *C0 (Pr. 900)* Pulse cycle T2: Set by *Pr. 55* (Valid for frequency monitoring only) — "SD" is common
Start signal Select signal	Across STF, STR, RH, RM, RL, JOG, RT, AU, STOP, CS (+) -SD		When open 20 to 30VDC ON voltage: 1V or less — "SD" is common
Reset	Across RES (+) -SD		"SD" is common
Output stop	Across MRS (+) -SD		"SD" is common
Alarm signal	Across A1-C1 Across B1-C1	Moving-coil type (such as tester)	Continuity check*3 <Normal> / <Abnormal> Across A1-C1: Discontinuity / Continuity Across B1-C1: Continuity / Discontinuity

*1 Use an FFT to measure the output voltage accurately. A tester or general measuring instrument cannot measure accurately.

*2 When the carrier frequency exceeds 5kHz, do not use this instrument since using it may increase eddy-current losses produced in metal parts inside the instrument, leading to burnout. If the wiring length between the inverter and motor is long, the instrument and CT may generate heat due to line-to-line leakage current.


*3 When the setting of *Pr. 195 ABC1 terminal function selection* is positive logic

WWW.BSNEW.IR

6.2.1 Measurement of powers


Using an electro-dynamometer type meter, measure the power in both the input and output sides of the inverter using the two- or three-wattmeter method. As the current is liable to be imbalanced especially in the input side, it is recommended to use the three-wattmeter method.
Examples of measured value differences produced by different measuring meters are shown below.
An error will be produced by difference between measuring instruments, e.g. power calculation type and two- or three-wattmeter type three-phase wattmeter. When a CT is used in the current measuring side or when the meter contains a PT on the voltage measurement side, an error will also be produced due to the frequency characteristics of the CT and PT.

[Measurement conditions]
Constant-torque (100%) load, constant-power at 60Hz or more.
3.7kW(5HP), 4-pole motor, value indicated in 3-wattmeter method is 100%.



Example of measuring inverter input power

[Measurement conditions]
Constant-torque (100%) load, constant-power at 60Hz or more.
3.7kW(5HP), 4-pole motor, value indicated in 3-wattmeter method is 100%.



Example of measuring inverter output power

6.2.2 Measurement of voltages and use of PT

(1) Inverter input side

As the input side voltage has a sine wave and it is extremely small in distortion, accurate measurement can be made with an ordinary AC meter.

(2) Inverter output side

Since the output side voltage has a PWM-controlled rectangular wave, always use a rectifier type voltmeter. A needle type tester can not be used to measure the output side voltage as it indicates a value much greater than the actual value. A moving-iron type meter indicates an effective value which includes harmonics and therefore the value is larger than that of the fundamental wave. The value monitored on the operation panel is the inverter-controlled voltage itself. Hence, that value is accurate and it is recommended to monitor values (provide analog output) using the operation panel.

(3) PT


No PT can be used in the output side of the inverter. Use a direct-reading meter. (A PT can be used in the input side of the inverter.)

WWW.BSNEW.IR

6.2.3 Measurement of currents


Use a moving-iron type meter on both the input and output sides of the inverter. However, if the carrier frequency exceeds 5kHz, do not use that meter since an overcurrent losses produced in the internal metal parts of the meter will increase and the meter may burn out. In this case, use an approximate-effective value type.
As the inverter input side current is easily imbalanced, measurement of currents in all three phases is recommended. Correct values can not be measured in one or two phases. On the other hand, the phase imbalanced ratio of the output side current must be within 10%.
When using a clamp ammeter, always use an effective value detection type. A mean value detection type produces a large error and may indicate an extremely smaller value than the actual value. The value monitored on the operation panel is accurate if the output frequency varies, and it is recommended to monitor values (provide analog output) using the operation panel.
An example of the measured value difference produced by different measuring meters is shown below.

[Measurement conditions]
Value indicated by moving-iron type ammeter is 100%.



Example of measuring inverter input current

[Measurement conditions]
Value indicated by moving-iron type ammeter is 100%.



Example of measuring inverter output current

6.2.4 Use of CT and transducer

A CT may be used in both the input and output sides of the inverter, but the one used should have the largest possible VA ability because an error will increase if the frequency gets lower.
When using a transducer, use the effective value calculation type which is immune to harmonics.

6.2.5 Measurement of inverter input power factor

Use the effective power and apparent power to calculate the inverter input power factor. A power-factor meter can not indicate an exact value.

$$\text{Total power factor of the inverter} = \frac{\text{Effective power}}{\text{Apparent power}}$$

$$= \frac{\text{Three-phase input power found by 3-wattmeter method}}{\sqrt{3} \times \text{V (power supply voltage)} \times \text{I (input current effective value)}}$$

WWW.BSNEW.IR

6.2.6 Measurement of converter output voltage (across terminals P/+ - N/-)

The output voltage of the converter is developed across terminals P/+ - N/- and can be measured with a moving-coil type meter (tester). Although the voltage varies according to the power supply voltage, approximately 270V to 300V (approximately 540V to 600V for the 400V class) is output when no load is connected and voltage decreases when a load is connected.
When regenerative energy is returned from the motor during deceleration, for example, the converter output voltage rises to nearly 400V to 450V (800V to 900V for the 400V class) maximum.

6.2.7 Measurement of inverter output frequency


A pulse train proportional to the output frequency is output across the frequency meter signal output terminal FM-SD of the inverter. This pulse train output can be counted by a frequency counter, or a meter (moving-coil type voltmeter) can be used to read the mean value of the pulse train output voltage. When a meter is used to measure the output frequency, approximately 5VDC is indicated at the maximum frequency.
For detailed specifications of the frequency meter signal output terminal FM, refer to *page 258*.

6.2.8 Insulation resistance test using megger

For the inverter, conduct the insulation resistance test on the main circuit only as shown below and do not perform the test on the control circuit. (Use a 500VDC megger.)

CAUTION

- Before performing the insulation resistance test on the external circuit, disconnect the cables from all terminals of the inverter so that the test voltage is not applied to the inverter.
- For the continuity test of the control circuit, use a tester (high resistance range) and do not use the megger or buzzer.



6.2.9 Pressure test

Do not conduct a pressure test. Deterioration may occur.

WWW.BSNEW.IR

7 SPECIFICATIONS

This chapter provides the "SPECIFICATIONS" of this product.
Always read the instructions before using the equipment

7.1 Rating 432
7.2 Common specifications 435
7.3 Outline dimension drawings 427
7.4 Installation of the heatsink portion outside the enclosure for use 447

WWW.BSNEW.IR

7.1 Rating

7.1.1 Inverter rating

(1) NA version

●200V class

Type FR-A720-□□□□-NA			00030	00050	00080	00110	00175	00240	00330	00460	00610	00760	00900	01150	01450	01750	02150	02880	03460
Applicable motor capacity for ND (kW) *1			0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90
Output	Rated capacity (kVA) *2		1.1	1.9	3.1	4.2	6.7	9.2	12.6	17.6	23.3	29	34	44	55	67	82	110	132
	Rated current (A) *3	SLD	4.6 (3.9)	7.1 (6.0)	10.5 (8.9)	16.7 (14.1)	24 (20.4)	34 (28.9)	49 (41.6)	63 (53.5)	77 (65.4)	93 (79.0)	125 (106) *10	154 (130)	187 (158)	233 (198)	316 (268) *11	380 (323)	475 (403)
		LD	4.2 (3.5)	6.5 (5.5)	9.6 (8.1)	15.2 (12.9)	23 (19.5)	31 (26.3)	45 (38.2)	58 (49.3)	70 (59.5)	85 (72.2)	114 (96.9) *10	140 (119)	170 (144)	212 (180)	288 (244) *11	346 (294)	432 (367)
		ND	3	5	8	11	17.5	24	33	46	61	76	90	115	145	175	215	288 (244)	346 (294)
		HD	1.5	3	5	8	11	17.5	24	33	46	61	76	90	115	145	175	215 (182)	288 (244)
	Overload current rating *4	SLD	110% 60s, 120% 3s (inverse time characteristics) ambient temperature 40°C																
		LD	120% 60s, 150% 3s (inverse time characteristics) ambient temperature 50°C																
		ND	150% 60s, 200% 3s (inverse time characteristics) ambient temperature 50°C																
		HD	200% 60s, 250% 3s (inverse time characteristics) ambient temperature 50°C																
	Voltage *5		Three-phase 200 to 240V																
	Regenerative braking torque	Maximum value/ permissible duty	150% torque/ 3%ED*6			100% torque/ 3%ED*6		100% torque/ 2%ED*6		20% torque/ continuous *6				20% torque/ continuous				10% torque/ continuous	
Power supply	Rated input AC voltage/frequency		Three-phase 200 to 220V 50Hz, 200 to 240V 60Hz																
	Permissible AC voltage fluctuation		170 to 242V 50Hz,170 to 264V 60Hz																
	Permissible frequency fluctuation		±5%																
	Power supply capacity (kVA) *7		1.5	2.5	4.5	5.5	9	12	17	20	28	34	41	52	66	80	100	110	132
Protective structure *9			Open type (NEMA1)							Enclosed type (UL type1 Plenum Rated) *8				Open type (IP00)					
Cooling system			Self-cooling		Forced air cooling														
Approx. mass (kg)			1.9	2.3	3.8	3.8	3.8	7.1	7.1	7.5	13	13	14	23	35	35	58	70	70

*1. The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.

*2. The rated output capacity indicated assumes that the output voltage is 220V.

*3. When operating the inverter of 02880 or more with a value larger than 2kHz set in *Pr. 72 PWM frequency selection*, the rated output current is the value in parenthesis.
When operating the inverter with the carrier frequency set to 3kHz or more with LD or SLD set, the carrier frequency will automatically decrease if the output current of the inverter exceeds the value in parenthesis of the rated current. This may cause the motor noise to increase.

*4. The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.

*5. The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about 2 that of the power supply.

*6. With the dedicated external brake resistor FR-ABR (option), the 00030 and 00050, 00080 to 00330, 00460 to 00900 will achieve the performance of 150% torque/10%ED, 100% torque/10%ED and 100% torque/6%ED respectively.

*7. The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).

*8. When the hook of the inverter front cover is cut off for installation of the plug-in option, the inverter changes to an open type (IP00).
When using the FR-A720-00900 with LD or SLD set, a wiring cover may need to be removed depending on the used wire size.
The protective structure is an open type (IP00) when a wiring cover is removed.

*9. FR-DU07:IP40 (except for the PU connector)

*10. Protective structure of SLD and LD rating of FR-A720-00900-NA is IP00 due to vending space.
The conduit plate needs to remove at SLD and LD.

*11. When LD or SLD is selected for the FR-A720-02150-NA, install a DC reactor (FR-HEL-75K).

WWW.BSNEW.IR

●400V class

ND is initially set.

Type FR-A740-□□□□-NA			00015	00025	00040	00060	00090	00120	00170	00230	00310	00380	00440	00570	00710	00860	01100
Applicable motor capacity for ND (kW) *1			0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55
Output	Rated capacity (kVA) *2		1.1	1.9	3	4.6	6.9	9.1	13	17.5	23.6	29	32.8	43.4	54	65	84
	Rated current (A) *3	SLD	2.3 (1.9)	3.8 (3.2)	5.2 (4.4)	8.3 (7.0)	12.6 (10.7)	17 (14.4)	25 (21.2)	31 (26.3)	38 (32.3)	47 (39.9)	62 (52.7)	77 (65.4)	93 (79.0)	116 (98.6)	180 (153) *10
		LD	2.1 (1.7)	3.5 (2.9)	4.8 (4.0)	7.6 (6.4)	11.5 (9.7)	16 (13.6)	23 (19.5)	29 (24.6)	35 (29.7)	43 (36.5)	57 (48.4)	70 (59.5)	85 (72.2)	106 (90.1)	144 (122) *10
		ND	1.5	2.5	4	6	9	12	17	23	31	38	44	57	71	86	110
		HD	0.8	1.5	2.5	4	6	9	12	17	23	31	38	44	57	71	86
	Overload current rating *4	SLD	110% 60s, 120% 3s (inverse time characteristics) ambient temperature 40°C														
		LD	120% 60s, 150% 3s (inverse time characteristics) ambient temperature 50°C														
		ND	150% 60s, 200% 3s (inverse time characteristics) ambient temperature 50°C														
		HD	200% 60s, 250% 3s (inverse time characteristics) ambient temperature 50°C														
	Voltage *5		Three-phase 380 to 480V														
	Regenerative braking torque	Maximum value/ permissible duty	100% torque/2%ED *6							20% torque/continuous *6				20% torque/continuous			
Power supply	Rated input AC voltage/frequency		Three-phase 380 to 480V 50Hz/60Hz														
	Permissible AC voltage fluctuation		323 to 528V 50Hz/60Hz														
	Permissible frequency fluctuation		±5%														
	Power supply capacity (kVA) *7		1.5	2.5	4.5	5.5	9	12	17	20	28	34	41	52	66	80	100
Protective structure *9			Open type (NEMA 1)							Enclosed type (UL type 1 plenum rated) *8				Open type (IP00)			
Cooling system			Self-cooling			Forced air cooling											
Approx. mass (kg)			3.8	3.8	3.8	3.8	3.8	7.1	7.1	7.5	7.5	13	13	23	35	35	37

Type FR-A740-□□□□-NA			01440	01800	02160	02600	03250	03610	04320	04810	05470	06100	06830	07700	08660	09620
Applicable motor capacity for ND (kW) *1			75	90	110	132	160	185	220	250	280	315	355	400	450	500
Output	Rated capacity (kVA) *2		110	137	165	198	248	275	329	367	417	465	521	587	660	733
	Rated current (A)*3	SLD	216 (183)	260 (221)	325 (276)	361 (306)	432 (367)	481 (408)	547 (464)	610 (518)	683 (580)	770 (654)	866 (736)	962 (817)	1094 (929)	1212 (1030)
		LD	180 (153)	216 (183)	260 (221)	325 (276)	361 (306)	432 (367)	481 (408)	547 (464)	610 (518)	683 (580)	770 (654)	866 (736)	962 (817)	1094 (929)
		ND	144 (122)	180 (153)	216 (183)	260 (221)	325 (276)	361 (306)	432 (367)	481 (408)	547 (464)	610 (518)	683 (580)	770 (654)	866 (736)	962 (817)
		HD	110 (93)	144 (122)	180 (153)	216 (183)	260 (221)	325 (276)	361 (306)	432 (367)	481 (408)	547 (464)	610 (518)	683 (580)	770 (654)	866 (736)
	Overload current rating *4	SLD	110% 60s, 120% 3s (inverse time characteristics) ambient temperature 40°C													
		LD	120% 60s, 150% 3s (inverse time characteristics) ambient temperature 50°C													
		ND	150% 60s, 200% 3s (inverse time characteristics) ambient temperature 50°C													
		HD	200% 60s, 250% 3s (inverse time characteristics) ambient temperature 50°C													
	Voltage*5		Three-phase 380 to 480V													
	Regenerative braking torque	Maximum value/ permissible duty	10% torque/continuous													
Power supply	Rated input AC voltage/frequency		Three-phase 380 to 480V 50Hz/60Hz													
	Permissible AC voltage fluctuation		323 to 528V 50Hz/60H													
	Permissible frequency fluctuation		±5%													
	Power supply capacity (kVA) *7		110	137	165	198	248	275	329	367	417	465	521	587	660	733
Protective structure *9			Open type (IP00)													
Cooling system			Forced air cooling													
Approx. mass (kg)			50	57	72	72	110	110	175	175	175	260	260	370	370	370

*1. The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
*2. The rated output capacity indicated assumes that the output voltage is 440V.
*3. When operating the inverter of 01440 or more with a value larger than 2kHz set in *Pr. 72 PWM frequency selection*, the rated output current is the value in parenthesis.
When operating the inverter with the carrier frequency set to 3kHz or more with LD or SLD set, the carrier frequency will automatically decrease if the output current of the inverter exceeds the value in parenthesis of the rated current. This may cause the motor noise to increase.
*4. The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
*5. The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about 2 that of the power supply.
*6. With the dedicated external brake resistor FR-ABR-H (option), the 00015 to 00170 and 00230 to 00440 will achieve the performance of 100% torque/10%ED and 100% torque/6%ED respectively.
*7. The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).
*8. When the hook of the inverter front cover is cut off for installation of the plug-in option, the inverter changes to an open type (IP00).
*9. FR-DU07:IP40 (except for the PU connector)
*10. When LD or SLD is selected for the FR-A720-01100-NA, install a DC reactor (FR-HEL-H90K).

WWW.BSNEW.IR

(2) N4 version

●200V class

Type FR-A720-□□□□-N4			00030	00050	00080	00110	00175	00240	00330
Applicable motor capacity for ND (kW) *1			0.4	0.75	1.5	2.2	3.7	5.5	7.5
Output	Rated capacity (kVA) *2		1.1	1.9	3.1	4.2	6.7	9.2	12.6
	Rated current (A) *3	SLD	4.6 (3.9)	7.1 (6.0)	10.5 (8.9)	16.7 (14.1)	24 (20.4)	34 (28.9)	49 (41.6)
		LD	4.2 (3.5)	6.5 (5.5)	9.6 (8.1)	15.2 (12.9)	23 (19.5)	31 (26.3)	45 (38.2)
		ND	3	5	8	11	17.5	24	33
		HD	1.5	3	5	8	11	17.5	24
	Overload current rating *4	SLD	110% 60s, 120% 3s (inverse time characteristics) ambient temperature 40°C						
		LD	120% 60s, 150% 3s (inverse time characteristics) ambient temperature 50°C						
		ND	150% 60s, 200% 3s (inverse time characteristics) ambient temperature 50°C						
		HD	200% 60s, 250% 3s (inverse time characteristics) ambient temperature 50°C						
	Voltage *5		Three-phase 200 to 240V						
	Regenerative braking torque	Maximum value/ permissible duty	150% torque/3%ED			100% torque/3%ED		100% torque/2%ED	
Power supply	Rated input AC voltage/frequency		Three-phase 200 to 220V 50Hz, 200 to 240V 60Hz						
	Permissible AC voltage fluctuation		170 to 242V 50Hz,170 to 264V 60Hz						
	Permissible frequency fluctuation		±5%						
	Power supply capacity (kVA) *6		1.5	2.5	4.5	5.5	9	12	17
Protective structure *7			Enclosed type (UL type 1 plenum rated)						
Cooling system			Self-cooling		Forced air cooling				
Approx. mass (kg)			2.3	2.7	4.7	4.7	4.7	7.9	7.9

*1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
*2 The rated output capacity indicated assumes that the output voltage is 220V.
*3 When operating the inverter with the carrier frequency set to 3kHz or more with LD or SLD set, the carrier frequency will automatically decrease if the output current of the inverter exceeds the value in parenthesis of the rated current. This may cause the motor noise to increase.
*4 The % value of the overload current rating indicates the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
*5 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about 2 that of the power supply.
*6 The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).
*7 FR-DU07:IP40 (except for the PU connector)

●400V class

Type FR-A740-□□□□-N4			00015	00025	00040	00060	00090	00120	00170
Applicable motor capacity for ND (kW) *1			0.4	0.75	1.5	2.2	3.7	5.5	7.5
Output	Rated capacity (kVA) *2		1.1	1.9	3	4.6	6.9	9.1	13
	Rated current (A) *3	SLD	2.3 (1.9)	3.8 (3.2)	5.2 (4.4)	8.3 (7.0)	12.6 (10.7)	17 (14.4)	25 (21.2)
		LD	2.1 (1.7)	3.5 (2.9)	4.8 (4.0)	7.6 (6.4)	11.5 (9.7)	16 (13.6)	23 (19.5)
		ND	1.5	2.5	4	6	9	12	17
		HD	0.8	1.5	2.5	4	6	9	12
	Overload current rating *4	SLD	110% 60s, 120% 3s (inverse time characteristics) ambient temperature 40°C						
		LD	120% 60s, 150% 3s (inverse time characteristics) ambient temperature 50°C						
		ND	150% 60s, 200% 3s (inverse time characteristics) ambient temperature 50°C						
		HD	200% 60s, 250% 3s (inverse time characteristics) ambient temperature 50°C						
	Voltage *5		Three-phase 380 to 480V						
	Regenerative braking torque	Maximum value/ permissible duty	100% torque/2%ED						
Power supply	Rated input AC voltage/frequency		Three-phase 380 to 480V 50Hz/60Hz						
	Permissible AC voltage fluctuation		323 to 528V 50Hz/60Hz						
	Permissible frequency fluctuation		±5%						
	Power supply capacity (kVA) *6		1.5	2.5	4.5	5.5	9	12	17
Protective structure *7			Enclosed type (UL type 1 plenum rated)						
Cooling system			Self-cooling			Forced air cooling			
Approx. mass (kg)			4.7	4.7	4.7	4.7	4.7	7.9	7.9

*1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
*2 The rated output capacity indicated assumes that the output voltage is 440V.
*3 When operating the inverter with the carrier frequency set to 3kHz or more with LD or SLD set, the carrier frequency will automatically decrease if the output current of the inverter exceeds the value in parenthesis of the rated current. This may cause the motor noise to increase.
*4 The % value of the overload current rating indicates the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
*5 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about 2 that of the power supply.
*6 The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).
*7 FR-DU07:IP40 (except for the PU connector)

WWW.BSNEW.IR

7.2 Common specifications

Control specifications	Control method		Soft-PWM control/high carrier frequency PWM control (selectable from among V/F control, advanced magnetic flux vector control and real sensorless vector control) / vector control (when used with option FR-A7AP)*1.
	Output frequency range		0.2 to 400Hz (The maximum frequency is 120Hz under real sensorless vector control and vector control.)
	Frequency setting resolution	Analog input	0.015Hz/0 to 60Hz (terminal 2, 4: 0 to 10V/12bit) 0.03Hz/0 to 60Hz (terminal 2, 4: 0 to 5V/11bit, 0 to 20mA/about 11bit, terminal 1: 0 to ±10V/12bit) 0.06Hz/0 to 60Hz (terminal 1: 0 to ±5V/11bit)
		Digital input	0.01Hz
	Frequency accuracy	Analog input	Within ±0.2% of the max. output frequency (25°C±10°C)
		Digital input	Within 0.01% of the set output frequency
	Voltage/frequency characteristics		Base frequency can be set from 0 to 400Hz Constant torque/variable torque pattern or adjustable 5 points V/F can be selected
	Starting torque		200% 0.3Hz (0.4K to 3.7K), 150% 0.3Hz (5.5K or more) (under real sensorless vector control or vector control)
	Torque boost		Manual torque boost
	Acceleration/deceleration time setting		0 to 3600s (acceleration and deceleration can be set individually), linear or S-pattern acceleration/deceleration mode, backlash measures acceleration/deceleration can be selected.
	DC injection brake		Operation frequency (0 to 120Hz), operation time (0 to 10s), operation voltage (0 to 30%) variable
	Stall prevention operation level		Operation current level can be set (0 to 220% adjustable), whether to use the function or not can be selected
	Torque limit level		Torque limit value can be set (0 to 400% variable)
Operation specifications	Frequency setting signal	Analog input	• Terminal 2, 4: 0 to 10V, 0 to 5V, 4 to 20mA (0 to 20mA) can be selected• Terminal 1: -10 to +10V, -5 to +5V can be selected
		Digital input	Input using the setting dial of the operation panel or parameter unit Four-digit BCD or 16 bit binary (when used with option FR-A7AX)
	Start signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.
	Input signals		You can select any twelve signals using *Pr. 178 to Pr. 189 (input terminal function selection)* from among multi speed selection, remote setting, stop-on-contact, second function selection, third function selection, terminal 4 input selection, JOG operation selection, selection of automatic restart after instantaneous power failure, flying start, external thermal relay input, inverter operation enable signal (FR-HC/FR-CV connection), FR-HC connection (instantaneous power failure detection), PU operation/external inter lock signal , external DC injection brake operation start, PID control enable terminal, brake opening completion signal, PU operation/external operation switchover, load pattern selection forward rotation reverse rotation boost, V/F switching, load torque high-speed frequency, S-pattern acceleration/deceleration C switchover, pre-excitation, output stop, start self-holding selection, control mode changing, torque limit selection, start-time tuning start external input, torque bias selection 1, 2 *1., P/PI control switchover, forward rotation command, reverse rotation command, inverter reset, PTC thermistor input, PID forward reverse operation switchover, PU-NET operation switchover, NET-external operation switchover, and command source switchover, conditional position pulse train sign *1., conditional position droop pulse clear *1., DC feeding operation permission, DC feeding cancel, magnetic flux decay output shutoff.
		Pulse train input	100kpps
	Operational functions		Maximum/minimum frequency setting, frequency jump operation, external thermal relay input selection, polarity reversible operation, automatic restart after instantaneous power failure operation, electronic bypass operation, forward/reverse rotation prevention, remote setting, brake sequence, second function, third function, multi-speed operation, original operation continuation at instantaneous power failure, stop-on-contact control, load torque high speed frequency control, droop control, regeneration avoidance, slip compensation, operation mode selection, offline auto tuning function, online auto tuning function, PID control, computer link operation (RS-485), motor end orientation*1., machine end orientation*1., pre-excitation, notch filter, machine analyzer*1., easy gain tuning, speed feed forward, and torque bias*1.
	Output signals	Operating status	You can select any signals using *Pr. 190 to Pr. 196 (output terminal function selection)* from among inverter running, up-to-frequency, instantaneous power failure/undervoltage, overload warning, output frequency (speed) detection, second output frequency (speed) detection, third output frequency (speed) detection, regenerative brake prealarm, electronic thermal relay function pre-alarm, PU operation mode, inverter operation ready, output current detection, zero current detection, PID lower limit, PID upper limit, PID forward rotation reverse rotation output, electronic bypass MC1, electronic bypass MC2, electronic bypass MC3, orientation completion*1., brake opening request, fan fault output, heatsink overheat pre-alarm , inverter running/start command on, deceleration at an instantaneous power failure, PID control activated, during retry, PID output interruption, life alarm, alarm output 1, 2, 3 (power-off signal), power savings average value update timing, current average monitor, maintenance timer alarm, remote output, forward rotation output*1., reverse rotation output*1., low speed output, torque detection, regenerative status output *1., start-time tuning completion, in-position completion*1., minor failure output and alarm output. Open collector output (5 points), relay output (2 points) and alarm code of the inverter can be output (4 bit) from the open collector.
		When used with the FR-A7AY, FR-A7AR (option)	In addition to the above, you can select any signals using *Pr. 313 to Pr. 319 (extension output terminal function selection)* from among control circuit capacitor life, main circuit capacitor life, cooling fan life, inrush current limit circuit life. (only positive logic can be set for extension terminals of the FR-A7AR)
		Pulse train output	50kpps
		Pulse/analog output	You can select any signals using *Pr. 54 FM terminal function selection (pulse train output)* and *Pr. 158 AM terminal function selection (analog output)* from among output frequency, motor current (steady or peak value), output voltage, frequency setting, operation speed, motor torque, converter output voltage (steady or peak value), electronic thermal relay function load factor, input power, output power, load meter, motor excitation current, reference voltage output, motor load factor, power saving effect, regenerative brake duty ,PID set point, PID measured value, PLC function output, motor output, torque command, torque current command, and torque monitor.
Indication	PU (FR-DU07/ FR-PU07/ FR-PU04)	Operating status	Output frequency, motor current (steady or peak value), output voltage, frequency setting, running speed,motor torque, overload, converter output voltage (steady or peak value), electronic thermal relay function load factor, input power, output power, load meter, motor excitation current, cumlative energization time, actual operation time, motor load factor, cumulative power, energy saving effect, cumulative saving power, regenerative brake duty, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, input terminal option monitor*2., output terminal option monitor*2., option fitting status*3., terminal assignment status*3., torque command, torque current command, feed back pulse*1.,motor output
		Alarm definition	Alarm definition is displayed during the protective function is activated, the output voltage/current/frequency/cumulative energization time right before the protection function was activated and past 8 alarm definitions are stored.
		Interactive guidance	Operation guide/trouble shooting with a help function*3.
Protective/warning function			Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during constant speed, overvoltage during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, instantaneous power failure occurrence, undervoltage, input phase failure, motor overload, output side earth (ground) fault overcurrent, output short circuit, main circuit element overheat, output phase failure, external thermal relay operation, PTC thermistor operation, option alarm, parameter error, PU disconnection, retry count excess, CPU alarm, operation panel power supply short circuit, 24VDC power output short circuit, output current detection value excess, inrush current limit circuit alarm, communication alarm (inverter), USB error, opposite rotation deceleration error, analog input error, fan fault, overcurrent stall prevention, overvoltage stall prevention, regenerative brake prealarm, electronic thermal relay function prealarm, PU stop, maintenance timer alarm*2., brake transistor alarm, parameter write error, copy operation error, operation panel lock, parameter copy alarm, speed limit indication, encoder no-signal*1., speed deviation large*1., overspeed*1., position error large*1., encoder phase error*1.
Environment	Ambient temperature		-10°C to +50°C (non-freezing)
	Ambient humidity		90%RH maximum (non-condensing)
	Storage temperature*4.		-20°C to +65°C
	Atmosphere		Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)
	Altitude/vibration		Maximum 1000m above sea level, 5.9m/s^2 or less *5.

*1. Available only when the option (FR-A7AP) is mounted
*2. Can be displayed only on the operation panel (FR-DU07).
*3. Can be displayed only on the parameter unit (FR-PU07/FR-PU04).
*4. Temperature applicable for a short period in transit, etc.
*5. 2.9m/s^2 or less for the FR-A740-03250 or more.


WWW.BSNEW.IR

7.3 Outline dimension drawings

7.3.1 Inverter outline dimension drawings

(1) NA version

● FR-A720-00030, 00050-NA




Inverter Type	D	D1	D2
FR-A720-00030-NA	110 (4.33)	21 (0.83)	53.5 (2.11)
FR-A720-00050-NA	125 (4.92)	36 (1.42)	68.5 (2.7)

Unit: mm (inches)

●FR-A720-00080, 00110, 00175-NA

●FR-A740-00015, 00025, 00040, 00060, 00090-NA




* The FR-A740-00015 to 00040-NA are not provided with a cooling fan.

Unit: mm (inches)

WWW.BSNEW.IR

●FR-A720-00240, 00330, 00460-NA

●FR-A740-00120, 00170, 00230, 00310-NA




Inverter Type	H	H1	D	D1	D2
FR-A720-00240, 00330-NA	260	245	170	84	139.8
FR-A740-00120, 00170-NA	(10.24)	(9.65)	(6.69)	(3.31)	(15.50)
FR-A720-00460-NA	300	285	190	101.5	158.3
FR-A740-00230, 00310-NA	(11.81)	(11.22)	(7.48)	(4.00)	(6.23)

Unit: mm (inches)

●FR-A720-00610, 00760, 00900-NA


●FR-A740-00380, 00440-NA



Unit: mm (inches)

WWW.BSNEW.IR

●FR-A720-01150, 01450, 01750, 02150-NA
●FR-A740-00570, 00710, 00860, 01100-NA




Inverter Type	W	W1	W2	H	H1	H2	d	D
FR-A720-01150-NA FR-A740-00570-NA	325 (12.80)	270 (10.63)	10 (0.39)	550 (21.65)	530 (20.87)	10 (0.39)	10 (0.39)	195 (7.68)
FR-A720-01450, 01750-NA FR-A740-00710, 00860, 01100-NA	435 (17.13)	380 (14.96)	12 (0.47)	550 (21.65)	525 (20.67)	15 (0.59)	12 (0.47)	250 (9.84)
FR-A720-02150-NA	465 (18.31)	410 (16.14)	12 (0.47)	700 (27.56)	675 (26.57)	15 (0.59)	12 (0.47)	250 (9.84)


Unit: mm (inches)

WWW.BSNEW.IR

●FR-A740-01440, 01800-NA



●DC reactor supplied




DC Reactor Type	W	W1	H	H1	D	S	Mass (Kg (lbs))
FR-HEL-H110K (FR-A740-01440-NA)	150 (5.91)	130 (5.12)	340 (13.39)	310 (12.20)	195 (7.68)	M6	22 (48.4)
FR-HEL-H132K (FR-A740-01800-NA)	175 (6.89)	150 (5.91)	405 (15.94)	370 (14.57)	200 (7.87)	M8	26 (57.2)


Unit: mm (inches)

WWW.BSNEW.IR

●FR-A720-02880, 03460-NA
●FR-A740-02160, 02600-NA



●DC reactor supplied




DC Reactor Type	W	W1	H	H1	D	S	Mass (Kg (lbs))
FR-HEL-90K (FR-A720-02880-NA)	150 (5.91)	130 (5.19)	340 (13.39)	310 (12.2)	200 (7.87)	M6	19 (41.8)
FR-HEL-110K (FR-A720-03460-NA)	175 (6.89)	150 (5.91)	400 (15.75)	365 (14.37)	200 (7.87)	M8	20 (44)
FR-HEL-H160K (FR-A740-02160-NA)	175 (6.89)	150 (5.91)	405 (15.94)	370 (14.57)	205 (8.07)	M8	28 (61.6)
FR-HEL-H185K (FR-A740-02600-NA)	175 (6.89)	150 (5.91)	405 (15.94)	370 (14.57)	240 (9.44)	M8	29 (63.8)


Unit: mm (inches)

WWW.BSNEW.IR


●FR-A740-03250, 03610-NA



●DC reactor supplied




* Remove the eye nut after installation of the product.




DC Reactor Type	W	W1	H	H1	D	S	S1	S2	φ	Mass (Kg (lbs))
FR-HEL-H220K (FR-A740-03250-NA)	175 (6.89)	150 (5.91)	405 (15.94)	370 (14.57)	240 (9.44)	M8	M6	M6	M12	30 (66)
FR-HEL-H250K (FR-A740-03610-NA)	190 (7.48)	165 (6.49)	440 (17.32)	400 (15.74)	250 (9.84)	M8	M8	M8	M12	35 (77)

Unit: mm (inches)


●FR-A740-04320, 04810, 05470-NA



●DC reactor supplied



* Remove the eye nut after installation of the product.




DC Reactor Type	W	W1	H	H1	D	S	S1	S2	φ	Mass (Kg (lbs))
FR-HEL-H280K (FR-A740-04320-NA)	190 (7.48)	165 (6.49)	440 (17.32)	400 (15.74)	255 (10.03)	M8	M8	M8	M16	38 (83.6)
FR-HEL-H315K (FR-A740-04810-NA)	210 (8.26)	185 (7.28)	495 (19.48)	450 (17.71)	250 (9.84)	M10	M8	M8	M16	42 (92.4)
FR-HEL-H355K (FR-A740-05470-NA)	210 (8.26)	185 (7.28)	495 (19.48)	450 (17.71)	250 (9.84)	M10	M8	M16	M16	46 (101.2)


Unit: mm (inches)

WWW.BSNEW.IR

●FR-A740-06100, 06830-NA



●DC reactor supplied




* Remove the eye nut after installation of the product.

DC Reactor Type	W	D	Mass (Kg (lbs))
FR-HEL-H400K (FR-A740-06100-NA)	235 (9.25)	250 (9.84)	50 (110)
FR-HEL-H450K (FR-A740-06830-NA)	240 (9.45)	270 (10.63)	57 (125.4)


Unit: mm (inches)

WWW.BSNEW.IR

●FR-A740-07700, 08660, 09620-NA



●DC reactor supplied




DC Reactor Type	H	D	D1	Mass (Kg (lbs))
FR-HEL-H500K (FR-A740-07700-NA)	345 (13.5)	455 (17.91)	405 (15.94)	67 (147.4)
FR-HEL-H560K (FR-A740-08660-NA)	360 (14.17)	460 (18.11)	410 (16.14)	85 (187)
FR-HEL-H630K (FR-A740-09620-NA)	360 (14.17)	460 (18.11)	410 (16.14)	95 (209)

Unit: mm (inches)

WWW.BSNEW.IR

(2) N4 version

● FR-A720-00030, 00050-N4




Inverter Type	D	D1
FR-A720-00030-N4	122 (4.8)	64.8 (2.55)
FR-A720-00050-N4	137 (5.39)	79.8 (3.14)

Unit: mm (inches)

●FR-A720-00080, 00110, 00175-N4

●FR-A740-00015, 00025, 00040, 00060, 00090-N4




* The FR-A740-00015 to 00040-N4 are not provided with a cooling fan.

Unit: mm (inches)

WWW.BSNEW.IR

●FR-A720-00240, 00330-N4
●FR-A740-00120, 00170-N4




Unit: mm (inches)

WWW.BSNEW.IR

● Operation panel (FR-DU07)


<Outline drawing> <Panel cutting dimension drawing>



(Unit: mm (inches))

● Parameter unit (option) (FR-PU07)

<Outline drawing> <Panel cutting dimension drawing>




*1 When installing the FR-PU07 on the enclosure, etc., remove screws for fixing the FR-PU07 to the inverter or fix the screws to the FR-PU07 with M3 nuts.

*2 Select the installation screws whose length will not exceed the effective depth of the installation screws hole.

(Unit: mm (inches))

● Parameter unit (option) (FR-PU04)

<Outline drawing> <Panel cutting dimension drawing>



(Unit: mm (inches))

Select the installation screws whose length will not exceed the effective depth of the installation screws hole.

WWW.BSNEW.IR

7.4 Installation of the heatsink portion outside the enclosure for use

When encasing the inverter in an enclosure, the generated heat amount in an enclosure can be greatly reduced by installing the heatsink portion of the inverter outside the enclosure. When installing the inverter in a compact enclosure, etc., this installation method is recommended.

7.4.1 When using a heatsink protrusion attachment (FR-A7CN)


For the FR-A720-00080 to 02150, FR-A740-00015 to 02600, a heatsink can be protruded outside the enclosure using a heatsink protrusion attachment (FR-A7CN). (For the FR-A740-03250 or more, attachment is not necessary when the heatsink is to be protruded.)
For a panel cut dimension drawing and an installation procedure of the heatsink protrusion attachment (FR-A7CN) to the inverter, refer to a manual of "heatsink protrusion attachment".

7.4.2 Protrusion of heatsink of the FR-A740-03250 or more

(1) Panel cutting


Cut the panel of the enclosure according to the inverter capacity.

• FR-A740-03250, 03610




Unit: mm (inches)

• FR-A740-04320, 04810, 05470




Unit: mm (inches)

• FR-A740-06100, 06830



Unit: mm (inches)

• FR-A740-07700, 08660, 09620




Unit: mm (inches)

WWW.BSNEW.IR

(2) Shift and removal of a rear side installation frame


- **FR-A740-03250 to 05470**

One installation frame is attached to each of the upper and lower parts of the inverter. Change the position of the rear side installation frame on the upper and lower sides of the inverter to the front side as shown on the right. When changing the installation frames, make sure that the installation orientation is correct.



- **FR-A740-06100 or more**


Two installation frames each are attached to the upper and lower parts of the inverter. Remove the rear side installation frame on the upper and lower sides of the inverter as shown on the right.




WWW.BSNEW.IR

(3) Installation of the inverter

Push the inverter heatsink portion outside the enclosure and fix the enclosure and inverter with upper and lower installation frame.



* For the FR-A740-03250 or more, there are finger guards behind the enclosure. Therefore, the thickness of the panel should be less than 10mm (0.39 inch) (*1) and also do not place anything around finger guards to avoid contact with the finger guards.



Inverter Type	D1
FR-A740-03250, 03610	185 (7.28)
FR-A740-04320 to 09620	184 (7.24)

Unit: mm (inches)

CAUTION

- Having a cooling fan, the cooling section which comes out of the enclosure can not be used in the environment of water drops, oil, mist, dust, etc.
- Be careful not to drop screws, dust etc. into the inverter and cooling fan section.

WWW.BSNEW.IR

MEMO

WWW.BSNEW.IR



APPENDICES

This chapter provides the "APPENDICES" of this product.
Always read the instructions before using the equipment.

WWW.BSNEW.IR

Appendix 1 For customers who have replaced the older model with this inverter


Appendix 1-1 Replacement of the FR-A500 series

(1) Instructions for installation

1) Removal procedure of the front cover was changed. (with screws) Please note. *(Refer to page 6.)*
2) Removal procedure of the operation panel was changed. (with screws) Please note. *(Refer to page 6.)*
3) Plug-in options of the A500 series are not compatible.
4) Operation panel (FR-DU04) can not be used.
5) Setup software (FR-SW0-SETUP/FR-SW1-SETUP) can not be used.

(2) Wiring instructions

1) The control circuit terminal block can be used for the FR-A700 series without removing wiring.
   Note that the wiring cover (FR-A720-00030 to 00900 (FR-A740-00015 to 00440)) is not compatible.



(Note that the relay output 2 (A2, B2, C2) specific for the FR-A700 series can not be used with the FR-A500 series terminals.)

(3) Instructions for continuous use of the FR-PU04 (parameter unit)

1) For the FR-A700 series, many functions (parameters) have been added. When setting these parameters, the parameter name and setting range are not displayed. User initial value list and user clear of the HELP function can not be used.
2) For the FR-A700 series, many protective functions have been added. These functions activate, but all alarms are displayed as "Fault 14". When the alarm history has been checked, "E.14" appears. Added alarm display will not appear on the parameter unit.
3) User initial value setting can not be used.
4) User registration/clear (user group 2) can not be used.
5) Parameter copy/verification function can not be used.

(4) Parameter resetting

It is easy if you use setup software (FR-Configurator).

WWW.BSNEW.IR

(5) Main differences and compatibilities with the FR-A500(L) series

Item	FR-A500(L)	FR-A700
Control method	V/F control Advanced magnetic flux vector control	V/F control Advanced magnetic flux vector control Real sensorless vector control Vector control (used with a plug-in option FR-A7AP)
Changed/cleared functions	User group 1 (16), user group 2 (16) *(Pr. 160, Pr. 173 to Pr. 175)*	User group (16) only Setting methods were partially changed *(Pr. 160, Pr. 172 to Pr. 173)*
	User initial value setting *(Pr. 199)*	User initial value setting *(Pr. 199)* was cleared Substitutable with the copy function of the operation panel (FR-DU07)
	Long wiring mode (*Pr. 240* setting 10, 11)	Setting is not necessary (*Pr. 240* settings "10" and "11" were cleared)
	Intelligent mode selection *(Pr. 60)*	Parameter number change *(Pr. 60 Energy saving control selection)* *(Pr. 292 Automatic acceleration/deceleration)*
	Program operation *(Pr. 200 to Pr. 231)*	Function was cleared
	PID action set point setting *(Pr. 133)*	Addition of "9999" to PID action set point (*Pr. 133*) setting (a value input from terminal 2 is a set point)
	Number of motor poles *(Pr. 81 , Pr. 144)*	Setting the number of motor poles in Number of motor poles (*Pr. 81*) automatically changes the speed setting switchover (*Pr. 144*) setting.
	Performing parameter clear and all clear (H5A96, HAA99) with the FR-A7ND clears *Pr. 345* and *Pr. 346*.	*Pr. 345* and *Pr. 346* are not cleared.
Terminal block	Removable terminal block	Removable terminal block Upward compatibility (A500 terminal block mountable)
PU	FR-PU04, DU04	FR-PU07 FR-DU07 FR-PU04 (Some functions, such as parameter copy, are unavailable.) FR-DU04 unavailable
Plug-in options	Dedicated plug-in option (incompatible)	
	Computer link, relay output option FR-A5NR	Built into the inverter (RS-485 terminals, relay output 2 points)
Installation size	· FR-A720-00030 to 03460, FR-A740-00015 to 00170, 00380 to 01100, 02160, 03250 are compatible in mounting dimensions For the FR-A740-00230, 00310, an optional intercompatibility attachment (FR-AAT) is necessary. · Heatsink protrusion attachment is not compatible. Also, the panel cut dimension of FR-A720-00030 to 00175, 01150, 02150 or more, FR-A740-00015 to 00090, 00230, 00310, 01440 or more is not compatible.	

Appendix 1-2 Replacement of the FR-A200 <EXCELENT> series

Instructions for installation

- When using the installation holes of the FR-A200(E) series, FR-A5AT (intercompatibility attachment) is necessary.

WWW.BSNEW.IR

Appendix 2 Control mode-based parameter (function) correspondence table and instruction code list

*1 These instruction codes are used for parameter read and write by using Mitsubishi inverter protocol with the RS-485 communication. (Refer to *page 327* for RS-485 communication)

*2 Validity and invalidity according to operation mode are as follows: ○:Usable parameter

×:Unusable parameter

Δ:Parameters available only during position control set by parameter

*3 "○" indicates valid and "×" indicates invalid of "parameter copy", "parameter clear", and "all parameter clear".

*4 Parameters can be used with conditions. Refer to *page 200* for details.

Symbols in the table indicate parameters which function when an option is mounted.

..... FR-A7AX, ... FR-A7AY, ... FR-A7AR, ... FR-A7AP, ... FR-A7AZ, ... FR-A7NC,
AX ..... FR-A7ND, AY ..... FR-A7NL, AR ..... AP ..... AZ ..... NC FR-A7NP
ND NL NP

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
0	Torque boost	00	80	0	○	×	×	×	×	×	×	○	○	○
1	Maximum frequency	01	81	0	○	○	○	○	○	○	○	○	○	○
2	Minimum frequency	02	82	0	○	○	○	○	×	○	○	○	○	○
3	Base frequency	03	83	0	○	×	×	×	×	×	×	○	○	○
4	Multi-speed setting (high speed)	04	84	0	○	○	○	○	Δ	○	○	○	○	○
5	Multi-speed setting (middle speed)	05	85	0	○	○	○	○	Δ	○	○	○	○	○
6	Multi-speed setting (low speed)	06	86	0	○	○	○	○	Δ	○	○	○	○	○
7	Acceleration time	07	87	0	○	○	○	○	Δ	○	○	○	○	○
8	Deceleration time	08	88	0	○	○	○	○	Δ	○	○	○	○	○
9	Electronic thermal O/L relay	09	89	0	○	○	○	○	○	○	○	○	○	○
10	DC injection brake operation frequency	0A	8A	0	○	○	○	○	×	○	○	○	○	○
11	DC injection brake operation time	0B	8B	0	○	○	○	○	×	○	○	○	○	○
12	DC injection brake operation voltage	0C	8C	0	○	○	×	×	×	○*4	○*4	○	○	○
13	Starting frequency	0D	8D	0	○	○	○	○	×	○	○	○	○	○
14	Load pattern selection	0E	8E	0	○	×	×	×	×	×	×	○	○	○
15	Jog frequency	0F	8F	0	○	○	○	○	×	○	○	○	○	○
16	Jog acceleration/ deceleration time	10	90	0	○	○	○	○	×	○	○	○	○	○
17	MRS input selection	11	91	0	○	○	○	○	○	○	○	○	○	○
18	High speed maximum frequency	12	92	0	○	○	×	×	×	×	×	○	○	○
19	Base frequency voltage	13	93	0	○	×	×	×	×	×	×	○	○	○
20	Acceleration/deceleration reference frequency	14	94	0	○	○	○	○	Δ	○	○	○	○	○
21	Acceleration/deceleration time increments	15	95	0	○	○	○	○	Δ	○	○	○	○	○
22	Stall prevention operation level (Torque limit level)	16	96	0	○	○	○	×	○	○	×	○	○	○
23	Stall prevention operation level compensation factor at double speed	17	97	0	○	○	×	×	×	×	×	○	○	○
24	Multi-speed setting (speed 4)	18	98	0	○	○	○	○	Δ	○	○	○	○	○
25	Multi-speed setting (speed 5)	19	99	0	○	○	○	○	Δ	○	○	○	○	○
26	Multi-speed setting (speed 6)	1A	9A	0	○	○	○	○	Δ	○	○	○	○	○
27	Multi-speed setting (speed 7)	1B	9B	0	○	○	○	○	Δ	○	○	○	○	○
28	Multi-speed input compensation selection	1C	9C	0	○	○	○	○	×	○	○	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
29	Acceleration/deceleration pattern selection	1D	9D	0	○	○	○	○	×	○	○	○	○	○
30	Regenerative function selection	1E	9E	0	○	○	○	○	○	○	○	○	○	○
31	Frequency jump 1A	1F	9F	0	○	○	○	○	×	○	○	○	○	○
32	Frequency jump 1B	20	A0	0	○	○	○	○	×	○	○	○	○	○
33	Frequency jump 2A	21	A1	0	○	○	○	○	×	○	○	○	○	○
34	Frequency jump 2B	22	A2	0	○	○	○	○	×	○	○	○	○	○
35	Frequency jump 3A	23	A3	0	○	○	○	○	×	○	○	○	○	○
36	Frequency jump 3B	24	A4	0	○	○	○	○	×	○	○	○	○	○
37	Speed display	25	A5	0	○	○	○	○	○	○	○	○	○	○
41	Up-to-frequency sensitivity	29	A9	0	○	○	○	×	×	○	×	○	○	○
42	Output frequency detection	2A	AA	0	○	○	○	○	○	○	○	○	○	○
43	Output frequency detection for reverse rotation	2B	AB	0	○	○	○	○	○	○	○	○	○	○
44	Second acceleration/ deceleration time	2C	AC	0	○	○	○	○	Δ	○	○	○	○	○
45	Second deceleration time	2D	AD	0	○	○	○	○	Δ	○	○	○	○	○
46	Second torque boost	2E	AE	0	○	×	×	×	×	×	×	○	○	○
47	Second V/F (base frequency)	2F	AF	0	○	×	×	×	×	×	×	○	○	○
48	Second stall prevention operation current	30	B0	0	○	○	×	×	×	×	×	○	○	○
49	Second stall prevention operation frequency	31	B1	0	○	○	×	×	×	×	×	○	○	○
50	Second output frequency detection	32	B2	0	○	○	○	○	○	○	○	○	○	○
51	Second electronic thermal O/L relay	33	B3	0	○	○	○	○	○	○	○	○	○	○
52	DU/PU main display data selection	34	B4	0	○	○	○	○	○	○	○	○	○	○
54	FM terminal function selection	36	B6	0	○	○	○	○	○	○	○	○	○	○
55	Frequency monitoring reference	37	B7	0	○	○	○	○	○	○	○	○	○	○
56	Current monitoring reference	38	B8	0	○	○	○	○	○	○	○	○	○	○
57	Restart coasting time	39	B9	0	○	○	○	○	×	○	○	○	○	○
58	Restart cushion time	3A	BA	0	○	○	×	×	×	×	×	○	○	○
59	Remote function selection	3B	BB	0	○	○	○	○	×	○	○	○	○	○
60	Energy saving control selection	3C	BC	0	○	×	×	×	×	×	×	○	○	○
61	Reference current	3D	BD	0	○	○	○	×	×	○	×	○	○	○
62	Reference value at acceleration	3E	BE	0	○	○	○	×	×	○	×	○	○	○
63	Reference value at dcceleration	3F	BF	0	○	○	○	×	×	○	×	○	○	○
64	Starting frequency for elevator mode	40	C0	0	○	×	×	×	×	×	×	○	○	○
65	Retry selection	41	C1	0	○	○	○	○	×	○	○	○	○	○
66	Stall prevention operation reduction starting frequency	42	C2	0	○	○	×	×	×	×	×	○	○	○
67	Number of retries at alarm occurrence	43	C3	0	○	○	○	○	×	○	○	○	○	○
68	Retry waiting time	44	C4	0	○	○	○	○	×	○	○	○	○	○
69	Retry count display erase	45	C5	0	○	○	○	○	×	○	○	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
70	Special regenerative brake duty	46	C6	0	○	○	○	○	○	○	○	○	○	○
71	Applied motor	47	C7	0	○	○	○	○	○	○	○	○	○	○
72	PWM frequency selection	48	C8	0	○	○	○	○	○	○	○	○	○	○
73	Analog input selection	49	C9	0	○	○	○	○	×	○	○	○	○	○
74	Input filter time constant	4A	CA	0	○	○	○	○	×	○	○	○	○	○
75	Reset selection/ disconnected PU detection/ PU stop selection	4B	CB	0	○	○	○	○	○	○	○	○	×	×
76	Alarm code output selection	4C	CC	0	○	○	○	○	○	○	○	○	○	○
77 *	Parameter write selection	4D	CD	0	○	○	○	○	○	○	○	○	○	○
78	Reverse rotation prevention selection	4E	CE	0	○	○	○	○	○	○	○	○	○	○
79 *	Operation mode selection	4F	CF	0	○	○	○	○	○	○	○	○	○	○
80	Motor capacity	50	D0	0	×	○	○	○	○	○	○	○	○	○
81	Number of motor poles	51	D1	0	×	○	○	○	○	○	○	○	○	○
82	Motor excitation current	52	D2	0	×	○	○	○	○	○	○	○	×	○
83	Motor rated voltage	53	D3	0	×	○	○	○	○	○	○	○	○	○
84	Rated motor frequency	54	D4	0	×	○	○	○	○	○	○	○	○	○
89	Speed control gain (magnetic flux vector)	59	D9	0	×	○	×	×	×	×	×	○	×	○
90	Motor constant (R1)	5A	DA	0	×	○	○	○	○	○	○	○	×	○
91	Motor constant (R2)	5B	DB	0	×	○	○	○	○	○	○	○	×	○
92	Motor constant (L1)	5C	DC	0	×	○	○	○	○	○	○	○	×	○
93	Motor constant (L2)	5D	DD	0	×	○	○	○	○	○	○	○	×	○
94	Motor constant (X)	5E	DE	0	×	○	○	○	○	○	○	○	×	○
95	Online auto tuning selection	5F	DF	0	×	○	○	○	○	○	○	○	○	○
96	Auto tuning setting/status	60	E0	0	×	○	○	○	○	○	○	○	×	○
100	V/F1(first frequency)	00	80	1	○	×	×	×	×	×	×	○	○	○
101	V/F1(first frequency voltage)	01	81	1	○	×	×	×	×	×	×	○	○	○
102	V/F2(second frequency)	02	82	1	○	×	×	×	×	×	×	○	○	○
103	V/F2(second frequency voltage)	03	83	1	○	×	×	×	×	×	×	○	○	○
104	V/F3(third frequency)	04	84	1	○	×	×	×	×	×	×	○	○	○
105	V/F3(third frequency voltage)	05	85	1	○	×	×	×	×	×	×	○	○	○
106	V/F4(fourth frequency)	06	86	1	○	×	×	×	×	×	×	○	○	○
107	V/F4(fourth frequency voltage)	07	87	1	○	×	×	×	×	×	×	○	○	○
108	V/F5(fifth frequency)	08	88	1	○	×	×	×	×	×	×	○	○	○
109	V/F5(fifth frequency voltage)	09	89	1	○	×	×	×	×	×	×	○	○	○
110	Third acceleration/ deceleration time	0A	8A	1	○	○	○	○	Δ	○	○	○	○	○
111	Third deceleration time	0B	8B	1	○	○	○	○	Δ	○	○	○	○	○
112	Third torque boost	0C	8C	1	○	×	×	×	×	×	×	○	○	○
113	Third V/F (base frequency)	0D	8D	1	○	×	×	×	×	×	×	○	○	○
114	Third stall prevention operation current	0E	8E	1	○	○	×	×	×	×	×	○	○	○
115	Thrid stall prevention operation frequency	0F	8F	1	○	○	×	×	×	×	×	○	○	○

* Read and write from communication with PU connector only is enabled.

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
116	Third output frequency detection	10	90	1	○	○	○	○	○	○	○	○	○	○
117	PU communication station number	11	91	1	○	○	○	○	○	○	○	○	○	○
118	PU communication speed	12	92	1	○	○	○	○	○	○	○	○	○	○
119	PU communication stop bit length	13	93	1	○	○	○	○	○	○	○	○	○	○
120	PU communication parity check	14	94	1	○	○	○	○	○	○	○	○	○	○
121	Number of PU communication retries	15	95	1	○	○	○	○	○	○	○	○	○	○
122	PU communication check time interval	16	96	1	○	○	○	○	○	○	○	○	○	○
123	PU communication waiting time setting	17	97	1	○	○	○	○	○	○	○	○	○	○
124	PU communication CR/LF presence/absence selection	18	98	1	○	○	○	○	○	○	○	○	○	○
125	Terminal 2 frequency setting gain frequency	19	99	1	○	○	○	○	×	○	○	○	×	○
126	Terminal 4 frequency setting gain frequency	1A	9A	1	○	○	○	○	×	○	○	○	×	○
127	PID control automatic switchover freqeuncy	1B	9B	1	○	○	○	×	×	○	×	○	○	○
128	PID action selection	1C	9C	1	○	○	○	×	×	○	×	○	○	○
129	PID proportional band	1D	9D	1	○	○	○	×	×	○	×	○	○	○
130	PID integral time	1E	9E	1	○	○	○	×	×	○	×	○	○	○
131	PID upper limit	1F	9F	1	○	○	○	×	×	○	×	○	○	○
132	PID lower limit	20	A0	1	○	○	○	×	×	○	×	○	○	○
133	PID action set point	21	A1	1	○	○	○	×	×	○	×	○	○	○
134	PID differential time	22	A2	1	○	○	○	×	×	○	×	○	○	○
135	Electronic bypass sequence selection	23	A3	1	○	○	○	×	×	○	×	○	○	○
136	MC switchover interlock time	24	A4	1	○	○	○	×	×	○	×	○	○	○
137	Start waiting time	25	A5	1	○	○	○	×	×	○	×	○	○	○
138	Bypass selection at an alarm	26	A6	1	○	○	○	×	×	○	×	○	○	○
139	Automatic switchover frequency from inverter to bypass operation	27	A7	1	○	○	○	×	×	○	×	○	○	○
140	Backlash acceleration stopping frequency	28	A8	1	○	○	○	○	×	○	○	○	○	○
141	Backlash acceleration stopping time	29	A9	1	○	○	○	○	×	○	○	○	○	○
142	Backlash deceleration stopping frequency	2A	AA	1	○	○	○	○	×	○	○	○	○	○
143	Backlash deceleration stopping time	2B	AB	1	○	○	○	○	×	○	○	○	○	○
144	Speed setting switchover	2C	AC	1	○	○	○	○	○	○	○	○	○	○
145	PU display language selection	2D	AD	1	○	○	○	○	○	○	○	○	×	×
148	Stall prevention level at 0V input	30	B0	1	○	○	×	×	×	×	×	○	○	○
149	Stall prevention level at 10V input	31	B1	1	○	○	×	×	×	×	×	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
150	Output current detection level	32	B2	1	○	○	○	○	○	○	○	○	○	○
151	Output current detection signal delay time	33	B3	1	○	○	○	○	○	○	○	○	○	○
152	Zero current detection level	34	B4	1	○	○	○	○	○	○	○	○	○	○
153	Zero current detection time	35	B5	1	○	○	○	○	○	○	○	○	○	○
154	Voltage reduction selection during stall prevention operation	36	B6	1	○	○	×	×	×	×	×	○	○	○
155	RT signal function validity condition selection	37	B7	1	○	○	○	×	×	○	×	○	○	○
156	Stall prevention operation selection	38	B8	1	○	○	×	×	×	×	×	○	○	○
157	OL signal output timer	39	B9	1	○	○	○	○	○	○	○	○	○	○
158	AM terminal function selection	3A	BA	1	○	○	○	○	○	○	○	○	○	○
159	Automatic switchover frequency range from bypass to inverter operation	3B	BB	1	○	○	○	×	×	○	×	○	○	○
160	User group read selection	00	80	2	○	○	○	○	○	○	○	○	○	○
161	Frequency setting/key lock operation selection	01	81	2	○	○	○	○	○	○	○	○	×	○
162	Automatic restart after instantaneous power failure selection	02	82	2	○	○	○	○	×	○	○	○	○	○
163	First cushion time for restart	03	83	2	○	○	×	×	×	×	×	○	○	○
164	First cushion voltage for restart	04	84	2	○	○	×	×	×	×	×	○	○	○
165	Stall prevention operation level for restart	05	85	2	○	○	×	×	×	×	×	○	○	○
166	Output current detection signal retention time	06	86	2	○	○	○	○	○	○	○	○	○	○
167	Output current detection operation selection	07	87	2	○	○	○	○	○	○	○	○	○	○
168	Parameter for manufacturer setting. Do not set.													
169														
170	Watt-hour meter clear	0A	8A	2	○	○	○	○	○	○	○	○	×	○
171	Operation hour meter clear	0B	8B	2	○	○	○	○	○	○	○	×	×	×
172	User group registered display/batch clear	0C	8C	2	○	○	○	○	○	○	○	○	×	×
173	User group registration	0D	8D	2	○	○	○	○	○	○	○	×	×	×
174	User group clear	0E	8E	2	○	○	○	○	○	○	○	×	×	×
178	STF terminal function selection	12	92	2	○	○	○	○	○	○	○	○	×	○
179	STR terminal function selection	13	93	2	○	○	○	○	○	○	○	○	×	○
180	RL terminal function selection	14	94	2	○	○	○	○	○	○	○	○	×	○
181	RM terminal function selection	15	95	2	○	○	○	○	○	○	○	○	×	○
182	RH terminal function selection	16	96	2	○	○	○	○	○	○	○	○	×	○
183	RT terminal function selection	17	97	2	○	○	○	○	○	○	○	○	×	○
184	AU terminal function selection	18	98	2	○	○	○	○	○	○	○	○	×	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
185	JOG terminal function selection	19	99	2	○	○	○	○	○	○	○	○	×	○
186	CS terminal function selection	1A	9A	2	○	○	○	○	○	○	○	○	×	○
187	MRS terminal function selection	1B	9B	2	○	○	○	○	○	○	○	○	×	○
188	STOP terminal function selection	1C	9C	2	○	○	○	○	○	○	○	○	×	○
189	RES terminal function selection	1D	9D	2	○	○	○	○	○	○	○	○	×	○
190	RUN terminal function selection	1E	9E	2	○	○	○	○	○	○	○	○	×	○
191	SU terminal function selection	1F	9F	2	○	○	○	○	○	○	○	○	×	○
192	IPF terminal function selection	20	A0	2	○	○	○	○	○	○	○	○	×	○
193	OL terminal function selection	21	A1	2	○	○	○	○	○	○	○	○	×	○
194	FU terminal function selection	22	A2	2	○	○	○	○	○	○	○	○	×	○
195	ABC1 terminal function selection	23	A3	2	○	○	○	○	○	○	○	○	×	○
196	ABC2 terminal function selection	24	A4	2	○	○	○	○	○	○	○	○	×	○
232	Multi-speed setting (speed 8)	28	A8	2	○	○	○	○	Δ	○	○	○	○	○
233	Multi-speed setting (speed 9)	29	A9	2	○	○	○	○	Δ	○	○	○	○	○
234	Multi-speed setting (speed 10)	2A	AA	2	○	○	○	○	Δ	○	○	○	○	○
235	Multi-speed setting (speed 11)	2B	AB	2	○	○	○	○	Δ	○	○	○	○	○
236	Multi-speed setting (speed 12)	2C	AC	2	○	○	○	○	Δ	○	○	○	○	○
237	Multi-speed setting (speed 13)	2D	AD	2	○	○	○	○	Δ	○	○	○	○	○
238	Multi-speed setting (speed 14)	2E	AE	2	○	○	○	○	Δ	○	○	○	○	○
239	Multi-speed setting (speed 15)	2F	AF	2	○	○	○	○	Δ	○	○	○	○	○
240	Soft-PWM operation selection	30	B0	2	○	○	○	○	○	○	○	○	○	○
241	Analog input display unit switchover	31	B1	2	○	○	○	○	○	○	○	○	○	○
242	Terminal 1 added compensation amount (terminal 2)	32	B2	2	○	○	○	○	×	○	○	○	○	○
243	Terminal 1 added compensation amount (terminal 4)	33	B3	2	○	○	○	○	×	○	○	○	○	○
244	Cooling fan operation selection	34	B4	2	○	○	○	○	○	○	○	○	○	○
245	Rated slip	35	B5	2	○	×	×	×	×	×	×	○	○	○
246	Slip compensation time constant	36	B6	2	○	×	×	×	×	×	×	○	○	○
247	Constant-power region slip compensation selection	37	B7	2	○	×	×	×	×	×	×	○	○	○
250	Stop selection	3A	BA	2	○	○	○	○	×	○	○	○	○	○
251	Output phase failure protection selection	3B	BB	2	○	○	○	○	○	○	○	○	○	○
252	Override bias	3C	BC	2	○	○	○	○	×	○	○	○	○	○
253	Override gain	3D	BD	2	○	○	○	○	×	○	○	○	○	○
255	Life alarm status display	3F	BF	2	○	○	○	○	○	○	○	×	×	×

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
256	Inrush current limit circuit life display	40	C0	2	○	○	○	○	○	○	○	×	×	×
257	Control circuit capacitor life display	41	C1	2	○	○	○	○	○	○	○	×	×	×
258	Main circuit capacitor life display	42	C2	2	○	○	○	○	○	○	○	×	×	×
259	Main circuit capacitor life measuring	43	C3	2	○	○	○	○	○	○	○	○	○	○
260	PWM frequency automatic switchover	44	C4	2	○	○	○	○	○	○	○	○	○	○
261	Power failure stop selection	45	C5	2	○	○	○	○	×	○	○	○	○	○
262	Subtracted frequency at deceleration start	46	C6	2	○	○	○	○	×	○	○	○	○	○
263	Subtraction starting frequency	47	C7	2	○	○	○	○	×	○	○	○	○	○
264	Power-failure deceleration time 1	48	C8	2	○	○	○	○	×	○	○	○	○	○
265	Power-failure deceleration time 2	49	C9	2	○	○	○	○	×	○	○	○	○	○
266	Power failure deceleration time switchover frequency	4A	CA	2	○	○	○	○	×	○	○	○	○	○
267	Terminal 4 input selection	4B	CB	2	○	○	○	○	○	○	○	○	×	○
268	Monitor decimal digits selection	4C	CC	2	○	○	○	○	○	○	○	○	○	○
269	Parameter for manufacturer setting. Do not set.													
270	Stop-on contact/load torque high-speed frequency control selection	4E	CE	2	○	○	○	×	×	○	×	○	○	○
271	High-speed setting maximum current	4F	CF	2	○	○	○	×	×	○	×	○	○	○
272	Middle-speed setting minimum current	50	D0	2	○	○	○	×	×	○	×	○	○	○
273	Current averaging range	51	D1	2	○	○	○	×	×	○	×	○	○	○
274	Current averaging filter time constant	52	D2	2	○	○	○	×	×	○	×	○	○	○
275	Stop-on contact excitation current low-speed multiplying factor	53	D3	2	×	○	×	×	×	×	×	○	○	○
276	PWM carrier frequency at stop-on contact	54	D4	2	×	○	×	×	×	×	×	○	○	○
278	Brake opening frequency	56	D6	2	×	○	○	×	×	○	×	○	○	○
279	Brake opening current	57	D7	2	×	○	○	×	×	○	×	○	○	○
280	Brake opening current detection time	58	D8	2	×	○	○	×	×	○	×	○	○	○
281	Brake operation time at start	59	D9	2	×	○	○	×	×	○	×	○	○	○
282	Brake operation frequency	5A	DA	2	×	○	○	×	×	○	×	○	○	○
283	Brake operation time at stop	5B	DB	2	×	○	○	×	×	○	×	○	○	○
284	Deceleration detection function selection	5C	DC	2	○	○	○	×	×	×	×	○	○	○
285	Overspeed detection frequency (Excessive speed deviation detection frequency)	5D	DD	2	○	○	○	×	×	○	×	○	○	○
286	Droop gain	5E	DE	2	×	○	○	×	×	○	×	○	○	○
287	Droop filter time constant	5F	DF	2	×	○	○	×	×	○	×	○	○	○
288	Droop function activation selection	60	E0	2	×	×	○	×	×	○	×	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
291	Pulse train I/O selection	63	E3	2	○	○	○	○	×	○	○	○	×	○
292	Automatic acceleration/ deceleration	64	E4	2	○	○	○	×	×	○	×	○	○	○
293	Acceleration/deceleration time individual calculation selection	65	E5	2	○	○	○	×	×	○	×	○	○	○
294	UV avoidance voltage gain	66	E6	2	○	○	○	○	×	○	○	○	○	○
299	Rotation direction detection selection at restarting	6B	EB	2	○	○	×	×	×	○	×	○	○	○
300	BCD input bias AX	00	80	3	○	○	○	○	×	○	○	○	○	○
301	BCD input gain AX	01	81	3	○	○	○	○	×	○	○	○	○	○
302	BIN input bias AX	02	82	3	○	○	○	○	×	○	○	○	○	○
303	BIN input gain AX	03	83	3	○	○	○	○	×	○	○	○	○	○
304	Digital input and analog input compensation enable/ disable selection AX	04	84	3	○	○	○	○	×	○	○	○	○	○
305	Read timing operation selection AX	05	85	3	○	○	○	○	×	○	○	○	○	○
306	Analog output signal selection AY	06	86	3	○	○	○	○	○	○	○	○	○	○
307	Setting for zero analog output AY	07	87	3	○	○	○	○	○	○	○	○	○	○
308	Setting for maximum analog output AY	08	88	3	○	○	○	○	○	○	○	○	○	○
309	Analog output signal voltage/current switchover AY	09	89	3	○	○	○	○	○	○	○	○	○	○
310	Analog meter voltage output selection AY	0A	8A	3	○	○	○	○	○	○	○	○	○	○
311	Setting for zero analog meter voltage output AY	0B	8B	3	○	○	○	○	○	○	○	○	○	○
312	Setting for maximum analog meter voltage output AY	0C	8C	3	○	○	○	○	○	○	○	○	○	○
313	DO0 output selection AY NC	0D	8D	3	○	○	○	○	○	○	○	○	○	○
314	DO1 output selection AY NC	0E	8E	3	○	○	○	○	○	○	○	○	○	○
315	DO2 output selection AY NC	0F	8F	3	○	○	○	○	○	○	○	○	○	○
316	DO3 output selection AY	10	90	3	○	○	○	○	○	○	○	○	○	○
317	DO4 output selection AY	11	91	3	○	○	○	○	○	○	○	○	○	○
318	DO5 output selection AY	12	92	3	○	○	○	○	○	○	○	○	○	○
319	DO6 output selection AY	13	93	3	○	○	○	○	○	○	○	○	○	○
320	RA1 output selection AR	14	94	3	○	○	○	○	○	○	○	○	○	○
321	RA2 output selection AR	15	95	3	○	○	○	○	○	○	○	○	○	○
322	RA3 output selection AR	16	96	3	○	○	○	○	○	○	○	○	○	○
323	AM0 0V adjustment AY	17	97	3	○	○	○	○	○	○	○	○	×	○
324	AM1 0mA adjustment AY	18	98	3	○	○	○	○	○	○	○	○	×	○
329	Digital input unit selection AX	1D	9D	3	○	○	○	○	×	○	○	○	×	○
331	RS-485 communication station	1F	9F	3	○	○	○	○	○	○	○	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
332	RS-485 communication speed	20	A0	3	○	○	○	○	○	○	○	○	○	○
333	RS-485 communication stop bit length	21	A1	3	○	○	○	○	○	○	○	○	○	○
334	RS-485 communication parity check selection	22	A2	3	○	○	○	○	○	○	○	○	○	○
335	RS-485 communication retry count	23	A3	3	○	○	○	○	○	○	○	○	○	○
336	RS-485 communication check time interval	24	A4	3	○	○	○	○	○	○	○	○	○	○
337	RS-485 communication waiting time setting	25	A5	3	○	○	○	○	○	○	○	○	○	○
338	Communication operation command source	26	A6	3	○	○	○	○	○	○	○	○	○	○
339	Communication speed command source	27	A7	3	○	○	○	○	○	○	○	○	○	○
340	Communication startup mode selection	28	A8	3	○	○	○	○	○	○	○	○	○	○
341	RS-485 communication CR/LF selection	29	A9	3	○	○	○	○	○	○	○	○	○	○
342	Communication EEPROM write selection	2A	AA	3	○	○	○	○	○	○	○	○	○	○
343	Communication error count	2B	AB	3	○	○	○	○	○	○	○	×	×	×
345	DeviceNet address ND	2D	AD	3	○	○	○	○	○	○	○	○	○	○
346	DeviceNet baud rate ND	2E	AE	3	○	○	○	○	○	○	○	○	○	○
349	Communication reset selection NC ND NL NP	31	B1	3	○	○	○	○	○	○	○	○	○	○
350	Stop position command selection AP	32	B2	3	○	○	○	×	×	×	×	○	○	○
351	Orientation speed AP	33	B3	3	○	○	○	×	×	×	×	○	○	○
352	Creep speed AP	34	B4	3	○	○	○	×	×	×	×	○	○	○
353	Creep switchover position AP	35	B5	3	○	○	○	×	×	×	×	○	○	○
354	Position loop switchover position AP	36	B6	3	○	○	○	×	×	×	×	○	○	○
355	DC injection brake start position AP	37	B7	3	○	○	○	×	×	×	×	○	○	○
356	Internal stop position command AP	38	B8	3	○	○	○	×	×	×	×	○	○	○
357	Orientation in-position zone AP	39	B9	3	○	○	○	×	×	×	×	○	○	○
358	Servo torque selection AP	3A	BA	3	○	○	○	×	×	×	×	○	○	○
359	Encoder rotation direction AP	3B	BB	3	○	○	○	○	○	×	×	○	○	○
360	16 bit data selection AP	3C	BC	3	○	○	○	×	×	×	×	○	○	○
361	Position shift AP	3D	BD	3	○	○	○	×	×	×	×	○	○	○
362	Orientation position loop gain AP	3E	BE	3	○	○	○	×	×	×	×	○	○	○
363	Completion signal output delay time AP	3F	BF	3	○	○	○	×	×	×	×	○	○	○
364	Encoder stop check time AP	40	C0	3	○	○	○	×	×	×	×	○	○	○
365	Orientation limit AP	41	C1	3	○	○	○	×	×	×	×	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
366	Recheck time AP	42	C2	3	○	○	○	×	×	×	×	○	○	○
367	Speed feedback range AP	43	C3	3	○	○	○	×	×	×	×	○	○	○
368	Feedback gain AP	44	C4	3	○	○	×	×	×	×	×	○	○	○
369	Number of encoder pulses AP	45	C5	3	○	○	○	○	○	×	×	○	○	○
374	Overspeed detection level	4A	CA	3	×	×	○	○	○	○	○	○	○	○
376	Encoder signal loss detection enable/disable selection AP	4C	CC	3	○	○	○	○	○	×	×	○	○	○
380	Acceleration S-pattern 1	50	D0	3	○	○	○	○	×	○	○	○	○	○
381	Deceleration S-pattern 1	51	D1	3	○	○	○	○	×	○	○	○	○	○
382	Acceleration S-pattern 2	52	D2	3	○	○	○	○	×	○	○	○	○	○
383	Deceleration S-pattern 2	53	D3	3	○	○	○	○	×	○	○	○	○	○
384	Input pulse division scaling factor	54	D4	3	○	○	○	○	×	○	○	○	○	○
385	Frequency for 0 input pulse	55	D5	3	○	○	○	○	×	○	○	○	○	○
386	Frequency for maximum input pulse	56	D6	3	○	○	○	○	×	○	○	○	○	○
387	Initial communication delay time NL	57	D7	3	○	○	○	○	○	○	○	○	○	○
388	Send time interval at heart beat NL	58	D8	3	○	○	○	○	○	○	○	○	○	○
389	Minimum sending time at heart beat NL	59	D9	3	○	○	○	○	○	○	○	○	○	○
390	% setting reference frequency NL	5A	DA	3	○	○	○	○	○	○	○	○	○	○
391	Receive time interval at heart beat NL	5B	DB	3	○	○	○	○	○	○	○	○	○	○
392	Event driven detection width NL	5C	DC	3	○	○	○	○	○	○	○	○	○	○
393	Orientation selection AP	5D	DD	3	×	×	○	×	×	×	×	○	○	○
396	Orientation speed gain (P term) AP	60	E0	3	×	×	○	×	×	×	×	○	○	○
397	Orientation speed integral time AP	61	E1	3	×	×	○	×	×	×	×	○	○	○
398	Orientation speed gain (D term) AP	62	E2	3	×	×	○	×	×	×	×	○	○	○
399	Orientation deceleration ratio AP	63	E3	3	×	×	○	×	×	×	×	○	○	○
406	High resolution analog input selection AZ	06	86	4	○	○	○	○	○	○	○	○	×	○
407	Motor temperature detection filter AZ	07	87	4	○	○	○	○	○	○	○	○	○	○
408	Motor thermistor selection AZ	08	88	4	○	○	○	○	○	○	○	○	○	○
414	PLC function operation selection	0E	8E	4	○	○	○	○	○	○	○	○	×	×
415	Inverter operation lock mode setting	0F	8F	4	○	○	○	○	○	○	○	○	○	○
416	Pre-scale function selection	10	90	4	○	○	○	○	○	○	○	○	○	○
417	Pre-scale setting value	11	91	4	○	○	○	○	○	○	○	○	○	○
419	Position command source selection AP	13	93	4	×	×	×	×	○	×	×	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
420	Command pulse scaling factor numerator AP	14	94	4	×	×	×	×	○	×	×	○	○	○
421	Command pulse scaling factor denominator AP	15	95	4	×	×	×	×	○	×	×	○	○	○
422	Position loop gain AP	16	96	4	×	×	×	×	○	×	×	○	○	○
423	Position feed forward gain AP	17	97	4	×	×	×	×	○	×	×	○	○	○
424	Position command acceleration/deceleration time constant AP	18	98	4	×	×	×	×	○	×	×	○	○	○
425	Position feed forward command filter AP	19	99	4	×	×	×	×	○	×	×	○	○	○
426	In-position width AP	1A	9A	4	×	×	×	×	○	×	×	○	○	○
427	Excessive level error AP	1B	9B	4	×	×	×	×	○	×	×	○	○	○
428	Command pulse selection AP	1C	9C	4	×	×	×	×	○	×	×	○	○	○
429	Clear signal selection AP	1D	9D	4	×	×	×	×	○	×	×	○	○	○
430	Pulse monitor selection AP	1E	9E	4	×	×	×	×	○	×	×	○	○	○
447	Digital torque command bias AX	2F	AF	4	×	×	×	○	×	×	○	○	○	○
448	Digital torque command gain AX	30	B0	4	×	×	×	○	×	×	○	○	○	○
450	Second applied motor	32	B2	4	○	○	×	×	×	○	○	○	○	○
451	Second motor control method selection	33	B3	4	○	○	×	×	×	○	○	○	○	○
453	Second motor capacity	35	B5	4	×	○	×	×	×	○	○	○	○	○
454	Number of second motor poles	36	B6	4	×	○	×	×	×	○	○	○	○	○
455	Second motor excitation current	37	B7	4	×	○	×	×	×	○	○	○	×	○
456	Rated second motor voltage	38	B8	4	×	○	×	×	×	○	○	○	○	○
457	Rated second motor frequency	39	B9	4	×	○	×	×	×	○	○	○	○	○
458	Second motor constant (R1)	3A	BA	4	×	○	×	×	×	○	○	○	×	○
459	Second motor constant (R2)	3B	BB	4	×	○	×	×	×	○	○	○	×	○
460	Second motor constant (L1)	3C	BC	4	×	○	×	×	×	○	○	○	×	○
461	Second motor constant (L2)	3D	BD	4	×	○	×	×	×	○	○	○	×	○
462	Second motor constant (X)	3E	BE	4	×	○	×	×	×	○	○	○	×	○
463	Second motor auto tuning setting/status	3F	BF	4	×	○	×	×	×	○	○	○	×	○
464	Digital position control sudden stop deceleration time AP	40	C0	4	×	×	×	×	○	×	×	○	○	○
465	First position feed amount lower 4 digits AP	41	C1	4	×	×	×	×	○	×	×	○	○	○
466	First position feed amount upper 4 digits AP	42	C2	4	×	×	×	×	○	×	×	○	○	○
467	Second position feed amount lower 4 digits AP	43	C3	4	×	×	×	×	○	×	×	○	○	○
468	Second position feed amount upper 4 digits AP	44	C4	4	×	×	×	×	○	×	×	○	○	○
469	Third position feed amount lower 4 digits AP	45	C5	4	×	×	×	×	○	×	×	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
470	Third position feed amount upper 4 digits AP	46	C6	4	×	×	×	×	○	×	×	○	○	○
471	Fourth position feed amount lower 4 digits AP	47	C7	4	×	×	×	×	○	×	×	○	○	○
472	Fourth position feed amount upper 4 digits AP	48	C8	4	×	×	×	×	○	×	×	○	○	○
473	Fifth position feed amount lower 4 digits AP	49	C9	4	×	×	×	×	○	×	×	○	○	○
474	Fifth position feed amount upper 4 digits AP	4A	CA	4	×	×	×	×	○	×	×	○	○	○
475	Sixth position feed amount lower 4 digits AP	4B	CB	4	×	×	×	×	○	×	×	○	○	○
476	Sixth position feed amount upper 4 digits AP	4C	CC	4	×	×	×	×	○	×	×	○	○	○
477	Seventh position feed amount lower 4 digits AP	4D	CD	4	×	×	×	×	○	×	×	○	○	○
478	Seventh position feed amount upper 4 digits AP	4E	CE	4	×	×	×	×	○	×	×	○	○	○
479	Eighth position feed amount lower 4 digits AP	4F	CF	4	×	×	×	×	○	×	×	○	○	○
480	Eighth position feed amount upper 4 digits AP	50	D0	4	×	×	×	×	○	×	×	○	○	○
481	Ninth position feed amount lower 4 digits AP	51	D1	4	×	×	×	×	○	×	×	○	○	○
482	Ninth position feed amount upper 4 digits AP	52	D2	4	×	×	×	×	○	×	×	○	○	○
483	Tenth position feed amount lower 4 digits AP	53	D3	4	×	×	×	×	○	×	×	○	○	○
484	Tenth position feed amount upper 4 digits AP	54	D4	4	×	×	×	×	○	×	×	○	○	○
485	Eleventh position feed amount lower 4 digits AP	55	D5	4	×	×	×	×	○	×	×	○	○	○
486	Eleventh position feed amount upper 4 digits AP	56	D6	4	×	×	×	×	○	×	×	○	○	○
487	Twelfth position feed amount lower 4 digits AP	57	D7	4	×	×	×	×	○	×	×	○	○	○
488	Twelfth position feed amount upper 4 digits AP	58	D8	4	×	×	×	×	○	×	×	○	○	○
489	Thirteenth position feed amount lower 4 digits AP	59	D9	4	×	×	×	×	○	×	×	○	○	○
490	Thirteenth position feed amount upper 4 digits AP	5A	DA	4	×	×	×	×	○	×	×	○	○	○
491	Fourteenth position feed amount lower 4 digits AP	5B	DB	4	×	×	×	×	○	×	×	○	○	○
492	Fourteenth position feed amount upper 4 digits AP	5C	DC	4	×	×	×	×	○	×	×	○	○	○
493	Fifteenth position feed amount lower 4 digits AP	5D	DD	4	×	×	×	×	○	×	×	○	○	○
494	Fifteenth position feed amount upper 4 digits AP	5E	DE	4	×	×	×	×	○	×	×	○	○	○
495	Remote output selection	5F	DF	4	○	○	○	○	○	○	○	○	○	○
496	Remote output data 1	60	E0	4	○	○	○	○	○	○	○	×	×	×
497	Remote output data 2	61	E1	4	○	○	○	○	○	○	○	×	×	×

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
498	PLC function flash memory clear	62	E2	4	○	○	○	○	○	○	○	×	×	×
500	Communication error execution waiting time NC ND NL NP	00	80	5	○	○	○	○	○	○	○	○	○	○
501	Communication error occurrence count display NC ND NL NP	01	81	5	○	○	○	○	○	○	○	×	○	○
502	Stop mode selection at communication error NC ND NL NP	02	82	5	○	○	○	○	○	○	○	○	○	○
503	Maintenance timer	03	83	5	○	○	○	○	○	○	○	×	×	×
504	Maintenance timer alarm output set time	04	84	5	○	○	○	○	○	○	○	○	×	○
505	Speed setting reference	05	85	5	○	○	○	○	○	○	○	○	○	○
506	Parameter 1 for user	06	86	5	○	○	○	○	○	○	○	○	○	○
507	Parameter 2 for user	07	87	5	○	○	○	○	○	○	○	○	○	○
508	Parameter 3 for user	08	88	5	○	○	○	○	○	○	○	○	○	○
509	Parameter 4 for user	09	89	5	○	○	○	○	○	○	○	○	○	○
510	Parameter 5 for user	0A	8A	5	○	○	○	○	○	○	○	○	○	○
511	Parameter 6 for user	0B	8B	5	○	○	○	○	○	○	○	○	○	○
512	Parameter 7 for user	0C	8C	5	○	○	○	○	○	○	○	○	○	○
513	Parameter 8 for user	0D	8D	5	○	○	○	○	○	○	○	○	○	○
514	Parameter 9 for user	0E	8E	5	○	○	○	○	○	○	○	○	○	○
515	Parameter 10 for user	0F	8F	5	○	○	○	○	○	○	○	○	○	○
516	S-pattern time at a start of acceleration	10	90	5	○	○	○	○	×	○	○	○	○	○
517	S-pattern time at a completion of acceleration	11	91	5	○	○	○	○	×	○	○	○	○	○
518	S-pattern time at a start of deceleraiton	12	92	5	○	○	○	○	×	○	○	○	○	○
519	S-pattern time at a completion of deceleraiton	13	93	5	○	○	○	○	×	○	○	○	○	○
539	Modbus-RTU communication check time interval	27	A7	5	○	○	○	○	○	○	○	○	○	○
541	Frequency command sign selection (CC-Link) NC	29	A9	5	○	○	○	×	×	○	×	○	○	○
542	Communication station number (CC-Link) NC	2A	AA	5	○	○	○	○	○	○	○	○	○	○
543	Baud rate (CC-Link) NC	2B	AB	5	○	○	○	○	○	○	○	○	○	○
544	CC-Link extended setting NC	2C	AC	5	○	○	○	○	○	○	○	○	○	○
547	USB communication station number	2F	AF	5	○	○	○	○	○	○	○	○	○	○
548	USB communication check time interval	30	B0	5	○	○	○	○	○	○	○	○	○	○
549	Protocol selection	31	B1	5	○	○	○	○	○	○	○	○	○	○
550	NET mode operation command source selection	32	B2	5	○	○	○	○	○	○	○	○	○	○
551	PU mode operation command source selection	33	B3	5	○	○	○	○	○	○	○	○	○	○
555	Current average time	37	B7	5	○	○	○	○	○	○	○	○	○	○
556	Data output mask time	38	B8	5	○	○	○	○	○	○	○	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
557	Current average value monitor signal output reference current	39	B9	5	○	○	○	○	○	○	○	○	○	○
563	Energization time carrying-over times	3F	BF	5	○	○	○	○	○	○	○	×	×	×
564	Operating time carrying-over times	40	C0	5	○	○	○	○	○	○	○	×	×	×
569	Second motor speed control gain	45	C5	5	×	○	×	×	×	×	×	○	×	○
570	Multiple rating setting	46	C6	5	○	○	○	○	○	○	○	○	×	×
571	Holding time at a start	47	C7	5	○	○	○	○	×	○	○	○	○	○
573	4mA input check selection	49	C9	5	○	○	○	○	×	○	○	○	○	○
574	Second motor online auto tuning	4A	CA	5	×	○	×	×	×	○	○	○	○	○
575	Output interruption detection time	4B	CB	5	○	○	○	×	×	○	×	○	○	○
576	Output interruption detection level	4C	CC	5	○	○	○	×	×	○	×	○	○	○
577	Output interruption cancel level	4D	CD	5	○	○	○	×	×	○	×	○	○	○
611	Acceleration time at a restart	0B	8B	6	○	○	○	×	×	○	×	○	○	○
665	Regeneration avoidance frequency gain	41	C1	6	○	○	○	×	×	○	×	○	○	○
684	Tuning data increments switchover	54	D4	6	×	○	○	○	○	○	○	○	○	○
800	Control method selection	00	80	8	○	○	○	○	○	○	○	○	○	○
802	Pre-excitation selection AP	02	82	8	×	×	○	×	×	×	×	○	○	○
803	Constant power range torque characteristic selection	03	83	8	×	×	○	○	○	○	○	○	○	○
804	Torque command source selection	04	84	8	×	×	×	○	×	×	○	○	○	○
805	Torque command value (RAM)	05	85	8	×	×	×	○	×	×	○	×	○	○
806	Torque command value (RAM,EEPROM)	06	86	8	×	×	×	○	×	×	○	○	○	○
807	Speed limit selection	07	87	8	×	×	×	○	×	×	○	○	○	○
808	Forward rotation speed limit	08	88	8	×	×	×	○	×	×	○	○	○	○
809	Reverse rotation speed limit	09	89	8	×	×	×	○	×	×	○	○	○	○
810	Torque limit input method selection	0A	8A	8	×	×	○	×	○	○	×	○	○	○
811	Set resolution switchover	0B	8B	8	○	○	○	○	○	○	○	○	○	○
812	Torque limit level (regeneration)	0C	8C	8	×	×	○	×	○	○	×	○	○	○
813	Torque limit level (3rd quadrant)	0D	8D	8	×	×	○	×	○	○	×	○	○	○
814	Torque limit level (4th quadrant)	0E	8E	8	×	×	○	×	○	○	×	○	○	○
815	Torque limit level 2	0F	8F	8	×	×	○	×	○	○	×	○	○	○
816	Torque limit level during acceleration	10	90	8	×	×	○	×	○	○	×	○	○	○
817	Torque limit level during deceleration	11	91	8	×	×	○	×	○	○	×	○	○	○
818	Easy gain tuning response level setting	12	92	8	×	×	○	×	○	○	×	○	○	○
819	Easy gain tuning selection	13	93	8	×	×	○	×	○	○	×	○	×	○
820	Speed control P gain 1	14	94	8	×	×	○	×	○	○	×	○	○	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
821	Speed control integral time 1	15	95	8	×	×	○	×	○	○	×	○	○	○
822	Speed setting filter 1	16	96	8	×	×	○	○	×	○	○	○	○	○
823	Speed detection filter 1 AP	17	97	8	×	×	○	○	○	×	×	○	○	○
824	Torque control P gain 1	18	98	8	×	×	○	○	○	○	○	○	○	○
825	Torque control integral time 1	19	99	8	×	×	○	○	○	○	○	○	○	○
826	Torque setting filter 1	1A	9A	8	×	×	○	○	○	○	○	○	○	○
827	Torque detection filter 1	1B	9B	8	×	×	○	○	○	○	○	○	○	○
828	Model speed control gain	1C	9C	8	×	×	○	×	○	○	×	○	○	○
830	Speed control P gain 2	1E	9E	8	×	×	○	×	○	○	×	○	○	○
831	Speed control integral time 2	1F	9F	8	×	×	○	×	○	○	×	○	○	○
832	Speed setting filter2	20	A0	8	×	×	○	○	×	○	○	○	○	○
833	Speed detection filter 2 AP	21	A1	8	×	×	○	×	○	×	×	○	○	○
834	Torque control P gain 2	22	A2	8	×	×	○	○	○	○	○	○	○	○
835	Torque control integral time 2	23	A3	8	×	×	○	○	○	○	○	○	○	○
836	Torque setting filter2	24	A4	8	×	×	○	○	○	○	○	○	○	○
837	Torque detection filter 2	25	A5	8	×	×	○	○	○	○	○	○	○	○
838	DA1 terminal function selection AZ	26	A6	8	○	○	○	○	○	○	○	○	○	○
839	DA1 output filter AZ	27	A7	8	○	○	○	○	○	○	○	○	○	○
840	Torque bias selection AP	28	A8	8	×	×	○	×	×	×	×	○	○	○
841	Torque bias 1 AP	29	A9	8	×	×	○	×	×	×	×	○	○	○
842	Torque bias 2 AP	2A	AA	8	×	×	○	×	×	×	×	○	○	○
843	Torque bias 3 AP	2B	AB	8	×	×	○	×	×	×	×	○	○	○
844	Torque bias filter AP	2C	AC	8	×	×	○	×	×	×	×	○	○	○
845	Torque bias operation time AP	2D	AD	8	×	×	○	×	×	×	×	○	○	○
846	Torque bias balance compensation AP	2E	AE	8	×	×	○	×	×	×	×	○	○	○
847	Fall-time torque bias terminal 1 bias AP	2F	AF	8	×	×	○	×	×	×	×	○	○	○
848	Fall-time torque bias terminal 1 gain AP	30	B0	8	×	×	○	×	×	×	×	○	○	○
849	Analog input off set adjustment	31	B1	8	○	○	○	○	○	○	○	○	○	○
850	Control operation selection	32	B2	8	×	×	×	×	×	○	○	○	○	○
853	Speed deviation time AP	35	B5	8	×	×	○	×	×	×	×	○	○	○
854	Excitation ratio	36	B6	8	×	×	○	○	○	○	○	○	○	○
857	DA1-0V adjustment AZ	39	B9	8	○	○	○	○	○	○	○	○	×	○
858	Terminal 4 function assignment	3A	BA	8	○	○	○	○	○	○	○	○	×	○
859	Torque current	3B	BB	8	×	○	○	○	○	○	○	○	×	○
860	Second motor torque current	3C	BC	8	×	○	×	×	×	○	○	○	×	○
862	Notch filter time constant	3E	BE	8	×	×	○	×	○	○	×	○	○	○
863	Notch filter depth	3F	BF	8	×	×	○	×	○	○	×	○	○	○
864	Torque detection	40	C0	8	×	×	○	○	○	○	○	○	○	○
865	Low speed detection	41	C1	8	×	×	○	○	○	○	○	○	○	○
866	Torque monitoring reference	42	C2	8	×	○	○	○	○	○	○	○	○	○
867	AM output filter	43	C3	8	○	○	○	○	○	○	○	○	○	○
868	Terminal 1 function assignment	44	C4	8	○	○	○	○	○	○	○	○	×	○

WWW.BSNEW.IR

Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
872	Input phase failure protection selection	48	C8	8	○	○	○	○	○	○	○	○	○	○
873	Speed limit AP	49	C9	8	×	×	○	×	×	×	×	○	○	○
874	OLT level setting	4A	CA	8	×	×	○	×	○	○	×	○	○	○
875	Fault definition	4B	CB	8	○	○	○	○	×	○	○	○	○	○
877	Speed feed forward control/ model adaptive speed control selection	4D	CD	8	×	×	○	×	○	○	×	○	○	○
878	Speed feed forward filter	4E	CE	8	×	×	○	×	○	○	×	○	○	○
879	Speed feed forward torque limit	4F	CF	8	×	×	○	×	○	○	×	○	○	○
880	Load inertia ratio	50	D0	8	×	×	○	×	○	○	×	○	×	○
881	Speed feed forward gain	51	D1	8	×	×	○	×	○	○	×	○	○	○
882	Regeneration avoidance operation selection	52	D2	8	○	○	○	×	×	○	×	○	○	○
883	Regeneration avoidance operation level	53	D3	8	○	○	○	×	×	○	×	○	○	○
884	Regeneration avoidance at deceleration detection sensitivity	54	D4	8	○	○	○	×	×	○	×	○	○	○
885	Regeneration avoidance compensation frequency limit value	55	D5	8	○	○	○	×	×	○	×	○	○	○
886	Regeneration avoidance voltage gain	56	D6	8	○	○	○	×	×	○	×	○	○	○
888	Free parameter 1	58	D8	8	○	○	○	○	○	○	○	○	×	×
889	Free parameter 2	59	D9	8	○	○	○	○	○	○	○	○	×	×
891	Cumulative power monitor digit shifted times	5B	DB	8	○	○	○	○	○	○	○	○	○	○
892	Load factor	5C	DC	8	○	○	○	○	○	○	○	○	○	○
893	Energy saving monitor reference (motor capacity)	5D	DD	8	○	○	○	○	○	○	○	○	○	○
894	Control selection during commercial power-supply operation	5E	DE	8	○	○	○	○	○	○	○	○	○	○
895	Power saving rate reference value	5F	DF	8	○	○	○	○	○	○	○	○	○	○
896	Power unit cost	60	E0	8	○	○	○	○	○	○	○	○	○	○
897	Power saving monitor average time	61	E1	8	○	○	○	○	○	○	○	○	○	○
898	Power saving cumulative monitor clear	62	E2	8	○	○	○	○	○	○	○	○	×	○
899	Operation time rate (estimated value)	63	E3	8	○	○	○	○	○	○	○	○	○	○
C0 (900)	FM terminal calibration	5C	DC	1	○	○	○	○	○	○	○	○	×	○
C1 (901)	AM terminal calibration	5D	DD	1	○	○	○	○	○	○	○	○	×	○
C2 (902)	Terminal 2 frequency setting bias frequency	5E	DE	1	○	○	○	○	○	○	○	○	×	○
C3 (902)	Terminal 2 frequency setting bias	5E	DE	1	○	○	○	○	○	○	○	○	×	○
125 (903)	Terminal 2 frequency setting gain frequency	5F	DF	1	○	○	○	○	○	○	○	○	×	○
C4 (903)	Terminal 2 frequency setting gain	5F	DF	1	○	○	○	○	○	○	○	○	×	○

WWW.BSNEW.IR


Parameter	Name	Instruction Code *1			Control Mode-based Correspondence Table *2							Parameter Copy *3	Parameter Clear *3	All Parameter Clear *3
		Read	Write	Extended	V/F Control	Advanced magnetic flux vector control	Vector control			Real sensorless vector control				
							Speed control	Torque control	Position control	Speed control	Torque control			
C5 (904)	Terminal 4 frequency setting bias frequency	60	E0	1	○	○	○	○	○	○	○	○	×	○
C6 (904)	Terminal 4 frequency setting bias	60	E0	1	○	○	○	○	○	○	○	○	×	○
126 (905)	Terminal 4 frequency setting gain frequency	61	E1	1	○	○	○	○	○	○	○	○	×	○
C7 (905)	Terminal 4 frequency setting gain	61	E1	1	○	○	○	○	○	○	○	○	×	○
C12 (917)	Terminal 1 bias frequency (speed)	11	91	9	×	×	○	○	○	○	○	○	×	○
C13 (917)	Terminal 1 bias frequency (speed)	11	91	9	×	×	○	○	○	○	○	○	×	○
C14 (918)	Terminal 1 gain frequency (speed)	12	92	9	×	×	○	○	○	○	○	○	×	○
C15 (918)	Terminal 1 gain (speed)	12	92	9	×	×	○	○	○	○	○	○	×	○
C16 (919)	Terminal 1 bias command (torque/magnetic flux)	13	93	9	×	×	○	○	○	○	○	○	×	○
C17 (919)	Terminal 1 bias (torque/ magnetic flux)	13	93	9	×	×	○	○	○	○	○	○	×	○
C18 (920)	Terminal 1 gain command (torque/magnetic flux)	14	94	9	×	×	○	○	○	○	○	○	×	○
C19 (920)	Terminal 1 gain (torque/ magnetic flux)	14	94	9	×	×	○	○	○	○	○	○	×	○
C29 (925)	Motor temperature detection calibration (analog input) AZ	19	99	9	○	○	○	○	○	○	○	○	×	○
C30 (926)	Terminal 6 bias frequency (speed) AZ	1A	9A	9	○	○	○	○	○	○	○	○	×	○
C31 (926)	Terminal 6 bias (speed) AZ	1A	9A	9	○	○	○	○	○	○	○	○	×	○
C32 (927)	Terminal 6 gain frequency (speed) AZ	1B	9B	9	○	○	○	○	○	○	○	○	×	○
C33 (927)	Terminal 6 gain (speed) AZ	1B	9B	9	○	○	○	○	○	○	○	○	×	○
C34 (928)	Terminal 6 bias command (torque) AZ	1C	9C	9	×	×	○	○	○	○	○	○	×	○
C35 (928)	Terminal 6 bias (torque) AZ	1C	9C	9	×	×	○	○	○	○	○	○	×	○
C36 (929)	Terminal 6 gain command (torque) AZ	1D	9D	9	×	×	○	○	○	○	○	○	×	○
C37 (929)	Terminal 6 gain (torque) AZ	1D	9D	9	×	×	○	○	○	○	○	○	×	○
C38 (932)	Terminal 4 bias command (torque/magnetic flux)	20	A0	9	×	×	○	○	○	○	○	○	×	○
C39 (932)	Terminal 4 bias (torque/ magnetic flux)	20	A0	9	×	×	○	○	○	○	○	○	×	○
C40 (933)	Terminal 4 gain command (torque/magnetic flux)	21	A1	9	×	×	○	○	○	○	○	○	×	○
C41 (933)	Terminal 4 gain (torque/ magnetic flux)	21	A1	9	×	×	○	○	○	○	○	○	×	○
989	Parameter copy alarm release	59	D9	9	○	○	○	○	○	○	○	○	×	○
990	PU buzzer control	5A	DA	9	○	○	○	○	○	○	○	○	○	○
991	PU contrast adjustment	5B	DB	9	○	○	○	○	○	○	○	○	×	○

WWW.BSNEW.IR

Appendix 3 SERIAL number check

Refer to *page 2* for the location of the rating plate.

Rating plate example



The SERIAL consists of 1 version symbol, 2 numeric characters or 1 numeric character and 1 alphabet letter indicating year and month, and 6 numeric characters indicating control number. Month is indicated as 1 to 9, X (October), Y (November), and Z (December).

WWW.BSNEW.IR

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Sep., 2005	IB(NA)-0600255ENG-A	First edition
Nov., 2006	IB(NA)-0600255ENG-B	Additions • FR-A720-00030 to 00330-N4 • FR-A740-00015 to 00170-N4
Feb., 2007	IB(NA)-0600255ENG-C	Additions • Setting value "74" of Pr.178 to Pr.189 • Connection of the FR-BU2 • FR-A7AZ Partial changes • Change in specification of a voltage/current input switch.

⚠ For Maximum Safety

- Mitsubishi inverters are not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi sales representative.
- Although this product was manufactured under conditions of strict quality control, you are strongly advised to install safety devices to prevent serious accidents when it is used in facilities where breakdowns of the product are likely to cause a serious accident.
- Please do not use this product for loads other than three-phase induction motors.

WWW.BSNEW.IR